

Embedded 'C' for Zynq-SoPC

Cristian Sisterna

Universidad Nacional San Juan

Argentina

Embedded C

Embedded C Programming Language, which is widely used in the development of Embedded Systems, is an extension of C Program Language

The extension in *Embedded C* from standard *C Programming Language* include I/O Hardware Addressing, fixed point arithmetic operations, accessing address spaces, etc.

Embedded C

Standard C and Embedded C: Differences (1)

Though *C* and *Embedded C* appear different and are used in different contexts, they have more similarities than the differences. Most of the constructs are same; the difference lies in their applications

Standard C is general-purpose programming language used for developing any type of desktop applications

Embedded C, that is an extension of Standard C, is used in the development of microcontroller/microprocessor based applications

Standard C and Embedded C: Differences (2)

Embedded systems programming is different from developing applications on a desktop computers. Key characteristics of an embedded system, when compared to PCs, are as follows:

- Embedded systems have resource constraints(limited ROM, limited RAM, limited stack space, less processing power)
- □ Components used in embedded system and PCs are different; embedded systems typically uses smaller, less power consuming components
- Embedded systems are more tied to the hardware
- □ Two salient features of Embedded Programming are *code speed* and *code size*. Code speed is controlled by the processing power, timing constraints. Whereas code size depends on the available program memory

Standard C and Embedded C: Differences (3)

Compilers for *C* (ANSI C) typically generate OS dependent executables. *Embedded C* is OS independent

Embedded C requires specific compilers to create files to be downloaded to the microcontrollers/microprocessors where it needs to run

Embedded C is fully hardware dependent language

OS system is a must for C programming whereas it's an option for *Embedded C*


Advantages of Using Embedded C

- It is small and reasonably simpler to learn, understand, program and debug
- Embedded C Compilers are available for almost all embedded devices in use today, and there is a large pool of experienced C programmers
- It supports easy access to I/O, memory map and facilitates the management of large embedded projects
- •Unlike assembly, Embedded C has advantage of processor-independence and is not specific to any particular microprocessor/ microcontroller or any system

Basic Embedded 'C' Program Template

Basic Embedded Program Architecture

An embedded application consists of a collection tasks, implemented by hardware accelerators, software routines, or both.



Embedded C - Basic Example

A flashing-LED system turns **on** and **off two LEDs** alternatively according to the interval specified by the **ten sliding switches**

Tasks for the infinite loop ????



- 1. reading the interval value from the switches
- 2. toggling the two LEDs after a specific amount of time

Embedded C - Basic Example

```
#include "nnnnn.h"
#include "aaaaa.h"
main()
int period;
while(1) {
      read sw(SWITCH S1 BASE, &period);
      led flash(LED L1 BASE, period);
```

Basic Example - Reading

```
/***********************
* function: read sw ()
* purpose: get flashing period from 10 switches
 argument:
    switch-base: base address of switch PIO
    period: pointer to period
* return:
    updated period
* note:
void read sw(u32 switch base, int *period)
 *period = my iord(switch base) & 0x000003ff; // read flashing period
                                   // from switch
```

Basic Example - Writing

```
* function: led.flash ()
* purpose: toggle 2 LEDs according to the given period
* argument:
       addr led-base: base address of discrete LED PIO
     period: flashing period in ms
* return : none
* note:
* - The delay is done by estimating execution time of a dummy for loop
* - Assumption: 400 ns per loop iteration (2500 iterations per ms)
* - 2 instruct. per loop iteration /10 clock cycles per instruction /20ns per clock cycle(50-MHz clock)
void led flash(u32 addr led base, int period)
 static u8 led pattern = 0x01;
                                          // initial pattern
 unsigned long i, itr;
  led pattern ^= 0x03;
                                        // toggle 2 LEDs (2 LSBs)
 my iowr(addr led base, led pattern); // write LEDs
  itr = period * 2500;
  for (i=0; i<itr; i++) {}</pre>
                                          // dummy loop for delay
```

Basic Example – Read / Write

```
int main()
{
  int period;


while(1) {
    read_sw(SWITCH_S1_BASE, &period);

    led_flash(LED_L1_BASE, period);
    }
  return 0;
}
```


```
void read_sw(u32 switch_base, int *period)
{
   *period = my_iord(switch_base) & 0x000003ff;
}
```

13

Read/Write From/To GPIO Inputs and Outputs Zyng SoPC




Read/Write From/To GPIO Inputs and Outputs



15

Read/Write From/To GPIO Inputs and Outputs



Steps for Data Reading from a GPIO – Embedded C

- 1. Create a GPIO instance
- 2. Initialize the GPIO
- 3. Set data direction (optional)
- 4. Read the data

Steps for Reading from a GPIO – Step 1

1. Create a GPIO instance

Steps for Reading from a GPIO – Step 2

2. Initialize the GPIO

```
(int) XGpio_Initialize(XGpio *InstancePtr, u16 DeviceID);
```

InstancePtr: is a pointer to an **XGpio** instance (already declared).

DeviceID: is the unique **ID** of the device controlled by this **XGpio** component (declared in the **xparameters.h** file)

@return

- XST_SUCCESS if the initialization was successfull.
- XST_DEVICE_NOT_FOUND if the device configuration data was not

xstatus.h

Steps for Reading from a GPIO – Step 2(cont')

```
(int) XGpio Initialize (XGpio *InstancePtr, u16 DeviceID);
// AXI GPIO switches initialization
XGpio Initialize (&switches, XPAR_BOARD_SW_8B_DEVICE ID);
                                                                            board_sw_8b
  h xparameters.h 💢 🖟 lab_gpio_in_out.c
                                                                           S AXI
      /* Definitions for peripheral BOARD S/ 8B */
                                                                                  GPIO-1-
                                                                                                  _____ sws_8bits
      #define XPAR BOARD SW 8B BASEADDR 0x41200000
                                                                           axi_aresetn
      #define XPAR_BOARD_SW_8B_HIGHADDR 2x4120FFFF
                                                       MOD AXI +
                                                                             AXI GPIO
      #define XPAR BOARD SW 8B DEVICE ID 1
                                                       M01_AXI-1-
      #define XPAR_BOARD_SW_8B_INTERRUPT_PRESENT 0
                                                                            board_leds_8b
      #define XPAR BOARD SW 8B IS DUAL 0
                                                                           IXA Z-I
                                                                                  GPIO-1-
                                                                                                  leds_8bits
                                                                           axi aresetn
                                                                             AXI GPIO
```

xparameters.h

The xparameters.h file contains the address map for peripherals created in Vivado

This file is generated from the hardware platform created in Vivado

```
#include "xparameters.h" ← Ctrl + Mouse Over #include "xgpio.h" #include "xgpiops.h"
```

```
exercise_05_bsp

i BSP Documentation


a  ps7_cortexa9_0

code
```

include

xparameters.h file can be found underneath the include folder in the ps7_cortexa9_0 folder of the BSP main folder

xparameters.h



Steps for Reading from a GPIO - Step 3

3. Set data direction

void XGpio_SetDataDirection (XGpio *InstancePtr, unsigned Channel, u32 DirectionMask);

InstancePtr: is a pointer to an XGpio instance to be working with.

Channel: contains the channel of the XGpio (1 o 2) to operate with.

DirectionMask: is a bitmask specifying which bits are inputs and which are outputs.


Bits set to '0' are output, bits set to '1' are inputs.

Return: none

Steps for Reading from a GPIO - Step 3 (cont')

void XGpio_SetDataDirection (XGpio *InstancePtr, unsigned Channel, u32 DirectionMask);

```
// AXI GPIO switches: bits direction configuration
XGpio_SetDataDirection(&board_sw_8b, 1, 0xffffffff);
```



Steps for Reading from a GPIO – Step 4

4. Read the data

u32 XGpio_DiscreteRead (XGpio *InstancePtr, unsigned Channel);

InstancePtr: is a pointer to an XGpio instance to be working with.

Channel: contains the channel of the XGpio (1 o 2) to operate with.

Return: read data

Steps for Reading from a GPIO – Step 4 (cont')

u32 XGpio_DiscreteRead (XGpio *InstancePtr, unsigned Channel);

```
// AXI GPIO: read data from the switches
sw_check = XGpio_DiscreteRead(&board_sw_8b, 1);
```

Steps for Writing to GPIO

- 1. Create a GPIO instance
- 2. Initialize the GPIO
- 3. Set the data direction (optional)
- 4. Read the data

Steps for Writing to a GPIO – Step 1

1. Create a GPIO instance

```
#include "xgpio.h"
int main (void)
                         /**
                          * The XGpio driver instance data. The user is required to allocate a
  XGpio switches;
                         * variable of this type for every GPIO device in the system. A pointer
                          * to a variable of this type is then passed to the driver API functions.
  XGpio leds;
                        typedef struct {
                            u32 BaseAddress; /* Device base address */
                                              /* Device is initialized and ready */
                            u32 IsReady;
                            int InterruptPresent; /* Are interrupts supported in h/w */
                            int IsDual; /* Are 2 channels supported in h/w */
                         } XGpio;
```

Steps for Writing to a GPIO – Step 2

2. Initialize the GPIO

```
(int) XGpio_Initialize(XGpio *InstancePtr, u16 DeviceID);
```

InstancePtr: is a pointer to an XGpio instance.

DeviceID: is the unique id of the device controlled by this XGpio component

@return

- XST SUCCESS if the initialization was successfull.
- XST_DEVICE_NOT_FOUND if the device configuration data was not

```
xstatus.h
```

Steps for Writing to a GPIO – Step 2(cont')

```
XGpio Initialize (XGpio *InstancePtr, u16 DeviceID);
// AXI GPIO leds initialization
XGpio Initialize (&board leds 8b, XPAR_BOARD_LEDS_8B_DEVICE_ID);
                                                        xi_periph
                                                                            board_sw_8b
       h xparameters.h ☒ 🖟 lab_gpio_in_...
                                      h xgpiops w.h
                                                                                GPIO-3
                                                                                               sws 8bits
          /* Definitions for peripheral BOARD LYDS 8B */
          #define XPAR BOARD LEDS 8B BASEADDR #x41210000
                                                        M00_AXI-}-
                                                                            AXI GPIO
          #define XPAR BOARD LEDS 8B HIGHADDR 0x4121FFFF
                                                                           board_leds_8b
          #define XPAR BOARD LEDS 8B DEVICE ID 0
          #define XPAR BOARD LEDS 8B INTERRUPT PRESENT 0
                                                                                GPIO-1
                                                                                               leds 8bits
          #define XPAR BOARD LEDS 8B IS DUAL 0
                                                                            AXI GPIO
```

Steps for Writing to a GPIO – Step 3

3. Write the data

void XGpio_DiscreteWrite (XGpio *InstancePtr, unsigned Channel, u32 Data);

InstancePtr: is a pointer to an XGpio instance to be worked on.

Channel: contains the channel of the XGpio (1 o 2) to operate with.

Data: Data is the value to be written to the discrete register

Return: none


Steps for Writing to a GPIO – Step 3 (cont')

void XGpio_DiscreteWrite (XGpio *InstancePtr, unsigned Channel, u32 Data);

```
// AXI GPIO: write data (sw_check) to the LEDs
XGpio_DiscreteWrite(& board leds 8b, 1, sw check);
```

'C' Drivers for IP Cores

SPI IP Core - Example



SPI IP Core - Example

```
#include "xparameters.h"
#include "xscugic.h"
#include "xil exception.h"
#include <stdio.h>
#include "xspi.h" /* SPI device driver */
                ------ SPI related functions ------//
              // Initialize the SPI driver
              SPI ConfigPtr = XSpi LookupConfig(XPAR AXI QUAD SPI 0 DEVICE ID);
              if (SPI ConfigPtr == NULL) return XST DEVICE NOT FOUND;
              Status = XSpi CfgInitialize(&SpiInstance, SPI ConfigPtr, SPI ConfigPtr->BaseAddress);
              if (Status != XST SUCCESS) return XST FAILURE;
             // Reset the SPI peripheral
             XSpi Reset(&SpiInstance);
```

SPI IP Core – Driver Example

```
/**
* Initializes a specific XSpi instance such that the driver is ready to use.
* The state of the device after initialization is:

    Device is disabled

   - Slave mode

    Active high clock polarity

    - Clock phase 0
          InstancePtr is a pointer to the XSpi instance to be worked on.
* @param
* @param Config is a reference to a structure containing information
        about a specific SPI device. This function initializes an
        InstancePtr object for a specific device specified by the
        contents of Config. This function can initialize multiple
        instance objects with the use of multiple calls giving
        different Config information on each call.
            EffectiveAddr is the device base address in the virtual memory
        address space. The caller is responsible for keeping the
        address mapping from EffectiveAddr to the device physical base
        address unchanged once this function is invoked. Unexpected
        errors may occur if the address mapping changes after this
        function is called. If address translation is not used, use
        Config->BaseAddress for this parameters, passing the physical
         address instead.
* @return
        - XST SUCCESS if successful.
        - XST DEVICE IS STARTED if the device is started. It must be
          stopped to re-initialize.
  @note
            None.
int XSpi CfgInitialize(XSpi *InstancePtr, XSpi Config *Config,
            UINTPTR EffectiveAddr)
```

Appendix

Reviewing Embedded 'C' Basic Concepts

Embedded C – Xilinx 'SDK' Basic Data Types

```
xbasic types.h
```

```
Xuint8; /**< unsigned 8-bit */
typedef unsigned char
                      Xint8; /**< signed 8-bit */
typedef char
typedef unsigned short Xuint16; /**< unsigned 16-bit */
                      Xint16; /**< signed 16-bit */
typedef short
                     Xuint32; /**< unsigned 32-bit */</pre>
typedef unsigned long
                      Xint32; /**< signed 32-bit */
typedef long
                      Xfloat32; /**< 32-bit floating point */
typedef float
                      Xfloat64; /**< 64-bit double precision FP */
typedef double
typedef unsigned long
                     Xboolean; /**< boolean (XTRUE or XFALSE) */
```

```
xil_types.h

typedef uint8_t u8;
typedef uint16_t u16;
typedef uint32 t u32;
```

Local vs Global Variables

Variables in C can be classified by their scope

Local Variables

Accessible only by the function within which they are declared and are allocated storage on the stack

Global Variables

Accessible by any part of the program and are allocated permanent storage in RAM

Global and Local Variables Declarations

```
int flag = 0;
char note = 'a';
main ()
     flag = 1;
     function1();
     flag = 2;
int function1()
int alarm = 128; → Local Variable
     . . .
     alarm =+1;
     flag = 3;
```

Local Variables

- *Local variables only occupy RAM while the function to which they belong is running
- *Usually the stack pointer addressing mode is used (This addressing mode requires one extra byte and one extra cycle to access a variable compared to the same instruction in indexed addressing mode)
 - If the code requires several consecutive accesses to local variables, the compiler will usually transfer the stack pointer to the 16-bit index register and use indexed addressing instead

Global Variables

- Global variables are allocated permanent storage in memory at an absolute address determined when the code is linked
- The memory occupied by a *global variable* cannot be reused by any other variable
- ❖ Global variables are not protected in any way, so any part of the program can access a global variable at any time
 - This means that the variable data could be corrupted if part of the variable is derived from one value and the rest of the variable is derived from another value
- The compiler will generally use the extended addressing mode to access *global* variables or indexed addressing mode if they are accessed though a pointer

Use of the 'static' modifier

- The 'static' access modifier may also be used with global variables
 - * This gives some degree of protection to the variable as it restricts access to the variable to those functions in the file in which the variable is declared
- The 'static' access modifier causes that the local variable to be permanently allocated storage in memory, like a global variable, so the value is preserved between function calls (but still is local)

```
static int flag
static char note = 'a';
main ()
    flaq = 1;
    function1();
    flag = 2;
int function1()
static int alarm = 128;
    alarm = +1;
    flag = 3;
```

Volatile Variable

The value of volatile variables may change from outside the program.

For example, you may wish to read an A/D converter or a port whose value is changing.

Often your compiler may eliminate code to read the port as part of the compiler's code optimization process if it does not realize that some outside process is changing the port's value.

You can avoid this by declaring the variable volatile.

Volatile Variable

```
#include <stdio.h>
 3 → /* Optimization code snippet 1 */
    #include<stdio.h>
    int x = 0;
    int main()
9 - {
                                                   #include<stdio.h>
10
        if (x == 0) // This condition is always 1
11 -
                                                   volatile int = 0: /* volatile Keyword*/
12
            printf(" x = 0 \n");
13
                 // Else part will be optimiz 5 int main()
14
        else
15 ±
           printf(" x != 0 \n");
16
                                                       x = 0;
17
18
        return 0;
                                                       if (x == 0)
19 }
                                              10 -
                                                       printf(" x = 0 \n");
                                              11
                                              12
                                              13
                                                       else // Now compiler never optimize else part because the
                                                       {     // variable is declared as volatile
                                              14 -
                                                       printf(" x != 0 \n");
                                              15
                                              16
                                              17
                                                       return 0;
                                              18 }
```

Functions Data Types


A function data type defines the value that a subroutine can return

- * A function of type int returns a signed integer value
- ❖ Without a specific return type, any function returns an int
- ❖ To avoid confusion, you should always declare main () with return type void

```
void XGpioPs_IntrEnable(XGpioPs *InstancePtr, u8 Bank, u32 Mask);
void XGpioPs_IntrDisable(XGpioPs *InstancePtr, u8 Bank, u32 Mask);
u32 XGpioPs_IntrGetEnabled(XGpioPs *InstancePtr, u8 Bank);
u32 XGpioPs_IntrGetStatus(XGpioPs *InstancePtr, u8 Bank);
```

Parameters Data Types

Indicate the values to be passed into the function and the memory to be reserved for storing them



Structures


```
#include "xparameters.h"
#include "xgpio.h"
#include "xgpiops.h"
static XGpioPs psGpioInstancePtr;
static int iPinNumber = 7; /*Led LD9
                            The XGpio driver instance data. The user is required to allocate a
                           * variable of this type for every GPIO device in the system. A pointer
                           * to a variable of this type is then passed to the driver API functions.
int main (void)
                          */
                          typedef struct {
      XGpio sw, led;
                             u32 BaseAddress; /* Device base address */
      int i, pshb check
                             u32 IsReady;
                                         /* Device is initialized and ready */
                             int InterruptPresent; /* Are interrupts supported in h/w */
                             int IsDual; /* Are 2 channels supported in h/w */
                            XGpio:
```

Review of 'C' Pointer

In 'C', the pointer data type corresponds to a MEMORY ADDRESS

```
a int x = 1, y = 5, z = 8, *ptr;
```

- b ptr = &x; // ptr gets (point to) address of x
- c y = *ptr; // y gets content pointed by ptr
- d *ptr = z; // location pointed by ptr gets the value of z



'C' Techniques for lowlevel I/O Operations

Bit Manipulation in 'C'

Bitwise operators in 'C': ~ (not), & (and), | (or), ^ (xor) which operate on one or two operands at bit levels

```
u8 mask = 0x60; //0110 0000 mask bits 6 and 5
 u8 data = 0xb3 //1011 0011 data
 u8 d0, d1, d2, d3; //data to work with in the coming example
d0 = data \& mask; // 0010 0000; isolate bits 6 and 5 from data
d1 = data \& \sim mask; // 1001 0011; clear bits 6 and 5 of data
d2 = data | mask; // 1111 0011; set bits 6 and 5 of data
d3 = data ^ mask; // 1101 0011; toggle bits 6 and 5 of data
```

Bit Shift Operators

Both operands of a bit shift operator must be integer values

The **right shift operator** shifts the data right by the specified number of positions. Bits shifted out the right side disappear. With unsigned integer values, 0s are shifted in at the high end, as necessary. For signed types, the values shifted in is implementation-dependant. The binary number is shifted right by *number* bits.

The **left shift operator** shifts the data right by the specified number of positions. Bits shifted out the left side disappear and new bits coming in are 0s. The binary number is shifted left by *number* bits

Bit Shift Example

```
void led_knight_rider(XGpio *pLED_GPIO, int nNumberOfTimes)
       int i=0; int j=0;
       u8 uchLedStatus=0;
       // Blink the LEDs back and forth nNumberOfTimes
       for (i=0; i<nNumberOfTimes; i++)</pre>
              for (j=0; j<8; j++) // Scroll the LEDs up
                     uchLedStatus = 1 << j;
                     XGpio DiscreteWrite(pLED GPIO, 1, uchLedStatus);
                     delay(ABOUT ONE SECOND / 15);
              for (j=0; j<8; j++) // Scroll the LEDs down
                     uchLedStatus = 8 >> j;
                     XGpio DiscreteWrite(pLED GPIO, 1, uchLedStatus);
                     delay(ABOUT ONE SECOND / 15);
```

Data Unpacking

There are cases that in the same memory address different fields are stored

Example: let's assume that a 32-bit memory address contains a 16-bit field for an integer data and two 8-bit fields for two characters

```
16 15 . . . 8 7 . . . 0
           31
                                      ch1
                                                 ch0
                    num
io_rd_data
            u32 io rd data;
            int num;
            char chl, ch0;
            io rd data = my iord(...); //my io read read a data
            num = (int) ((io_rd data & 0xffff0000) >> 16);
            chl = (char) ((io rd data & 0x0000ff00) >> 8);
            ch0 = (char) ((io rd data & 0x000000ff));
```

Data Packing

There are cases that in the same memory address different fields are written

Example: let's assume that a 32-bit memory address will be written as a 16-bit field for an integer data and two 8-bit fields for two characters


```
16 15 . . . 8 7 . . . 0
             31
                                         ch1
                                                     ch0
  io_wr_data
                      num
    u32 wr data;
    int num = 5;
    char chl, ch0;
      wr data = (u32) (num);
                                               //num[15:0]
Packing
      wr data = (wr data << 8) | (u32) ch1; //num[23:8], ch1[7:0]
      wr data = (wr data << 8) | (u32) ch0; //num[31:16], ch1[15:8]
      my iowr( . . , wr data) ;
                                              //ch0[7:0]
```

Another Way of Data Packing....


```
wr_data = (((u32)(num)) << 16) | (((u32)ch1) << 8) | (u32)ch0;
```

'C' Drivers for Custom IP

Custom IP



My IP – Memory Address Range




Custom IP Drivers

- The *driver code* are generated automatically when the IP template is created.
- The *driver* includes higher level functions which can be called from the user application.
- The *driver* will implement the low level functionality used to control your peripheral.


$$led_ip \setminus ip_repo \setminus led_ip_1.0 \setminus drivers \setminus led_ip_v1_0 \setminus src = \begin{cases} led_ip.c \\ led_ip.h \end{cases} LED_IP_mWriteReg(...)$$

Custom IP Drivers: *.c



Custom IP Drivers: *.h

led_ip\ip_repo\led_ip_1.0\drivers\led_ip_v1_0\src\led_ip.h



63

Custom IP Drivers: *.h (cont' 1)

Custom IP Drivers: *.h (cont' 2)

```
/**
 * Write a value to a LED IP register. A 32 bit write is performed.
 * If the component is implemented in a smaller width, only the least
 * significant data is written.
 * @param BaseAddress is the base address of the LED IPdevice.
 * @param RegOffset is the register offset from the base to write to.
  @param
           Data is the data written to the register.
 * @return None.
 * @note
 * C-style signature:
 * void LED IP mWriteReg(u32 BaseAddress, unsigned RegOffset, u32 Data)
#define LED IP mWriteReg(BaseAddress, RegOffset, Data) \
   Xil Out32((BaseAddress) + (RegOffset), (u32)(Data))
```

Custom IP Drivers: *.h (cont' 3)

```
/**
* Read a value from a LED IP register. A 32 bit read is performed.
 * If the component is implemented in a smaller width, only the least
 * significant data is read from the register. The most significant data
 * will be read as 0.
  @param BaseAddress is the base address of the LED IP device.
          RegOffset is the register offset from the base to write to.
  @param
  @return Data is the data from the register.
 * @note
 * C-style signature:
 * u32 LED IP mReadReg(u32 BaseAddress, unsigned RegOffset)
*/
#define LED IP mReadReg(BaseAddress, RegOffset) \
   Xil In32((BaseAddress) + (RegOffset))
```

Custom IP Drivers: *.h (cont' 4)

```
/**
 * Run a self-test on the driver/device. Note this may be a destructive test if
 * resets of the device are performed.
 * If the hardware system is not built correctly, this function may never
 * return to the caller.
           baseaddr p is the base address of the LED IP instance to be worked on
  @return

    XST SUCCESS if all self-test code passed

     - XST FAILURE if any self-test code failed
           Caching must be turned off for this function to work.
 * @note
           Self test may fail if data memory and device are not on the same bus.
  @note
 */
XStatus LED IP Reg SelfTest(void * baseaddr p);
```

'C' Code for Writing to My_IP

```
#include "xparameters.h"
#include "xgpio.h"
#include "led ip.h"
//-----
int main (void)
  XGpio dip, push;
  int i, psb_check, dip_check;
  xil printf("-- Start of the Program --\r\n");
  XGpio Initialize(&dip, XPAR SWITCHES DEVICE ID);
  XGpio SetDataDirection(&dip, 1, 0xffffffff);
  XGpio Initialize(&push, XPAR BUTTONS DEVICE ID);
  XGpio SetDataDirection(&push, 1, 0xffffffff);
  while (1)
     psb check = XGpio DiscreteRead(&push, 1);
     xil printf("Push Buttons Status %x\r\n", psb check);
     dip check = XGpio DiscreteRead(&dip, 1);
     xil printf("DIP Switch Status %x\r\n", dip check);
     for (i=0; i<9999999; i++);
```

IP Drivers – Xil_Out32/Xil_In32

```
#define LED_IP_mWriteReg(BaseAddress, RegOffset, Data) Xil Out32 (BaseAddress) + (RegOffset), (Xuint32)(Data))
#define LED_IP_mReadReg(BaseAddress, RegOffset) Xil_In32 ((BaseAddress) + (RegOffset))
```

- For this driver, you can see the macros are aliases to the lower level functions
 Xil_Out32() and Xil_In32()
- The macros in this file make up the higher level API of the led_ip driver.
- o If you are writing your own driver for your own IP, you will need to use low level functions like these to read and write from your IP as required. The low level hardware access functions are wrapped in your driver making it easier to use your IP in an Application project.

IP Drivers – Xil_In32 (xil_io.h/xil_io.c)


```
/**
* Performs an input operation for a 32-bit memory location by reading from the
* specified address and returning the Value read from that address.
             Addr contains the address to perform the input operation at.
* @param
* @return
             The Value read from the specified input address.
* @note
             None.
u32 Xil_In32(INTPTR Addr)
         return *(volatile u32 *) Addr;
```

IP Drivers – Xil_Out32 (xil_io.h/xil_io.c)

```
/**
* Performs an output operation for a 32-bit memory location by writing the
* specified Value to the the specified address.
            Addr contains the address to perform the output operation at.
* @param
* @param
            Value contains the Value to be output at the specified address.
* @return
            None.
* @note
            None.
void Xil_Out32(INTPTR Addr, u32 Value)
         u32 *LocalAddr = (u32 *)Addr;
         *LocalAddr = Value;
```

IP Drivers – SDK 'Activation'

- Select < project_name > _bsp in the project view pane. Right-click
- Select Board Support Package Settings




IP Drivers – SDK 'Activation'

- Select *Drivers* on the *Overview* pane
- If the led_ip driver has not already been selected, select Generic under the

Driver Column for *led_ip* to access the dropdown menu. From the dropdown

menu, select *led_ip*, and click OK

Embedded C



I/O Read Macro

Read from an Input

```
int switch s1;
switch s1 = *(volatile int *)(0x00011000);
#define SWITCH S1 BASE = 0 \times 00011000;
switch s1 = *(volatile int *)(SWITCH S1 BASE);
#define SWITCH S1 BASE = 0 \times 00011000;
#define my iord(addr) (*(volatile int *)(addr))
                                                       Macro
switch s1 = my iord(SWITCH S1 BASE); //
```

I/O Write Macro

Write to an Output

```
#define LED_L1_BASE = 0x11000110;
#define my_iowr(addr, data) (*(int *)(addr) = (data))

. . .
my_iowr(LED_L1_BASE, (int)pattern); //
```