ELEC4402 Formula Sheet

Henry Chen

November 3, 2024

Abstract

Key formulae and helpers for ELEC4402 - Communication Systems. Hopefully this helps to carry!!!

Contents

1	Har	ndy Formulae
	1.1	Rectangle Functions
	1.2	Sinusoid Integration
2	Sign	nal Characteristics
	2.1	(Average) Power of a Signal
	2.2	Energy of a Signal
	2.3	Representation of Narrowband (NB) Signals
	2.4	Complex Envelope
3	Am	plitude Modulation (AM) Formulae
	3.1	Conventional AM Signal
	3.2	AM Modulation Index
	3.3	AM Power Efficiency
	3.4	AM Signal Modulation Index
4	Free	quency Modulation (FM) Formulae
	4.1	FM Modulation Index
	4.2	Maximum Frequency Deviation
	4.3	FM Complex Envelope
	4.4	Single Tone FM Signal
		4.4.1 Time Domain Representation
		4.4.2 Frequency Domain Representation
	4.5	Carson's Rule
		4.5.1 Narrow Band Signals $(\beta < 1)$
		4.5.2 Wideband Signals $(\beta > 1)$
		4.5.3 For Arbitrary Signals

CONTENTS 0

	4.6 Arbitrary Signal Helpers for FM	7 7 7
5	Sampling and Quantization 5.1 Pulse Train Fourier Transform	
6	Pulse Amplitude Modulation (PAM)	8
7	PAM Signal Representation 7.1 Bit Duration and Bit Rate	9 9
8	Entropy	
9	Joint Entropy	9

1 Handy Formulae

1.1 Rectangle Functions

$$\operatorname{rect}(t) \to \begin{cases} 1, & -\frac{1}{2} \le t \le \frac{1}{2} \\ 0, & \text{otherwise} \end{cases}$$
$$\operatorname{rect}\left(\frac{t}{T}\right) \to \begin{cases} 1, & -\frac{T}{2} \le t \le \frac{T}{2} \\ 0, & \text{otherwise} \end{cases}$$
$$\operatorname{rect}\left(\frac{t-T}{T}\right) \to \begin{cases} 1, & T - \frac{T}{2} \le t \le T + \frac{T}{2} \\ 0, & \text{otherwise} \end{cases}$$

1.2 Sinusoid Integration

$$\int \sin(at) dt = -\frac{\cos(at)}{a} + C$$

$$\int \cos(at) dt = \frac{\sin(at)}{a} + C$$

$$\int e^{at} dt = \frac{e^{at}}{a} + C$$

2 Signal Characteristics

2.1 (Average) Power of a Signal

$$P_x = \frac{1}{T} \int_{-\frac{T}{2}}^{\frac{T}{2}} x^2(t) dt$$

For sinusoidal signals, the power can be simplified to:

$$P_x = \frac{A_c^2}{2}$$

2.2 Energy of a Signal

$$E = \int_{-\infty}^{\infty} x^2(t) \, dt$$

2.3 Representation of Narrowband (NB) Signals

$$g(t) = a(t)\cos(\underbrace{2\pi f_c t}_{\mathbf{A}} + \underbrace{\phi(t)}_{\mathbf{B}})$$

Using the identity $\cos(A+B) = \cos(A)\cos(B) - \sin(A)\sin(B)$

$$\tilde{g}(t) = \underbrace{a(t)\cos(\phi(t))}_{\text{in-phase}} - \underbrace{a(t)\sin(\phi(t))}_{\text{quadrature}}$$

$$g_i(t) = a(t)\cos(\omega_c t + \phi(t))$$

$$g_q(t) = a(t)\sin(\omega_c t + \phi(t))$$

2.4 Complex Envelope

Given $g_i(t)$ and $g_q(t)$ and a(t)

$$g(t) = g(t) + j \cdot g(t)$$

$$a(t) = e^{j\phi(t)}$$

3 Amplitude Modulation (AM) Formulae

3.1 Conventional AM Signal

$$s(t) = A_c \left[1 + \mu \cos(2\pi f_m t) \right] \cos(2\pi f_c t)$$

3.2 AM Modulation Index

$$\mu = k_a \cdot A_m$$

Where:

- $0 \le \mu \le 1$
- $\mu = 1 \Rightarrow$ overmodulated

3.3 AM Power Efficiency

$$\eta = \frac{\text{Baseband Power}}{\text{Total Power}} = \frac{\mu^2}{2 + \mu^2}$$

3.4 AM Signal Modulation Index

$$\mu = \frac{A_{\text{max}} - A_{\text{min}}}{A_{\text{max}} + A_{\text{min}}}$$

Where:

- Maximum Amplitude: $A_{\text{max}} = A_c(1 + \mu)$
- Minimum Amplitude: $A_{\text{max}} = A_c(1 \mu)$

4 Frequency Modulation (FM) Formulae

4.1 FM Modulation Index

$$\beta = \frac{\Delta f}{f_m} = \frac{k_f A_m}{f_m}$$

Where:

• Narrowband: $\beta < 1$

• Wideband: $\beta > 1$

4.2 Maximum Frequency Deviation

$$\Delta f = k_f \cdot A_m$$
$$= \beta \cdot f_m$$

Where:

• k_f : Frequency Sensitivity; typically the VCO Specification

• A_m : Message Amplitude; the message signal is usually injected into the VCO to drive the signal

• β : The FM Modulation Index

4.3 FM Complex Envelope

$$s(t) = A_c \cos(2\pi f_c t + \beta \sin(2\pi f_m t))$$

$$= Re \left[A_c \cdot e^{2\pi f_c t j + j\beta \sin(2\pi f_m t)} \right]$$

$$= Re \left[A_c \cdot e^{2\pi f_c t j} \cdot e^{j\beta \cdot \sin(2\pi f_m t)} \right]$$

$$= Re \left[\tilde{s}(t) \cdot e^{j\beta \cdot \sin(2\pi f_c t)} \right]$$

Where:

• $\tilde{s}(t) = A_c \cdot e^{j\beta \cdot \sin(2\pi f_m t)}$: The complex envelope of the FM signal

4.4 Single Tone FM Signal

4.4.1 Time Domain Representation

$$s(t) = A_c \sum_{n=-\infty}^{\infty} J_n(\beta) \cos \left[2\pi (f_c + nf_m)t\right]$$
$$\tilde{s}(t) = A_c \sum_{n=-\infty}^{\infty} J_n(\beta) e^{2\pi \cdot nf_m t \cdot j}$$

4.4.2 Frequency Domain Representation

$$s(f) = \frac{A_c}{2} \sum_{n = -\infty}^{\infty} \underbrace{J_n(\beta) \left[\delta(f - f_c - nf_m) + \delta(f + f_c + nf_m) \right]}_{\text{Bessel Function of Delta Functions}}$$

4.5 Carson's Rule

4.5.1 Narrow Band Signals ($\beta < 1$)

$$B=2f_m$$

4.5.2 Wideband Signals ($\beta > 1$)

$$B = 2\Delta f + 2f_m$$

4.5.3 For Arbitrary Signals

$$W = 2DW + 2W$$

$$W = 2DW(1 + \frac{1}{D})$$

$$= 2 \cdot \max_{t} |k_f m(t)| + 2f_m$$

$$k_f \times \text{message bw}$$

Where:

- $D = \frac{\Delta f}{W}$: Frequency Deviation of the arbitrary signal
- 4.6 Arbitrary Signal Helpers for FM

$$f(t) = \frac{1}{2\pi} \cdot \frac{d\theta(t)}{d(t)} = f_c + k_f m(t)$$

Generic form of s(t):

$$s(t) = A_c \cos(2\pi f_c t + \beta m(t))$$
carrier baseband

Base-Band Frequency of a Signal:

$$f(t) = f_c + k_f m(t)$$

Power Spectral Density (PSD)

$$G(f) = \lim_{T \to \infty} \frac{|X_T(f)|^2}{T}$$

4.7 PSD through an LTI System

$$G_y(f) = |H(f)|^2 \cdot G_x(f)$$

Where:

• H(f): Fourier Transform of the LTI System's Transfer. By squaring it, you then get the Power Spectral Density

4.8 PSD of a Random Process

$$G_X(f) = \lim_{T \to \infty} \frac{\mathbb{E}\left\{|X_T(f, \varepsilon_i)|^2\right\}}{T}$$

NOTE: very similar for deterministic signals PSD

NOTE: The PSD is an ensemble average of the powers of the of captured samples

4.9 Power of a PSD

$$P = \int_{-\infty}^{\infty} G_X(f) \, df$$

4.10 PSD Of Narrowband Random Processes

The PSD of random processes (noise) are the same in both, the in-phase and quadrature components (i.e. $G_{x_s} == G_{x_c}$).

$$x(t) = x_c \cos(2\pi f_c t) - x_s \sin(2\pi f_c t)$$

Where:

- x(t): Is a random process
- $x_c \cos(2\pi f_c t)$: In-Phase component of x(t).

• $x_s \sin(2\pi f_c t)$: Quadratur component of x(t).

In this case, the upconverted PSD of the signals are also equal within the bandwidth of the upconverted channel.

$$G_{x_s} = G_{x_c} = \begin{cases} G_x(f + f_c) + G_x(f - f_c) & \text{if } |f| < B \\ 0 & \text{otherwise} \end{cases}$$

5 Sampling and Quantization

5.1 Pulse Train Fourier Transform

The fourier transform of a periodid pulse train in the tiem domain leads to a series of impulses in the frequency domain:

$$\sum_{m=-\infty}^{\infty} \delta(t - mT_0) \xrightarrow{\mathcal{F}T} \sum_{n=-\infty}^{\infty} \delta(f - nf_0)$$

Where:

• $f_0 = 1/T_0$: is the sampling frequency of the pulse train

 \therefore the Fourier Transform of a periodic pulse train results in a series of delta functions, representing the discrete frequency components present in the signal. The spectrm of x(f) - the signal being sampled - is replicated around mulitples of f_0 .

5.2 Quantizer Step Size

$$\Delta = \frac{2V}{N} = \frac{2V}{2^m}$$

Where:

- \bullet V: The amplitude of the signal
- \bullet N: Number of Quantization Steps
- m: Bit depth of quantization $(m = \log_2 N)$

6 Pulse Amplitude Modulation (PAM)

- \bullet T: Symbol period (duration of each symbol).
- $D = \frac{1}{T}$: Symbol rate or pulse rate.
- Note: A single symbol can represent multiple bits, depending on the modulation scheme.

Joint Entropy 9

7 PAM Signal Representation

The PAM signal for the m-th symbol, $s_m(t)$, is given by:

$$s_m(t) = A_m \cdot V(t)$$

where:

- A_m : Amplitude corresponding to the m-th symbol.
- V(t): Fixed pulse shape.
- m = 1, 2, ..., M, where M is the number of symbols, typically based on the quantization levels.

7.1 Bit Duration and Bit Rate

- T_b : Bit duration, or time taken to transmit one bit.
- R_b : Bit rate, or number of bits transmitted per second $1/T_b$.

7.2 Relationship between Bit Rate, Symbol Rate, and Bits per Symbol

The relationship between bit duration, bit rate, symbol rate, and the number of bits per symbol is given by:

$$T_b = \frac{1}{R_b} = \frac{1}{kD} = \frac{T}{k} = \frac{T}{\log_2 M}$$

where:

- k: Number of bits per symbol.
- M: Number of distinct symbols in the signal set, with $M = 2^k$, so that each symbol represents $k = \log_2 M$ bits.

8 Entropy

$$H(X) = -\sum p(x)\log_2 p(x)$$

9 Joint Entropy

$$H(X,Y) = -\sum \sum p(x,y) \log_2 p(x,y)$$