

# Lithium-Ion Battery Base Model in ID

This is a template base model containing the physics, geometry, and mesh of a lithium-ion battery.

The model is defined using the Lithium-Ion Battery interface, based on the Doyle-Fuller-Newman framework (Ref. 1). For a general introduction to the Lithium-Ion Battery interface, the user is recommended to first run the tutorial 1D Isothermal Lithium-Ion Battery, which is set up in a similar way.

This base model uses the global SOC and Initial Charge Distribution node to define the cell state-of-charge and initial charge inventory. The following tutorials, available in the Battery Design Module Application Library, make use of this base model:

- 1D Lithium-Ion Battery Drive-Cycle Monitoring, which demonstrates how to run the model using a time-dependent current load curve
- Lithium-Ion Battery Rate Capability, which uses the base model to perform a range of discharge simulations at different rates. By modifying the cross-sectional capacity of the cell, an energy-optimized cell is compared to a power-optimized cell in a Ragone plot.
- Lithium-Ion Battery Internal Resistance, which simulates a hybrid pulse power characterization (HPPC) test and makes a full analysis of the different roots of the various voltage losses in the cell.
- Diffusion-Induced Stress in a Lithium-Ion Battery, which adds stresses and strains to the particles and in the negative electrode, and analyzes the mechanical stress that the particles are subjected to during a current load.
- Surrogate Model Training of a Battery Rate Capability Model, which is an application that uses the base model to compute data for training a deep neural network function. The application can be used to investigate the effect of battery electrode parameters on the rate capability of the battery.

# Model Definition

The model is defined in 1D along the through-layer direction between the metal current collector foils of a lithium jelly roll. The geometry thus consists of one negative porous electrode, one separator and one positive porous electrode domain.

In this tutorial, we will investigate a 21,700 battery where it is assumed that 90% of the internal volume is occupied by the active jelly roll (electrode, separator, and current collector layers). Because of the 1D geometry, the current load of the battery model is formulated as a current density boundary condition with the unit of  $A/m^2$ . The cell

current is calculated using a 1 C current variable  $I_{1C, \text{cell}}(A)$ , which is provided by the SOC and Initial Charge Distribution node. To convert from cell current (A) to cell current density  $(A/m^2)$  on the jelly roll, the cell area is used. The cell area is computed as

$$A_{\text{cell}} = \frac{V_{\text{cell}}}{L_{\text{cell}}} \tag{1}$$

where the length  $L_{\rm cell}$  of the cell is calculated as

$$L_{\rm cell} = L_{\rm neg} + L_{\rm sep} + L_{\rm pos} + L_{\rm ccs}/2 \tag{2}$$

where  $L_{ccs}$  is the sum of the thicknesses of the positive and negative current collector foils in the jelly roll. The factor 1/2 stems from the configuration of a typical jelly roll, where each metal foil is being coated on both sides by the same electrode layer.

#### MATERIALS

The battery model consists of the following materials:

- Negative electrode: Graphite (MCMB Li<sub>x</sub>C<sub>6</sub>)
- Positive electrode: NMC 111 (Li<sub>1/3</sub>Mn<sub>1/3</sub>Co<sub>1/3</sub>O<sub>2</sub>)
- Electrolyte: 1.0 M LiPF<sub>6</sub> in 3:7 EC:EMC

These materials are available from the Battery Material Library.

#### ELECTRODE THICKNESS BALANCING

The thickness of the positive electrode is set to  $45 \mu m$ . The negative electrode thickness is calculated based on electrode balancing, using the following criteria:

- In order to avoid lithium plating during fast charging, the negative graphite electrode should have excess host capacity, so that an approximate negative electrode lithiation level of 80% is reached at 100% cell state of charge (SOC).
- In order to avoid gassing and other harmful side reactions, the positive electrode potential is limited to about 4.23 V at 100% SOC, corresponding to a positive electrode lithiation level of 10%.

Based on the maximum Li concentration ( $c_{s,\,\rm max}$ ) and volume fractions ( $\epsilon_s$ ) of the electrode materials, the thickness of the negative electrode may now be computed as

$$L_{\text{neg}} = \frac{(1 - 0.1)\varepsilon_{s, \text{ NMC}}c_{s, \text{ max, NMC}}}{0.8\varepsilon_{s, \text{ Gr}}c_{s, \text{ max, Gr}}}L_{\text{pos}}$$

#### PHYSICAL MODEL

The Lithium-Ion Battery interface, used for defining the model, accounts for:

- Electronic conduction in the electrodes
- Ionic charge transport in the electrodes and electrolyte or separator
- Material transport in the electrolyte, allowing for the introduction of the effects of concentration on the ionic conductivity and concentration overpotentials
- Material transport within the spherical particles that form the electrodes, defined on an extra (pseudo) dimension
- Butler-Volmer electrode kinetics using experimentally measured discharge curves for the equilibrium (half cell) potentials.

This tutorial model uses the global SOC and Initial Charge Distribution node to define the cell state-of-charge and initial charge inventory. This node is activated by enabling Define cell state-of-charge (SOC) and initial charge inventory on the interface top node. In this model, the cell voltages at 0% and 100% SOC are set to be defined from operational potential limits, and the initial cell charge distribution is defined by an initial cell SOC parameter. The total initial charge inventory of the cell is defined by the positive electrode host capacity. A formation loss is added in order to reduce the initial charge inventory, assuming that some charge inventory has been irreversibly lost prior to the start of the simulation.

The Lithium-Ion Battery interface defines and solves for the solid lithium concentration in the electrode particles, individually for each electrode. Based on the lithium concentration, the degree of lithiation, SOL (dimensionless), then relates the solid concentration levels to the maximum concentration of lithium atoms that the electrode material can host:

$$SOL = \frac{c_{s}}{c_{s,max}}$$
 (3)

The individual degrees of lithiation for each electrode then in turns determine the local equilibrium potential for intercalation (the half cell potentials). During charge of a lithium- ion battery,  $c_s$  in the negative electrode will increase, whereas  $c_s$  in the positive electrode will decrease, with the rate being proportional to the battery current.

At open circuit of a fully relaxed cell, the cell voltage  $E_{OCV,cell}$  can be expressed as

$$E_{\text{OCV,cell}} = E_{\text{eq,pos}}(\text{sol}_{\text{pos}}) - E_{\text{eq,neg}}(\text{sol}_{\text{neg}})$$
(4)

where  $E_{\rm eq,pos}$  and  $E_{\rm eq,neg}$  (V) are the equilibrium potentials, expressed as functions of the degrees of lithiation  $SOL_{pos}$  and  $SOL_{neg}\left(1\right)$  of the positive and negative electrode materials, respectively, based on the average  $e_s$  variables of the corresponding electrode.

Unless the degrees of lithiation in the individual electrodes are coupled in some way, there exists an infinite number of combinations of values of SOL<sub>pos</sub> and SOL<sub>neg</sub> that fulfill the above equation. However, for an assembled battery cell, a change in SOL<sub>pos</sub> will always result in a corresponding change in SOL<sub>neg</sub>, and vice versa. The reason is that the total amount of lithium in the cell isconserved during cycling, resulting in a unique solution to the above equation.

In contrast to the individual electrode degrees of intercalation, which depend on the local concentrations of lithium, the state of charge (SOC) of a battery cell is typically defined on a global level as being proportional to the amount of charge passed when cycling between two corresponding open circuit voltage limits. The lower voltage limit corresponds to 0% SOC, and the upper voltage limit corresponds to 100% SOC. A cell state-of-charge variable is automatically calculated by the SOC and Initial Charge Distribution node.

# Reference

1. M. Doyle, J. Newman, A.S. Gozdz, C.N. Schmutz, and J.M. Tarascon, "Comparison of Modeling Predictions with Experimental Data from Plastic Lithium Ion Cells," J. Electrochem. Soc., vol. 143, no. 6, pp. 1890–1903, 1996.

Application Library path: Battery\_Design\_Module/Batteries,\_Lithium-Ion/ lib\_base\_model\_1d

# Modeling Instructions

From the File menu, choose New.

In the New window, click Model Wizard.

#### MODEL WIZARD

- I In the Model Wizard window, click ID.
- 2 In the Select Physics tree, select Electrochemistry>Batteries>Lithium-Ion Battery (liion).

- 3 Click Add.
- 4 Click Study.
- 5 In the Select Study tree, select Preset Studies for Selected Physics Interfaces>
  Time Dependent with Initialization.
- 6 Click M Done.

#### **GLOBAL DEFINITIONS**

#### Parameters 1

Load the parameters from a text file.

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- 3 Click Load from File.
- **4** Browse to the model's Application Libraries folder and double-click the file lib\_base\_model\_1d\_parameters.txt.

#### ADD MATERIAL

- I In the **Home** toolbar, click **Add Material** to open the **Add Material** window. Add some data for the electrolyte and the electrodes from the material library.
- 2 Go to the Add Material window.
- 3 In the tree, select Battery>Electrolytes>LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery).
- 4 Right-click and choose Add to Component I (compl).
- 5 In the tree, select Battery>Electrodes>Graphite, LixC6 MCMB (Negative, Li-ion Battery).
- 6 Right-click and choose Add to Component I (compl).
- 7 In the tree, select Battery>Electrodes>NMC 111, LiNi0.33Mn0.33Co0.3302 (Positive, Liion Battery).
- 8 Right-click and choose Add to Component I (compl).
- 9 In the Home toolbar, click **Add Material** to close the Add Material window.

#### **GEOMETRY I**

Draw the model geometry by defining the individual thicknesses of the negative electrode, the separator and the positive electrode.

Interval I (iI)

I In the Model Builder window, under Component I (compl) right-click Geometry I and choose Interval.

- 2 In the Settings window for Interval, locate the Interval section.
- 3 From the Specify list, choose Interval lengths.
- **4** In the table, enter the following settings:

Lengths (m)	
L_neg	
L_sep	
L_pos	

5 Click | Build Selected.

#### MATERIALS

LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery) (mat1)

Now assign the previously added materials to the different domains of the geometry. Create selections at the same time to facilitate choosing the same domains later on.

- I In the Model Builder window, under Component I (compl)>Materials click LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery) (matl).
- **2** Select Domain 2 only.
- 3 In the Settings window for Material, locate the Geometric Entity Selection section.
- 4 Click **Create Selection**.
- 5 In the Create Selection dialog box, type Separator in the Selection name text field.
- 6 Click OK.

Graphite, LixC6 MCMB (Negative, Li-ion Battery) (mat2)

- I In the Model Builder window, click Graphite, LixC6 MCMB (Negative, Liion Battery) (mat2).
- 2 In the Settings window for Material, locate the Geometric Entity Selection section.
- 3 Click Clear Selection.
- 4 Select Domain 1 only.
- 5 Click **Create Selection**.
- 6 In the Create Selection dialog box, type Negative Electrode in the Selection name text field.
- 7 Click OK.

NMC 111, LiNi0.33Mn0.33Co0.33O2 (Positive, Li-ion Battery) (mat3)

- I In the Model Builder window, click NMC 111, LiNi0.33Mn0.33Co0.3302 (Positive, Liion Battery) (mat3).
- 2 Select Domain 3 only.
- 3 In the Settings window for Material, locate the Geometric Entity Selection section.
- 4 Click Create Selection.
- 5 In the Create Selection dialog box, type Positive Electrode in the Selection name text field.
- 6 Click OK.

#### LITHIUM-ION BATTERY (LIION)

Now start defining the physics. Use the SOC and Initial Charge Distribution node in order to calculate the initial charge distribution in the cell.

- I In the Model Builder window, under Component I (compl) click Lithium-Ion Battery (liion).
- 2 In the Settings window for Lithium-Ion Battery, locate the Cross-Sectional Area section.
- 3 In the  $A_c$  text field, type A\_cell.
- 4 Locate the Cell Settings section. Select the Define cell state of charge (SOC) and initial charge inventory check box.

SOC and Initial Charge Distribution 1

- I In the Model Builder window, under Component I (compl)>Lithium-lon Battery (liion) click SOC and Initial Charge Distribution I.
- 2 In the Settings window for SOC and Initial Charge Distribution, locate the Initial Cell Charge Distribution section.
- **3** In the  $SOC_0$  text field, type soc init.

Negative Electrode Selection I

- I In the Model Builder window, click Negative Electrode Selection I.
- 2 In the Settings window for Negative Electrode Selection, locate the Domain Selection section.
- 3 From the Selection list, choose Negative Electrode.

Positive Electrode Selection I

I In the Model Builder window, click Positive Electrode Selection I.

- 2 In the Settings window for Positive Electrode Selection, locate the Domain Selection section.
- 3 From the Selection list, choose Positive Electrode.

#### Separator I

- I In the Model Builder window, under Component I (compl)>Lithium-lon Battery (liion) click Separator 1.
- 2 In the Settings window for Separator, locate the Porous Matrix Properties section.
- **3** In the  $\varepsilon_1$  text field, type epsl sep.

#### Porous Electrode - Negative

- I In the Physics toolbar, click **Domains** and choose **Porous Electrode**.
- 2 In the Settings window for Porous Electrode, type Porous Electrode Negative in the Label text field.
- 3 Locate the Domain Selection section. From the Selection list, choose Negative Electrode.
- 4 Locate the Electrolyte Properties section. From the Electrolyte material list, choose LiPF6 in 3:7 EC:EMC (Liquid, Li-ion Battery) (matl).
- **5** Locate the **Electrode Properties** section. In the  $\sigma_s$  text field, type sigmas\_neg.
- **6** Locate the **Porous Matrix Properties** section. In the  $\varepsilon_s$  text field, type epss\_neg.
- **7** In the  $\varepsilon_1$  text field, type epsl\_neg.
- 8 Locate the Effective Transport Parameter Correction section. From the **Electrical conductivity** list, choose **No correction**.

#### Particle Intercalation I

- I In the Model Builder window, click Particle Intercalation I.
- 2 In the Settings window for Particle Intercalation, locate the Particle Transport Properties section.
- **3** In the  $r_{\rm p}$  text field, type rp\_neg.

#### Porous Electrode Reaction I

- I In the Model Builder window, click Porous Electrode Reaction I.
- 2 In the Settings window for Porous Electrode Reaction, locate the Electrode Kinetics section.
- **3** In the  $i_{0,ref}(T)$  text field, type i0\_ref\_neg.

### Porous Electrode - Negative

In the Model Builder window, right-click Porous Electrode - Negative and choose Duplicate.

#### Porous Electrode - Positive

- I In the Model Builder window, under Component I (compl)>Lithium-lon Battery (liion) click Porous Electrode - Negative I.
- 2 In the Settings window for Porous Electrode, type Porous Electrode Positive in the Label text field.
- 3 Locate the Domain Selection section. From the Selection list, choose Positive Electrode.
- **4** Locate the **Electrode Properties** section. In the  $\sigma_s$  text field, type sigmas\_pos.
- **5** Locate the **Porous Matrix Properties** section. In the  $\varepsilon_s$  text field, type epss\_pos.
- **6** In the  $\varepsilon_1$  text field, type epsl pos.

#### Particle Intercalation 1

- I In the Model Builder window, expand the Porous Electrode Positive node, then click Particle Intercalation 1.
- 2 In the Settings window for Particle Intercalation, locate the Particle Transport Properties section.
- **3** In the  $r_{\rm D}$  text field, type rp\_pos.

#### Porous Electrode Reaction I

- I In the Model Builder window, click Porous Electrode Reaction I.
- 2 In the Settings window for Porous Electrode Reaction, locate the Electrode Kinetics section.
- **3** In the  $i_{0,ref}(T)$  text field, type i0\_ref\_pos.

#### Electric Ground 1

- I In the Physics toolbar, click Boundaries and choose Electric Ground.
- 2 Select Boundary 1 only.
- 3 In the Settings window for Electric Ground, locate the Boundary Selection section.
- 4 Click **Greate Selection**.
- 5 In the Create Selection dialog box, type Negative CC in the Selection name text field.
- 6 Click OK.

#### Electrode Current Density I

- I In the Physics toolbar, click Boundaries and choose Electrode Current Density.
- 2 Select Boundary 4 only.
- 3 In the Settings window for Electrode Current Density, locate the Boundary Selection section.

- 4 Click **Create Selection**.
- 5 In the Create Selection dialog box, type Positive CC in the Selection name text field.
- 6 Click OK.
- 7 In the Settings window for Electrode Current Density, locate the Electrode Current Density
- **8** In the  $i_{n,s}$  text field, type I\_1C.

#### **GLOBAL DEFINITIONS**

Default Model Inbuts

- I In the Model Builder window, under Global Definitions click Default Model Inputs.
- 2 In the Settings window for Default Model Inputs, locate the Browse Model Inputs section.
- 3 In the tree, select General>Temperature (K) minput.T.
- 4 Find the Expression for remaining selection subsection. In the Temperature text field, type Τ.

#### **DEFINITIONS (COMPI)**

Load some variables definitions from a text file.

Variables 1

- I In the Model Builder window, under Component I (compl) right-click Definitions and choose Variables.
- 2 In the Settings window for Variables, locate the Variables section.
- 3 Click Load from File.
- 4 Browse to the model's Application Libraries folder and double-click the file lib\_base\_model\_1d\_variables.txt.

Point Probe I (point I)

- I In the **Definitions** toolbar, click **Probes** and choose **Point Probe**.
- 2 In the Settings window for Point Probe, type E cell in the Variable name text field.
- **3** Locate the **Probe Type** section. From the **Type** list, choose **Integral**.
- 4 Locate the Source Selection section. From the Selection list, choose Positive CC.
- **5** Locate the **Expression** section. In the **Expression** text field, type phis.
- **6** Select the **Description** check box. In the associated text field, type **Cell voltage**.
- 7 Click to expand the Table and Window Settings section. Click + Add Table.

#### RESULTS

In the Model Builder window, expand the Results node.

Cell Voltage Probe Data

- I In the Model Builder window, expand the Results>Tables node, then click Table I.
- 2 In the Settings window for Table, type Cell Voltage Probe Data in the Label text field.

#### STUDY I

Step 2: Time Dependent

- I In the Model Builder window, under Study I click Step 2: Time Dependent.
- 2 In the Settings window for Time Dependent, locate the Study Settings section.
- **3** From the **Time unit** list, choose **h**.
- 4 In the Output times text field, type range (0,0.1,0.9).