

Bracket — General Periodic Dynamic Analysis

The steady-state response of a system subjected to a nonharmonic periodic excitation can be computed using two different approaches:

- The most straightforward is a time-dependent analysis in which a large number of cycles is computed so that any traces of startup transients fade away. For structures with a low damping, a fairly large number of cycles may be needed so the computational cost can be high.
- An alternative, more efficient approach, is to represent the forcing function by a Fourier series. It is then possible to compute a sequence of frequency domain solutions, one for each term in the series. In order to get the results back into the time domain, the results for each harmonic has to be superimposed over the time of a full period.

In this example, you learn how to compute the Fourier series coefficients of the periodic forcing function, and how to use them to perform a frequency response analysis. The results from the frequency response analysis is used as input to an inverse FFT analysis to get the steady-state time-varying response for a complete period. In order to validate the results from this approach, a time-dependent analysis is performed.

In both cases, a full or a modal solution scheme can be used. Compared to full timedependent or frequency-domain methods, modal methods offer advantages with a reduced problem size if a limited number of eigenmode is excited. By representing the dynamics of the system by a few significant eigenmodes, the modal method reduces the size of problem. In this example, modal solution methods are used in both cases.

It is recommended that you review the Introduction to the Structural Mechanics Module, which includes background information and discusses the bracket basic.mph model relevant to this example.

Model Definition

This model is an extension of the model example described in the section "The Fundamentals: A Static Linear Analysis" in the Introduction to the Structural Mechanics Module.

The geometry is shown in Figure 1.




Figure 1: Bracket geometry.

The time varying periodic load is a force applied in the X direction at the bracket holes. It consists of a triangular pulse with an amplitude of 750 N amplitude and zero mean, varying with 40 Hz frequency as shown in Figure 2.




Figure 2: The load history.




Figure 3: The damping ratio curve.

Rayleigh damping is chosen since it is applicable both in frequency and time domains. The relative damping is set to 0.03 at the frequencies $100~\mathrm{Hz}$ and $300~\mathrm{Hz}$. The damping ratio curve is shown in Figure 3.

An eigenfrequency analysis of this structure is performed in the tutorial model Bracket — Eigenfrequency Analysis. It shows that the first resonance frequency is about 115 Hz. The fundamental frequency of the load, having the frequency 40 Hz, will thus mainly excite the first mode of the bracket.

FOURIER SERIES

A periodic function F(t) with period T_0 (and corresponding angular frequency ω_0) can be decomposed into a discrete Fourier series of the form

$$F(t) = F_{a0} + \sum_{n=1}^{\infty} (F_{an}\cos(n\omega_0 t) + F_{bn}\sin(n\omega_0 t))$$
 (1)

where

$$F_{a0} = \frac{1}{T} \int_{T}^{T} F(t)dt$$

$$\int_{T}^{0} F(t) \cos(n\omega_{0}t)dt$$

$$\int_{T}^{0} F(t) \sin(n\omega_{0}t)dt$$

$$F_{bn} = \frac{2}{T} \int_{0}^{T} F(t) \sin(n\omega_{0}t)dt$$

$$\int_{0}^{0} F(t) \sin(n\omega_{0}t)dt$$

$$\int_{0}^{0} F(t) \sin(n\omega_{0}t)dt$$

The periodic load in this model is a triangular function which is an odd function with zero mean. The Fourier series coefficients can be shown to be

$$\begin{split} F_{\rm a0} &= 0 \\ F_{\rm an} &= 0 \\ F_{\rm bn} &= 4A \bigg(\frac{1 - (-1)^n}{\pi^2 n^2} \bigg) \end{split} \tag{3}$$

Here A is the amplitude of the triangular function. For even values of n, the coefficients $F_{\rm bn}$ are zero.

Alternatively, the trigonometric functions and Fourier coefficients can be expressed on complex form:

$$F(t) = F_{a0} + \text{Re}\left(\sum_{n=1}^{\infty} F_n e^{in\omega_0 t}\right)$$
 (4)

where $F_{\rm n}$ are complex valued. This is the notation used in COMSOL Multiphysics. The relation between the Fourier series coefficients in the two formulations are

$$\begin{aligned} F_{\rm an} &= {\rm Re}(F_{\rm n}) \\ F_{\rm bn} &= -{\rm Im}(F_{\rm n}) \end{aligned} \tag{5}$$

Since the Fourier coefficients for the given load can be determined analytically, the accuracy of the computed values can be investigated. In Figure 4, the Fourier series coefficients are plotted against the frequency.




Figure 4: Numerical and analytical values of Fourier series coefficients.

As can be seen, the computed values match the values given by Equation 3 very well.

Another way of investigating the accuracy of the computed Fourier series coefficients is to compare the real and imaginary values. Since, for this loading function, all coefficients are purely imaginary, the real parts should be small. This comparison is shown in Figure 5. It can be seen that the error increases with the order of the term, but the accuracy is still good up to 2000 – 3000 Hz. The accuracy can be improved by computing a higher number of terms, that is the setting Maximum output frequency in the Time to Frequency FFT study step.




Figure 5: Real and imaginary parts of the Fourier series coefficients.

In Figure 6 and Figure 7, the von Mises stress at a certain time in the period is plotted for the two different solution methods. The results are very similar. There are two different possible sources of inaccuracy:

- The accuracy in the computation of Fourier series coefficients.
- Errors in the time integration, in particular the number of periods used for letting startup transients fade away. In this case, 21 periods are computed.

In most cases, the time-stepping algorithm will be the larger source of error.




Figure 6: Equivalent stress at t = 0.022 s using the general periodic approach.




Figure 7: Equivalent stress at t = 0.022 s using a time-dependent modal approach.

In Figure 8, the contributions to the displacement from each harmonic is plotted. This is the amplitude for each frequency in the frequency sweep. It can be seen that it is mainly

the Fourier terms at 40 Hz and 120 Hz that contribute. Thus, it is only some of the few terms with the very best accuracy that are dominating.




Figure 8: Amplitude contribution from each harmonic to the displacement in the X direction at the tip of the bracket.

In Figure 9, the displacement at the tip of the bracket is shown for one period. The two different solution methods are compared, and the results are almost indistinguishable.

In Figure 10, a similar graph for the σ_{xx} stress component at a point in the highly stressed fillet is shown.

In both graphs the effect of the two dominating frequencies 40 Hz and 120 Hz is clearly visible. The frequency content of the excitation is filtered by the dynamic properties of the structure, giving a response that bears little similarity to the excitation.




Figure 9: Displacement in the X direction at the tip of the bracket.




Figure 10: Stress in the critical region in the fillet.

Notes About the COMSOL Implementation

Frequency-domain analysis in COMSOL Multiphysics is performed using a complexvalued representation. The complex-valued Fourier series coefficients can then be directly used as loads. In order to assign the correct coefficient to the corresponding frequency, a withsol() operator is used.

As the load is periodic, either a discrete Fourier transform (DFT) or continuous Fourier transform (CFT) can be used. In the CFT, the Fourier series coefficients are scaled in a more natural way, so it is used to compute the Fourier series coefficients. When transforming back into the time domain, a DFT is used. The unscaled version is suitable for performing a direct superposition of the computed frequency response.

In the modal time-dependent procedure, all loads must have the same variation in time, specified in the study step. This means that you should not enter any time-dependent loads (that is, loads with an explicit dependency on the time variable t). In this example, the

amplitude of the periodic load is entered in the Boundary Load node, while the periodic part of the load is entered at the Modal Solver node.

Two action buttons are provided in the **Damping Settings** section in order to visualize the damping ratio with respect to frequency. The first button shows a dynamic preview plot of the damping ratio, while the second button generates a plot in the **Results** node.

Application Library path: Structural Mechanics Module/Tutorials/ bracket general periodic

Modeling Instructions

APPLICATION LIBRARIES

- I From the File menu, choose Application Libraries.
- 2 In the Application Libraries window, select Structural Mechanics Module>Tutorials> bracket basic in the tree.
- 3 Click Open.

Describe the periodic load using interpolation and analytical functions.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
A0	750[N]	750 N	Peak load intensity
MO	O[N]	0 N	Mean load intensity
f0	40[Hz]	40 Hz	Fundamental frequency
T0	1/f0	0.025 s	Base period

Interpolation I (int I)

- I In the Home toolbar, click f(x) Functions and choose Global>Interpolation.
- 2 In the Settings window for Interpolation, locate the Definition section.

3 In the table, enter the following settings:

t	f(t)	
0	МО	
T0/4	MO+AO	
3/4*T0	MO-A0	
T0	MO	

4 Locate the **Units** section. In the **Argument** table, enter the following settings:

Argument	Unit
t	s

5 In the **Function** table, enter the following settings:

Function	Unit
intl	N

Analytic I (an I)

I In the Home toolbar, click f(X) Functions and choose Global>Analytic.

2 In the Settings window for Analytic, type loadHistory in the Function name text field.

3 Locate the **Definition** section. In the **Expression** text field, type int1(x).

4 Click to expand the **Periodic Extension** section. Select the **Make periodic** check box.

5 In the **Upper limit** text field, type **T0**.

6 Locate the **Units** section. In the table, enter the following settings:

Argument	Unit
x	S

7 In the Function text field, type N.

8 Locate the **Plot Parameters** section. In the table, enter the following settings:

Plot	Argument	Lower limit	Upper limit	Fixed value	Unit
$\sqrt{}$	x	0	5*T0	0	s

9 Click Told Plot.

10 Right-click Analytic I (loadHistory) and choose Duplicate.

Analytic 2 (loadHistory2)

I In the Model Builder window, under Global Definitions click Analytic 2 (loadHistory2).

- 2 In the Settings window for Analytic, type Periodic in the Function name text field.
- 3 Locate the **Definition** section. In the **Expression** text field, type int1(x)/A0.
- 4 Locate the Units section. In the Function text field, type 1.

In order to find the Fourier series coefficients of the periodic function, add a zerodimensional component with a Global ODEs and DAEs mathematical interface.

ADD COMPONENT

In the Model Builder window, right-click the root node and choose Add Component>0D.

ADD PHYSICS

- I In the Home toolbar, click open the Add Physics window.
- 2 Go to the Add Physics window.
- 3 In the tree, select Mathematics>ODE and DAE Interfaces>Global ODEs and DAEs (ge).
- 4 Click Add to Component 2 in the window toolbar.
- 5 In the Home toolbar, click of Add Physics to close the Add Physics window.

GLOBAL ODES AND DAES (GE)

Global Equations I (ODEI)

- I In the Model Builder window, under Component 2 (comp2)>Global ODEs and DAEs (ge) click Global Equations I (ODEI).
- 2 In the Settings window for Global Equations, locate the Global Equations section.
- **3** In the table, enter the following settings:

Name	f(u,ut,utt,t) (I)	Initial value (u_0) (1)	Initial value (u_t0) (1/s)	Description
Р	P- loadHistory(t)	loadHistory(0)	0	

- 4 Locate the Units section. Click Select Dependent Variable Quantity.
- 5 In the Physical Quantity dialog box, type force in the text field.
- 6 Click **Filter**.
- 7 In the tree, select General>Force (N).
- 8 Click OK.
- 9 In the Settings window for Global Equations, locate the Units section.
- 10 Click Select Source Term Quantity.

II In the Physical Quantity dialog box, select General>Force (N) in the tree.

I2 Click OK.

Add Time Dependent and Time to Frequency FFT study steps to generate Fourier coefficients.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies> Time Dependent.
- 4 Right-click and choose Add Study.
- **5** In the **Model Builder** window, click the root node.
- 6 In the Home toolbar, click Add Study to close the Add Study window.

STUDY I: FOURIER COEFFICIENT GENERATION

- In the Settings window for Study, type Study 1: Fourier Coefficient Generation in the Label text field.
- 2 Locate the Study Settings section. Clear the Generate default plots check box.

Step 1: Time Dependent

- I In the Model Builder window, under Study I: Fourier Coefficient Generation click Step I: Time Dependent.
- 2 In the Settings window for Time Dependent, locate the Study Settings section.
- 3 In the Output times text field, type range (0, T0/1000, T0).
- 4 Locate the Physics and Variables Selection section. In the table, clear the Solve for check box for Solid Mechanics (solid).

Step 2: Time to Frequency FFT

- I In the Study toolbar, click Study Steps and choose Frequency Domain>
 Time to Frequency FFT.
- 2 In the Settings window for Time to Frequency FFT, locate the Study Settings section.
- 3 In the End time text field, type T0.
 By setting a high upper frequency, the accuracy of the Fourier coefficients for the lower frequencies will be improved.
- 4 In the Maximum output frequency text field, type 10000.
- 5 Locate the Physics and Variables Selection section. In the table, clear the Solve for check box for Solid Mechanics (solid).

Solution I (soll)

- 2 In the Model Builder window, expand the Solution I (soll) node.
- 3 In the Model Builder window, under Study 1: Fourier Coefficient Generation> Solver Configurations>Solution I (soll) click Time-Dependent Solver I.
- 4 In the Settings window for Time-Dependent Solver, click to expand the Time Stepping section.
- 5 From the Steps taken by solver list, choose Strict.
- 6 Find the Algebraic variable settings subsection. From the Consistent initialization list, choose Off.
- 7 In the Study toolbar, click **Compute**.

RESULTS

Fourier Coefficients, Computed vs. Analytical

- I In the Model Builder window, expand the Results node.
- 2 Right-click Results and choose ID Plot Group.
- 3 In the Settings window for ID Plot Group, type Fourier Coefficients, Computed vs. Analytical in the Label text field.
- 4 Locate the Data section. From the Parameter selection (freq) list, choose Manual.
- 5 In the Parameter indices (1-251) text field, type range (1,1,100).
- 6 Click to expand the Title section. From the Title type list, choose Label.
- 7 Locate the **Plot Settings** section.
- 8 Select the x-axis label check box. In the associated text field, type freq (Hz).
- 9 Select the y-axis label check box. In the associated text field, type Fourier Coefficients (N).
- 10 Locate the Axis section. Select the y-axis log scale check box.

Global: Computed

- I Right-click Fourier Coefficients, Computed vs. Analytical and choose Global.
- 2 In the Settings window for Global, type Global: Computed in the Label text field.
- 3 Locate the y-Axis Data section. In the table, enter the following settings:

Expression	Unit	Description
abs(comp2.P)	N	

- 4 Click to expand the Coloring and Style section. Find the Line style subsection. From the Line list, choose None.
- 5 Find the Line markers subsection. From the Marker list, choose Circle.
- **6** From the **Width** list, choose **3**.
- 7 Click to expand the Legends section. From the Legends list, choose Manual.
- **8** In the table, enter the following settings:

Legends	
Computed	

9 Right-click Global: Computed and choose Duplicate.

Global: Analytical

- I In the Model Builder window, under Results>Fourier Coefficients, Computed vs. Analytical click Global: Computed 1.
- 2 In the Settings window for Global, type Global: Analytical in the Label text field.
- **3** Locate the **y-Axis Data** section. In the table, enter the following settings:

Expression	Unit	Description
8*A0/(pi^2*(freq/f0)^2)	N	

- 4 Locate the Data section. From the Dataset list, choose Study 1: Fourier Coefficient Generation/Solution 1 (sol1).
- 5 From the Parameter selection (freq) list, choose Manual.
- 6 In the Parameter indices (1-251) text field, type range (2, 2, 100).
- 7 Locate the Coloring and Style section. Find the Line markers subsection. From the Marker list, choose Plus sign.
- **8** Locate the **Legends** section. In the table, enter the following settings:



Fourier Coefficients; Real and Imaginary

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Fourier Coefficients; Real and Imaginary in the Label text field.

- 3 Locate the Title section. From the Title type list, choose Label.
- 4 Locate the Data section. From the Parameter selection (freq) list, choose Manual.
- 5 In the Parameter indices (1-251) text field, type range (2, 2, 100).
- 6 Locate the Axis section. Select the x-axis log scale check box.
- 7 Select the y-axis log scale check box.
- 8 Locate the Plot Settings section.
- **9** Select the **x-axis label** check box. In the associated text field, type freq (Hz).
- 10 Select the y-axis label check box. In the associated text field, type Fourier Coefficients (N).

Global I

- I Right-click Fourier Coefficients; Real and Imaginary and choose Global.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
abs(real(comp2.P))	N	
abs(imag(comp2.P))	N	

- 4 Locate the Coloring and Style section. Find the Line style subsection. From the Line list, choose None.
- 5 Find the Line markers subsection. From the Marker list, choose Circle.
- **6** From the **Width** list, choose **3**.
- 7 Locate the Legends section. From the Legends list, choose Manual.
- **8** In the table, enter the following settings:

Legends	
Real	
Imaginary	

9 In the Fourier Coefficients; Real and Imaginary toolbar, click Plot.

Now, set up the Solid Mechanics interface in order to find the response of the bracket to the periodic load.

DEFINITIONS (COMPI)

In the Model Builder window, expand the Component I (compl)>Definitions>Selections node.

SOLID MECHANICS (SOLID)

Linear Elastic Material I

In the Model Builder window, expand the Component I (compl)>Solid Mechanics (solid) node, then click Linear Elastic Material I.

Damping I

- I In the Physics toolbar, click 🕞 Attributes and choose Damping. Rayleigh damping is used for this example since it is applicable both in frequency and time domain analysis.
- 2 In the Settings window for Damping, locate the Damping Settings section.
- 3 From the Input parameters list, choose Damping ratios.
- **4** In the f_1 text field, type 100.
- **5** In the ζ_1 text field, type 0.03.
- **6** In the f_2 text field, type 300.
- **7** In the ζ_2 text field, type 0.03. In order to visualize the damping ratio curve, create the Damping Ratio plot through an action button from the Damping Settings section.
- 8 Click Damping Ratio Preview in the upper-right corner of the Damping Settings section. From the menu, choose Create Damping Ratio Plot.

RESULTS

Damping Ratio Plot

- I In the Model Builder window, under Results click Damping Ratio Plot.
- 2 In the Damping Ratio Plot toolbar, click Plot.

You can now apply an external harmonic load in terms of the Fourier Series coefficients to the bracket arms.

SOLID MECHANICS (SOLID)

Boundary Load, Harmonic

I In the Physics toolbar, click **Boundaries** and choose **Boundary Load**.

- 2 In the Settings window for Boundary Load, type Boundary Load, Harmonic in the Label text field.
- 3 Locate the Boundary Selection section. From the Selection list, choose Pin Holes.
- 4 Locate the Force section. From the Load type list, choose Total force.
- **5** Specify the \mathbf{F}_{tot} vector as

<pre>withsol('sol1',comp2.P,setval(freq,freq))</pre>	х
0	у
0	z

To define a harmonic load in the frequency domain modal analysis, you need to mark the load as being a harmonic perturbation.

6 Right-click Boundary Load, Harmonic and choose Harmonic Perturbation.

Add the Frequency Domain, Modal study along with the Time to Frequency FFT study step.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select Preset Studies for Selected Physics Interfaces>Solid Mechanics>Frequency Domain, Modal.
- 4 Right-click and choose Add Study.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 2: FREQUENCY DOMAIN MODAL + FFT

In the Settings window for Study, type Study 2: Frequency Domain Modal + FFT in the Label text field.

Steb 1: Eigenfrequency

- I In the Model Builder window, under Study 2: Frequency Domain Modal + FFT click Step 1: Eigenfrequency.
- 2 In the Settings window for Eigenfrequency, locate the Study Settings section.
- 3 Select the **Desired number of eigenfrequencies** check box. In the associated text field, type 12.
- 4 Locate the Physics and Variables Selection section. Select the Modify model configuration for study step check box.

- 5 In the tree, select Component I (compl)>Solid Mechanics (solid)> Linear Elastic Material I>Damping I.
- 6 Right-click and choose Disable.
- 7 In the tree, select Component 2 (comp2)>Global ODEs and DAEs (ge).
- 8 Right-click and choose Disable in Solvers.

Step 2: Frequency Domain, Modal

- I In the Model Builder window, click Step 2: Frequency Domain, Modal.
- 2 In the Settings window for Frequency Domain, Modal, locate the Study Settings section.
- 3 In the Frequencies text field, type range (f0, f0, 40*f0).
- 4 Locate the Physics and Variables Selection section. Select the Modify model configuration for study step check box.
- 5 In the tree, select Component 2 (comp2)>Global ODEs and DAEs (ge).
- 6 Right-click and choose Disable in Solvers.

Step 3: Frequency to Time FFT

- I In the Study toolbar, click Study Steps and choose Time Dependent> Frequency to Time FFT.
- 2 In the Settings window for Frequency to Time FFT, locate the Study Settings section.
- 3 In the **Times** text field, type range(0,T0/100,T0).

 The purpose of the inverse FFT study step is just to superimpose the results from the different harmonics, so the unscaled discrete FFT is suitable.
- 4 From the Scaling list, choose Discrete Fourier transform.
- 5 Locate the Physics and Variables Selection section. Select the Modify model configuration for study step check box.
- 6 In the tree, select Component 2 (comp2)>Global ODEs and DAEs (ge).
- 7 Right-click and choose Disable in Solvers.
- 8 In the Study toolbar, click **Compute**.

RESULTS

Stress: Frequency Domain Modal + FFT

- I In the Settings window for 3D Plot Group, locate the Data section.
- **2** From the Time (s) list, choose **0.022**.
- 3 Locate the Color Legend section. Select the Show maximum and minimum values check box.

4 In the Label text field, type Stress: Frequency Domain Modal + FFT.

Volume 1

- I In the Model Builder window, expand the Stress: Frequency Domain Modal + FFT node, then click Volume 1.
- 2 In the Settings window for Volume, locate the Expression section.
- 3 From the Unit list, choose MPa.

Displacement Amplitude [Frequency Response]

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Displacement Amplitude [Frequency Response] in the Label text field.
- 3 Locate the Title section. From the Title type list, choose Label.
- 4 Locate the Data section. From the Dataset list, choose Study 2: Frequency Domain Modal + FFT/Solution Store 3 (sol5).
- 5 From the Parameter selection (freq) list, choose Manual.
- 6 In the Parameter indices (1-40) text field, type range (1,1,10).

Point Graph 1

- I Right-click Displacement Amplitude [Frequency Response] and choose Point Graph.
- **2** Select Point 1 only.
- 3 In the Settings window for Point Graph, click Replace Expression in the upper-right corner of the y-Axis Data section. From the menu, choose Component I (compl)> Solid Mechanics>Displacement>Displacement amplitude (material and geometry frames) m>solid.uAmpX - Displacement amplitude, X-component.
- 4 Locate the y-Axis Data section. From the Unit list, choose mm.
- 5 Click to expand the Coloring and Style section. Find the Line style subsection. From the Line list, choose None.
- 6 Find the Line markers subsection. From the Marker list, choose Diamond.

For verification, solve the problem also in time domain. To provide the time-domain load, enter its amplitude in a Boundary Load node, and its time dependency in the solver settings for the Time Dependent, Modal study step.

SOLID MECHANICS (SOLID)

Boundary Load, Time Domain Amplitude

- I In the Physics toolbar, click **Boundaries** and choose **Boundary Load**.
- 2 In the Settings window for Boundary Load, type Boundary Load, Time Domain Amplitude in the Label text field.
- 3 Locate the Boundary Selection section. From the Selection list, choose Pin Holes.
- 4 Locate the Force section. From the Load type list, choose Total force.
- **5** Specify the \mathbf{F}_{tot} vector as

Α0	x
0	у
0	z

Disable the transient boundary load in the second study. While not necessary, since it is a harmonic perturbation load, it makes the modeling easier to follow.

STUDY 2: FREQUENCY DOMAIN MODAL + FFT

Step 2: Frequency Domain, Modal

- I In the Model Builder window, under Study 2: Frequency Domain Modal + FFT click Step 2: Frequency Domain, Modal.
- 2 In the Settings window for Frequency Domain, Modal, locate the Physics and Variables Selection section.
- 3 In the tree, select Component I (compl)>Solid Mechanics (solid)>Boundary Load, Time Domain Amplitude.
- 4 Right-click and choose Disable.

Step 3: Frequency to Time FFT

- I In the Model Builder window, click Step 3: Frequency to Time FFT.
- 2 In the Settings window for Frequency to Time FFT, locate the Physics and Variables Selection section.
- 3 In the tree, select Component I (compl)>Solid Mechanics (solid)>Boundary Load, Time Domain Amplitude.
- 4 Right-click and choose **Disable**.

Add the Time-Dependent, Modal study.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select Preset Studies for Selected Physics Interfaces>Solid Mechanics>Time Dependent, Modal.
- 4 Right-click and choose Add Study.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 3: TIME-DEPENDENT MODAL [VERIFICATION]

In the Settings window for Study, type Study 3: Time-Dependent Modal [Verification] in the Label text field.

Since the eigenfrequencies are already computed in a previous study, it is possible to remove the eigenfrequency study step here.

Step 1: Eigenfrequency

In the Model Builder window, under Study 3: Time-Dependent Modal [Verification] rightclick **Step 1: Eigenfrequency** and choose **Delete**.

Steb 1: Time Dependent, Modal

In order for any startup transients to fade away, a significant number of cycles need to be analyzed, but only the results from the last cycle need to be stored. Here, 20 periods will pass before results are stored.

- I In the Model Builder window, under Study 3: Time-Dependent Modal [Verification] click Step I: Time Dependent, Modal.
- 2 In the Settings window for Time Dependent, Modal, locate the Study Settings section.
- 3 In the Output times text field, type -20*TO range(0,T0/100,T0). For a Time Dependent, Modal study step, the time-dependent part of the load needs to be entered in the study settings.
- 4 In the Load factor text field, type Periodic(t).
- 5 Locate the Physics and Variables Selection section. Select the Modify model configuration for study step check box.
- 6 In the tree, select Component I (compl)>Solid Mechanics (solid)>Boundary Load, Harmonic.
- 7 Right-click and choose Disable.
- 8 In the tree, select Component 2 (comp2)>Global ODEs and DAEs (ge).

9 Right-click and choose Disable in Solvers.

Solution 6 (sol6)

- I In the Study toolbar, click Show Default Solver. Enforce small time steps.
- 2 In the Model Builder window, expand the Solution 6 (sol6) node, then click Modal Solver 1.
- 3 In the Settings window for Modal Solver, locate the General section.
- 4 From the Maximum step constraint list, choose Constant.
- 5 In the Maximum step text field, type 5e-5. Since the eigenfrequency study step has been removed from this study, it is necessary to point to the study step that provides the eigenvalue solution.
- 6 Locate the Eigenpairs section. From the Solution list, choose Solution 3 (sol3).
- 7 From the Use list, choose Solution Store 2 (sol4).
- 8 In the Study toolbar, click **Compute**.

RESULTS

Stress: Time-Dependent Modal

- I In the Settings window for 3D Plot Group, locate the Data section.
- 2 From the Time (s) list, choose 0.022.
- 3 Locate the Color Legend section. Select the Show maximum and minimum values check box.
- 4 In the Label text field, type Stress: Time-Dependent Modal.

Volume 1

- I In the Model Builder window, expand the Stress: Time-Dependent Modal node, then click Volume 1.
- 2 In the Settings window for Volume, locate the Expression section.
- 3 From the Unit list, choose MPa.
- 4 In the Stress: Time-Dependent Modal toolbar, click **Plot**.

ADD PREDEFINED PLOT

- I In the Home toolbar, click Add Predefined Plot to open the Add Predefined Plot window.
- 2 Go to the Add Predefined Plot window.

- 3 In the tree, select Study 3: Time-Dependent Modal [Verification]/Solution 6 (sol6)> Solid Mechanics>Applied Loads (solid)>Boundary Loads (solid).
- 4 Click Add Plot in the window toolbar.
- 5 In the Home toolbar, click Add Predefined Plot to close the Add Predefined Plot window.

RESULTS

Boundary Loads (solid)

In the Boundary Loads (solid) toolbar, click **O** Plot.

The maximum displacement occurs at the tip of the bracket, and the maximum stress occurs in the fillet near the bolt holes. Generate 1D plots of displacement and stress in order to visualize the transient response of the bracket. Plot the response from Study 3 along with **Study 2** in order to validate the results.

Tip Displacement

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, locate the Data section.
- 3 From the Dataset list, choose Study 2: Frequency Domain Modal + FFT/Solution 3 (sol3).
- 4 In the Label text field, type Tip Displacement.
- **5** Locate the **Title** section. From the **Title type** list, choose **None**.

Point Graph 1

- I Right-click Tip Displacement and choose Point Graph.
- **2** Select Point 1 only.
- 3 In the Settings window for Point Graph, locate the y-Axis Data section.
- **4** In the **Expression** text field, type u.
- 5 From the Unit list, choose mm.
- **6** In the **Tip Displacement** toolbar, click **Plot**.
- 7 Click to expand the **Legends** section. Select the **Show legends** check box.
- 8 From the Legends list, choose Manual.
- **9** In the table, enter the following settings:

Legends				
Frequency	Domain	Modal	+	FFT

10 Right-click Point Graph I and choose Duplicate.

Point Graph 2

- I In the Model Builder window, click Point Graph 2.
- 2 In the Settings window for Point Graph, locate the Data section.
- 3 From the Dataset list, choose Study 3: Time-Dependent Modal [Verification]/ Solution 6 (sol6).
- 4 From the Time selection list, choose Manual.
- 5 In the Time indices (1-102) text field, type range (2, 102).
- **6** Locate the **Legends** section. In the table, enter the following settings:

Legends Time-Dependent Modal

7 In the Tip Displacement toolbar, click **Plot**.

Tip Displacement

In the Model Builder window, right-click Tip Displacement and choose Duplicate.

Fillet Stress

- I In the Model Builder window, under Results click Tip Displacement I.
- 2 In the Settings window for ID Plot Group, type Fillet Stress in the Label text field.

Point Graph 1

- I In the Model Builder window, expand the Fillet Stress node, then click Point Graph I.
- 2 In the Settings window for Point Graph, locate the Selection section.
- 3 Click to select the **Activate Selection** toggle button.
- 4 Click Clear Selection.
- **5** Select Point 34 only.
- 6 Locate the y-Axis Data section. In the Expression text field, type solid.sx.
- 7 From the Unit list, choose MPa.

Point Graph 2

- I In the Model Builder window, click Point Graph 2.
- 2 In the Settings window for Point Graph, locate the Selection section.
- **3** Click to select the **Activate Selection** toggle button.
- 4 Click Clear Selection.
- **5** Select Point 34 only.
- 6 Locate the y-Axis Data section. In the Expression text field, type solid.sx.

- 7 From the **Unit** list, choose **MPa**.
- 8 In the Fillet Stress toolbar, click Plot.