

Micromechanical Model of a Triply-Periodic-Minimal-Surface-Based Composite

Introduction

The use of composites in various industries like automotive, aerospace, infrastructure, and many others has been rising over last few decades. Ever-increasing advancement of the technology demands advancements in the materials. Triply-periodic-minimal-surfacebased (TPMS-based) composites are finding increasing use in various applications due to their outstanding mechanical and thermal properties; see Ref. 1. The accuracy of structural and thermal analyses relies on an accurate estimation of the mechanical and thermal properties of the composite material. At global scale, the composite needs to be treated as a homogeneous material in the continuum mechanics, which needs homogenization techniques to get the effective properties for such materials based on the material properties of the constituents.

In this example, the homogenized elastic and thermal properties of a composite material based on a TPMS are computed and the results are compared to those presented in Ref. 1. A gyroid TPMS-based unit cell is subjected to periodic boundary conditions to get the homogenized material properties. The effects of a negative Poisson's ratio and different volume fractions on the homogenized properties are analyzed.

Model Definition

A unit cell of a gyroid TPMS is shown in Figure 1. The size of unit cell is 100 mm. The TPMS volume fraction is computed from the wall thickness of the TPMS.




Figure 1: Geometry of the gyroid unit cell.

TPMS and Matrix Properties

The material properties are taken from Ref. 1. The elastic moduli of TPMS and matrix are not explicitly given in Ref. 1; rather a ratio of 20 is given. This example assumes the elastic moduli 200 GPa and 10 GPa of the TPMS and matrix, respectively. The Poisson's ratio of the TPMS and matrix in Ref. 1 are taken from a set of [0.3, -0.3, -0.5, -0.75]. For this example, we vary the Poisson's ratio of the TPMS from the above set but keep the Poisson's ratio of the matrix fixed to 0.3. The coefficient of thermal expansion for the TMPS and matrix are given as 0.8×10^{-6} 1/K and 44×10^{-6} 1/K, respectively.

Results and Discussion

Figure 2, Figure 3, and Figure 4 show the variation of the effective Young's modulus, Poisson's ratio, and shear modulus with different Poisson's ratio and volume fractions of the TPMS. The variation of the effective coefficient of thermal expansion is shown in Figure 5. The result matches closely with results presented in Ref. 1 (see figure 5).

The authors in Ref. 1 investigated the effect of a negative Poisson's ratio of the TPMS on the effective properties of the composite. As reported in Ref. 1, with negative Poisson's ratio of the TPMS, the effective Young's modulus, shear modulus, and coefficient of thermal expansion increase, while the effective Poisson's ratio decreases. An increasing

fiber volume fraction of the TPMS increases the effective Young's modulus and shear modulus. The coefficient of thermal expansion and effective Poisson's ratio decrease with increases in the TPMS fiber volume fraction.

The study indicates that the properties of the gyroid-based composite can be customized by changing the Poisson's ratio or fiber volume fraction of the TPMS.




Figure 2: Effective Young's modulus versus TPMS volume fraction.




Figure 3: Effective Poisson's ratio versus TPMS volume fraction.




Figure 4: Effective shear modulus versus TPMS volume fraction.




Figure 5: Effective coefficient of thermal expansion versus TPMS volume fraction.

Notes About the COMSOL Implementation

- In order to perform a micromechanical analysis, the **Cell Periodicity** node in the **Solid** Mechanics interface is used. The Cell Periodicity node is used to apply periodic boundary conditions to the three (two) pairs of faces of the unit cell in 3D (2D).
- The **Cell Periodicity** node has three action buttons in the toolbar of the **Periodicity Type** section: Create Load Groups and Study, Create Material by Value, and Create Material by Reference. The action button Create Load Groups and Study generates load groups and a stationary study with load cases. The action button Create Material by Value generates a Global Material with homogenized material properties, with material properties as numbers. The action button Create Material by Reference generates a Global Material with homogenized material properties, with material properties as variables. The action buttons are active depending on the choices in the Periodicity Type and Calculate Average **Properties** lists.
- The Create Load Groups and Study button does not generate a parametric study by default. In many situations, a parametric study is needed and the homogenized elasticity

matrix **D** needs to be based on the tag of the parametric solution. To do this, use the given options in the **Advanced** section of the feature.

• Use the Free Expansion option with Coefficient of thermal expansion to extract the homogenized coefficient of thermal expansions.

Reference

1. K. Chawla and R. Kiran, "Numerical predictions for the effect of negative Poisson's ratio on thermoelastic properties of triply periodic minimal surface-based composites," Results Mater., vol. 14, p. 100273, 2022.

Application Library path: Structural Mechanics Module/Material Models/ micromechanical_model_of_a_tpms_composite

Modeling Instructions

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click **3D**.
- 2 In the Select Physics tree, select Structural Mechanics>Solid Mechanics (solid).
- 3 Click Add.
- 4 Click M Done.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- 3 Click Load from File.
- 4 Browse to the model's Application Libraries folder and double-click the file micromechanical model of a tpms composite parameters.txt.

GEOMETRY I

Next, create a unit cell for a gyroid (TPMS) based composite. This unit cell like many others can be found in the built-in Part Libraries.

PART LIBRARIES

- I In the Home toolbar, click Windows and choose Part Libraries.
- 2 In the Model Builder window, under Component I (compl) click Geometry I.
- 3 In the Part Libraries window, select COMSOL Multiphysics>Unit Cells and RVEs> **Miscellaneous>gyroid** in the tree.

Gyroid I (pil)

- I Right-click Component I (compl)>Geometry I and choose Add to Geometry.
- 2 In the Settings window for Part Instance, locate the Input Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
lm	L	0.1 m	Cell length
th	th	0.004 m	Wall thickness

Use **Remove Details** to automatically fix small issues in the geometry. This will improve meshing and computation.

Remove Details I (rmd1)

- I In the Geometry toolbar, click Remove Details.
- 2 In the Settings window for Remove Details, locate the Parameters section.
- 3 In the Continuous tangent tolerance text field, type 10.
- 4 Click | Build Selected.

Form Union (fin)

In the **Geometry** toolbar, click **Build All**.

DEFINITIONS

Integration | (intob|)

- I In the **Definitions** toolbar, click Nonlocal Couplings and choose Integration.
- 2 In the Settings window for Integration, locate the Source Selection section.
- 3 From the Selection list, choose Gyroid domain (Gyroid 1).

Variables 1

- I In the Model Builder window, right-click Definitions and choose Variables.
- 2 In the Settings window for Variables, locate the Variables section.
- **3** In the table, enter the following settings:

Name	Expression	Unit	Description
v_f	intop1(1)/L^3		Volume fraction of tpms
E_h	1/solid.cp1.Dinv11		Homogenized Young's modulus
nu_h	-E_h*solid.cp1.Dinv12		Homogenized Poisson's ratio
G_h	1/solid.cp1.Dinv55		Homogenized shear modulus
alpha_h	solid.cp2.alphaXX		Homogenized coefficient of thermal expansion

SOLID MECHANICS (SOLID)

Linear Elastic Material I

In the Model Builder window, under Component I (compl)>Solid Mechanics (solid) click Linear Elastic Material I.

Thermal Expansion 1

- I In the Physics toolbar, click 🕞 Attributes and choose Thermal Expansion.
- 2 In the Settings window for Thermal Expansion, locate the Model Input section.
- **3** From the T list, choose **User defined**. In the associated text field, type 294.15[K].

Cell Periodicity for Elastic Properties

- I In the Physics toolbar, click **Domains** and choose **Cell Periodicity**.
- 2 In the Settings window for Cell Periodicity, type Cell Periodicity for Elastic Properties in the Label text field.
- 3 Locate the Cell Properties section. From the Boundary conditions list, choose Average strain.
- 4 From the Calculate average properties list, choose Elasticity matrix, Standard (XX, YY, ZZ, XY, YZ, XZ).

Boundary Pair I

- I In the Physics toolbar, click 🖳 Attributes and choose Boundary Pair.
- 2 In the Settings window for Boundary Pair, locate the Boundary Selection section.

- 3 From the Selection list, choose Pair I (Gyroid I).
- 4 Right-click Boundary Pair I and choose Manual Destination Selection.
- 5 Locate the **Destination Selection** section. From the **Selection** list, choose **Pair I**, Destination (Gyroid 1).
- 6 Right-click Boundary Pair I and choose Duplicate.

Boundary Pair 2

- I In the Model Builder window, click Boundary Pair 2.
- 2 In the Settings window for Boundary Pair, locate the Boundary Selection section.
- 3 From the Selection list, choose Pair 2 (Gyroid 1).
- 4 Locate the Destination Selection section. From the Selection list, choose Pair 2, Destination (Gyroid 1).
- 5 Right-click Boundary Pair 2 and choose Duplicate.

Boundary Pair 3

- I In the Model Builder window, click Boundary Pair 3.
- 2 In the Settings window for Boundary Pair, locate the Boundary Selection section.
- 3 From the Selection list, choose Pair 3 (Gyroid I).
- 4 Locate the Destination Selection section. From the Selection list, choose Pair 3, Destination (Gyroid 1).

With the Average strain option in the Cell Periodicity feature, appropriate load groups, a study and a material with computed elastic properties can be generated automatically. To create load groups and a study node, click the Create Load Groups and Study button in the section toolbar.

Cell Periodicity for Elastic Properties

To create a parametric study, use the options in the **Advanced** section of the feature. To see the section, activate the Advanced Physics option from Show button.

- I Click the Show More Options button in the Model Builder toolbar.
- 2 In the Show More Options dialog box, in the tree, select the check box for the node Physics>Advanced Physics Options.
- 3 Click OK.
- 4 In the Model Builder window, click Cell Periodicity for Elastic Properties.
- 5 In the Settings window for Cell Periodicity, click to expand the Advanced section.
- 6 From the Add parametric sweep list, choose Yes.

- 7 From the Sweep type list, choose All combinations.
- 8 Click + Add.
- **9** In the **Parameters** table, enter the following settings:

Index	Parameter name	Parameter value list	Parameter unit
1	th	range(4,2,12)	mm
2	nu_f	0.3 -0.3 -0.5 -0.75	1

- 10 Locate the Cell Properties section. Click Create Load Groups and Study in the upper-right corner of the section.
- II Right-click Cell Periodicity for Elastic Properties and choose Duplicate.

Cell Periodicity for Thermal Properties

- I In the Model Builder window, under Component I (compl)>Solid Mechanics (solid) click Cell Periodicity for Elastic Properties 1.
- 2 In the Settings window for Cell Periodicity, type Cell Periodicity for Thermal Properties in the Label text field.
- 3 Locate the Cell Properties section. From the Boundary conditions list, choose Free expansion.
- 4 From the Calculate average properties list, choose Coefficient of thermal expansion.

MATERIALS

Material I: Matrix

- I In the Model Builder window, under Component I (compl) right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, type Material 1: Matrix in the Label text field.
- 3 Locate the Geometric Entity Selection section. From the Selection list, choose Matrix (Gyroid I).

4 Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Young's modulus	E	E_m	Pa	Young's modulus and Poisson's ratio
Poisson's ratio	nu	nu_m	I	Young's modulus and Poisson's ratio
Density	rho	rho_m	kg/m³	Basic
Coefficient of thermal expansion	alpha_iso; alphaii = alpha_iso, alphaij = 0	alpha_m	I/K	Basic

Material 2: TPMS

- I Right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, type Material 2: TPMS in the Label text field.
- 3 Locate the Geometric Entity Selection section. From the Selection list, choose Gyroid domain (Gyroid I).
- **4** Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Young's modulus	E	E_f	Pa	Young's modulus and Poisson's ratio
Poisson's ratio	nu	nu_f	I	Young's modulus and Poisson's ratio
Density	rho	rho_f	kg/m³	Basic
Coefficient of thermal expansion	alpha_iso; alphaii = alpha_iso, alphaij = 0	alpha_f	I/K	Basic

MESH I

- I In the Model Builder window, under Component I (compl) click Mesh I.
- 2 In the Settings window for Mesh, locate the Physics-Controlled Mesh section.
- **3** From the **Element size** list, choose **Fine**.
- 4 Click III Build All.

For this study, disable the thermal expansion node and the cell periodicity feature for thermal expansion.

CELL PERIODICITY STUDY FOR ELASTIC PROPERTIES

- I In the Model Builder window, click Cell Periodicity Study.
- 2 In the Settings window for Study, type Cell Periodicity Study for Elastic Properties in the Label text field.

Step 1: Stationary

- I In the Model Builder window, expand the Cell Periodicity Study for Elastic Properties node, then click Step 1: Stationary.
- 2 In the Settings window for Stationary, locate the Physics and Variables Selection section.
- 3 Select the Modify model configuration for study step check box.
- 4 In the tree, select Component I (compl)>Solid Mechanics (solid)> Linear Elastic Material I>Thermal Expansion I.
- 5 Right-click and choose Disable.
- 6 In the tree, select Component I (compl)>Solid Mechanics (solid)> **Cell Periodicity for Thermal Properties.**
- 7 Right-click and choose **Disable**.

The iterative solver is lean on memory usage. Enable the default iterative solver.

Solver Configurations

In the Model Builder window, expand the Cell Periodicity Study for Elastic Properties> **Solver Configurations** node.

Solution (solidcp | sol)

- I In the Model Builder window, expand the Cell Periodicity Study for Elastic Properties> Solver Configurations>Solution (solidcp | sol)>Stationary Solver | node.
- 2 Right-click Suggested Iterative Solver (solid) and choose Enable.
- 3 In the Home toolbar, click **Compute**.

Add a separate study to compute the homogeneous thermal properties. For this study, disable the cell periodicity feature for elastic properties.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies>Stationary.
- 4 Right-click and choose Add Study.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

CELL PERIODICITY STUDY FOR THERMAL PROPERTIES

In the Settings window for Study, type Cell Periodicity Study for Thermal Properties in the Label text field.

Parametric Sweep

I In the Study toolbar, click Parametric Sweep.

This study computes the homogenized thermal properties for varying volume fraction and Poisson's ratio. Therefore, use a parametric sweep for the parameter th along with nu_f.

- 2 In the Settings window for Parametric Sweep, locate the Study Settings section.
- 3 From the Sweep type list, choose All combinations.
- 4 Click + Add.
- **5** In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
th (Wall thickness)	range(4,2,12)	mm

6 Click + Add.

7 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
nu_f (Poisson's ratio, TPMS)	0.3 -0.3 -0.5 -0.75	1

Steb 1: Stationary

- I In the Model Builder window, click Step I: Stationary.
- 2 In the Settings window for Stationary, locate the Physics and Variables Selection section.
- 3 Select the Modify model configuration for study step check box.

- 4 In the tree, select Component I (compl)>Solid Mechanics (solid)> Cell Periodicity for Elastic Properties.
- 5 Right-click and choose Disable.
- 6 In the Study toolbar, click **Compute**.

RESULTS

Stress (solid)

- I In the Model Builder window, under Results click Stress (solid).
- 2 In the Settings window for 3D Plot Group, locate the Data section.
- 3 From the Parameter value (th (mm)) list, choose 4.
- 4 From the Load case list, choose Load case 1.
- 5 From the Parameter value (nu_f) list, choose 0.3.
- 6 In the Stress (solid) toolbar, click Plot.

Stress (solid) |

- I In the Model Builder window, click Stress (solid) I.
- 2 In the Settings window for 3D Plot Group, locate the Data section.
- 3 From the Parameter value (th (mm)) list, choose 4.
- 4 From the Parameter value (nu_f) list, choose 0.3.
- 5 In the Stress (solid) I toolbar, click Plot.

Homogenized Young's Modulus vs. TPMS Volume Fraction

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Homogenized Young's Modulus vs. TPMS Volume Fraction in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Cell Periodicity Study for Elastic Properties/Solution 2 (solidcplsolp).
- 4 From the Parameter selection (Load case) list, choose First.
- 5 Click to expand the Title section. From the Title type list, choose Label.
- 6 Locate the Plot Settings section.
- 7 Select the x-axis label check box. In the associated text field, type v_f.
- 8 Select the y-axis label check box. In the associated text field, type E_h/ E_m.
- **9** Locate the **Legend** section. From the **Position** list, choose **Upper left**.

Global I

- I Right-click Homogenized Young's Modulus vs. TPMS Volume Fraction and choose Global.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
E_h/E_m	1	

- 4 Locate the x-Axis Data section. From the Axis source data list, choose th.
- 5 From the Parameter list, choose Expression.
- 6 In the Expression text field, type v_f.
- 7 Click to expand the Coloring and Style section. Find the Line markers subsection. From the Marker list, choose Cycle.
- 8 From the Positioning list, choose Interpolated.
- 9 Click to expand the Legends section. From the Legends list, choose Manual.
- **10** In the table, enter the following settings:

Legends
\nu _f = 0.3
$\ne \ne \ne \ne \ne \ne \ne \ne \ne \ne $
$\ne \ne \ne \ne \ne \ne \ne \ne \ne \ne $
\nu _f = -0.75

II In the Homogenized Young's Modulus vs. TPMS Volume Fraction toolbar, click Plot.

Homogenized Young's Modulus vs. TPMS Volume Fraction

In the **Model Builder** window, right-click

Homogenized Young's Modulus vs. TPMS Volume Fraction and choose Duplicate.

Homogenized Poisson's Ratio vs. TPMS Volume Fraction

- I In the Model Builder window, under Results click Homogenized Young's Modulus vs. TPMS Volume Fraction 1.
- 2 In the Settings window for ID Plot Group, type Homogenized Poisson's Ratio vs. TPMS Volume Fraction in the Label text field.
- 3 Locate the Plot Settings section. In the y-axis label text field, type \nu_h.
- 4 Locate the Legend section. From the Position list, choose Lower left.

Global I

- I In the Model Builder window, expand the Homogenized Poisson's Ratio vs. TPMS Volume Fraction node, then click Global 1.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
nu_h	1	

4 In the Homogenized Poisson's Ratio vs. TPMS Volume Fraction toolbar, click Plot.

Homogenized Young's Modulus vs. TPMS Volume Fraction

In the Model Builder window, under Results right-click

Homogenized Young's Modulus vs. TPMS Volume Fraction and choose Duplicate.

Homogenized Shear Modulus vs. TPMS Volume Fraction

- I In the Model Builder window, under Results click Homogenized Young's Modulus vs. TPMS Volume Fraction 1.
- 2 In the Settings window for ID Plot Group, type Homogenized Shear Modulus vs. TPMS Volume Fraction in the Label text field.
- 3 Locate the Plot Settings section. In the y-axis label text field, type G_h/ G_m.

Global I

- I In the Model Builder window, expand the Homogenized Shear Modulus vs. TPMS Volume Fraction node, then click Global 1.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
G_h/G_m	1	

4 In the Homogenized Shear Modulus vs. TPMS Volume Fraction toolbar, click o Plot.

Homogenized Young's Modulus vs. TPMS Volume Fraction

In the Model Builder window, under Results right-click

Homogenized Young's Modulus vs. TPMS Volume Fraction and choose Duplicate.

Homogenized Coefficient of Thermal Expansion vs. TPMS Volume Fraction

- I In the Model Builder window, under Results click Homogenized Young's Modulus vs. TPMS Volume Fraction 1.
- 2 In the Settings window for ID Plot Group, type Homogenized Coefficient of Thermal Expansion vs. TPMS Volume Fraction in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose None.
- 4 Locate the Plot Settings section. In the y-axis label text field, type \alpha_h /\alpha_m.
- 5 Locate the Legend section. From the Position list, choose Upper right.

Global I

- I In the Model Builder window, expand the Homogenized Coefficient of Thermal Expansion vs. TPMS Volume Fraction node, then click Global I
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
alpha_h/alpha_m		

Homogenized Coefficient of Thermal Expansion vs. TPMS Volume Fraction

- I In the Model Builder window, click Homogenized Coefficient of Thermal Expansion vs. TPMS Volume Fraction.
- 2 In the Settings window for ID Plot Group, locate the Data section.
- 3 From the Dataset list, choose Cell Periodicity Study for Thermal Properties/ Parametric Solutions I (sol22).

Global I

- I In the Model Builder window, click Global I.
- 2 In the Settings window for Global, locate the x-Axis Data section.
- 3 From the Axis source data list, choose th.
- 4 In the Homogenized Coefficient of Thermal Expansion vs. TPMS Volume Fraction toolbar, click **Plot**.