

Pyroelectric Detector

The pyroelectric phenomenon, when absorbed energy causes a change in temperature and polarization within a pyroelectric material, is the basis of operation of some laser energy meters. The change in polarization manifests itself as a pyroelectric current, which can be measured by an ammeter circuit. Laser energy meters based on the pyroelectric phenomenon are used to calibrate of laser sources.

This 2D axisymmetric model demonstrates the operation of a pyroelectric detector based on a lithium niobate (LiNbO₃) crystal sandwiched between two electrodes with connection to an external circuit. To represent the absorbed laser energy, an energy flux that varies with position and time is applied to the top surface of the disk. This model uses (i) the Piezoelectricity and Pyroelectricity multiphysics interface and (ii) the Electrical Circuit interface. A time-dependent study solves for temperature evolution in the disk and the pyroelectric current generated.

Model Definition

A 25 µm-thick LiNbO₃ crystal in the shape of a disk with a diameter of 3 mm is bonded to an electrically conductive base by a 40 µm thick ring-shaped silver (Ag) pad. Most material properties of the LiNbO₃ and Ag domains are defined by material models from the material library and some properties need to be added manually. The pyroelectric coefficient of LiNbO₃ was specified as $-83 \mu C/(m^2 \cdot K)$. The top and bottom surfaces of the crystal are coated with a thin metal layer, forming the top and bottom electrodes. The model geometry is fully parameterized to allow for easy changes in the device structure for future optimization.

This model uses the Piezoelectricity and Pyroelectricity multiphysics interface, which automatically sets up the Electrostatics, Solid Mechanics, and Heat Transfer interfaces together with Pyroelectricity, Piezoelectric Effect, and Thermal Expansion couplings. In the Electrostatics interface, a Charge Conservation, Piezoelectric material model is assigned to the LiNbO₃ domain. In the Solid Mechanics interface, a Fixed Constraint is applied to the base of the Ag pad. In the **Heat Transfer** interface, an **Heat Flux** applied to the top surface of the disk represents the laser energy while a constant temperature of 293.15 K is assigned to the base of the Ag pad. These assignments can be seen in Figure 1.




Figure 1: A cross section of the 2D axi-symmetric model showing the material models and boundary conditions used. The disk is lithium niobate (purple) and the pad is silver (gray). The bottom surface of the disk is grounded (yellow) while the top electrode (red) is connected to an external circuit. A fixed constraint and $T=293.15~\rm K$ is applied to the bottom of the silver pad.

To calculate output power, the device is connected to an external circuit using the **Electrical Circuit** interface. The terminals of the LiNbO₃ disk is connected in parallel to the capacitor C1 with a capacitance value of $C_{\rm ext} = 100$ pF. The disk is also connected to the load R1 with resistance value of $R_{\rm ext} = 0.1$, $5 \cdot 10^6$, $5 \cdot 10^7$, or $10^9 \, \Omega$. The electrical power is calculated as the product of the voltage and current across R1. The circuit components are parameterized to allow for easy changes in the device structure for future optimization.

The model solves a multiphysics problem involving **Pyroelectricity**, **Piezoelectric Effect**, and **Thermal Expansion** couplings using a time-dependent study. In the first study, the model includes all couplings and is referred to as the full model. In the second study, the **Piezoelectric Effect** and **Thermal Expansion** couplings are disabled, and the model is referred to as pyroelectricity-only.

A plot of temperature and current through R1versus time is shown in Figure 2 with the temperature measured at the center of the disk.




Figure 2: Temperature and current through R1 versus time at the center of the disk.

Figure 3 shows a plot of voltage versus time with the voltage measurements taken across the load R1.




Figure 3: Voltage versus time. Voltage measurements taken across the load R1.

Figure 4 shows a plot of electric power versus time, with the electric power measurements taken through the load R1.




Figure 4: Electric power versus time. Electric power measurements taken through the load R1.

Figure 5 shows a comparison of the electric power between the full model and the pyroelectricity-only model. The electric power for the full model is about 8% less than for the pyroelectricity-only model.




Figure 5: Comparison of electric power between full model and pyroelectricity-only model.

Application Library path: MEMS Module/Sensors/pyroelectric detector

Modeling Instructions

Start by creating a new 2D axi-symmetric model with the Piezoelectricity and Pyroelectricity multiphysics interface and the Electrical Circuit interface.

From the File menu, choose New.

NEW

In the New window, click Model Wizard.

MODEL WIZARD

- I In the Model Wizard window, click 2D Axisymmetric.
- 2 In the Select Physics tree, select AC/DC>Electromagnetics and Mechanics>Piezoelectricity> Piezoelectricity and Pyroelectricity.
- 3 Click Add.
- 4 In the Select Physics tree, select AC/DC>Electrical Circuit (cir).
- 5 Click Add.
- 6 Click 🔵 Study.
- 7 In the Select Study tree, select General Studies>Time Dependent.
- 8 Click **Done**.

Define and enter the values for the following global parameters.

GLOBAL DEFINITIONS

Parameters 1

- I In the Model Builder window, under Global Definitions click Parameters I.
- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
r_el	1.4[mm]	0.0014 m	Radius of top electrode
r_s	0.25[mm]	2.5E-4 m	Width of standoff
r_d	1.5[mm]	0.0015 m	Radius of crystal
t_d	0.025[mm]	2.5E-5 m	Thickness of crystal
t_s	0.040[mm]	4E-5 m	Thickness of standoff
w_b	2[mm]	0.002 m	Width of laser beam
Qmax	500[W/m^2]	500 W/m ²	Maximum laser power density
pulse	1[s]	l s	Duration of laser pulse
C_ext	100[pF]	1E-10 F	Capacitance of C1
R_ext	1000[ohm]	1000 Ω	Resistance of R1

Define a rectangular function and an analytical function describing the shape of laser pulse.

DEFINITIONS

Rectangle I (rect1)

- I In the Home toolbar, click f(x) Functions and choose Local>Rectangle.
- 2 In the Settings window for Rectangle, locate the Parameters section.
- 3 In the Lower limit text field, type 0.2.
- 4 In the **Upper limit** text field, type 1.

Analytic I (an I)

- I In the Home toolbar, click f(x) Functions and choose Local>Analytic.
- 2 In the Settings window for Analytic, locate the Definition section.
- 3 In the Expression text field, type $\exp(-((r^2)/(2*(10000)^2)))$.
- 4 In the Arguments text field, type r.
- **5** Locate the **Units** section. In the table, enter the following settings:

Argument	Unit
r	um

Define the expression for the energy flux representing laser pulse using the functions previously defined.

Variables 1

- I In the Model Builder window, right-click Definitions and choose Variables.
- 2 In the Settings window for Variables, locate the Variables section.
- **3** In the table, enter the following settings:

Name	Expression	Unit	Description	
Flux	Qmax*an1(r)*rect1(t/pulse)	W/m²	Power density distribution	

GEOMETRY I

- I In the Model Builder window, under Component I (compl) click Geometry I.
- 2 In the Settings window for Geometry, locate the Units section.
- 3 From the Length unit list, choose mm.

Rectangle I (rI)

- I In the Geometry toolbar, click Rectangle.
- 2 In the Settings window for Rectangle, locate the Size and Shape section.

- 3 In the Width text field, type r_d.
- 4 In the Height text field, type t_d.

Rectangle 2 (r2)

- I In the Geometry toolbar, click Rectangle.
- 2 In the Settings window for Rectangle, locate the Size and Shape section.
- 3 In the Width text field, type r s.
- 4 In the **Height** text field, type t_s.
- 5 Locate the **Position** section. In the r text field, type r d-0.3.
- 6 In the z text field, type -t_p.
- 7 In the r text field, type r_d-r_s.
- 8 In the z text field, type -t s.

Rectangle 3 (r3)

- I In the Geometry toolbar, click Rectangle.
- 2 In the Settings window for Rectangle, locate the Size and Shape section.
- 3 In the Width text field, type r_el.
- 4 In the Height text field, type t d.
- 5 Click | Build Selected.

MULTIPHYSICS

Pyroelectricity I (pye I)

- I In the Model Builder window, under Component I (compl)>Multiphysics click Pyroelectricity I (pyeI).
- **2** Select Domains 1 and 3 only.

Add the lithium niobate model from the library.

ADD MATERIAL

- I In the Home toolbar, click **‡ Add Material** to open the **Add Material** window.
- 2 Go to the Add Material window.
- 3 In the tree, select Piezoelectric>Lithium Niobate.
- 4 Click Add to Component in the window toolbar.
- 5 In the Home toolbar, click **Add Material** to close the Add Material window.

MATERIALS

Lithium Niobate (mat1)

Next, enter missing properties for lithium niobate.

- I In the Settings window for Material, locate the Material Contents section.
- **2** In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Thermal conductivity	k_iso ; kii = k_iso, kij = 0	4.2	W/(m·K)	Basic
Heat capacity at constant pressure	Ср	628	J/(kg·K)	Basic
Coefficient of thermal expansion	{alpha I I, alpha22, alpha33}; alphaij = 0	{6.5e-6, 6.5e-6, 14.8e-6}	I/K	Basic
Total pyroelectric coefficient	{pET1, pET2, pET3}	{0,0,- 8.3e-5}	C/(m²·K)	Pyroelectric

Set up the boundary conditions for the Electrostatics interface.

ELECTROSTATICS (ES)

Charge Conservation, Piezoelectric I

- I In the Model Builder window, under Component I (compl)>Electrostatics (es) click Charge Conservation, Piezoelectric I.
- 2 Select Domains 1 and 3 only.

Ground I

- I In the Physics toolbar, click Boundaries and choose Ground.
- 2 Select Boundaries 2, 6, and 8 only.

Terminal I

- I In the Physics toolbar, click Boundaries and choose Terminal.
- 2 In the Settings window for Terminal, locate the Boundary Selection section.
- 3 Click Paste Selection.
- 4 In the Paste Selection dialog box, type 3 in the Selection text field.
- 5 Click OK.

- 6 In the Settings window for Terminal, locate the Terminal section.
- 7 From the Terminal type list, choose Circuit.

Charge Conservation I

- I In the Model Builder window, click Charge Conservation I.
- 2 In the Settings window for Charge Conservation, locate the Material Type section.
- 3 From the Material type list, choose Solid.

SOLID MECHANICS (SOLID)

Piezoelectric Material I

- I In the Model Builder window, under Component I (compl)>Solid Mechanics (solid) click Piezoelectric Material I.
- **2** Select Domains 1 and 3 only.

Set up the boundary conditions for the Solid Mechanics interface.

Fixed Constraint I

- I In the Physics toolbar, click Boundaries and choose Fixed Constraint.
- 2 Select Boundary 5 only.

Set up the boundary conditions for the Heat Transfer interface.

HEAT TRANSFER IN SOLIDS (HT)

In the Model Builder window, under Component I (compl) click Heat Transfer in Solids (ht).

Heat Flux I

- I In the Physics toolbar, click Boundaries and choose Heat Flux.
- 2 In the Settings window for Heat Flux, locate the Material Type section.
- 3 From the Material type list, choose Solid.
- **4** Locate the **Heat Flux** section. In the q_0 text field, type Flux.
- **5** Select Boundaries 3 and 9 only.

Temperature I

- I In the Physics toolbar, click Boundaries and choose Temperature.
- 2 Select Boundary 5 only.

Add the Electric Circuit interface, define the capacitor C_ext and the load R_ext and how they are connected to the detector terminals.

ELECTRICAL CIRCUIT (CIR)

In the Model Builder window, under Component I (compl) click Electrical Circuit (cir).

Resistor I (RI)

- I In the Electrical Circuit toolbar, click Resistor.
- 2 In the Settings window for Resistor, locate the Node Connections section.
- **3** In the table, enter the following settings:

Label	Node names
n	0

4 Locate the **Device Parameters** section. In the R text field, type R_{ext} .

Capacitor I (CI)

- I In the Electrical Circuit toolbar, click Capacitor.
- 2 In the Settings window for Capacitor, locate the Node Connections section.
- **3** In the table, enter the following settings:

Label	Node names
P	1
n	0

4 Locate the **Device Parameters** section. In the C text field, type C_{ext} .

External I-Terminal I (termII)

- I In the Electrical Circuit toolbar, click External I-Terminal.
- 2 In the Settings window for External I-Terminal, locate the Node Connections section.
- 3 In the Node name text field, type 1.
- 4 Locate the External Terminal section. From the V list, choose Terminal voltage (es/term1).

Add material model for silver.

ADD MATERIAL

- I In the Home toolbar, click **Add Material** to open the Add Material window.
- 2 Go to the Add Material window.
- 3 In the tree, select MEMS>Metals>Ag Silver.
- 4 Click Add to Component in the window toolbar.
- 5 In the Home toolbar, click Radd Material to close the Add Material window.

MATERIALS

Ag - Silver (mat2)

Next, enter missing properties for silver.

- I Select Domain 2 only.
- 2 In the Settings window for Material, locate the Material Contents section.
- **3** In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	1	I	Basic

4 Click the **Zoom Extents** button in the **Graphics** toolbar.

MESH I

Free Triangular I

In the Mesh toolbar, click Free Triangular.

Size 1

- I Right-click Free Triangular I and choose Size.
- 2 In the Settings window for Size, locate the Element Size section.
- 3 From the Predefined list, choose Extremely fine.
- 4 Click Build Selected.

Add a time-dependent study using the full model to analyze effect of thermal expansion, piezoelectricity and pyroelectricity.

STUDY I

Time Dependent, Full Model

- I In the Model Builder window, under Study I click Step I: Time Dependent.
- 2 In the Settings window for Time Dependent, locate the Study Settings section.
- 3 In the Output times text field, type range (0,0.02,2).
- 4 In the Label text field, type Time Dependent, Full Model.
- 5 Click to expand the Study Extensions section. Select the Auxiliary sweep check box.

6 Click + Add.

7 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
R_ext (Resistance of RI)	0.1 5e6 5e7 1e9	Ω

- 8 In the Model Builder window, click Study 1.
- 9 In the Settings window for Study, locate the Study Settings section.
- 10 Clear the Generate default plots check box.
- II In the Home toolbar, click **Compute**.

Add a time-dependent study using the pyroelectricity-only model to analyze effect of pyroelectricity.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies> Time Dependent.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 2

Time Dependent - Pyroelectricity Only

- I In the Settings window for Time Dependent, type Time Dependent -Pyroelectricity Only in the Label text field.
- 2 Locate the Study Settings section. In the Output times text field, type range (0,0.02, 2).
- 3 Locate the Physics and Variables Selection section. In the table, enter the following settings:

Physics interface	Solve for	Equation form
Electrostatics (es)	\checkmark	Automatic (Time dependent)
Solid Mechanics (solid)		Automatic (Stationary)
Heat Transfer in Solids (ht)	V	Automatic (Time dependent)
Electrical Circuit (cir)	V	Automatic (Time dependent)

4 In the table, enter the following settings:

Multiphysics couplings	Solve for	Equation form
Piezoelectricity I (pzel)		Automatic (Stationary)
Thermal Expansion 1 (tel)		Automatic (Stationary)

- 5 Locate the Study Extensions section. Select the Auxiliary sweep check box.
- 6 Click + Add.
- 7 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
R_ext (Resistance of R1)	0.1 5e6 5e7 1e9	Ω

- 8 In the Model Builder window, click Study 2.
- 9 In the Settings window for Study, locate the Study Settings section.
- 10 Clear the Generate default plots check box.
- II In the Home toolbar, click **Compute**.

Plot temperature and current density versus time, taking measurement at the center of the disk.

RESULTS

Temperature and Current Density, Full Model

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Temperature and Current Density, Full Model in the Label text field.
- 3 Locate the Plot Settings section. Select the Two y-axes check box.

Temperature

- I Right-click Temperature and Current Density, Full Model and choose Point Graph.
- 2 Click the **Zoom Extents** button in the **Graphics** toolbar.
- **3** Select Point 2 only.
- 4 In the Settings window for Point Graph, locate the y-Axis Data section.
- **5** In the **Expression** text field, type T.
- **6** Select the **Description** check box.
- 7 In the Temperature and Current Density, Full Model toolbar, click **1** Plot.
- 8 In the Label text field, type Temperature.

Circuit Current

- I In the Model Builder window, right-click Temperature and Current Density, Full Model and choose Global.
- 2 In the Settings window for Global, type Circuit Current in the Label text field.
- 3 Locate the y-Axis section. Select the Plot on secondary y-axis check box.
- 4 Locate the y-Axis Data section. In the table, enter the following settings:

Expression	Unit	Description
cir.R1_i	uA	Current through device R1

- 5 Click to expand the **Legends** section. Find the **Include** subsection. Clear the **Description** check box.
- 6 In the Temperature and Current Density, Full Model toolbar, click on Plot.

Temperature and Current Density, Full Model

- I In the Model Builder window, click Temperature and Current Density, Full Model.
- 2 In the Settings window for ID Plot Group, locate the Plot Settings section.
- 3 In the table, select the Plot on secondary y-axis check box for Circuit Current.
- 4 In the Temperature and Current Density, Full Model toolbar, click on Plot.

Plot voltage versus time, taking measurement across the load R_ext.

Voltage, Full Model

- I In the Home toolbar, click **Add Plot Group** and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Voltage, Full Model in the Label text
- **3** Locate the **Legend** section. From the **Position** list, choose **Lower right**.

Global I

- I Right-click Voltage, Full Model and choose Global.
- 2 In the Settings window for Global, click Replace Expression in the upper-right corner of the y-Axis Data section. From the menu, choose Component I (compl)> Electrical Circuit>Devices>RI>cir.RI v - Voltage across device RI - V.
- **3** Locate the **Legends** section. Find the **Include** subsection. Clear the **Description** check box.
- 4 In the Voltage, Full Model toolbar, click **Plot**.

Plot electric power versus time, taking measurement across the load R_ext.

Electric Power, Full Model

- I In the Home toolbar, click **Add Plot Group** and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Electric Power, Full Model in the **Label** text field.

Global I

- I Right-click Electric Power, Full Model and choose Global.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
realdot(cir.R1_i,cir.R1_v)	uW	Electric Power

- **4** Locate the **Legends** section. Find the **Include** subsection. Clear the **Description** check box.
- 5 In the Electric Power, Full Model toolbar, click **Plot**.

Plot electric power versus time for R ext = 1e9 ohms for the full model and the pyroelectricity-only model.

Full Model vs. Pyroelectricity Only

- I In the Home toolbar, click **Add Plot Group** and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Full Model vs. Pyroelectricity Only in the Label text field.

Electric Power, Full Model

- I Right-click Full Model vs. Pyroelectricity Only and choose Global.
- 2 In the Settings window for Global, type Electric Power, Full Model in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study I/Solution I (soll).
- 4 From the Parameter selection (R ext) list, choose From list.
- 5 In the Parameter values (R_ext (Ω)) list, select 1E9.
- **6** Locate the **y-Axis Data** section. In the table, enter the following settings:

Expression	Unit	Description
realdot(cir.R1_i,cir.R1_v)	uW	Electric Power, Full Model

- 7 Locate the **Legends** section. Find the **Include** subsection. Clear the **Solution** check box.
- 8 Right-click Electric Power, Full Model and choose Duplicate.

Electric Power, Pyroelectricity Only

- I In the Model Builder window, under Results>Full Model vs. Pyroelectricity Only click Electric Power, Full Model I.
- 2 In the Settings window for Global, type Electric Power, Pyroelectricity Only in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 2/Solution 2 (sol2).
- 4 Locate the y-Axis Data section. In the table, enter the following settings:

Expression	Unit	Description
realdot(cir.R1_i,cir.R1_v)	uW	Electric Power, Pyroelectricity Only

5 In the Full Model vs. Pyroelectricity Only toolbar, click **Plot**.