

# Car Windshield Antenna Effect on a Cable Harness

This example simulates an FM antenna printed on the rear windshield of a vehicle. The simulation computes the far-field radiation pattern of the antenna and the electric fields on an interior cable harness.




Figure 1: A simplified car model consisting of a metallic body, lossy tires, tire rims, thin dielectric windshields, a printed antenna, and a cable harness connected to electronic component enclosures. The surrounding air domain and ground plane are not included in this figure.

# Model Definition

Modeling begins by importing the geometry that describes a car body, cable harness, and a windshield FM antenna (Figure 1). Interior objects inside the car are not included. All metal parts are modeled as perfect electric conductors (PEC), which include the car body, a printed antenna on the rear windshield, tire rims, a cable harness connected to electronic component enclosures, and the ground plane. The tire domains are modeled as a lossy medium, using a loss tangent constitutive relation. Except for the ground plane, the car is surrounded by an air domain, which is enclosed by perfectly matched layers (PML). The 1 cm thick windshield is considered transparent and very thin in the FM frequency range. It is configured using the Transition boundary condition.

To calculate the Far-field radiation pattern over the ground plane (which is simplified as a PEC surface) and create an image of a radiating source, a symmetry condition in the Farfield Calculation Boundary settings is applied.

The antenna is excited by a lumped port with a 50 ohm reference impedance.

# Results and Discussion

In Figure 2, the default electric field norm is visualized on the ground plane.




Figure 2: The electric field is nonuniformly illuminated over the ground, which contributes to the distorted radiation pattern of the antenna.

A 3D far-field radiation pattern is shown in Figure 3. Due to the shape and placement of the antenna, the overall shape of the radiation pattern is asymmetric.




Figure 3: 3D far-field radiation pattern of the printed antenna.

Figure 4 shows the electric field norm over the cable harness surface as well as which part of the cable is more affected by the antenna radiation.




Figure 4: The cable harness that's closer to the right-side tires is more exposed to the antenna radiation.

**Application Library path:** RF\_Module/EMI\_EMC\_Applications/car\_emiemc

# Modeling Instructions

From the File menu, choose New.

#### NEW

In the New window, click Model Wizard.

## MODEL WIZARD

- I In the Model Wizard window, click 1 3D.
- 2 In the Select Physics tree, select Radio Frequency>Electromagnetic Waves, Frequency Domain (emw).

- 3 Click Add.
- 4 Click Study.
- 5 In the Select Study tree, select General Studies>Frequency Domain.
- 6 Click M Done.

#### STUDY I

# Step 1: Frequency Domain

Define the study frequency ahead of performing any frequency-dependent operation such as building mesh. The physics-controlled mesh uses the specified frequency value.

- I In the Model Builder window, under Study I click Step I: Frequency Domain.
- 2 In the Settings window for Frequency Domain, locate the Study Settings section.
- 3 In the Frequencies text field, type 80[MHz].

#### **GEOMETRY I**

Import I (impl)

- I In the Home toolbar, click Import.
- 2 In the Settings window for Import, locate the Import section.
- 3 Click **Browse**.
- **4** Browse to the model's Application Libraries folder and double-click the file car\_emiemc.mphbin.
- 5 Click Import.
- 6 Click the Wireframe Rendering button in the Graphics toolbar.

Sphere I (sph I)

- I In the Geometry toolbar, click  $\bigcirc$  Sphere.
- 2 In the Settings window for Sphere, locate the Size section.
- 3 In the Radius text field, type 4.
- 4 Click to expand the **Layers** section. In the table, enter the following settings:

Layer name	Thickness (m)		
Layer 1	0.5		

Block I (blk I)

- I In the Geometry toolbar, click Block.
- 2 In the Settings window for Block, locate the Size and Shape section.

- 3 In the Width text field, type 8.
- 4 In the **Depth** text field, type 8.
- 5 In the Height text field, type 4.
- 6 Locate the Position section. From the Base list, choose Center.
- 7 In the z text field, type -2.

# Difference I (dif1)


- I In the Geometry toolbar, click Booleans and Partitions and choose Difference.
- **2** Select the object **sph1** only.
- 3 In the Settings window for Difference, locate the Difference section.
- 4 Click to select the Activate Selection toggle button for Objects to subtract.
- **5** Select the object **blk1** only.
- 6 Click Build All Objects.

# Ignore Vertices I (igvI)

- I In the Geometry toolbar, click \to Virtual Operations and choose Ignore Vertices.
- 2 In the Settings window for Ignore Vertices, locate the Input section.
- 3 Click the Paste Selection button for Vertices to ignore.
- 4 In the Paste Selection dialog box, type 110 111 117 118 190 191 in the Selection text field.
- 5 Click OK.

This removes some vertices generating unnecessary finer mesh elements.

6 In the Geometry toolbar, click **Build All**.



#### DEFINITIONS

Create a set of selections before setting up the physics.

#### Windshield

- I In the **Definitions** toolbar, click **\( \) Explicit**.
- 2 In the Settings window for Explicit, type Windshield in the Label text field.
- 3 Locate the Input Entities section. From the Geometric entity level list, choose Boundary.
- 4 Click Paste Selection.
- 5 In the Paste Selection dialog box, type 66-67, 104-107, 127-128, 169-170, 191-196, 202 in the Selection text field.
- 6 Click OK.

#### Tire

- I In the **Definitions** toolbar, click **\( \bigcap\_{\bigcap} \) Explicit**.
- 2 In the Settings window for Explicit, type Tire in the Label text field.
- 3 Select Domains 5, 6, 18, and 19 only.

## Harness

- I In the **Definitions** toolbar, click **Explicit**.
- 2 In the Settings window for Explicit, type Harness in the Label text field.

**3** Select Domains 7–12 and 15–17 only.

Perfectly Matched Layer I (pml1)

- I In the Definitions toolbar, click M. Perfectly Matched Layer.
- **2** Select Domains 1, 2, 13, and 14 only.
- 3 In the Settings window for Perfectly Matched Layer, locate the Geometry section.
- 4 From the Type list, choose Spherical.

# ELECTROMAGNETIC WAVES, FREQUENCY DOMAIN (EMW)

Perfect Electric Conductor 2

- I In the Model Builder window, under Component I (compl) right-click

  Electromagnetic Waves, Frequency Domain (emw) and choose the boundary condition

  Perfect Electric Conductor.
- 2 In the Settings window for Perfect Electric Conductor, locate the Boundary Selection section.
- 3 Click Paste Selection.
- **4** In the **Paste Selection** dialog box, type 9-31, 45-46, 54-60, 88-89, 95-96, 98-103, 108-111, 121-126, 145-155, 172-173, 177-178, 181-182, 185-188, 198-200, 203-206, 208-219 in the **Selection** text field.
- 5 Click OK.

Perfect Electric Conductor 3

- In the Physics toolbar, click **Boundaries** and choose Perfect Electric Conductor.
- 2 In the Settings window for Perfect Electric Conductor, locate the Boundary Selection section.
- 3 Click Paste Selection.
- 4 In the Paste Selection dialog box, type 44, 47, 171, 174 in the Selection text field.
- 5 Click OK.

Perfect Electric Conductor 4

- I In the Physics toolbar, click **Boundaries** and choose Perfect Electric Conductor.
- 2 In the Settings window for Perfect Electric Conductor, locate the Boundary Selection section.
- 3 Click Paste Selection.
- 4 In the Paste Selection dialog box, type 189-190, 197, 207 in the Selection text field.
- 5 Click OK.

# Perfect Electric Conductor 5

- In the Physics toolbar, click **Domains** and choose Perfect Electric Conductor.
- 2 In the Settings window for Perfect Electric Conductor, locate the Domain Selection section.
- 3 From the Selection list, choose Harness.

# Transition Boundary Condition I

- I In the Physics toolbar, click **Boundaries** and choose **Transition Boundary Condition**.
- 2 In the Settings window for Transition Boundary Condition, locate the Boundary Selection section.
- 3 From the Selection list, choose Windshield.

#### Wave Equation, Electric 2

- I In the Physics toolbar, click **Domains** and choose **Wave Equation**, **Electric**.
- 2 In the Settings window for Wave Equation, Electric, locate the Domain Selection section.
- **3** From the **Selection** list, choose **Tire**.
- 4 Locate the Electric Displacement Field section. From the Electric displacement field model list, choose Loss tangent, loss angle.

# Lumped Port I

- I In the Physics toolbar, click **Boundaries** and choose **Lumped Port**.
- 2 Select Boundary 201 only.

For the first port, wave excitation is **on** by default.

#### Far-Field Domain 1

In the Physics toolbar, click **Domains** and choose Far-Field Domain.

#### Far-Field Calculation 1

- I In the Model Builder window, expand the Far-Field Domain I node, then click Far-Field Calculation 1.
- 2 In the Settings window for Far-Field Calculation, locate the Far-Field Calculation section.
- 3 Select the Symmetry in the z=0 plane check box.
- 4 From the Symmetry type list, choose Symmetry in H (PEC).

#### MATERIALS

Material I (mat I)

- I In the Model Builder window, under Component I (compl) right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, locate the Material Contents section.
- **3** In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	1	I	Basic
Relative permeability	mur_iso; murii = mur_iso, murij = 0	1	I	Basic
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	0	S/m	Basic

# Material 2 (mat2)

- I Right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, locate the Geometric Entity Selection section.
- 3 From the Selection list, choose Tire.
- **4** Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permittivity (real part)	epsilonPrim_iso; epsilonPrimii = epsilonPrim_iso, epsilonPrimij = 0	2	I	Loss tangent, loss angle
Loss tangent, loss angle	delta	0.00005	rad	Loss tangent, loss angle
Relative permeability	mur_iso ; murii = mur_iso, murij = 0	1	I	Basic

Material 3 (mat3)

- I Right-click Materials and choose Blank Material.
- 2 In the Settings window for Material, locate the Geometric Entity Selection section.
- 3 From the Geometric entity level list, choose Boundary.
- 4 From the Selection list, choose Windshield.
- **5** Locate the **Material Contents** section. In the table, enter the following settings:

Property	Variable	Value	Unit	Property group
Relative permittivity	epsilonr_iso; epsilonrii = epsilonr_iso, epsilonrij = 0	4	I	Basic
Relative permeability	mur_iso; murii = mur_iso, murij = 0	1	I	Basic
Electrical conductivity	sigma_iso; sigmaii = sigma_iso, sigmaij = 0	0	S/m	Basic

#### MESH I

Information 1

In the Model Builder window, under Component I (compl) right-click Mesh I and choose **Build All.** 


## DEFINITIONS

Hide for Physics 1

- I In the Model Builder window, right-click View I and choose Hide for Physics. Suppress some boundaries to get a better view when reviewing the meshed results.
- 2 In the Settings window for Hide for Physics, locate the Geometric Entity Selection section.
- 3 From the Geometric entity level list, choose Boundary.
- **4** Select Boundaries 4, 6, 112, 114, and 115 only.

MESH I

In the Model Builder window, under Component I (compl) click Mesh I.



## STUDY I

Step 1: Frequency Domain

In the **Home** toolbar, click **Compute**.


#### RESULTS

## Multislice

- I In the Model Builder window, expand the Electric Field (emw) node, then click Multislice.
- 2 In the Settings window for Multislice, locate the Multiplane Data section.
- 3 Find the X-planes subsection. In the Planes text field, type 0.
- 4 Find the Y-planes subsection. In the Planes text field, type 0.
- 5 Find the **Z-planes** subsection. From the **Entry method** list, choose **Coordinates**.
- 6 In the Coordinates text field, type 0.
- 7 In the Electric Field (emw) toolbar, click Plot.

# 2D Far Field (emw)

In the Model Builder window, under Results click 2D Far Field (emw).



## Radiation Pattern 1

- I In the Model Builder window, expand the 3D Far Field, Gain (emw) node, then click Radiation Pattern I.
- 2 In the Settings window for Radiation Pattern, locate the Evaluation section.
- 3 Find the Angles subsection. In the Number of azimuth angles text field, type 40.
- 4 In the 3D Far Field, Gain (emw) toolbar, click Plot.

## 3D Plot Group 4

In the Home toolbar, click ( Add Plot Group and choose 3D Plot Group.

## Surface I

- I Right-click 3D Plot Group 4 and choose Surface.
- 2 In the Settings window for Surface, click to expand the Range section.
- 3 Select the Manual color range check box.
- 4 In the Maximum text field, type 5.

#### Selection I

I Right-click Surface I and choose Selection.

- 2 In the Settings window for Selection, locate the Selection section.
- 3 From the Geometric entity level list, choose Domain.
- 4 From the Selection list, choose Harness.
- 5 In the 3D Plot Group 4 toolbar, click Plot.