

Capacitive Micromachined Ultrasonic Transducer with Lumped Model

A capacitive micromachined ultrasonic transducer (CMUT) converts ultrasound to an electrical signal for high-resolution imaging applications. As a mechanical system, a CMUT can be modeled as a spring-mass system with one degree of freedom. Such model can be useful when analyzing an array of CMUTs where FEM modeling would be impractical. This tutorial demonstrates how a lumped model of a MEMS transducer can be derived from its FEM model using the Lumped Mechanical System interface and the Parameter Estimation study. The Lumped Mechanical System interface is available the Multibody Dynamics Module. The Parameter Estimation study is available in the Optimization Module.

Model Definition

This tutorial makes use of an existing FEM model and adds a lumped model defined by the Lumped Mechanical System interface.

FEM Model of the CMUT

This tutorial starts by opening the Application Library model Capacitive Micromachined Ultrasonic Transducer. You can refer to the accompanying documentation for discussions on the device geometry and operation. A Stationary study is added to compute keff, an estimate for the effective spring constant of the CMUT. In this test, uniform pressure is applied to the top surface of the CMUT and membrane displacement is measured. The total force is p max*1^2, with p max the applied pressure and 1^2 the area of the CMUT. Varying p max and then plotting the total force against displacement gives the value for keff. The CMUT has distributed mass and stiffness so keff is only an estimate. The second study is a Frequency Domain, Prestressed study for the frequency response around 7.5 MHz, its natural frequency. The result is used as the reference data for subsequent studies.

LMS Model of the CMUT

The Lumped Mechanical System interface is used to define the lumped model with three the parameters: the damping coefficient c, the effective spring constant keff, and the effective mass meff. The value for meff is $2.837 \cdot 10^{-11}$ kg, as calculated based on the equation

$$m_{\text{eff}} = \frac{k_{\text{eff}}}{(2\pi f_0)^2}$$

Using the lumped model, a Frequency Domain study is performed for the frequency response around 7.5 MHz.

The Parameter Estimation Study

The Parameter Estimation study is used to derive the accurate values of the model parameters. In the Parameter Estimation study, a model expression is computed from the Frequency Domain study of the circuit model defined by the three parameters, which are varied to fit the experimental data (from FEM). To fit the model expression to the experimental data, Parameter Estimation minimizes an objective function defined as the error between model expression and experimental data. The output of the Parameter Estimation (PE) is the set of circuit parameters that best approximates the frequency response from FEM.

Figure 1 shows the total force (integrated over the surface of CMUT) versus maximum displacement (measured at the center). The slope of this plot gives keff, which is approximately 63,000 N/m.




Figure 1: The plot total force versus z-displacement from the FEM simulation. The slope of the plot is the effective spring constant keff in the lumped model.

Figure 2 shows the z-displacement as a function of frequency from the Frequency Domain, Prestressed study frequency range of 7.2 to 7.8 MHz. The maximum zdisplacement at the center of the device and is 30 nm at 7.5 MHz.




Figure 2: Plot of z-displacement versus frequency from FEM simulation.

From the previous results, the initial values of the lumped model parameters are summarized in Table 1.

TABLE I: INITIAL VALUES OF LUMPED MODEL PARAMETERS.

Parameter	Value
С	IE-5 N·s/m
keff	63E3 N/m
meff	2.837 E-11 kg

Figure 3 compares the frequency response curves of the FEM and lumped models computed with initial values for c, keff, and meff.




Figure 3: Plot of z-displacement versus frequency from FEM simulation and lumped model using the initial values in Table 1.

Figure 4 shows the output of the Parameter Estimation study comparison between experimental data and model expression. The fitted parameters are listed in Table 2.




Figure 4: Plot of FEM result and lumped model using the final parameters from the Parameter Estimation study.

TABLE 2: VALUES OF LUMPED PARAMETERS COMPUTED FROM PARAMETER ESTIMATION STUDY.

Parameter	Values	
С	1.986E-5 N·s/m	
keff	98.677E3 N/m	
meff	4.441E-11 kg	

Reference

1. C. Chou, P. Chen, H. Wu, T. Hsu, and M. Li, "Piston-Shaped CMOS-MEMS CMUT Front-End Featuring Force-Displacement Transduction Enhancement," Proceedings of the 21st International Conference on Solid-State Sensors, Actuators and Microsystems (Transducers), pp. 26-29, 2021.

Application Library path: MEMS Module/Sensors/

capacitive_micromachined_ultrasonic_transducer_lumped_model

Modeling Instructions

Start by opening the FEM model.

APPLICATION LIBRARIES

- I From the File menu, choose Application Libraries.
- 2 In the Application Libraries window, select MEMS Module>Sensors> capacitive_micromachined_ultrasonic_transducer in the tree.
- 3 Click Open.

Before setting up the **Stationary** study to measure the effective spring constant, add a second **Boundary Load** feature.

COMPONENT I (COMPI)

In the Model Builder window, expand the Component I (compl) node.

SOLID MECHANICS (SOLID)

Boundary Load 2

- I In the Model Builder window, expand the Component I (compl)>Solid Mechanics (solid) node.
- 2 Right-click Solid Mechanics (solid) and choose Boundary Load.
- 3 In the Settings window for Boundary Load, locate the Force section.
- **4** Specify the \mathbf{F}_{A} vector as

5 Select Boundary 22 only.

Set up a **Stationary** study to measure the effective spring constant. Use only the second **Boundary Load** by disabling the first **Boundary Load**.

ADD STUDY

I In the Home toolbar, click Add Study to open the Add Study window.

- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies>Stationary.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 3

Stationary - Force vs. Displacement

- I In the **Settings** window for **Stationary**, type Stationary Force vs. Displacement in the **Label** text field.
- 2 Locate the Physics and Variables Selection section. Select the Modify model configuration for study step check box.
- 3 In the tree, select Component I (compl)>Solid Mechanics (solid), Controls spatial frame> Boundary Load I.
- 4 Click O Disable.
- 5 Clear the Modify model configuration for study step check box.
- 6 In the table, clear the Solve for check boxes for Electrostatics (es), Electrical Circuit (cir), and Moving mesh (Component 1).
- 7 In the table, clear the Solve for check box for Electromechanical Forces I (emel).
- 8 Click to expand the Study Extensions section. Select the Auxiliary sweep check box.
- 9 Click + Add.
- **10** In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
p_max (Maximum pressure)	range(0,2e5,1e6)	Pa

II In the Model Builder window, click Study 3.

12 In the Settings window for Study, locate the Study Settings section.

13 Clear the Generate default plots check box.

14 In the **Home** toolbar, click **Compute**.

From the results of Study 3, plot the force versus displacement.

RESULTS

ID Plot Group 5

In the Home toolbar, click **Add Plot Group** and choose **ID Plot Group**.

Global I

Right-click ID Plot Group 5 and choose Global.

Effective Spring Constant

- I In the Settings window for ID Plot Group, type Effective Spring Constant in the Label text field.
- 2 Locate the Data section. From the Dataset list, choose Study 3/Solution 4 (sol4).
- 3 Locate the Plot Settings section. Select the Flip the x- and y-axes check box.
- 4 Locate the Legend section. From the Position list, choose Lower right.

Global I


- I In the Model Builder window, click Global I.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
abs(minop1(w))	μ m	

- 4 Locate the x-Axis Data section. From the Parameter list, choose Expression.
- 5 In the Expression text field, type p max*1^2.
- **6** Locate the **y-Axis Data** section. In the table, enter the following settings:

Expression	Unit	Description
abs(minop1(w))	μ m	Maximum displacement

7 In the Effective Spring Constant toolbar, click **Plot**.



From this plot, the effective spring constant is approximately 63,000 N/m. This value will be used in the lumped model.

For the next Frequency Domain, Prestressed study, add the Damping feature under Linear Elastic Material.

SOLID MECHANICS (SOLID)

Linear Elastic Material I

In the Model Builder window, under Component I (compl)>Solid Mechanics (solid) click Linear Elastic Material I.

Damping I

- I In the Physics toolbar, click 🕞 Attributes and choose Damping.
- 2 In the Settings window for Damping, locate the Damping Settings section.
- 3 From the Damping type list, choose Isotropic loss factor.
- 4 From the η_s list, choose User defined. In the associated text field, type 1e-2.

Set up a Frequency Domain, Prestressed study. Use only the first Boundary Load feature by disabling the second Boundary Load.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select Preset Studies for Selected Physics Interfaces>Solid Mechanics>Frequency Domain, Prestressed.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 4

Step 1: Stationary

- I In the Settings window for Stationary, locate the Physics and Variables Selection section.
- 2 Select the Modify model configuration for study step check box.
- 3 In the tree, select Component I (compl)>Solid Mechanics (solid), Controls spatial frame> Boundary Load 2.
- 4 Right-click and choose Disable.

Frequency Domain Perturbation, FEM

- I In the Model Builder window, under Study 4 click Step 2: Frequency-Domain Perturbation.
- 2 In the Settings window for Frequency-Domain Perturbation, type Frequency Domain Perturbation, FEM in the Label text field.
- 3 Locate the Study Settings section. From the Frequency unit list, choose MHz.
- 4 In the Frequencies text field, type range (7.2,0.01,7.8).
- 5 Click to expand the **Study Extensions** section. Select the **Auxiliary sweep** check box.
- 6 Click + Add.
- 7 In the table, enter the following settings:

Parameter name	Parameter value list	Parameter unit
p_max (Maximum pressure)	0.01[MPa]	Pa

- 8 Locate the Physics and Variables Selection section. Select the Modify model configuration for study step check box.
- 9 In the tree, select Component I (compl)>Solid Mechanics (solid), Controls spatial frame> Boundary Load 2.
- 10 Right-click and choose Disable.

- II In the Model Builder window, click Study 4.
- 12 In the Settings window for Study, locate the Study Settings section.
- **13** Clear the **Generate default plots** check box.
- 14 In the Home toolbar, click **Compute**.

From the results of Study 4, plot the frequency response of the FEM model.

RESULTS

Frequency Response

- I In the Home toolbar, click Add Plot Group and choose ID Plot Group.
- 2 In the Settings window for ID Plot Group, type Frequency Response in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 4/Solution 5 (sol5).


Global I

- I Right-click Frequency Response and choose Global.
- 2 In the Settings window for Global, locate the y-Axis Data section.
- **3** In the table, enter the following settings:

Expression	Unit	Description
minop1(w)	μm	FEM

- **4** Locate the **Legends** section. Find the **Include** subsection. Clear the **Solution** check box.
- 5 Locate the y-Axis Data section. From the Expression evaluated for list, choose RMS for total solution.
- 6 Locate the x-Axis Data section. From the Axis source data list, choose freq.

7 In the Frequency Response toolbar, click **Plot**.



Define and enter the values for the following parameters. These are the initial values for the lumped model.

GLOBAL DEFINITIONS

Parameters 2

- I In the Home toolbar, click P; Parameters and choose Add>Parameters.
- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
keff	63000[N/m]	63000 N/m	Effective spring constant
meff	keff/(2*pi* 7.5[MHz])^2	2.837E-11 kg	Effective mass
С	1e-5[N*s/m]	IE-5 N·s/m	Damping coefficient
fapp	p_max*1^2	0.0040322 N	Applied force

Add the **Lumped Mechanical System** interface and set up the lumped model.

ADD PHYSICS

- I In the Home toolbar, click open the Add Physics window.
- 2 Go to the Add Physics window.
- 3 In the tree, select Structural Mechanics>Lumped Mechanical System (Ims).
- 4 Click Add to Component I in the window toolbar.
- 5 In the Home toolbar, click Add Physics to close the Add Physics window.

LUMPED MECHANICAL SYSTEM (LMS)

Spring I (KI)

- I Right-click Component I (compl)>Lumped Mechanical System (lms) and choose Spring.
- 2 In the Settings window for Spring, locate the Node Connections section.
- **3** In the table, enter the following settings:

Label	Node names
рl	1
p2	0

4 Locate the **Component Parameters** section. In the k text field, type keff.

Damber I (CI)

- I In the Physics toolbar, click A Global and choose Damper.
- 2 In the Settings window for Damper, locate the Node Connections section.
- **3** In the table, enter the following settings:

Label	Node names
рΙ	1
p2	0

4 Locate the **Component Parameters** section. In the c text field, type c.

Mass I (MI)

- I In the Physics toolbar, click A Global and choose Mass.
- 2 In the Settings window for Mass, locate the Node Connections section.

3 In the table, enter the following settings:

Label	Node names
рΙ	1
p2	2

4 Locate the **Component Parameters** section. In the *m* text field, type meff.

Force Node I (frc1)

- I In the Physics toolbar, click A Global and choose Force Node.
- 2 In the Settings window for Force Node, locate the Terminal Parameters section.
- 3 In the f_{p10} text field, type fapp.
- **4** Locate the **Node Connections** section. In the table, enter the following settings:

Label	Node name
pl	2

For the next **Frequency Domain**, change the values of some LMS parameter.

GLOBAL DEFINITIONS

Parameters 2

- I In the Model Builder window, under Global Definitions click Parameters 2.
- 2 In the Settings window for Parameters, locate the Parameters section.
- **3** In the table, enter the following settings:

Name	Expression	Value	Description
fapp	0.01[MPa]*1^2	4.0323E-5 N	Applied force

Set up a Frequency Domain study for the LMS model.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select General Studies> Frequency Domain.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 5

Frequency Domain, LMS

- I In the Settings window for Frequency Domain, type Frequency Domain, LMS in the **Label** text field.
- 2 Locate the Study Settings section. From the Frequency unit list, choose MHz.
- 3 Locate the Physics and Variables Selection section. In the table, clear the Solve for check box for Electrostatics (es).
- 4 Locate the Study Settings section. In the Frequencies text field, type ramnge (7.2,0.01, 7.8).
- 5 Locate the Physics and Variables Selection section. In the table, clear the Solve for check boxes for Solid Mechanics (solid), Electrical Circuit (cir), and Moving mesh (Component I).
- 6 In the table, clear the Solve for check box for Electromechanical Forces I (eme I).
- 7 Locate the Study Settings section. In the Frequencies text field, type range (7.2,0.01, 7.8).
- 8 In the Model Builder window, click Study 5.
- 9 In the Settings window for Study, locate the Study Settings section.
- 10 Clear the Generate default plots check box.
- II In the Home toolbar, click **Compute**.

From the results of Study 5, plot the frequency response of the LMS model.

RESULTS

Frequency Response

- I In the Model Builder window, under Results click Frequency Response.
- 2 In the Settings window for ID Plot Group, locate the Plot Settings section.
- 3 Select the x-axis label check box.
- 4 Select the y-axis label check box. In the associated text field, type Displacement (um).


Global 2 - LMS

- I Right-click Frequency Response and choose Global.
- 2 In the Settings window for Global, type Global 2 LMS in the Label text field.
- 3 Locate the Data section. From the Dataset list, choose Study 5/Solution 7 (sol7).
- 4 Click Add Expression in the upper-right corner of the y-Axis Data section. From the menu, choose Component I (compl)>Lumped Mechanical System>Two port components> MI>Ims.MI uRMS - Displacement, RMS (MI) - m.

- 5 In the Frequency Response toolbar, click **Plot**.
- **6** Locate the **y-Axis Data** section. In the table, enter the following settings:

Expression	Unit	Description
lms.M1_uRMS	μ m	LMS

- 7 Locate the **Legends** section. Find the **Include** subsection. Clear the **Solution** check box.
- 8 In the Frequency Response toolbar, click Plot.



Copy the result of Study 4 to a table for use as reference data in the Parameter Estimation study.

Global I

In the Model Builder window, right-click Global I and choose Copy Plot Data to Table.

FEM Reference Data

- I In the Model Builder window, under Results>Tables click Table I.
- 2 In the Settings window for Table, type FEM Reference Data in the Label text field.

Set up a Parameter Estimation study based on the previous Frequency Domain study for the LMS model.

ADD STUDY

- I In the Home toolbar, click Add Study to open the Add Study window.
- 2 Go to the Add Study window.
- 3 Find the Studies subsection. In the Select Study tree, select Empty Study.
- 4 Click Add Study in the window toolbar.
- 5 In the Home toolbar, click Add Study to close the Add Study window.

STUDY 5

Steb 1: Frequency Domain, LMS

In the Model Builder window, under Study 5 right-click Step 1: Frequency Domain, LMS and choose Copy.

STUDY 6

In the Model Builder window, right-click Study 6 and choose Paste Frequency Domain.

Parameter Estimation

- I In the Study toolbar, click optimization and choose Parameter Estimation.
- 2 In the Settings window for Parameter Estimation, locate the Experimental Data section.
- 3 From the Data source list, choose Result table.
- 4 Locate the **Data Column Settings** section. In the table, enter the following settings:

Columns	Туре	Settings
freq (MHz)	Frequency	Frequency unit=MHz

- 5 From the Frequency unit list, choose MHz.
- **6** In the table, click to select the cell at row number 2 and column number 2.
- 7 In the Model expression text field, type comp1.lms.M1 uRMS.
- 8 In the **Unit** text field, type um.
- 9 From the Scale list, choose Manual.
- 10 In the Scale value text field, type 1e-9.

Select the model parameters to be included in the study. Specify their initial values, scaling, and the lower and upper bounds. For this study, a default plot will be generated automatically comparing the FEM reference data and the lumped model using the final values of the lumped parameters.

II Locate the Estimated Parameters section. Click + Add.

12 In the table, enter the following settings:

Parameter name	Initial value	Scale	Lower bound	Upper bound
c (Damping coefficient)	1e-5[N*s/	3e-5[N*	1e-6[N*	3e-5[N*
	m]	s/m]	s/m]	s/m]

13 Click + Add.

14 In the table, enter the following settings:

Parameter name	Initial value	Scale	Lower bound	Upper bound
meff (Effective mass)	2.882e- 11[kg]	5e-11[kg]	1e-11[kg]	5e-11[kg]

I5 Click + Add.

16 In the table, enter the following settings:

Parameter name	Initial value	Scale	Lower bound	Upper bound
keff (Effective spring constant)	63000[N/m]	1e5[N/m]	1e4[N/m]	1e5[N/m]

17 Locate the Parameter Estimation Method section. From the Method list, choose SNOPT.

18 Find the Solver settings subsection. From the Least-squares time/parameter method list, choose Use only least-squares data points.

Because in the Frequency Domain study the variables are complex, the option for Split complex variables in real and imaginary parts must be enabled.

Solution 8 (sol8)

- I In the Study toolbar, click Show Default Solver.
- 2 In the Model Builder window, expand the Solution 8 (sol8) node, then click Compile Equations: Frequency Domain, LMS.
- 3 In the Settings window for Compile Equations, locate the Study and Step section.
- 4 Select the Split complex variables in real and imaginary parts check box.
- 5 Click **Compute**.

RESULTS

Parameter estimation

