Table of Contents

Installing Anaconda and Launching KairoSight 3.0	2
Running KairoSight	3
Running KairoSight with EC Coupling	4
Two Separate Files	4
One File	5
Processing	7
Binning	7
Filtering	7
Drift	7
Normalizing	7
Interpolation	7
Standard Analysis Options	8
Activation	8
APD/CaD	8
APD/CaD Ensemble	9
Dynamic Alternan	9
Manual Alternan	10
Fixed APD Alternan	11
Conduction Velocity	11
S1-S2	12
Signal to Noise Ratio	12
EC Coupling Analysis Options	14
Max Slope EC Coupling	14
Repolarization EC Coupling	14
Trouble Shooting	15
Notes	15

Installing Anaconda and Launching KairoSight 3.0

- 1. First you will need to install Anaconda, which can be found here or if you have an older operating system here.
- Select "Just Me (Recommended)" when prompted.
- 3. Clone or download the repository (save the contents to a location that is easy to remember/navigate to). a. To find, scroll to the top of this page > locate "Code" (in green) > select the drop-down > locate "Download ZIP" > select "Download ZIP" b. Note: If you download the repository, unzip the contents of the zip file (your repository is the folder 'KairoSight-3.0-main')
- 4. Navigate to your computers search bar and type "Anaconda Prompt"
- 5. Select the Anaconda Prompt
- 6. Type 'cd', press the space bar, and then type the directory where you cloned/downloaded the repository (e.g.,
 - "OneDrive\Documents\GitHub\KairoSight-3.0-main") a. Note: you can copy the file path by finding the directory in your folders, right clicking, and pasting the file path into the anaconda prompt
- 7. Press 'Enter' on your keyboard
- 8. Enter the following command: conda env create -f kairosight_env.yml
- 9. Press 'Enter' on your keyboard
- 10. When Anaconda has finished installing the environment it should instruct you to run step 11
- 11. Type 'conda activate kairosight_3-0'
- 12. Press 'Enter' on your keyboard
- 13. When anaconda has finished this step, close the 'Anaconda Prompt'
- 14. Navigate to your computers search bar and type 'Anaconda Navigator'
- 15. When the application finishes opening, navigate to the drop-down next to 'Application' a. Note: the drop-down will most likely say 'base(root)'
- 16. Switch the drop-down to 'kairosight_3-0'
- 17. In the save 'Anaconda Navigator' window, find the "Spyder" application
- 18. Launch the "Spyder" application
- 19. In the top menu select: Tools -> Preferences

- 20. Select "IPython Console" on the left hand menu
- 21. Select the "Graphics" tab and make sure the 'Graphics backend' is set to Qt5
- 22. Select "Apply" to save any changes, and select "OK" to close the window
- 23. Navigate to: File -> Open -> 'location of KairoSight-3.0-main' -> src (inside your KairoSight-3.0-main folder)
- 24. Select the 'kairosight_retro.py' file
- 25. When loaded in spyder, select the green play button (in the top menu)
- 26. KairoSight should now be up and running

Running KairoSight

- 1. Press "Select Directory" and choose folder with desired files
- Select desired folder and press "Select Folder"
- 3. Select desired file from list and press "Load"
- 4. Input frame rate
- 5. Select image type, either "Voltage" or "Calcium"
 - a. If a dual image, select the type you want to analyze
- 6. Check "Crop" if cropping is desired
- 7. Select "Save Properties"
 - a. If you wish to update the cropped area select "Update Properties" and repeat steps 6-7.
- 8. Select draw mask area and click around the heart to remove the background.
- 9. Press "Enter" on your keyboard
 - a. If the draw mask command causes the program to freeze/stop responding:
 - i. Tools → Preferences → iPython console → Graphics → Graphics
 Backend → Switch Graphics Backend to Automatic
- 10. Process your image to your specifications, select "Prepare"
 - a. See processing section for more information on these settings
- 11. Move the slider, underneath the image, to see activation through the heart
- 12. Click "Select Signal" and select first point of activation
- 13. Click "Select Signal" again and select where the heart is activating a few frames after the initial activation

- 14. Click "Select Signal" and select the last point of activation
- 15. To analyze other images, repeat steps, starting at step 3
- 16. If you wish to redo your signal selection, select "Reset Signal" and repeats steps 9-13.

Running KairoSight with EC Coupling

Follow the steps below if your voltage and calcium images are two separate files:

- If the desired object for imaging is shifted between the calcium and voltage images, follow step 1, otherwise skip to step 2.
- 1. Register your calcium and voltage images in ImageJ
- 2. Press "Select Directory" and choose directory with desired calcium file
- 3. Select desired calcium file and press "Load"
- 4. Input frame rate
- 5. Set image type to "Calcium"
- 6. Check "EC Coupling"
- 7. Crop image, and keep a note of the size of the cropped image
- 8. Select draw mask area and click around the heart to remove the background.
- 9. Press "Enter" on your keyboard
 - a. If the draw mask command causes the program to freeze/stop responding:
 - i. Tools → Preferences → iPython console → Graphics → Graphics
 Backend → Switch Graphics Backend to Automatic
- 10. Process your image to your specifications, select "Prepare"
 - a. See processing section for more information on these settings
 - Note: This automatically saves a .npy file of the calcium data to the scr folder in KairoSight
- 11. Navigate back to your selected directory and select desired voltage file and press "Load"
- 12. Input frame rate, should be the same value used for calcium
- 13. Set image type to "Voltage"
- 14. Check "EC Coupling"
- 15. Crop image to have the same height and width used for calcium

- 16. Select "Use Saved Mask" to use the same mask that was used for calcium
- 17. Press "Enter" on your keyboard
- 18. Process your image to the same specifications as calcium, select "Prepare"
 - a. See processing section for more information on these settings
 - Note: This automatically saves a .npy file of the voltage data to the scr folder in KairoSight
- 19. Click "Select Signal" and select first point of activation, identified using the slider
- 20. Click "Select Signal" and select last point of activation
- 21. Navigate to the **EC Coupling Analysis** section of the manual

Follow the steps below if your voltage and calcium images are one file:

- 1. Press "Select Directory" and choose directory with desired file
- Select desired calcium file and press "Load"
- 3. Input frame rate
- 4. Set image type to "Calcium"
- 5. Check "EC Coupling"
- 6. Crop image, cutting the y-axis in half and keeping only the calcium side of the image.
 - a. Keep a note of the height of the cropped image
- 7. Select draw mask area and click around the heart to remove the background.
- 8. Press "Enter" on your keyboard
 - a. If the draw mask command causes the program to freeze/stop responding:
 - i. Tools → Preferences → iPython console → Graphics → Graphics
 Backend → Switch Graphics Backend to Automatic
- 9. Process your image to your specifications, select "Prepare"
 - a. See processing section for more information on these settings
 - Note: This automatically saves a .npy file of the calcium data to the scr folder in KairoSight
- 10. Select "Update Image Properties"
- 11. Set image type to "Voltage"
- 12. Check "EC Coupling"

- 13. Crop image using the other half of the y-axis, keeping only the voltage side of the image.
 - a. Use the same height as your calcium image.
- 14. Press "Enter" on your keyboard
 - a. If the draw mask command causes the program to freeze/stop responding:
 - i. Tools → Preferences → iPython console → Graphics → Graphics
 Backend → Switch Graphics Backend to Automatic
- 15. Process your image to the same specifications as calcium, select "Prepare"
 - a. See processing section for more information on these settings
 - Note: This automatically saves a .npy file of the calcium data to the scr folder in KairoSight
- 16. Click "Select Signal" and select first point of activation, identified using the slider
- 17. Click "Select Signal" and select last point of activation
- 18. Navigate to the **EC Coupling Analysis** section of the manual

Processing

Binning

Binning the image averages the pixels around each other, reducing the number of pixels in the whole image. Accordingly, follow these guidelines:

- 1. Alternans: No binning
- 2. Activation/Conduction Velocity: Any binning

Filtering

Filtering the image reduces the amount of noise from the desired signal. Accordingly, follow these guidelines:

 Start at ~100 and adjust from there. A smaller filtering value results in more filtering.

Drift

Removing drift from the image removes any upward or downward sloping trend. Accordingly, follow these guidelines.

- 1. Increasing the order helps level the signal more.
- 2. 1st order is typically enough to remove any upward or downward drift.
- 3. Use higher orders if the smaller order doesn't remove all desired drift.

Normalizing

Normalizing the signal sets the min and max from 0 to 1.

Interpolation

Interpolating the image averages points on the signal, allowing the program to find various parts of a noisy signal easily.

1. Note: Always use the least amount of interpolation necessary.

Standard Analysis Options

Activation

To map the activation time across the heart, follow these steps:

- 1. In the drop-down menu under **Analysis**, select "Activation"
- 2. In "Start Time", input the time a beat begins, based on the first activation point
- 3. In "End Time", input the time the same desired beat ends, based on the last activation point
- 4. Select "Map"
- 5. If the bounds of the default map should be change
 - 1. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
 - 2. Select "Modify Colorbar"

APD/CaD

To map the action potential duration or calcium transient duration across the heart, follow these steps:

- 1. In the drop-down menu under **Analysis**, select "APD" or "CaD"
- In "Start Time", input the time the desired beat begins, based on the first activation point
- 3. In "End Time", input the time the same desired beat ends, based on the last activation point
- 4. In "% APD₁" or "% CaD₁", input the duration percentage desired
- 5. Select "Map"
- 6. If there are holes in the maps, adjust the interpolation and repeat step 5.
- 7. If the bounds of the default map should be change
 - 1. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
 - 2. Select "Modify Colorbar"

APD/CaD Ensemble

To obtain the values for multiple APD or CaD traces, follow these steps:

- In the drop-down menu under **Analysis**, select "APD Ensemble" or "CaD Ensemble"
- 2. In "Start Time", input the time the desired beat begins, based on the first activation point
- 3. In "End Time", input the time the last desired beat ends, based on the last activation point
- 4. In "Max Amp", input the maximum amplitude threshold desired.
 - a. Note, it should be just below the shortest APD/CaD amplitude.
- 5. In "% APD1" or "% CaD1", input the duration percentage desired
- 6. In "% APD2" or "% CaD2", input the second duration percentage desired
- 7. Select "Map"
- 8. When the "Save File" is opened, navigate to the desired folder, and give the file its desired name in "File Name"
- 9. Select "Save"
- 10. Open file from saved location to evaluate saved parameters

Dynamic Alternan

- 1. In the drop-down menu under **Analysis**, select "Dynamic Alternan"
- 2. Identify two consecutive beats that make up an alternan
- 3. In "Start Time", input the time the desired alternan begins, based on the first activation point
- 4. In "End Time", input the time the same desired alternan ends, based on the last activation point
- 5. In "Peak Coeff.", input a peak coefficient of 4
- 6. Select "Map"
- 7. If there are holes in the maps, adjust the interpolation and the peak coefficient then select "Map" again.
 - a. When interpolation increases, peak coefficient should also increase, and vice versa.

- 8. This returns a map of the AP or CaT alternan coefficient
- 9. If the bounds of the default map should be change
 - a. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
 - b. Select "Modify Colorbar"

Manual Alternan

- 1. In the drop-down menu under **Analysis**, select "Manual Alternan"
- 2. Identify two consecutive beats that make up an alternan
- 3. In "Start Time", input the time the desired alternan begins, based on the first activation point
- 4. In "End Time", input the time the desired alternan ends, based on the last activation point
- 5. In "Peak Coefficient", input a peak coefficient of 4
- If there are holes in the maps, adjust the interpolation and the peak coefficient and map again. When interpolation increases, peak coefficient should also increase, and vice versa.
- 7. Use the map to determine the optimal level of repolarization from a local minima map (use it to determine the Z value for fixed alternan analysis).
 - a. To do this "click" on the area of the image with the highest value in the color bar.
 - b. The Z value from this selection will be populated in the command window of Spyder.
 - i. Note: This Z value can then be used for the %APD/CaD when the "Fixed Alternan" option is selected from the drop down.
 - ii. Also Note: "Z" is the percent repolarization or percent reuptake
- 8. If the bounds of the default map should be change
 - a. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
 - b. Select "Modify Colorbar"

Fixed APD Alternan

- 1. In the drop-down menu under **Analysis**, select "Fixed APD Alternan"
- 2. Identify two consecutive beats that make up an alternan
- 3. In "Alt. 1 Start Time", input the time the first beat of the alternan begins
- 4. In "Alt. 1 End Time", input the time the first beat of the alternan ends
- 5. In "Alt. 2 Start Time", input the time the second beat of the alternan begins
- 6. In "Alt. 2 End Time", input the time the second beat of the alternan ends
- 7. In "% APD₁" either:
 - a. Input the Z value found with manual alternan. This will find the optimal percent repolarization or reuptake for each beat in the alternan.
 - i. Allowing you to find the optimal %APD duration.
 - b. Input 50
 - i. Allowing you to find %APD at 50% repolarization.
- 8. Select "Map"
- 9. If the bounds of the default map should be change
 - a. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
 - b. Select "Modify Colorbar"

Conduction Velocity

- 1. Follow steps under the **Activation** section
- Under Conduction Velocity, in the text box next to "Scale (px/cm)" enter the scale in terms of pixels/cm
- Under Single Vector, in the text box next to "No of Vectors" input the number of vectors desired
- 4. Select "Plot"
- 5. Click the area of the heart that is first activated, as denoted by the colormap
- 6. Click the area of the heart that is activation last
- 7. For each additional vector, repeat steps 5-6
- 8. When finished selecting vectors, press enter (on the keyboard)
- 9. The conduction velocity will be shown next to its corresponding vector

S1-S2

- 1. In the drop-down menu under **Analysis**, select "S1-S2"
- 2. In "Alt. 1 Start Time", input the time the beat before the second to last S1 beat begins
- 3. In "Alt. 1 End Time", input the time the beat before the second to last S1 beat ends
- 4. In "Alt. 2 Start Time", input the time the last S1 beat begins
- 5. In "Alt. 2 End Time", input the time the S2 beat ends
 - a. Note, your alt. 2 start and end time should encompass two beats (the last S1 beat and the following S2 beat).
- 6. In "Max Amp", input the maximum amplitude threshold desired.
 - a. Note, it should be just below the shortest APD/CaD amplitude.
- 7. In "% APD₁" or "% CaD₁", input the duration percentage desired
- 8. In "% APD2" or "% CaD2", input a peak coefficient of 4
- 9. Select "Map"
- 10. If there are holes in the maps, adjust the interpolation and the peak coefficient then select "Map" again.
 - a. When interpolation increases, peak coefficient should also increase, and vice versa.
- 11. If the bounds of the default map should be change
 - a. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
 - b. Select "Modify Colorbar"

Signal to Noise Ratio

- 1. In the drop-down menu under **Analysis**, select "SNR"
- 2. In "Start Time", input the time a beat begins, based on the first activation point
- 3. In "End Time", input the time a beat's activation is complete
- 4. Select "Map"
- 5. If the bounds of the default map should be change

- 1. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
- 2. Select "Modify Colorbar"

EC Coupling Analysis Options

Max Slope EC Coupling

- 1. In the drop-down menu under **Analysis**, select "Activation EC"
- 2. In "Start Time", input the time a beat begins, based on the first activation point
- 3. In "End Time", input the time a beat's activation is complete
- 4. Select "Map"
- 5. If the bounds of the default map should be change
 - 1. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
 - 2. Select "Modify Colorbar"

Repolarization EC Coupling

- 1. In the drop-down menu under **Analysis**, select "Repolarization EC Latency"
- 2. In "Start Time", input the time a beat begins, based on the first activation point
- 3. In "End Time", input the time a beat end, based on the last activation point
- 4. In "% APD₁", input the percentage of repolarization you are interested in
- 5. Select "Map"
- 6. If the bounds of the default map should be change
 - 1. In the **Min** and **Max** text boxes, next to "Modify Colorbar", enter bounds for the colorbar (if the default is not a valid representation of the data)
 - 2. Select "Modify Colorbar"

Troubleshooting

- 1. If the draw mask command causes the program to freeze/stop responding:
 - Tools → Preferences → iPython console → Graphics → Graphics
 Backend → Switch Graphics Backend to Automatic

Notes:

- At high pacing (beats are fused or tend to be fused) --- SNR will be inaccurate,
 only do SNR with slower pacing
- To increase SNR, increase binning; can be increased to 15x15
- If the dynamic alternan functionality is returning an error, ensure the file used has alternans and try increasing the processing settings on the image.
- You can update the properties to analyze a different part of the image without
 having to reload the image, you can update properties and change the crop and
 mask to analyze the desired section of the image.