

Lecture 07 병렬성 및 멀티스레디드 아키텍처





병렬성





Types of Parallelism

ILP

Task parallelism


Data parallelism





Task Parallelism

- The job of preparing a banquet
- Meal preparation consists of tasks
 - Preparing appetizer, salad, main dish, and desert
- Four different chefs
 - Each focus on one of the four tasks








Task Parallelism (contd.)

- Performing distinct tasks at the same time
- Dividing an application into different parallel tasks (functions)
 - Most applications only have a few parallel tasks






5



Data Parallelism

- The job of preparing a banquet
- P chefs prepare N meals
 - Each producing N/P complete meals
- As N increases, P can be increased if there are sufficient resources, such as stoves, cutting boards, etc.









Data Parallelism (contd.)

- Also known as loop-level parallelism
- Performing the same operation to different items of data at the same time
- More data, more parallelism

```
for(i=0; i<16; i++)
{
    c[i] = a[i] + b[i];
}</pre>
```










Data Parallelism (contd.)

```
for(i=0; i<16; i++)
{
    c[i] = a[i] + b[i];
}</pre>
```

```
for(i=0;i<4;i++)
{
    c[i]=a[i]+b[i];
}</pre>
for(i=4;i<8;i++)
{
    c[i]=a[i]+b[i];
}
for(i=8;i<12;i++)
{
    c[i]=a[i]+b[i];
}
c[i]=a[i]+b[i];
}
for(i=12;i<16;i++)
{
    c[i]=a[i]+b[i];
}
```








SIMD

- Single Instruction, Multiple Data
- A single instruction (or copies of a single instruction)
 performs the same operation in parallel on multiple data
 items of the same type and size
 - A single program counter
- Compilers typically support auto-vectorization
- Multiple parallel execution units are called lanes







SIMD (contd.)

```
for(i = 0; i < 4; i++)
  c[i] = a[i] + b[i];
```


```
for(i = 4; i < 8; i++)
  c[i] = a[i] + b[i];
```








Core 1



Core 2



Core 3








SPMD


- Single Program, Multiple Data
- 같은 코드를 다른 데이터 아이템에 동시에 실행
- 개념적으로 한 개의 제어 스레드(thread of control)

```
LL = myid() * 4;
                          LL = myid() * 4;
                                                     LL = myid() * 4;
                                                                               LL = myid() * 4;
                          UL = LL + 4
                                                     UL = LL + 4
                                                                               UL = LL + 4
UL = LL + 4
for(i = LL; i < UL; i++) for(i = LL; i < UL; i++)
                                                    for(i = LL; i < UL; i++)
                                                                               for(i = LL; i < UL; i++)
    c[i] = a[i] + b[i];
                              c[i] = a[i] + b[i];
                                                         c[i] = a[i] + b[i];
                                                                                   c[i] = a[i] + b[i];
```











© Jaejin Lee



멀티스레디드 아키텍처





Multithreaded Processors

- Issue instructions from multiple threads of control for the pipeline
 - To guarantee no dependences between instructions in a pipeline
- Exploit ILP from multiple threads that are executing simultaneously
- Functional units remain unchanged
- The lack of ILP in a single thread
 - However, ILP enabled the rapid increase in processor speed





Thread-level Parallelism (TLP)

- TLP is explicitly represented by the use of multiple threads of execution
 - To improve throughput

TLP could be more cost-effective to exploit than ILP





Issue Width of Superscalar Processors

- The goal of the instruction pipeline
 - To issue an instruction on every clock cycle
- Issuing an instruction
 - The instruction proceeds into the reservation station
- Scheduling (dispatching) an instruction
 - The instruction proceeds into the execution unit from the reservation station
- Issue-width is the maximum number of instructions that can be issued by a processor
 - When the hardware can issue up to n instructions on every cycle:
 - The processor has n issue slots
 - The processor is an n-issue processor
 - Fetch n instructions simultaneously
 - There are n decode units








Superscalar Processors

- Inefficiency
 - Vertical waste and horizontal waste





16



Vertical Multithreading


- Reduce vertical waste by scheduling threads to hide long latency
 - Switching different thread contexts each cycle
 - Tolerate long latency operations (remove vertical waste)
- Still waste unused issue slots (horizontal waste)
- Scheduling
 - Fine-grained multithreading context switch among threads every cycle
 - Coarse-grained multithreading context switch among threads every few cycles on data hazards, cache misses, etc.
- CDC 6600 (Cray, 1964)
 - For peripheral processing unit
- HEP (Burton Smith, 1982)
 - First commercial hardware-threading for CPU
- Tera MTA (1990)







Vertical Multithreading (contd.)









Simultaneous Multithreading (SMT)


- Selects instructions for execution from all threads on each cycle
 - Remove both horizontal and vertical waste
 - To more fully utilize the issue width
- Superscalar processors already have many HW mechanisms to support multithreading
- Hyper-threading (Intel)
- IBM Power 5






Homogeneous Multicores









Multiprocessor


Uniprocessor CPU with simultaneous multithreading



Multicore CPU with private caches



Multicore CPU with a shared cache



Multicore CPU with simultaneous multithreading

20