TODO:

• Buy physical copy of Elektrotechnik - Albach

Uebungsgruppe Polybox: https://polybox.ethz.ch/index.php/s/TovEOAu8zo6xh0p

Surface / Volume Integration nudge factors:

Cylindrical coordinate system: r

Spherical coordinate system: $r^2 \sin(\vartheta)$ (where ϑ is the angle from the z axis)

Das Coulomb'sche Gesetz

$$\overrightarrow{F_2} = \frac{Q_1 Q_2 \overrightarrow{e_{12}}}{4\pi\varepsilon_0 |\overrightarrow{r_{12}}|^2}$$

Das elektrostatische Feld

Zum Beispiel: Elektrische, magnetisch

- Distance is from centre of point charge
- A positive test charge of 1C is used to plot electric fields this means a positive charge has arrows away from it
- Unit vector is always $rac{ec{r}_{12}}{|r|}=ec{e}_{12}$

Feld - die eigenschaften eines Raums, die eine Wirkung auf andere Ladungsstoffen haben Homogene Feld - Field with the same strength and direction in all points. In reality it exists only when zooming in on a small area. Antonym: inhomogene / ortsabhaengige Feld.

$$\vec{E} = \frac{\vec{F}}{Q_2}$$

Um die Kraft in einer gewisse Punkt im Raum zu finden, man muss die Ladung mit dem Feld an diesem Punkt multiplizieren.

Any point in a field always has a unique direction. The electric field at the point exactly between two like charges is 0 as they cancel each other out.

Quantitative - Numbers based

Qualitative - Interpretation based

Das elektrostastische Potential

$$\vec{F} = \vec{E}Q$$

$$W_e = -\int_{P_0}^{P_1} \vec{F} \cdot d\vec{s} = -Q \int_{P_0}^{P_1} \vec{E} \cdot d\vec{s}$$

The work done as a positive charge moves towards another positive is negative, as external energy is needed in order to overcome the repulsive force.

 ϕ - Closed integral, when a line begins and ends at the same point in space.

Provided the speed as the charge moves through the field tends towards 0 (to minimize the arising electromagnetic field):

$$\oint_C \vec{E} \cdot d\vec{s} = 0$$

Electrostatic potential is the work needed per unit of charge to move it between two points.

$$\varphi = \frac{W_e}{Q}$$

A reference potential (ground) must always be defined, often the Earth's surface / an infinitely far away point is taken as $\varphi_e = 0$. In a circuit, the negative terminal is often used.

Taking r_1 as an infinitely far away point with potential 0, the electrostatic potential in the space surrounding a point charge Q as a scalar is:

$$\varphi(r_2) = \frac{Q}{4\pi\varepsilon_0 r_2}$$

The change in electrostatic potential does not depend on the path taken through the field, only the start and end point.

$$W_e = -Q \int_{P_0}^{P_1} \vec{E} \cdot \vec{s} = Q \left[\varphi_{e(P_1)} - \varphi_{e(P_0)} \right] \label{eq:We}$$

Voltage (*U*) - Difference between two potentials with the same reference potential.

$$U_{12}=\varphi(P_1)-\varphi(P_2)=\int_{P_1}^{P_2} \vec{E}\cdot d\vec{s}$$

Elektrische Fluss (Flux)

TODO: Reread Anhang C to understand where the name Fluss comes from

Elektrische Flussdichte (aka elektrische Erregung): How the electric field interacts with a material at a point in space. TODO: Expand after learning about permittivity.

$$\vec{D} = \varepsilon_0 \vec{E} = \vec{e_r} \frac{Q}{4\pi r^2}$$

Elektrische Fluss (Ψ) - Total flux density flowing through a surface. In the case of a charge inside an arbitrary closed surface, it is equal to Q regardless of the charges position / size of the surface.

Electric Flux Density, considering a charge Q inside a sphere with radius r:

$$r = \text{constant}$$

$$\Psi \coloneqq \oiint \vec{D} \cdot d\vec{A}$$

Nudge factor needed for spherical coordinate system

$$\begin{split} &= \int_0^{2\pi} \int_0^\pi r^2 \sin(\vartheta) \varepsilon_0 \overline{E(r,\vartheta,\varphi)} \cdot d\vartheta d\varphi \\ &= \frac{\varepsilon_0 Q r^2}{4\pi \varepsilon_0 r^2} \int_0^{2\pi} \int_0^\pi \sin(\vartheta) \vec{e_r} \cdot d\vartheta d\varphi \\ \vec{e_r} \cdot d\vartheta d\varphi \text{ is 1, as they are always parallel.} \end{split}$$

$$\begin{split} &= \frac{Q}{4\pi} \int_0^{2\pi} (-\cos(\pi)) - (-\cos(0)) d\varphi = \frac{Q}{4\pi} \int_0^{2\pi} 2d\varphi \\ &= \frac{Q}{4\pi} ((4\pi) - (0)) = \frac{4\pi Q}{4\pi} = Q \end{split}$$

¹Derivation in Elektrotechnik, Albach 1.8.1

Gauss'sche Gesetz