

# **CUDA Math API**

API Reference Manual

## Table of Contents

Chapter 1. Modules	1
1.1. FP8 Intrinsics	2
FP8 Conversion and Data Movement	2
C++ struct for handling fp8 data type of e5m2 kind	2
C++ struct for handling vector type of two fp8 values of e5m2 kind	2
C++ struct for handling vector type of four fp8 values of e5m2 kind	3
C++ struct for handling fp8 data type of e4m3 kind	3
C++ struct for handling vector type of two fp8 values of e4m3 kind	3
C++ struct for handling vector type of four fp8 values of e4m3 kind	3
1.1.1. FP8 Conversion and Data Movement	3
nv_fp8_interpretation_t	3
nv_saturation_t	3
nv_fp8_storage_t	4
nv_fp8x2_storage_t	4
nv_fp8x4_storage_t	4
nv_cvt_bfloat16raw2_to_fp8x2	4
nv_cvt_bfloat16raw_to_fp8	4
nv_cvt_double2_to_fp8x2	5
nv_cvt_double_to_fp8	5
nv_cvt_float2_to_fp8x2	6
nv_cvt_float_to_fp8	
nv_cvt_fp8_to_halfraw	
nv_cvt_fp8x2_to_halfraw2	
nv_cvt_halfraw2_to_fp8x2	
nv_cvt_halfraw_to_fp8	8
1.1.2. C++ struct for handling fp8 data type of e5m2 kind	
nv_fp8_e5m2	
nv_fp8_e5m2::x	
nv_fp8_e5m2::nv_fp8_e5m2	
nv fp8 e5m2:: nv fp8 e5m2	10

nv_fp8_e5m2::nv_fp8_e5m2	10
nv_fp8_e5m2::nv_fp8_e5m2	
nv_fp8_e5m2::nv_fp8_e5m2	10
nv_fp8_e5m2::operatorhalf	10
nv_fp8_e5m2::operatornv_bfloat16	11
nv_fp8_e5m2::operator bool	11
nv_fp8_e5m2::operator double	11
nv_fp8_e5m2::operator float	11
nv_fp8_e5m2::operator int	
nv_fp8_e5m2::operator long long int	11
nv_fp8_e5m2::operator short int	12
nv_fp8_e5m2::operator signed char	12
nv_fp8_e5m2::operator unsigned char	12
nv_fp8_e5m2::operator unsigned int	12
nv_fp8_e5m2::operator unsigned long long int	12
nv_fp8_e5m2::operator unsigned short int	13
1.1.3. C++ struct for handling vector type of two fp8 values of e5m2 kind	13
nv_fp8x2_e5m2	13
nv_fp8x2_e5m2::x	13
nv_fp8x2_e5m2::nv_fp8x2_e5m2	13
nv_fp8x2_e5m2::nv_fp8x2_e5m2	13
nv_fp8x2_e5m2::nv_fp8x2_e5m2	14
nv_fp8x2_e5m2::nv_fp8x2_e5m2	14
nv_fp8x2_e5m2::nv_fp8x2_e5m2	14
nv_fp8x2_e5m2::operatorhalf2	14
nv_fp8x2_e5m2::operator float2	14
1.1.4. C++ struct for handling vector type of four fp8 values of e5m2 kind	14
nv_fp8x4_e5m2	15
nv_fp8x4_e5m2::x	15
nv_fp8x4_e5m2::nv_fp8x4_e5m2	
nv_fp8x4_e5m2::nv_fp8x4_e5m2	15
nv_fp8x4_e5m2::nv_fp8x4_e5m2	15
nv_fp8x4_e5m2::nv_fp8x4_e5m2	15
nv_fp8x4_e5m2::nv_fp8x4_e5m2	
nv_fp8x4_e5m2::operator float4	
1.1.5. C++ struct for handling fp8 data type of e4m3 kind	16
nv_fp8_e4m3	16
nv fp8 e4m3:: x	16

nv_fp8_e4m3::nv_fp8_e4m3	16
nv_fp8_e4m3::nv_fp8_e4m3	16
nv_fp8_e4m3::nv_fp8_e4m3	17
nv_fp8_e4m3::nv_fp8_e4m3	18
nv_fp8_e4m3::operatorhalf	18
nv_fp8_e4m3::operatornv_bfloat16	18
nv_fp8_e4m3::operator bool	19
nv_fp8_e4m3::operator double	19
nv_fp8_e4m3::operator float	19
nv_fp8_e4m3::operator int	19
nv_fp8_e4m3::operator long long int	19
nv_fp8_e4m3::operator short int	19
nv_fp8_e4m3::operator signed char	20
nv_fp8_e4m3::operator unsigned char	20
nv_fp8_e4m3::operator unsigned int	20
nv_fp8_e4m3::operator unsigned long long int	20
nv_fp8_e4m3::operator unsigned short int	20
1.1.6. C++ struct for handling vector type of two fp8 values of e4m3 kind	21
nv_fp8x2_e4m3	21
nv_fp8x2_e4m3::x	21
nv_fp8x2_e4m3::nv_fp8x2_e4m3	22
nv_fp8x2_e4m3::nv_fp8x2_e4m3	22
nv_fp8x2_e4m3::operatorhalf2	22
nv_fp8x2_e4m3::operator float2	22
1.1.7. C++ struct for handling vector type of four fp8 values of e4m3 kind	22
nv_fp8x4_e4m3	22
nv_fp8x4_e4m3::x	22
ny fn8x4 e4m3·· ny fn8x4 e4m3	23

nv_fp8x4_e4m3::nv_fp8x4_e4m3	23
nv_fp8x4_e4m3::nv_fp8x4_e4m3	23
nv_fp8x4_e4m3::nv_fp8x4_e4m3	23
nv_fp8x4_e4m3::nv_fp8x4_e4m3	23
nv_fp8x4_e4m3::operator float4	23
1.2. Half Precision Intrinsics	24
Half Arithmetic Functions	24
Half2 Arithmetic Functions	24
Half Comparison Functions	24
Half2 Comparison Functions	24
Half Precision Conversion and Data Movement	24
Half Math Functions	24
Half2 Math Functions	24
1.2.1. Half Arithmetic Functions	24
habs	25
hadd	25
hadd_rn	25
hadd_sat	25
hdiv	26
hfma	26
hfma_relu	26
hfma_sat	27
hmul	27
hmul_rn	28
hmul_sat	28
hneg	
hsub	28
hsub_rn	29
hsub_sat	29
atomicAdd	29
1.2.2. Half2 Arithmetic Functions	30
h2div	30
habs2	30
hadd2	31
hadd2_rn	31
hadd2_sat	31
hcmadd	32
hfma?	22

hfma2_relu	32
hfma2_sat	
hmul2	34
hmul2_rn	34
hmul2_sat	34
hneg2	35
hsub2	35
hsub2_rn	35
hsub2_sat	
atomicAdd	
.2.3. Half Comparison Functions	36
heq	
hequ	
hge	
hgeu	
hgt	
s hgtu	
hisinf	
hisnan	
hle	
hleu	
 hlt	
 hltu	
 hmax	
hmax_nan	
hmin	
 hmin_nan	
hne	
hneu	
hbeq2	
hbequ2	
hbge2	
hbgeu2	
hbgt2	
hbgtu2	
hble2	
hblou?	47

hblt2	48
hbltu2	49
hbne2	49
hbneu2	50
heq2	50
heq2_mask	51
hequ2	51
hequ2_mask	52
hge2	52
hge2_mask	53
hgeu2	53
hgeu2_mask	54
hgt2	54
hgt2_mask	55
hgtu2	55
hgtu2_mask	56
hisnan2	56
hle2	56
hle2_mask	57
hleu2	57
hleu2_mask	58
hlt2	58
hlt2_mask	59
hltu2	59
hltu2_mask	60
hmax2	60
hmax2_nan	61
hmin2	61
hmin2_nan	61
hne2	62
hne2_mask	62
hneu2	63
hneu2_mask	63
1.2.5. Half Precision Conversion and Data Movement	64
double2half	64
float22half2_rn	64
float2half	65
float?half? rn	45

float2half_rd	65
float2half_rn	66
float2half_ru	66
float2half_rz	67
floats2half2_rn	67
half22float2	68
half2float	68
half2half2	68
half2int_rd	69
half2int_rn	69
half2int_ru	70
half2int_rz	70
half2ll_rd	70
half2ll_rn	71
half2ll_ru	71
half2ll_rz	72
half2short_rd	72
half2short_rn	72
half2short_ru	73
half2short_rz	73
half2uint_rd	74
half2uint_rn	74
half2uint_ru	75
half2uint_rz	75
half2ull_rd	75
half2ull_rn	76
half2ull_ru	76
half2ull_rz	77
half2ushort_rd	77
half2ushort_rn	78
half2ushort_ru	78
half2ushort_rz	79
half_as_short	79
half_as_ushort	
halves2half2	
high2float	80
high2half	
high?half?	81

_	_highs2half2	. 82
_	_int2half_rd	.82
	_int2half_rn	83
	_int2half_ru	83
	_int2half_rz	. 83
	_ldca	.84
_	_ldca	.84
_	_ldcg	.84
_	_ldcg	.85
_	_ldcs	.85
	_ldcs	.85
	_ldcv	. 85
	_ldcv	. 86
	_ldg	.86
_	_ldg	.86
	_ldlu	. 86
_	_ldlu	. 87
_	_ll2half_rd	.87
_	_ll2half_rn	.87
_	_ll2half_ru	.88
_	_ll2half_rz	. 88
_	_low2float	89
_	_low2half	.89
_	_low2half2	.89
_	_lowhigh2highlow	.90
_	_lows2half2	. 90
_	_shfl_down_sync	. 91
_	_shfl_down_sync	. 92
_	_shfl_sync	. 93
_	_shfl_sync	. 93
	_shfl_up_sync	. 94
	_shfl_up_sync	. 95
	_shfl_xor_sync	.96
	 _shfl_xor_sync	
	 _short2half_rd	
	 _short2half_rn	
	 _short2half_ru	
	short2half_rz	99

short_as_half	99
stcg	100
stcg	100
stcs	100
stcs	100
stwb	101
stwb	101
stwt	101
stwt	101
uint2half_rd	102
uint2half_rn	102
uint2half_ru	102
uint2half_rz	103
ull2half_rd	103
ull2half_rn	104
ull2half_ru	104
ull2half_rz	105
ushort2half_rd	105
ushort2half_rn	106
ushort2half_ru	106
ushort2half_rz	107
ushort_as_half	107
1.2.6. Half Math Functions	107
hceil	108
hcos	108
hexp	108
hexp10	109
hexp2	109
hfloor	109
hlog	110
hlog10	110
hlog2	111
hrcp	111
hrint	
hrsqrthrsqrt	112
hsin	
hsqrt	
htrunc	

1.2.7. Half2 Math Functions	113
h2ceil	114
h2cos	114
h2exph	114
h2exp10	115
h2exp2	115
h2floor	116
h2log	116
h2log10	116
h2log2	117
h2rcp	117
h2rint	118
h2rsqrt	118
h2sin	118
h2sqrt	119
h2trunc	119
1.3. Bfloat16 Precision Intrinsics	119
Bfloat16 Arithmetic Functions	120
Bfloat162 Arithmetic Functions	120
Bfloat16 Comparison Functions	120
Bfloat162 Comparison Functions	120
Bfloat16 Precision Conversion and Data Movement	
Bfloat16 Math Functions	120
Bfloat162 Math Functions	120
1.3.1. Bfloat16 Arithmetic Functions	120
h2div	121
habs	121
 hadd	121
 hadd_rn	121
hadd_sat	122
hdiv	122
 hfma	
 hfma_relu	123
 hfma_sat	
 hmul	
 hmul_rn	
 hneg	

hsub	125
hsub_rn	125
hsub_sat	125
atomicAdd	126
1.3.2. Bfloat162 Arithmetic Functions	126
habs2	127
hadd2	127
hadd2_rn	127
hadd2_sat	128
hcmadd	128
hfma2	129
hfma2_relu	129
hfma2_sat	130
hmul2	130
hmul2_rn	131
hmul2_sat	131
hneg2	131
hsub2	132
hsub2_rn	132
hsub2_sat	132
atomicAdd	132
1.3.3. Bfloat16 Comparison Functions	133
heq	133
hequ	134
hge	134
hgeu	135
hgt	135
hgtu	136
hisinf	136
hisnan	137
hle	137
hleu	138
hlt	138
 hltu	139
 hmax	139
 hmax_nan	139
 hmin	
— hmin nan	140

hne	140
hneu	141
1.3.4. Bfloat162 Comparison Functions	141
hbeq2	141
hbequ2	142
hbge2	142
hbgeu2	143
hbgt2	144
hbgtu2	144
hble2	145
hbleu2	145
hblt2	146
hbltu2	147
hbne2	147
hbneu2	148
heq2	148
heq2_mask	149
hequ2	149
hequ2_mask	150
hge2	150
hge2_mask	151
hgeu2	151
hgeu2_mask	152
hgt2	
hgt2_mask	153
hgtu2	153
hgtu2_mask	154
hisnan2	154
hle2	155
hle2_mask	155
hleu2	156
hleu2_mask	156
hlt2	157
hlt2_mask	157
hltu2	158
hltu2_mask	158
hmax2	159
hmax2 nan	

hmin2	160
hmin2_nan	160
hne2	160
hne2_mask	161
hneu2	161
hneu2_mask	162
1.3.5. Bfloat16 Precision Conversion and Data Movement	162
bfloat1622float2	162
bfloat162bfloat162	163
bfloat162float	163
bfloat162int_rd	164
bfloat162int_rn	164
bfloat162int_ru	164
bfloat162int_rz	165
bfloat162ll_rd	165
bfloat162ll_rn	166
bfloat162ll_ru	166
bfloat162ll_rz	167
bfloat162short_rd	167
bfloat162short_rn	168
bfloat162short_ru	168
bfloat162short_rz	169
bfloat162uint_rd	169
bfloat162uint_rn	170
bfloat162uint_ru	170
bfloat162uint_rz	171
bfloat162ull_rd	171
bfloat162ull_rn	172
bfloat162ull_ru	172
bfloat162ull_rz	173
bfloat162ushort_rd	173
bfloat162ushort_rn	174
bfloat162ushort_ru	174
bfloat162ushort_rz	175
bfloat16_as_short	175
bfloat16_as_ushort	176
double2bfloat16	176
float22bfloat162 rn	

_	_float2bfloat16	177
	_float2bfloat162_rn	178
	_float2bfloat16_rd	178
	_float2bfloat16_rn	179
_	_float2bfloat16_ru	179
_	_float2bfloat16_rz	.180
	_floats2bfloat162_rn	.180
_	_halves2bfloat162	.181
_	_high2bfloat16	181
_	_high2bfloat162	182
	_high2float	182
	_highs2bfloat162	183
	_int2bfloat16_rd	.183
_	_int2bfloat16_rn	.184
	_int2bfloat16_ru	.184
	_int2bfloat16_rz	. 184
	_ldca	. 185
	_ldca	. 185
	 _ldcg	.185
	_ldcg	.186
	ldcs	. 186
	_ldcs	. 186
	_ldcv	186
	ldcv	187
	 _ldg	
	_ldg	.187
		187
	 ldlu	188
	 ll2bfloat16_rd	.188
	 _ll2bfloat16_rn	
	 ll2bfloat16_rz	
	 low2bfloat16	
	 low2bfloat162	
	low2float	
	 _lowhigh2highlow	
_	_lows2bfloat162	
_	shfl down sync	

shfl_down_sync	193
shfl_sync	
shfl_sync	195
shfl_up_sync	196
shfl_up_sync	197
shfl_xor_sync	198
shfl_xor_sync	199
short2bfloat16_rd	200
short2bfloat16_rn	200
short2bfloat16_ru	201
short2bfloat16_rz	201
short_as_bfloat16	202
stcg	
stcg	202
stcs	203
stcs	203
stwb	203
stwb	203
stwt	204
stwt	204
uint2bfloat16_rd	204
uint2bfloat16_rn	205
uint2bfloat16_ru	205
uint2bfloat16_rz	206
ull2bfloat16_rd	206
ull2bfloat16_rn	207
ull2bfloat16_ru	207
ull2bfloat16_rz	208
ushort2bfloat16_rd	208
ushort2bfloat16_rn	209
ushort2bfloat16_ru	209
ushort2bfloat16_rz	210
ushort_as_bfloat16	210
.3.6. Bfloat16 Math Functions	210
hceil	211
hcos	211
hexp	211
hexp10	212

hexp2	212
hfloor	213
hlog	213
hlog10	213
hlog2	214
hrcp	214
hrint	214
hrsqrt	215
hsin	215
hsqrt	216
htrunc	216
1.3.7. Bfloat162 Math Functions	216
h2ceil	217
h2cos	217
h2exp	217
h2exp10	218
h2exp2	218
h2floor	219
h2log	219
h2log10	219
h2log2	220
h2rcp	220
h2rint	221
h2rsqrt	221
h2sin	221
h2sqrt	222
h2trunc	222
1.4. Mathematical Functions	223
1.5. Single Precision Mathematical Functions	223
acosf	223
acoshf	224
asinf	224
asinhf	225
atan2f	225
atanf	226
atanhf	226
cbrtf	227
ceilf	227

copysignf	228
cosf	228
coshf	228
cospif	229
cyl_bessel_i0f	229
cyl_bessel_i1f	
erfcf	230
erfcinvf	230
erfcxf	231
erff	231
erfinvf	232
exp10f	232
exp2f	233
expf	233
expm1f	234
fabsffabsf	234
fdimf	235
fdividef	235
floorf	236
fmaf	236
fmaxf	237
fminf	237
fmodf	238
frexpf	238
hypotf	239
ilogbf	239
isfinite	240
isinf	240
isnan	241
Of	241
1f	241
inf	242
ldexpf	242
lgammaf	. 243
Urintf	243
llroundf	
log10f	
log1nf	245

og2f	. 245
ogbf	. 246
ogf	. 246
rintf	. 247
roundf	. 247
max	. 247
min	. 248
nodff	248
nanf	. 248
nearbyintf	249
nextafterf	. 249
norm3df	. 250
norm4df	. 250
normcdff	. 251
normcdfinvf	251
normf	. 252
oowf	. 252
-cbrtf	. 253
remainderf	254
remquof	. 254
-hypotf	255
rintf	. 255
norm3df	256
norm4df	256
normf	257
oundf	. 257
rsqrtf	. 258
scalblnf	. 258
scalbnf	. 258
signbit	
sincosf	259
sincospif	260
sinf	. 260
sinhf	. 261
sinpif	
sqrtf	
anf	
ranhf	263

tgammaf	263
truncf	264
y0f	264
y1f	264
ynf	
1.6. Double Precision Mathematical Functions	266
acos	266
acosh	266
asin	267
asinh	267
atan	268
atan2	268
atanh	269
cbrt	269
ceil	270
copysign	270
COS	270
cosh	271
cospi	271
cyl_bessel_i0	272
cyl_bessel_i1	272
erf	272
erfc	273
erfcinv	273
erfcx	
erfinv	
exp	
exp10	
exp2	
expm1	
fabs	
fdim	
floor	
fma	
fmax	
fmin	
fmod	
frexn	280

nypot	281
logb	281
sfinitesfinite	282
sinf	282
snan	283
0	283
1	283
n	284
dexp	284
gamma	285
lrint	285
lround	286
og	286
og10	286
og1p	287
og2	287
ogb	288
rint	288
round	289
max	289
max	
max	
min	
min	
min	
nodf	
nan	291
nearbyint	
nextafter	
norm	
norm3d	
norm4d	
normcdf	
normcdfinv	
00W	
rcbrt	
remainder	
remquo	

rhypot	297
rint	298
rnorm	298
rnorm3d	299
rnorm4d	299
round	300
rsqrt	300
scalbln	301
scalbn	301
signbit	301
sin	302
sincos	302
sincospi	303
sinh	303
sinpi	304
sqrt	304
tan	305
tanh	305
tgamma	305
trunc	306
y0	306
y1	307
yn	307
1.7. Integer Mathematical Functions	308
abs	308
labs	308
llabs	308
llmax	309
llmin	309
max	309
max	309
max	310
max	
max	
max	310
max	
max	
max	311

max	311
max	311
max	311
min	312
min	313
min	314
min	314
min	314
ullmax	314
ullmin	314
umax	315
umin	315
1.8. Single Precision Intrinsics	315
cosf	315
exp10f	316
expf	316
fadd_rd	316
fadd_rn	317
fadd_ru	317
fadd_rz	318
fdiv_rd	318
fdiv_rn	318
fdiv_ru	319
fdiv_rz	319
fdividef	319
fmaf_ieee_rd	320
fmaf_ieee_rn	320
fmaf_ieee_ru	320
fmaf_ieee_rz	321
fmaf_rd	321
fmaf rn	321

fmaf_ru	322
fmaf_rz	
fmul_rd	323
fmul_rn	323
fmul_ru	324
fmul_rz	324
frcp_rd	325
frcp_rn	325
frcp_ru	325
frcp_rz	
frsqrt_rn	326
fsqrt_rd	327
fsqrt_rn	
fsqrt_ru	327
fsqrt_rz	328
fsub_rd	328
fsub_rn	329
fsub_ru	329
fsub_rz	329
log10f	330
log2f	330
logf	331
powf	331
saturatef	331
sincosf	332
sinf	332
tanf	333
1.9. Double Precision Intrinsics	333
dadd_rd	333
dadd_rn	334
dadd_ru	334
dadd_rz	334
ddiv_rd	335
ddiv_rn	335
ddiv_ru	
ddiv_rz	336
dmul_rd	
dmul rn	337

dmul_ru	
dmul_rz	338
drcp_rd	338
drcp_rn	
drcp_ru	339
drcp_rz	339
dsqrt_rd	340
dsqrt_rn	340
dsqrt_ru	341
dsqrt_rz	341
dsub_rd	342
dsub_rn	342
dsub_ru	342
dsub_rz	343
fma_rd	343
fma_rn	344
fma_ru	344
fma_rz	345
.10. Integer Intrinsics	346
brev	346
brevll	346
byte_perm	346
clz	347
clzll	347
ffs	347
ffsll	348
funnelshift_l	348
funnelshift_lc	348
funnelshift_r	349
funnelshift_rc	349
hadd	349
mul24	350
mul64hi	350
mulhi	350
popc	
popcll	
rhadd	
cad	351

uhadd	352
umul24	352
umul64hi	352
umulhi	353
urhadd	353
usad	353
1.11. Type Casting Intrinsics	354
double2float_rd	354
double2float_rn	354
double2float_ru	354
double2float_rz	355
double2hiint	355
double2int_rd	355
double2int_rn	356
double2int_ru	356
double2int_rz	356
double2ll_rd	356
double2ll_rn	357
double2ll_ru	357
double2ll_rz	357
double2loint	358
double2uint_rd	358
double2uint_rn	358
double2uint_ru	358
double2uint_rz	359
double2ull_rd	359
double2ull_rn	359
double2ull_ru	360
double2ull_rz	360
double_as_longlong	360
float2int_rd	361
float2int_rn	361
float2int_ru	361
float2int_rz	361
float2ll_rd	362
float2ll_rn	362
float2ll_ru	362
floatall ra	242

float2uint_rd	363
float2uint_rn	
float2uint_ru	363
float2uint_rz	
float2ull_rd	364
float2ull_rn	364
float2ull_ru	365
float2ull_rz	365
float_as_int	
float_as_uint	365
hiloint2double	366
int2double_rn	366
int2float_rd	366
int2float_rn	367
int2float_ru	367
int2float_rz	367
int_as_float	367
ll2double_rd	368
ll2double_rn	
ll2double_ru	
ll2double_rz	369
ll2float_rd	
ll2float_rn	369
ll2float_ru	369
ll2float_rz	370
longlong_as_double	370
uint2double_rn	370
uint2float_rd	371
uint2float_rn	371
uint2float_ru	371
uint2float_rz	371
uint_as_float	372
ull2double_rd	
ull2double_rn	372
ull2double_ru	373
ull2double_rz	373
ull2float_rd	373
ull?float rp	27/.

ull2float_ru	374
ull2float_rz	374
1.12. SIMD Intrinsics	375
vabs2	375
vabs4	375
vabsdiffs2	375
vabsdiffs4	376
vabsdiffu2	376
vabsdiffu4	376
vabsss2	377
vabsss4	377
vadd2	377
vadd4	378
vaddss2	378
vaddss4	378
vaddus2	379
vaddus4	379
vavgs2	379
vavgs4	
vavgu2	380
vavgu4	380
vcmpeq2	381
vcmpeq4	381
vcmpges2	381
vcmpges4	382
vcmpgeu2	382
vcmpgeu4	382
vcmpgts2	383
vcmpgts4	383
vcmpgtu2	383
vcmpgtu4	
vcmples2	384
vcmples4	384
vcmpleu2	
vcmpleu4	
vcmplts2	
vcmplts4	
vempltu?	204

386
387
387
387
388
388
388
389
389
389
390
390
390
391
391
391
392
392
392
393
393
394
394
394
395
395
396
396
396
397
397
397
398
398
398
399
399
399

vimin3_u32	400
vimin_s16x2_relu	400
vimin_s32_relu	400
vmaxs2	401
vmaxs4	401
vmaxu2	401
vmaxu4	402
vmins2	402
vmins4	402
vminu2	403
vminu4	403
vneg2	403
vneg4	404
vnegss2	404
vnegss4	404
vsads2	404
vsads4	405
vsadu2	405
vsadu4	
vseteq2	406
vseteq4	
vsetges2	
vsetges4	
vsetgeu2	
vsetgeu4	
vsetgts2	
vsetgts4	
vsetgtu2	
vsetqtu4	
vsetles2	
vsetles4	
vsetleu2	
vsetleu4	
vsetlts2	
vsetlts4	
vsetltu2	
vsetttu2vsetttu4	
vsetno?	411

vsetne4	412
vsub2	412
vsub4	413
vsubss2	413
vsubss4	413
vsubus2	414
vsubus4	414
Chapter 2. Data Structures	415
nv_fp8_e4m3	
X	415
nv_fp8_e4m3	415
nv_fp8_e4m3	416
nv_fp8_e4m3	417
operatorhalf	417
operatornv_bfloat16	418
operator bool	418
operator double	418
operator float	418
operator int	418
operator long long int	418
operator short int	418
operator signed char	419
operator unsigned char	419
operator unsigned int	419
operator unsigned long long int	419
operator unsigned short int	419
nv_fp8_e5m2	419
x	420
nv_fp8_e5m2	420
ny fn9 a5m2	/.20

nv_fp8_e5m2	420
nv_fp8_e5m2	420
nv_fp8_e5m2	420
nv_fp8_e5m2	421
operatorhalf	
operatornv_bfloat16	422
operator bool	422
operator double	422
operator float	422
operator int	422
operator long long int	423
operator short int	423
operator signed char	423
operator unsigned char	423
operator unsigned int	423
operator unsigned long long int	423
operator unsigned short int	424
_nv_fp8x2_e4m3	424
x	424
nv_fp8x2_e4m3	425
nv_fp8x2_e4m3	425
operatorhalf2	
operator float2	425
_nv_fp8x2_e5m2	425
x	425
nv_fp8x2_e5m2	425
nv_fp8x2_e5m2	426
nv_fp8x2_e5m2	426
nv_fp8x2_e5m2	426
ny fn8v2 a5m2	424

operatorhalf2	
operator float2	426
nv_fp8x4_e4m3	427
x	427
nv_fp8x4_e4m3	
nv_fp8x4_e4m3	427
nv_fp8x4_e4m3	427
nv_fp8x4_e4m3	427
nv_fp8x4_e4m3	428
operator float4	428
nv_fp8x4_e5m2	428
x	428
nv_fp8x4_e5m2	428
nv_fp8x4_e5m2	428
nv_fp8x4_e5m2	429
nv_fp8x4_e5m2	429
nv_fp8x4_e5m2	429
operator float4	429
Chapter 3. Data Fields	430

CUDA Math API vRelease Version | xxxiv

# Chapter 1. Modules

#### Here is a list of all modules:

- ► FP8 Intrinsics
  - ► FP8 Conversion and Data Movement
  - C++ struct for handling fp8 data type of e5m2 kind.
  - C++ struct for handling vector type of two fp8 values of e5m2 kind.
  - ► C++ struct for handling vector type of four fp8 values of e5m2 kind.
  - C++ struct for handling fp8 data type of e4m3 kind.
  - ► C++ struct for handling vector type of two fp8 values of e4m3 kind.
  - ► C++ struct for handling vector type of four fp8 values of e4m3 kind.
- Half Precision Intrinsics
  - ► Half Arithmetic Functions
  - Half2 Arithmetic Functions
  - Half Comparison Functions
  - Half2 Comparison Functions
  - Half Precision Conversion and Data Movement
  - Half Math Functions
  - Half2 Math Functions
- Bfloat16 Precision Intrinsics
  - Bfloat16 Arithmetic Functions
  - Bfloat162 Arithmetic Functions
  - Bfloat16 Comparison Functions
  - Bfloat162 Comparison Functions
  - Bfloat16 Precision Conversion and Data Movement

CUDA Math API vRelease Version | 1

- ▶ Bfloat16 Math Functions
- ▶ Bfloat162 Math Functions
- Mathematical Functions
- Single Precision Mathematical Functions
- Double Precision Mathematical Functions
- ► Integer Mathematical Functions
- Single Precision Intrinsics
- Double Precision Intrinsics
- Integer Intrinsics
- Type Casting Intrinsics
- SIMD Intrinsics

## 1.1. FP8 Intrinsics

This section describes fp8 intrinsic functions. To use these functions, include the header file cuda\_fp8.h in your program. The following macros are available to help users selectively enable/disable various definitions present in the header file:

- \_\_CUDA\_NO\_FP8\_CONVERSIONS\_\_ If defined, this macro will prevent any use of the C++ type conversions (converting constructors and conversion operators) defined in the header.
- \_\_CUDA\_NO\_FP8\_CONVERSION\_OPERATORS\_\_ If defined, this macro will prevent any use of the C++ conversion operators from fp8 to other types.

### FP8 Conversion and Data Movement

C++ struct for handling fp8 data type of e5m2 kind.

C++ struct for handling vector type of two fp8 values of e5m2 kind.

CUDA Math API vRelease Version | 2

C++ struct for handling vector type of four fp8 values of e5m2 kind.

C++ struct for handling fp8 data type of e4m3 kind.

C++ struct for handling vector type of two fp8 values of e4m3 kind.

C++ struct for handling vector type of four fp8 values of e4m3 kind.

## 1.1.1. FP8 Conversion and Data Movement

FP8 Intrinsics

To use these functions, include the header file cuda fp8.h in your program.

## enum nv fp8 interpretation t

Enumerates the possible interpretations of the 8-bit values when referring to them as fp8 types.

#### **Values**

#### \_\_NV\_E4M3

Stands for fp8 numbers of e4m3 kind.

NV\_E5M2

Stands for fp8 numbers of e5m2 kind.

## enum nv saturation t

Enumerates the modes applicable when performing a narrowing conversion to £p8 destination types.

#### **Values**

#### NV NOSAT

Means no saturation to finite is performed when conversion results in rounding values outside the range of destination type. NOTE: for fp8 type of e4m3 kind, the results that are larger than the maximum representable finite number of the target format become NaN.

**NV SATFINITE** 

Means input larger than the maximum representable finite number MAXNORM of the target format round to the MAXNORM of the same sign as input.

## typedef unsigned char \_\_nv\_fp8\_storage\_t

8-bit unsigned integer type abstraction used to for fp8 floating-point numbers storage.

## typedef unsigned short int \_\_nv\_fp8x2\_storage\_t

16-bit unsigned integer type abstraction used to for storage of pairs of fp8 floating-point numbers.

## typedef unsigned int \_\_nv\_fp8x4\_storage\_t

32-bit unsigned integer type abstraction used to for storage of tetrads of fp8 floating-point numbers.

```
__host____device____nv_fp8x2_storage_t
__nv_cvt_bfloat16raw2_to_fp8x2 (const __nv_bfloat162_raw
x, const __nv_saturation_t saturate, const
__nv_fp8_interpretation_t fp8_interpretation)
```

Converts input vector of two nv\_bfloat16 precision numbers packed in \_\_nv\_bfloat162\_raw x into a vector of two values of fp8 type of the requested kind using round-to-nearest-even rounding and requested saturation mode.

#### Returns

► The \_\_nv\_fp8x2\_storage\_t value holds the result of conversion.

## Description

Converts input vector  $\mathbf{x}$  to a vector of two fp8 values of the kind specified by fp8\_interpretation parameter, using round-to-nearest-even rounding and saturation mode specified by saturate parameter.

```
__host____device____nv_fp8_storage_t
__nv_cvt_bfloat16raw_to_fp8 (const __nv_bfloat16_raw
x, const __nv_saturation_t saturate, const
__nv_fp8_interpretation_t fp8_interpretation)
```

Converts input  $nv\_bfloat16$  precision x to fp8 type of the requested kind using round-to-nearest-even rounding and requested saturation mode.

#### Returns

▶ The nv fp8 storage t value holds the result of conversion.

### Description

Converts input x to fp8 type of the kind specified by fp8\_interpretation parameter, using round-to-nearest-even rounding and saturation mode specified by saturate parameter.

```
__host____device____nv_fp8x2_storage_t
__nv_cvt_double2_to_fp8x2 (const double2 x, const
__nv_saturation_t saturate, const __nv_fp8_interpretation_t
fp8_interpretation)
```

Converts input vector of two double precision numbers packed in double2  $\mathbf{x}$  into a vector of two values of fp8 type of the requested kind using round-to-nearest-even rounding and requested saturation mode.

#### Returns

► The nv fp8x2 storage t value holds the result of conversion.

## Description

Converts input vector  $\mathbf{x}$  to a vector of two fp8 values of the kind specified by fp8\_interpretation parameter, using round-to-nearest-even rounding and saturation mode specified by saturate parameter.

```
__host____device____nv_fp8_storage_t
__nv_cvt_double_to_fp8 (const double x, const
__nv_saturation_t saturate, const __nv_fp8_interpretation_t
fp8_interpretation)
```

Converts input double precision x to fp8 type of the requested kind using round-to-nearest-even rounding and requested saturation mode.

#### Returns

► The \_\_nv\_fp8\_storage\_t value holds the result of conversion.

## Description

Converts input x to fp8 type of the kind specified by fp8\_interpretation parameter, using round-to-nearest-even rounding and saturation mode specified by saturate parameter.

```
__host____device____nv_fp8x2_storage_t
__nv_cvt_float2_to_fp8x2 (const float2 x, const
__nv_saturation_t saturate, const __nv_fp8_interpretation_t
fp8_interpretation)
```

Converts input vector of two single precision numbers packed in  $float2 \times into$  a vector of two values of fp8 type of the requested kind using round-to-nearest-even rounding and requested saturation mode.

#### Returns

▶ The nv fp8x2 storage t value holds the result of conversion.

## Description

Converts input vector  $\mathbf{x}$  to a vector of two fp8 values of the kind specified by fp8\_interpretation parameter, using round-to-nearest-even rounding and saturation mode specified by saturate parameter.

```
__host____device____nv_fp8_storage_t
__nv_cvt_float_to_fp8 (const float x, const
__nv_saturation_t saturate, const __nv_fp8_interpretation_t
fp8_interpretation)
```

Converts input single precision x to fp8 type of the requested kind using round-to-nearest-even rounding and requested saturation mode.

#### Returns

► The \_\_nv\_fp8\_storage\_t value holds the result of conversion.

## Description

Converts input x to fp8 type of the kind specified by fp8\_interpretation parameter, using round-to-nearest-even rounding and saturation mode specified by saturate parameter.

Converts input fp8 x of the specified kind to half precision.

#### Returns

▶ The half raw value holds the result of conversion.

## Description

Converts input x of fp8 type of the kind specified by fp8\_interpretation parameter to half precision.

```
__host____device__ __half2_raw
__nv_cvt_fp8x2_to_halfraw2 (const __nv_fp8x2_storage_t x,
const __nv_fp8_interpretation_t fp8_interpretation)
```

Converts input vector of two fp8 values of the specified kind to a vector of two half precision values packed in half2 raw structure.

#### Returns

▶ The half2 raw value holds the result of conversion.

## Description

Converts input vector  $\mathbf{x}$  of fp8 type of the kind specified by fp8\_interpretation parameter to a vector of two half precision values and returns as \_\_half2\_raw structure.

```
__host____device____nv_fp8x2_storage_t
__nv_cvt_halfraw2_to_fp8x2 (const __half2_raw x, const
__nv_saturation_t saturate, const __nv_fp8_interpretation_t
fp8_interpretation)
```

Converts input vector of two half precision numbers packed in  $\__half2_raw x$  into a vector of two values of fp8 type of the requested kind using round-to-nearest-even rounding and requested saturation mode.

#### Returns

► The \_\_nv\_fp8x2\_storage t value holds the result of conversion.

### Description

Converts input vector  $\mathbf{x}$  to a vector of two fp8 values of the kind specified by fp8\_interpretation parameter, using round-to-nearest-even rounding and saturation mode specified by saturate parameter.

```
__host____device____nv_fp8_storage_t
__nv_cvt_halfraw_to_fp8 (const __half_raw x, const
__nv_saturation_t saturate, const __nv_fp8_interpretation_t
fp8 interpretation)
```

Converts input half precision x to fp8 type of the requested kind using round-to-nearest-even rounding and requested saturation mode.

#### Returns

► The \_\_nv\_fp8\_storage\_t value holds the result of conversion.

## Description

Converts input x to fp8 type of the kind specified by fp8\_interpretation parameter, using round-to-nearest-even rounding and saturation mode specified by saturate parameter.

## 1.1.2. C++ struct for handling fp8 data type of e5m2 kind.

**FP8 Intrinsics** 

Storage variable contains the fp8 floating-point data.

## Description

Constructor from long long int data type, relies on \_\_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const int val)

## Description

Constructor from int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const short int val)

## Description

Constructor from short int data type.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const unsigned long long int val)

## Description

Constructor from unsigned long long int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const unsigned int val)

## Description

Constructor from unsigned int data type, relies on  $\_\_{NV\_SATFINITE}$  behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const unsigned short int val)

## Description

Constructor from unsigned short int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const double f)

## Description

Constructor from double data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const float f)

## Description

Constructor from float data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const nv bfloat16 f)

## Description

Constructor from \_\_nv\_bfloat16 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::\_\_nv\_fp8\_e5m2 (const half f)

## Description

Constructor from \_\_half data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

nv fp8 e5m2:: nv fp8 e5m2()

## Description

Constructor by default.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator \_\_half ()

## Description

Conversion operator to \_\_half data type.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator \_\_nv\_bfloat16

## Description

Conversion operator to \_\_nv\_bfloat16 data type.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator bool ()

## Description

Conversion operator to bool data type. +0 and -0 inputs convert to false. Non-zero inputs convert to true.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator double ()

## Description

Conversion operator to double data type.

\_\_host\_\_\_\_device\_\_\_nv\_fp8\_e5m2::operator float ()

## Description

Conversion operator to float data type.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator int ()

## **Description**

Conversion operator to int data type. Clamps too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_device\_\_\_nv\_fp8\_e5m2::operator long long int

## Description

Conversion operator to long long int data type. Clamps too large inputs to the output range. NaN inputs convert to 0x8000000000000LL.

\_\_host\_\_\_device\_\_\_nv\_fp8\_e5m2::operator short int ()

## Description

Conversion operator to short int data type. Clamps too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator signed char ()

## Description

Conversion operator to signed char data type. Clamps too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator unsigned char ()

## Description

Conversion operator to unsigned char data type. Clamps negative and too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator unsigned int

## Description

Conversion operator to unsigned int data type. Clamps negative and too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator unsigned long long int ()

## Description

Conversion operator to unsigned long long int data type. Clamps negative and too large inputs to the output range. NaN inputs convert to 0x800000000000000000.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e5m2::operator unsigned short int ()

## Description

Conversion operator to unsigned short int data type. Clamps negative and too large inputs to the output range. NaN inputs convert to zero.

## 1.1.3. C++ struct for handling vector type of two fp8 values of e5m2 kind.

FP8 Intrinsics

Storage variable contains the vector of two fp8 floating-point data values.

## Description

Constructor from double2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

## Description

Constructor from float2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_device\_\_\_nv\_fp8x2\_e5m2::\_\_nv\_fp8x2\_e5m2 (const \_\_nv\_bfloat162 f)

## Description

Constructor from  $\__nv\_bfloat162$  data type, relies on  $\__nv\_satfinite$  behavior for out-of-range values.

\_\_host\_\_\_device\_\_\_\_nv\_fp8x2\_e5m2::\_\_nv\_fp8x2\_e5m2 (const \_\_half2 f)

## Description

Constructor from \_\_half2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_nv\_fp8x2\_e5m2::\_\_nv\_fp8x2\_e5m2 ()

## Description

Constructor by default.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x2\_e5m2::operator \_\_half2 ()

## Description

Conversion operator to  $\_\_$ half2 data type.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x2\_e5m2::operator float2 ()

## Description

Conversion operator to float2 data type.

1.1.4. C++ struct for handling vector type of four fp8 values of e5m2 kind.

**FP8 Intrinsics** 

```
struct __nv_fp8x4_e5m2
```

\_\_nv\_fp8x4\_e5m2 datatype

Storage variable contains the vector of four fp8 floating-point data values.

## Description

Constructor from double4 vector data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

## Description

Constructor from float4 vector data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

```
__host____device____nv_fp8x4_e5m2::__nv_fp8x4_e5m2 (const __nv_bfloat162 flo, const __nv_bfloat162 fhi)
```

## **Description**

Constructor from a pair of \_\_nv\_bfloat162 data type values, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

```
__host___device____nv_fp8x4_e5m2::__nv_fp8x4_e5m2 (const __half2 flo, const __half2 fhi)
```

## Description

Constructor from a pair of \_\_half2 data type values, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

## Description

Constructor by default.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x4\_e5m2::operator float4 ()

## Description

Conversion operator to float4 vector data type.

## 1.1.5. C++ struct for handling fp8 data type of e4m3 kind.

FP8 Intrinsics

Storage variable contains the fp8 floating-point data.

## Description

Constructor from long long int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const int val)

## Description

Constructor from int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_device\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const short int val)

## Description

Constructor from short int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const unsigned long long int val)

## Description

Constructor from unsigned long long int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const unsigned int val)

## Description

Constructor from unsigned int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const unsigned short int val)

## Description

Constructor from unsigned short int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const double f)

## Description

Constructor from double data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const float f)

## Description

Constructor from float data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const \_\_nv\_bfloat16 f)

## Description

Constructor from \_\_nv\_bfloat16 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 (const half f)

## Description

Constructor from \_\_half data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_nv\_fp8\_e4m3::\_\_nv\_fp8\_e4m3 ()

## Description

Constructor by default.

\_\_host\_\_\_device\_\_\_nv\_fp8\_e4m3::operator \_\_half ()

## Description

Conversion operator to \_\_half data type.

\_\_host\_\_\_device\_\_\_nv\_fp8\_e4m3::operator \_\_nv\_bfloat16

## Description

Conversion operator to \_\_nv\_bfloat16 data type.

hostdevicenv_fp8_e4m3::operator bool ()
Description
Conversion operator to bool data type. +0 and -0 inputs convert to false. Non-zero inputs convert to true.
hostdevicenv_fp8_e4m3::operator double ()
Description
Conversion operator to double data type.
hostdevicenv_fp8_e4m3::operator float ()
Description
Conversion operator to float data type.
hostdevicenv_fp8_e4m3::operator int ()
Description
Conversion operator to int data type. NaN inputs convert to zero.
hostdevicenv_fp8_e4m3::operator long long in

## Description

Conversion operator to long long int data type. NaN inputs convert to 0x80000000000000000LL.

\_\_host\_\_\_device\_\_\_nv\_fp8\_e4m3::operator short int ()

## Description

Conversion operator to short int data type. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::operator signed char ()

## Description

Conversion operator to signed char data type. Clamps too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::operator unsigned char ()

## Description

Conversion operator to unsigned char data type. Clamps negative and too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::operator unsigned int

## Description

Conversion operator to unsigned int data type. Clamps negative inputs to zero. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8\_e4m3::operator unsigned long long int ()

## Description

Conversion operator to unsigned long long int data type. Clamps negative inputs to zero. NaN inputs convert to 0x80000000000000ULL.

\_\_host\_\_\_device\_\_\_nv\_fp8\_e4m3::operator unsigned short int ()

## Description

Conversion operator to unsigned short int data type. Clamps negative inputs to zero. NaN inputs convert to zero.

## 1.1.6. C++ struct for handling vector type of two fp8 values of e4m3 kind.

FP8 Intrinsics

Storage variable contains the vector of two fp8 floating-point data values.

## Description

Constructor from double2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

## Description

Constructor from float2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

## Description

Constructor from  $\_nv\_bfloat162$  data type, relies on  $\_nv\_satfinite$  behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x2\_e4m3::\_\_nv\_fp8x2\_e4m3 (const half2 f)

## Description

Constructor from \_\_half2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

## Description

Constructor by default.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x2\_e4m3::operator \_\_half2 ()

## Description

Conversion operator to \_\_half2 data type.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x2\_e4m3::operator float2 ()

## Description

Conversion operator to float2 data type.

## 1.1.7. C++ struct for handling vector type of four fp8 values of e4m3 kind.

FP8 Intrinsics

Storage variable contains the vector of four fp8 floating-point data values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x4\_e4m3::\_\_nv\_fp8x4\_e4m3 (const double4 f)

## Description

Constructor from double4 vector data type, relies on \_\_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x4\_e4m3::\_\_nv\_fp8x4\_e4m3 (const float4 f)

## Description

Constructor from float4 vector data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x4\_e4m3::\_\_nv\_fp8x4\_e4m3 (const nv bfloat162 flo, const nv bfloat162 fhi)

## Description

Constructor from a pair of \_\_nv\_bfloat162 data type values, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_host\_\_\_device\_\_\_\_nv\_fp8x4\_e4m3::\_\_nv\_fp8x4\_e4m3 (const \_\_half2 flo, const \_\_half2 fhi)

## Description

Constructor from a pair of \_\_half2 data type values, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_nv\_fp8x4\_e4m3::\_\_nv\_fp8x4\_e4m3 ()

## Description

Constructor by default.

\_\_host\_\_\_\_device\_\_\_\_nv\_fp8x4\_e4m3::operator float4 ()

## Description

Conversion operator to float4 vector data type.

## 1.2. Half Precision Intrinsics

This section describes half precision intrinsic functions that are only supported in device code. To use these functions, include the header file cuda\_fp16.h in your program. The following macros are available to help users selectively enable/disable various definitions present in the header file:

- CUDA\_NO\_HALF If defined, this macro will prevent the definition of additional type aliases in the global namespace, helping to avoid potential conflicts with symbols defined in the user program.
- ► \_\_CUDA\_NO\_HALF\_CONVERSIONS\_\_ If defined, this macro will prevent the use of the C ++ type conversions (converting constructors and conversion operators) that are common for built-in floating-point types, but may be undesirable for half which is essentially a user-defined type.
- ► \_\_CUDA\_NO\_HALF\_OPERATORS\_\_ and \_\_CUDA\_NO\_HALF2\_OPERATORS\_\_ If defined, these macros will prevent the inadvertent use of usual arithmetic and comparison operators. This enforces the storage-only type semantics and prevents C++ style computations on half and half2 types.

Half Arithmetic Functions

Half2 Arithmetic Functions

Half Comparison Functions

Half2 Comparison Functions

Half Precision Conversion and Data Movement

Half Math Functions

Half2 Math Functions

## 1.2.1. Half Arithmetic Functions

Half Precision Intrinsics

To use these functions, include the header file cuda fp16.h in your program.

\_\_device\_\_ \_half \_\_habs (const \_\_half a)

Calculates the absolute value of input half number and returns the result.

#### **Parameters**

a

- half. Is only being read.

#### Returns

half

► The absolute value of a.

## Description

Calculates the absolute value of input half number and returns the result.

\_\_device\_\_ \_half \_\_hadd (const \_\_half a, const \_\_half b)

Performs half addition in round-to-nearest-even mode.

## Description

Performs half addition of inputs a and b, in round-to-nearest-even mode.

\_\_device\_\_ \_half \_\_hadd\_rn (const \_\_half a, const \_\_half b)

Performs half addition in round-to-nearest-even mode.

## Description

Performs half addition of inputs a and b, in round-to-nearest-even mode. Prevents floating-point contractions of mul+add into fma.

\_\_device\_\_ \_half \_\_hadd\_sat (const \_\_half a, const \_\_half b)

Performs half addition in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

a

- half. Is only being read.

b

- half. Is only being read.

#### Returns

half

▶ The sum of a and b, with respect to saturation.

## Description

Performs half add of inputs a and b, in round-to-nearest-even mode, and clamps the result to range [0.0, 1.0]. NaN results are flushed to +0.0.

\_\_device\_\_ \_half \_\_hdiv (const \_\_half a, const \_\_half b)

Performs half division in round-to-nearest-even mode.

## Description

Divides half input a by input b in round-to-nearest mode.

\_\_device\_\_ \_ half \_\_hfma (const \_\_half a, const \_\_half b,
const \_\_half c)

Performs half fused multiply-add in round-to-nearest-even mode.

## Description

Performs half multiply on inputs a and b, then performs a half add of the result with c, rounding the result once in round-to-nearest-even mode.

\_\_device\_\_ \_half \_\_hfma\_relu (const \_\_half a, const \_\_half b, const half c)

Performs half fused multiply-add in round-to-nearest-even mode with relu saturation.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

C

- half. Is only being read.

#### Returns

half

The result of fused multiply-add operation on a, b, and c with relu saturation.

### Description

Performs half multiply on inputs a and b, then performs a half add of the result with c, rounding the result once in round-to-nearest-even mode. Then negative result is clamped to 0. NaN result is converted to canonical NaN.

## \_\_device\_\_ \_\_half \_\_hfma\_sat (const \_\_half a, const \_\_half b, const \_\_half c)

Performs half fused multiply-add in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

C

- half. Is only being read.

#### Returns

half

The result of fused multiply-add operation on a, b, and c, with respect to saturation.

## Description

Performs half multiply on inputs a and b, then performs a half add of the result with c, rounding the result once in round-to-nearest-even mode, and clamps the result to range [0.0, 1.0]. NaN results are flushed to +0.0.

\_\_device\_\_ \_half \_\_hmul (const \_\_half a, const \_\_half b)

Performs half multiplication in round-to-nearest-even mode.

## Description

Performs half multiplication of inputs a and b, in round-to-nearest mode.

# \_\_device\_\_ \_half \_\_hmul\_rn (const \_\_half a, const \_\_half b)

Performs half multiplication in round-to-nearest-even mode.

## Description

Performs half multiplication of inputs a and b, in round-to-nearest mode. Prevents floating-point contractions of mul+add or sub into fma.

## \_\_device\_\_ \_half \_\_hmul\_sat (const \_\_half a, const \_\_half b)

Performs half multiplication in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

half

The result of multiplying a and b, with respect to saturation.

## Description

Performs half multiplication of inputs a and b, in round-to-nearest mode, and clamps the result to range [0.0, 1.0]. NaN results are flushed to +0.0.

## device\_\_ \_half \_hneg (const \_half a)

Negates input half number and returns the result.

## Description

Negates input half number and returns the result.

\_\_device\_\_ \_half \_ hsub (const \_ half a, const \_ half b)

Performs half subtraction in round-to-nearest-even mode.

### Description

Subtracts half input b from input a in round-to-nearest mode.

## \_\_device\_\_ \_half \_\_hsub\_rn (const \_\_half a, const \_\_half b)

Performs half subtraction in round-to-nearest-even mode.

### Description

Subtracts half input b from input a in round-to-nearest mode. Prevents floating-point contractions of mul+sub into fma.

## \_\_device\_\_ \_half \_\_hsub\_sat (const \_\_half a, const \_\_half b)

Performs half subtraction in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

half

▶ The result of subtraction of b from a, with respect to saturation.

## Description

Subtracts half input b from input a in round-to-nearest mode, and clamps the result to range [0.0, 1.0]. NaN results are flushed to +0.0.

## \_\_device\_\_ \_half atomicAdd (const \_\_half \*address, const half val)

Adds val to the value stored at address in global or shared memory, and writes this value back to address. This operation is performed in one atomic operation.

#### **Parameters**

#### address

- half\*. An address in global or shared memory.

#### val

- half. The value to be added.

#### Returns

half

▶ The old value read from address.

### Description

The location of address must be in global or shared memory. This operation has undefined behavior otherwise. This operation is only supported by devices of compute capability 7.x and higher.



#### Note:

For more details for this function see the Atomic Functions section in the CUDA C++ Programming Guide.

## 1.2.2. Half2 Arithmetic Functions

Half Precision Intrinsics

To use these functions, include the header file cuda fp16.h in your program.

## \_\_device\_\_ \_half2 \_\_h2div (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector division in round-to-nearest-even mode.

## Description

Divides half2 input vector a by input vector b in round-to-nearest mode.

## \_\_device\_\_ \_half2 \_habs2 (const \_half2 a)

Calculates the absolute value of both halves of the input half2 number and returns the result.

#### **Parameters**

a

- half2. Is only being read.

#### Returns

half2

Returns a with the absolute value of both halves.

## Description

Calculates the absolute value of both halves of the input half2 number and returns the result.

\_\_device\_\_ \_half2 \_\_hadd2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector addition in round-to-nearest-even mode.

## Description

Performs half2 vector add of inputs a and b, in round-to-nearest mode.

Performs half2 vector addition in round-to-nearest-even mode.

## Description

Performs half2 vector add of inputs a and b, in round-to-nearest mode. Prevents floating-point contractions of mul+add into fma.

Performs half2 vector addition in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- half2. Is only being read.

h

- half2. Is only being read.

#### Returns

half2

The sum of a and b, with respect to saturation.

## Description

Performs half2 vector add of inputs a and b, in round-to-nearest mode, and clamps the results to range [0.0, 1.0]. NaN results are flushed to +0.0.

\_\_device\_\_ \_half2 \_\_hcmadd (const \_\_half2 a, const \_\_half2 b, const \_\_half2 c)

Performs fast complex multiply-accumulate.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

C

- half2. Is only being read.

#### Returns

half2

▶ The result of complex multiply-accumulate operation on complex numbers a, b, and c

### Description

Interprets vector half2 input pairs a, b, and c as complex numbers in half precision and performs complex multiply-accumulate operation: a\*b + c

\_\_device\_\_ \_half2 \_hfma2 (const \_half2 a, const \_half2 b, const half2 c)

Performs half2 vector fused multiply-add in round-to-nearest-even mode.

## **Description**

Performs half2 vector multiply on inputs a and b, then performs a half2 vector add of the result with c, rounding the result once in round-to-nearest-even mode.

\_\_device\_\_ \_half2 \_hfma2\_relu (const \_half2 a, const half2 b, const half2 c)

Performs half2 vector fused multiply-add in round-to-nearest-even mode with relusaturation.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

C

- half2. Is only being read.

#### Returns

#### half2

The result of elementwise fused multiply-add operation on vectors a, b, and c with relu saturation.

### Description

Performs half2 vector multiply on inputs a and b, then performs a half2 vector add of the result with c, rounding the result once in round-to-nearest-even mode. Then negative result is clamped to 0. NaN result is converted to canonical NaN.

```
__device__ _half2 __hfma2_sat (const __half2 a, const __half2 b, const __half2 c)
```

Performs half2 vector fused multiply-add in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

C

- half2. Is only being read.

#### Returns

half2

The result of elementwise fused multiply-add operation on vectors a, b, and c, with respect to saturation.

## Description

Performs half2 vector multiply on inputs a and b, then performs a half2 vector add of the result with c, rounding the result once in round-to-nearest-even mode, and clamps the results to range [0.0, 1.0]. NaN results are flushed to +0.0.



Performs half2 vector multiplication in round-to-nearest-even mode.

## Description

Performs half2 vector multiplication of inputs a and b, in round-to-nearest-even mode.

Performs half2 vector multiplication in round-to-nearest-even mode.

## Description

Performs half2 vector multiplication of inputs a and b, in round-to-nearest-even mode. Prevents floating-point contractions of mul+add or sub into fma.

Performs half2 vector multiplication in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

The result of elementwise multiplication of vectors a and b, with respect to saturation.

## Description

Performs half2 vector multiplication of inputs a and b, in round-to-nearest-even mode, and clamps the results to range [0.0, 1.0]. NaN results are flushed to +0.0.

## \_\_device\_\_ \_half2 \_\_hneg2 (const \_\_half2 a)

Negates both halves of the input half2 number and returns the result.

## Description

Negates both halves of the input half2 number a and returns the result.

Performs half2 vector subtraction in round-to-nearest-even mode.

## Description

Subtracts half2 input vector b from input vector a in round-to-nearest-even mode.

Performs half2 vector subtraction in round-to-nearest-even mode.

## Description

Subtracts half2 input vector b from input vector a in round-to-nearest-even mode. Prevents floating-point contractions of mul+sub into fma.

Performs half2 vector subtraction in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The subtraction of vector b from a, with respect to saturation.

### Description

Subtracts half2 input vector b from input vector a in round-to-nearest-even mode, and clamps the results to range [0.0, 1.0]. NaN results are flushed to +0.0.

## \_\_device\_\_ \_\_half2 atomicAdd (const \_\_half2 \*address, const half2 val)

Vector add val to the value stored at address in global or shared memory, and writes this value back to address. The atomicity of the add operation is guaranteed separately for each of the two \_\_half elements; the entire \_\_half2 is not guaranteed to be atomic as a single 32-bit access

#### **Parameters**

#### address

- half2\*. An address in global or shared memory.

#### val

- half2. The value to be added.

#### Returns

half2

► The old value read from address.

## Description

The location of address must be in global or shared memory. This operation has undefined behavior otherwise. This operation is only supported by devices of compute capability 6.x and higher.



#### Note:

For more details for this function see the Atomic Functions section in the CUDA C++ Programming Guide.

## 1.2.3. Half Comparison Functions

Half Precision Intrinsics

To use these functions, include the header file cuda fp16.h in your program.

## \_\_device\_\_ bool \_\_heq (const \_\_half a, const \_\_half b)

Performs half if-equal comparison.

## **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

▶ The boolean result of if-equal comparison of a and b.

## Description

Performs half if-equal comparison of inputs a and b. NaN inputs generate false results.

## \_\_device\_\_ bool \_\_hequ (const \_\_half a, const \_\_half b)

Performs half unordered if-equal comparison.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

The boolean result of unordered if-equal comparison of a and b.

## Description

Performs half if-equal comparison of inputs a and b. NaN inputs generate true results.

## \_\_device\_\_ bool \_\_hge (const \_\_half a, const \_\_half b)

Performs half greater-equal comparison.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

▶ The boolean result of greater-equal comparison of a and b.

## Description

Performs half greater-equal comparison of inputs a and b. NaN inputs generate false results.

\_\_device\_\_\_ bool \_\_\_hgeu (const \_\_\_half a, const \_\_\_half b)

Performs half unordered greater-equal comparison.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

▶ The boolean result of unordered greater-equal comparison of a and b.

## Description

Performs half greater-equal comparison of inputs a and b. NaN inputs generate true results.

\_\_device\_\_ bool \_\_hgt (const \_\_half a, const \_\_half b)

Performs half greater-than comparison.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

▶ The boolean result of greater-than comparison of a and b.

# Description

Performs half greater-than comparison of inputs a and b. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hgtu (const \_\_half a, const \_\_half b)

Performs half unordered greater-than comparison.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

▶ The boolean result of unordered greater-than comparison of a and b.

# Description

Performs half greater-than comparison of inputs a and b. NaN inputs generate true results.

# \_\_device\_\_ int \_\_hisinf (const \_\_half a)

Checks if the input half number is infinite.

### **Parameters**

а

- half. Is only being read.

#### Returns

int

- ► -1 iff a is equal to negative infinity,
- 1 iff a is equal to positive infinity,
- ▶ 0 otherwise.

## Description

Checks if the input half number a is infinite.

# device bool hisnan (const half a)

Determine whether half argument is a NaN.

### **Parameters**

a

- half. Is only being read.

#### Returns

bool

true iff argument is NaN.

# Description

Determine whether half value a is a NaN.

\_\_device\_\_ bool \_\_hle (const \_\_half a, const \_\_half b)

Performs half less-equal comparison.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

▶ The boolean result of less-equal comparison of a and b.

# Description

Performs half less-equal comparison of inputs a and b. NaN inputs generate false results.

\_device\_\_ bool \_\_hleu (const \_\_half a, const \_\_half b)

Performs half unordered less-equal comparison.

## **Parameters**

a

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

▶ The boolean result of unordered less-equal comparison of a and b.

## Description

Performs half less-equal comparison of inputs a and b. NaN inputs generate true results.

\_\_device\_\_ bool \_\_hlt (const \_\_half a, const \_\_half b)

Performs half less-than comparison.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

▶ The boolean result of less-than comparison of a and b.

# Description

Performs half less-than comparison of inputs a and b. NaN inputs generate false results.

\_\_device\_\_ bool \_\_hltu (const \_\_half a, const \_\_half b)

Performs half unordered less-than comparison.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

bool

The boolean result of unordered less-than comparison of a and b.

# Description

Performs half less-than comparison of inputs a and b. NaN inputs generate true results.

\_\_device\_\_ \_half \_\_hmax (const \_\_half a, const \_\_half b)

Calculates half maximum of two input values.

# Description

Calculates half max(a, b) defined as (a > b)? a:b.

- If either of inputs is NaN, the other input is returned.
- If both inputs are NaNs, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0

\_\_device\_\_ \_half \_\_hmax\_nan (const \_\_half a, const \_\_half b)

Calculates half maximum of two input values, NaNs pass through.

## Description

Calculates half max(a, b) defined as (a > b)? a : b.

- If either of inputs is NaN, then canonical NaN is returned.
- ► If values of both inputs are 0.0, then +0.0 > -0.0

\_\_device\_\_ \_half \_\_hmin (const \_\_half a, const \_\_half b)

Calculates half minimum of two input values.

#### Description

Calculates half min(a, b) defined as (a < b)? a : b.

- If either of inputs is NaN, the other input is returned.
- If both inputs are NaNs, then canonical NaN is returned.
- If values of both inputs are 0.0, then +0.0 > -0.0

\_\_device\_\_ \_half \_\_hmin\_nan (const \_\_half a, const \_\_half b)

Calculates half minimum of two input values, NaNs pass through.

#### Description

Calculates half min(a, b) defined as (a < b)? a : b.

If either of inputs is NaN, then canonical NaN is returned.

▶ If values of both inputs are 0.0, then +0.0 > -0.0

# \_\_device\_\_ bool \_\_hne (const \_\_half a, const \_\_half b)

Performs half not-equal comparison.

#### **Parameters**

- а
- half. Is only being read.
- b
- half. Is only being read.

#### Returns

bool

The boolean result of not-equal comparison of a and b.

## Description

Performs half not-equal comparison of inputs a and b. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hneu (const \_\_half a, const \_\_half b)

Performs half unordered not-equal comparison.

#### **Parameters**

- a
- half. Is only being read.
- b
- half. Is only being read.

#### Returns

bool

▶ The boolean result of unordered not-equal comparison of a and b.

# Description

Performs half not-equal comparison of inputs a and b. NaN inputs generate true results.

# 1.2.4. Half2 Comparison Functions

Half Precision Intrinsics

To use these functions, include the header file cuda fp16.h in your program.

# \_\_device\_\_\_ bool \_\_\_hbeq2 (const \_\_\_half2 a, const \_\_\_half2 b)

Performs half2 vector if-equal comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of if-equal comparison of vectors a and b are true;
- false otherwise.

## Description

Performs half2 vector if-equal comparison of inputs a and b. The bool result is set to true only if both half if-equal comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbequ2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered if-equal comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of unordered if-equal comparison of vectors a and b are true;
- ▶ false otherwise.

Performs half2 vector if-equal comparison of inputs a and b. The bool result is set to true only if both half if-equal comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

# \_\_device\_\_ bool \_\_hbge2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector greater-equal comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of greater-equal comparison of vectors a and b are true;
- ► false otherwise.

# Description

Performs half2 vector greater-equal comparison of inputs a and b. The bool result is set to true only if both half greater-equal comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbgeu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered greater-equal comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of unordered greater-equal comparison of vectors a and b are true;
- ► false otherwise.

Performs half2 vector greater-equal comparison of inputs a and b. The bool result is set to true only if both half greater-equal comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

\_\_device\_\_ bool \_\_hbgt2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector greater-than comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of greater-than comparison of vectors a and b are true;
- false otherwise.

# Description

Performs half2 vector greater-than comparison of inputs a and b. The bool result is set to true only if both half greater-than comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

\_\_device\_\_ bool \_\_hbgtu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered greater-than comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of unordered greater-than comparison of vectors a and b are true;
- false otherwise.

## Description

Performs half2 vector greater-than comparison of inputs a and b. The bool result is set to true only if both half greater-than comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

\_\_device\_\_ bool \_\_hble2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector less-equal comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

### Returns

bool

- true if both half results of less-equal comparison of vectors a and b are true;
- ► false otherwise.

# Description

Performs half2 vector less-equal comparison of inputs a and b. The bool result is set to true only if both half less-equal comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

\_\_device\_\_ bool \_\_hbleu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered less-equal comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

a

- half2. Is only being read.

#### b

- half2. Is only being read.

#### Returns

bool

- true if both half results of unordered less-equal comparison of vectors a and b are true;
- false otherwise.

## Description

Performs half2 vector less-equal comparison of inputs a and b. The bool result is set to true only if both half less-equal comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

# \_\_device\_\_ bool \_\_hblt2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector less-than comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of less-than comparison of vectors a and b are true;
- false otherwise.

# Description

Performs half2 vector less-than comparison of inputs a and b. The bool result is set to true only if both half less-than comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# device bool hbltu2 (const half2 a, const half2 b)

Performs half2 vector unordered less-than comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of unordered less-than comparison of vectors a and b are true;
- false otherwise.

## Description

Performs half2 vector less-than comparison of inputs a and b. The bool result is set to true only if both half less-than comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

# \_\_device\_\_ bool \_\_hbne2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector not-equal comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of not-equal comparison of vectors a and b are true,
- ▶ false otherwise.

Performs half2 vector not-equal comparison of inputs a and b. The bool result is set to true only if both half not-equal comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbneu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered not-equal comparison and returns boolean true iff both half results are true, boolean false otherwise.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

bool

- true if both half results of unordered not-equal comparison of vectors a and b are true;
- ► false otherwise.

# Description

Performs half2 vector not-equal comparison of inputs a and b. The bool result is set to true only if both half not-equal comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

\_\_device\_\_ \_half2 \_\_heq2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector if-equal comparison.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

The vector result of if-equal comparison of vectors a and b.

Performs half2 vector if-equal comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

# \_\_device\_\_ unsigned \_\_heq2\_mask (const \_\_half2 a, const half2 b)

Performs half2 vector if-equal comparison.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

▶ The vector mask result of if-equal comparison of vectors a and b.

# Description

Performs half2 vector if-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

# \_\_device\_\_ \_half2 \_\_hequ2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered if-equal comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The vector result of unordered if-equal comparison of vectors a and b.

Performs half2 vector if-equal comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

# \_\_device\_\_ unsigned \_\_hequ2\_mask (const \_\_half2 a, const half2 b)

Performs half2 vector unordered if-equal comparison.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

The vector mask result of unordered if-equal comparison of vectors a and b.

## Description

Performs half2 vector if-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

\_\_device\_\_ \_half2 \_\_hge2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector greater-equal comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The vector result of greater-equal comparison of vectors a and b.

### Description

Performs half2 vector greater-equal comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

# \_\_device\_\_ unsigned \_\_hge2\_mask (const \_\_half2 a, const half2 b)

Performs half2 vector greater-equal comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

The vector mask result of greater-equal comparison of vectors a and b.

## Description

Performs half2 vector greater-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

# \_\_device\_\_ \_half2 \_\_hgeu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered greater-equal comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The half2 vector result of unordered greater-equal comparison of vectors a and b.

# Description

Performs half2 vector greater-equal comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

# \_\_device\_\_ unsigned \_\_hgeu2\_mask (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered greater-equal comparison.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

The vector mask result of unordered greater-equal comparison of vectors a and b.

# Description

Performs half2 vector greater-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

\_\_device\_\_ \_half2 \_hgt2 (const \_half2 a, const \_half2 b)

Performs half2 vector greater-than comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The vector result of greater-than comparison of vectors a and b.

## Description

Performs half2 vector greater-than comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

# \_\_device\_\_ unsigned \_\_hgt2\_mask (const \_\_half2 a, const half2 b)

Performs half2 vector greater-than comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

The vector mask result of greater-than comparison of vectors a and b.

# Description

Performs half2 vector greater-than comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

# \_\_device\_\_ \_half2 \_\_hgtu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered greater-than comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

The half2 vector result of unordered greater-than comparison of vectors a and b.

# Description

Performs half2 vector greater-than comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

# \_\_device\_\_ unsigned \_\_hgtu2\_mask (const \_\_half2 a, const half2 b)

Performs half2 vector unordered greater-than comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

The vector mask result of unordered greater-than comparison of vectors a and b.

# Description

Performs half2 vector greater-than comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

\_\_device\_\_ \_half2 \_\_hisnan2 (const \_\_half2 a)

Determine whether half2 argument is a NaN.

#### **Parameters**

а

- half2. Is only being read.

#### Returns

half2

▶ The half2 with the corresponding half results set to 1.0 for NaN, 0.0 otherwise.

# Description

Determine whether each half of input half2 number a is a NaN.

\_\_device\_\_ \_half2 \_\_hle2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector less-equal comparison.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The half2 result of less-equal comparison of vectors a and b.

## Description

Performs half2 vector less-equal comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

# \_\_device\_\_ unsigned \_\_hle2\_mask (const \_\_half2 a, const half2 b)

Performs half2 vector less-equal comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

▶ The vector mask result of less-equal comparison of vectors a and b.

# Description

Performs half2 vector less-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

# \_\_device\_\_ \_half2 \_\_hleu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered less-equal comparison.

### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The vector result of unordered less-equal comparison of vectors a and b.

## Description

Performs half2 vector less-equal comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

# \_\_device\_\_ unsigned \_\_hleu2\_mask (const \_\_half2 a, const half2 b)

Performs half2 vector unordered less-equal comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

The vector mask result of unordered less-equal comparison of vectors a and b.

# Description

Performs half2 vector less-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

\_\_device\_\_ \_half2 \_\_hlt2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector less-than comparison.

### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The half2 vector result of less-than comparison of vectors a and b.

Performs half2 vector less-than comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

Performs half2 vector less-than comparison.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

▶ The vector mask result of less-than comparison of vectors a and b.

## Description

Performs half2 vector less-than comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

# \_\_device\_\_ \_half2 \_\_hltu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered less-than comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

▶ The vector result of unordered less-than comparison of vectors a and b.

Performs half2 vector less-than comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

# \_\_device\_\_ unsigned \_\_hltu2\_mask (const \_\_half2 a, const half2 b)

Performs half2 vector unordered less-than comparison.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

The vector mask result of unordered less-than comparison of vectors a and b.

# Description

Performs half2 vector less-than comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

# \_\_device\_\_ \_half2 \_\_hmax2 (const \_\_half2 a, const \_\_half2 b)

Calculates half2 vector maximum of two inputs.

## Description

Calculates half2 vector max(a, b). Elementwise half operation is defined as (a > b)? a : b.

- If either of inputs is NaN, the other input is returned.
- ▶ If both inputs are NaNs, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0
- ► The result of elementwise maximum of vectors a and b

# \_\_device\_\_ \_half2 \_\_hmax2\_nan (const \_\_half2 a, const half2 b)

Calculates half2 vector maximum of two inputs, NaNs pass through.

## Description

Calculates half2 vector max(a, b). Elementwise half operation is defined as (a > b)? a : b.

- If either of inputs is NaN, then canonical NaN is returned.
- ► If values of both inputs are 0.0, then +0.0 > -0.0
- ▶ The result of elementwise maximum of vectors a and b, with NaNs pass through

Calculates half2 vector minimum of two inputs.

# Description

Calculates half2 vector min(a, b). Elementwise half operation is defined as (a < b)? a : b.

- If either of inputs is NaN, the other input is returned.
- If both inputs are NaNs, then canonical NaN is returned.
- ► If values of both inputs are 0.0, then +0.0 > -0.0
- ▶ The result of elementwise minimum of vectors a and b

# \_\_device\_\_ \_half2 \_\_hmin2\_nan (const \_\_half2 a, const \_\_half2 b)

Calculates half2 vector minimum of two inputs, NaNs pass through.

## Description

Calculates half2 vector min(a, b). Elementwise half operation is defined as (a < b)? a : b.

- If either of inputs is NaN, then canonical NaN is returned.
- ► If values of both inputs are 0.0, then +0.0 > -0.0
- The result of elementwise minimum of vectors a and b, with NaNs pass through

\_\_device\_\_ \_half2 \_\_hne2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector not-equal comparison.

### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

► The vector result of not-equal comparison of vectors a and b.

## Description

Performs half2 vector not-equal comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

\_\_device\_\_ unsigned \_\_hne2\_mask (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector not-equal comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

▶ The vector mask result of not-equal comparison of vectors a and b.

# Description

Performs half2 vector not-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

# \_\_device\_\_ \_half2 \_\_hneu2 (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered not-equal comparison.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

The vector result of unordered not-equal comparison of vectors a and b.

# Description

Performs half2 vector not-equal comparison of inputs a and b. The corresponding half results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

# \_\_device\_\_ unsigned \_\_hneu2\_mask (const \_\_half2 a, const \_\_half2 b)

Performs half2 vector unordered not-equal comparison.

#### **Parameters**

a

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

unsigned int

The vector mask result of unordered not-equal comparison of vectors a and b.

# Description

Performs half2 vector not-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

# 1.2.5. Half Precision Conversion and Data Movement

Half Precision Intrinsics

To use these functions, include the header file cuda fp16.h in your program.

\_\_host\_\_\_device\_\_half \_\_double2half (const double a)

Converts double number to half precision in round-to-nearest-even mode and returns half with converted value.

#### **Parameters**

a

- double. Is only being read.

#### Returns

half

a converted to half.

## Description

Converts double number a to half precision in round-to-nearest-even mode.

\_\_host\_\_\_device\_\_ \_half2 \_\_float22half2\_rn (const float2 a)

Converts both components of float2 number to half precision in round-to-nearest-even mode and returns half2 with converted values.

#### **Parameters**

а

- float2. Is only being read.

#### Returns

half2

▶ The half2 which has corresponding halves equal to the converted float2 components.

## Description

Converts both components of float2 to half precision in round-to-nearest mode and combines the results into one half2 number. Low 16 bits of the return value correspond to a.x and high 16 bits of the return value correspond to a.y.

# \_\_host\_\_\_device\_\_half \_\_float2half (const float a)

Converts float number to half precision in round-to-nearest-even mode and returns half with converted value.

#### **Parameters**

а

- float. Is only being read.

#### Returns

half

a converted to half.

# Description

Converts float number a to half precision in round-to-nearest-even mode.

# \_\_host\_\_\_device\_\_ \_half2 \_\_float2half2\_rn (const float a)

Converts input to half precision in round-to-nearest-even mode and populates both halves of half2 with converted value.

#### **Parameters**

a

- float. Is only being read.

#### Returns

half2

The half2 value with both halves equal to the converted half precision number.

# Description

Converts input a to half precision in round-to-nearest-even mode and populates both halves of half2 with converted value.

# \_\_host\_\_\_\_device\_\_ \_ half \_\_float2half\_rd (const float a)

Converts float number to half precision in round-down mode and returns half with converted value.

#### **Parameters**

а

- float. Is only being read.

#### Returns

half

a converted to half.

# Description

Converts float number a to half precision in round-down mode.

\_\_host\_\_\_device\_\_ \_half \_\_float2half\_rn (const float a)

Converts float number to half precision in round-to-nearest-even mode and returns half with converted value.

#### **Parameters**

а

- float. Is only being read.

#### Returns

half

a converted to half.

# Description

Converts float number a to half precision in round-to-nearest-even mode.

\_\_host\_\_\_device\_\_ \_half \_\_float2half\_ru (const float a)

Converts float number to half precision in round-up mode and returns half with converted value.

## **Parameters**

а

- float. Is only being read.

#### Returns

half

a converted to half.

# Description

Converts float number a to half precision in round-up mode.

# \_\_host\_\_\_device\_\_ \_half \_\_float2half\_rz (const float a)

Converts float number to half precision in round-towards-zero mode and returns half with converted value.

#### **Parameters**

a

- float. Is only being read.

#### Returns

half

a converted to half.

# Description

Converts float number a to half precision in round-towards-zero mode.

# \_\_host\_\_\_device\_ \_half2 \_\_floats2half2\_rn (const float a, const float b)

Converts both input floats to half precision in round-to-nearest-even mode and returns half2 with converted values.

#### **Parameters**

а

- float. Is only being read.

b

- float. Is only being read.

#### Returns

half2

▶ The half2 value with corresponding halves equal to the converted input floats.

# Description

Converts both input floats to half precision in round-to-nearest-even mode and combines the results into one half2 number. Low 16 bits of the return value correspond to the input a, high 16 bits correspond to the input b.

\_\_host\_\_\_device\_\_ float2 \_\_half22float2 (const \_\_half2 a)

Converts both halves of half2 to float2 and returns the result.

### **Parameters**

a

- half2. Is only being read.

#### Returns

float2

a converted to float2.

## Description

Converts both halves of half2 input a to float2 and returns the result.

\_\_host\_\_\_device\_\_ float \_\_half2float (const \_\_half a)

Converts half number to float.

#### **Parameters**

а

- float. Is only being read.

#### Returns

float

a converted to float.

# Description

Converts half number a to float.

\_\_device\_\_ \_half2 \_\_half2half2 (const \_\_half a)

Returns half2 with both halves equal to the input value.

#### **Parameters**

а

- half. Is only being read.

#### Returns

half2

► The vector which has both its halves equal to the input a.

Returns half2 number with both halves equal to the input a half number.

# \_\_device\_\_ int \_\_half2int\_rd (const \_\_half h)

Convert a half to a signed integer in round-down mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

int

▶ h converted to a signed integer.

# Description

Convert the half-precision floating-point value h to a signed integer in round-down mode. NaN inputs are converted to 0.

# \_\_device\_\_ int \_\_half2int\_rn (const \_\_half h)

Convert a half to a signed integer in round-to-nearest-even mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

int

▶ h converted to a signed integer.

# Description

Convert the half-precision floating-point value  ${\tt h}$  to a signed integer in round-to-nearest-even mode. NaN inputs are converted to 0.

# device int half2int ru (const half h)

Convert a half to a signed integer in round-up mode.

### **Parameters**

h

- half. Is only being read.

#### Returns

int

h converted to a signed integer.

## Description

Convert the half-precision floating-point value h to a signed integer in round-up mode. NaN inputs are converted to 0.

\_\_host\_\_\_device\_\_ int \_\_half2int\_rz (const \_\_half h)

Convert a half to a signed integer in round-towards-zero mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

int

► h converted to a signed integer.

# Description

Convert the half-precision floating-point value  ${\tt h}$  to a signed integer in round-towards-zero mode. NaN inputs are converted to 0.

\_\_device\_\_ long long int \_\_half2ll\_rd (const \_\_half h)

Convert a half to a signed 64-bit integer in round-down mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

long long int

▶ h converted to a signed 64-bit integer.

# Description

Convert the half-precision floating-point value h to a signed 64-bit integer in round-down mode. NaN inputs return a long long int with hex value of 0x8000000000000000.

# \_\_device\_\_ long long int \_\_half2ll\_rn (const \_\_half h)

Convert a half to a signed 64-bit integer in round-to-nearest-even mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

long long int

▶ h converted to a signed 64-bit integer.

# Description

Convert the half-precision floating-point value h to a signed 64-bit integer in round-to-nearest-even mode. NaN inputs return a long long int with hex value of 0x8000000000000000.

# \_\_device\_\_ long long int \_\_half2ll\_ru (const \_\_half h)

Convert a half to a signed 64-bit integer in round-up mode.

### **Parameters**

h

- half. Is only being read.

#### Returns

long long int

▶ h converted to a signed 64-bit integer.

# Description

Convert the half-precision floating-point value h to a signed 64-bit integer in round-up mode. NaN inputs return a long long int with hex value of 0x800000000000000.

# \_\_host\_\_\_\_device\_\_ long long int \_\_half2ll\_rz (const \_\_half h)

Convert a half to a signed 64-bit integer in round-towards-zero mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

long long int

▶ h converted to a signed 64-bit integer.

## Description

Convert the half-precision floating-point value h to a signed 64-bit integer in round-towards-zero mode. NaN inputs return a long long int with hex value of 0x8000000000000000.

# \_\_device\_\_ short int \_\_half2short\_rd (const \_\_half h)

Convert a half to a signed short integer in round-down mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

short int

▶ h converted to a signed short integer.

# Description

Convert the half-precision floating-point value  ${\tt h}$  to a signed short integer in round-down mode. NaN inputs are converted to 0.

# \_\_device\_\_\_ short int \_\_\_half2short\_rn (const \_\_\_half h)

Convert a half to a signed short integer in round-to-nearest-even mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

short int

▶ h converted to a signed short integer.

# Description

Convert the half-precision floating-point value  ${\tt h}$  to a signed short integer in round-to-nearest-even mode. NaN inputs are converted to 0.

\_\_device\_\_ short int \_\_half2short\_ru (const \_\_half h)

Convert a half to a signed short integer in round-up mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

short int

▶ h converted to a signed short integer.

# Description

Convert the half-precision floating-point value  ${\tt h}$  to a signed short integer in round-up mode. NaN inputs are converted to 0.

\_\_host\_\_\_\_device\_\_ short int \_\_half2short\_rz (const \_\_half
h)

Convert a half to a signed short integer in round-towards-zero mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

short int

▶ h converted to a signed short integer.

Convert the half-precision floating-point value h to a signed short integer in round-towards-zero mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned int \_\_half2uint\_rd (const \_\_half h)

Convert a half to an unsigned integer in round-down mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned int

▶ h converted to an unsigned integer.

# Description

Convert the half-precision floating-point value  ${\tt h}$  to an unsigned integer in round-down mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned int \_\_half2uint\_rn (const \_\_half h)

Convert a half to an unsigned integer in round-to-nearest-even mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned int

▶ h converted to an unsigned integer.

# Description

Convert the half-precision floating-point value h to an unsigned integer in round-to-nearesteven mode. NaN inputs are converted to 0.

## \_\_device\_\_ unsigned int \_\_half2uint\_ru (const \_\_half h)

Convert a half to an unsigned integer in round-up mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned int

▶ h converted to an unsigned integer.

#### Description

Convert the half-precision floating-point value  ${\tt h}$  to an unsigned integer in round-up mode. NaN inputs are converted to 0.

Convert a half to an unsigned integer in round-towards-zero mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned int

▶ h converted to an unsigned integer.

## Description

Convert the half-precision floating-point value  ${\tt h}$  to an unsigned integer in round-towards-zero mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned long long int \_\_half2ull\_rd (const \_\_half h)

Convert a half to an unsigned 64-bit integer in round-down mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned long long int

▶ h converted to an unsigned 64-bit integer.

#### Description

Convert the half-precision floating-point value  ${\tt h}$  to an unsigned 64-bit integer in round-down mode. NaN inputs return 0x80000000000000.

# \_\_device\_\_ unsigned long long int \_\_half2ull\_rn (const half h)

Convert a half to an unsigned 64-bit integer in round-to-nearest-even mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned long long int

▶ h converted to an unsigned 64-bit integer.

## Description

Convert the half-precision floating-point value h to an unsigned 64-bit integer in round-to-nearest-even mode. NaN inputs return 0x80000000000000.

# \_\_device\_\_ unsigned long long int \_\_half2ull\_ru (const \_\_half h)

Convert a half to an unsigned 64-bit integer in round-up mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned long long int

▶ h converted to an unsigned 64-bit integer.

## Description

Convert the half-precision floating-point value h to an unsigned 64-bit integer in round-up mode. NaN inputs return 0x800000000000000.

# \_\_host\_\_\_\_device\_\_ unsigned long long int \_\_half2ull\_rz (const half h)

Convert a half to an unsigned 64-bit integer in round-towards-zero mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned long long int

▶ h converted to an unsigned 64-bit integer.

#### Description

Convert the half-precision floating-point value h to an unsigned 64-bit integer in round-towards-zero mode. NaN inputs return 0x8000000000000.

# \_\_device\_\_ unsigned short int \_\_half2ushort\_rd (const half h)

Convert a half to an unsigned short integer in round-down mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned short int

h converted to an unsigned short integer.

#### Description

Convert the half-precision floating-point value h to an unsigned short integer in round-down mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned short int \_\_half2ushort\_rn (const \_\_half h)

Convert a half to an unsigned short integer in round-to-nearest-even mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned short int

▶ h converted to an unsigned short integer.

## Description

Convert the half-precision floating-point value h to an unsigned short integer in round-to-nearest-even mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned short int \_\_half2ushort\_ru (const half h)

Convert a half to an unsigned short integer in round-up mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned short int

▶ h converted to an unsigned short integer.

#### Description

Convert the half-precision floating-point value h to an unsigned short integer in round-up mode. NaN inputs are converted to 0.

# \_\_host\_\_\_\_device\_\_ unsigned short int \_\_half2ushort\_rz (const \_\_half h)

Convert a half to an unsigned short integer in round-towards-zero mode.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned short int

▶ h converted to an unsigned short integer.

#### Description

Convert the half-precision floating-point value h to an unsigned short integer in round-towards-zero mode. NaN inputs are converted to 0.

\_\_device\_\_ short int \_\_half\_as\_short (const \_\_half h)

Reinterprets bits in a half as a signed short integer.

#### **Parameters**

h

- half. Is only being read.

#### Returns

short int

► The reinterpreted value.

## Description

Reinterprets the bits in the half-precision floating-point number h as a signed short integer.

\_\_device\_\_ unsigned short int \_\_half\_as\_ushort (const \_\_half h)

Reinterprets bits in a half as an unsigned short integer.

#### **Parameters**

h

- half. Is only being read.

#### Returns

unsigned short int

► The reinterpreted value.

#### Description

Reinterprets the bits in the half-precision floating-point h as an unsigned short number.

\_\_device\_\_ \_half2 \_\_halves2half2 (const \_\_half a, const \_\_half b)

Combines two half numbers into one half2 number.

#### **Parameters**

а

- half. Is only being read.

b

- half. Is only being read.

#### Returns

half2

The half2 with one half equal to a and the other to b.

## Description

Combines two input half number a and b into one half2 number. Input a is stored in low 16 bits of the return value, input b is stored in high 16 bits of the return value.

\_\_host\_\_\_device\_\_ float \_\_high2float (const \_\_half2 a)

Converts high 16 bits of half2 to float and returns the result.

#### **Parameters**

a

- half2. Is only being read.

#### Returns

float

► The high 16 bits of a converted to float.

#### Description

Converts high 16 bits of half2 input a to 32-bit floating-point number and returns the result.

\_\_device\_\_ \_half \_\_high2half (const \_\_half2 a)

Returns high 16 bits of half2 input.

#### **Parameters**

а

- half2. Is only being read.

#### Returns

half

► The high 16 bits of the input.

#### Description

Returns high 16 bits of half2 input a.

\_\_device\_\_ \_half2 \_\_high2half2 (const \_\_half2 a)

Extracts high 16 bits from half2 input.

#### **Parameters**

a

- half2. Is only being read.

#### Returns

half2

► The half2 with both halves equal to the high 16 bits of the input.

#### Description

Extracts high 16 bits from half2 input a and returns a new half2 number which has both halves equal to the extracted bits.

# \_\_device\_\_ \_half2 \_\_highs2half2 (const \_\_half2 a, const \_\_half2 b)

Extracts high 16 bits from each of the two half2 inputs and combines into one half2 number.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

The high 16 bits of a and of b.

## Description

Extracts high 16 bits from each of the two half2 inputs and combines into one half2 number. High 16 bits from input a is stored in low 16 bits of the return value, high 16 bits from input b is stored in high 16 bits of the return value.

# device\_\_ \_half \_\_int2half\_rd (const int i)

Convert a signed integer to a half in round-down mode.

#### **Parameters**

i

- int. Is only being read.

#### Returns

half

▶ i converted to half.

## Description

Convert the signed integer value i to a half-precision floating-point value in round-down mode.

# \_\_host\_\_\_device\_\_half \_\_int2half\_rn (const int i)

Convert a signed integer to a half in round-to-nearest-even mode.

#### **Parameters**

i

- int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the signed integer value i to a half-precision floating-point value in round-to-nearest-even mode.

## \_\_device\_\_ \_half \_\_int2half\_ru (const int i)

Convert a signed integer to a half in round-up mode.

#### **Parameters**

i

- int. Is only being read.

#### Returns

half

▶ i converted to half.

## Description

Convert the signed integer value i to a half-precision floating-point value in round-up mode.

# \_\_device\_\_ \_half \_\_int2half\_rz (const int i)

Convert a signed integer to a half in round-towards-zero mode.

#### **Parameters**

i

- int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the signed integer value i to a half-precision floating-point value in round-towards-zero mode.

\_\_device\_\_ \_half \_\_ldca (const \_\_half \*ptr)

Generates a `ld.global.ca` load instruction.

#### **Parameters**

ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_half2 \_\_ldca (const \_\_half2 \*ptr)

Generates a `ld.global.ca` load instruction.

#### **Parameters**

ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_half \_\_ldcg (const \_\_half \*ptr)

Generates a `ld.global.cg` load instruction.

#### **Parameters**

ptr

- memory location

#### Returns

The value pointed by `ptr`

# \_\_device\_\_ \_half2 \_\_ldcg (const \_\_half2 \*ptr) Generates a `ld.global.cg` load instruction. **Parameters** ptr - memory location Returns The value pointed by `ptr` \_\_device\_\_ \_half \_\_ldcs (const \_\_half \*ptr) Generates a `ld.global.cs` load instruction. **Parameters** ptr - memory location Returns The value pointed by `ptr` \_\_device\_\_ \_half2 \_\_ldcs (const \_\_half2 \*ptr) Generates a `ld.global.cs` load instruction. **Parameters** ptr - memory location Returns The value pointed by `ptr` \_\_device\_\_ \_half \_\_ldcv (const \_\_half \*ptr) Generates a `ld.global.cv` load instruction. **Parameters** ptr - memory location

Returns

The value pointed by `ptr`

# \_\_device\_\_ \_\_half2 \_\_ldcv (const \_\_half2 \*ptr) Generates a `ld.global.cv` load instruction. Parameters ptr - memory location Returns The value pointed by `ptr` \_\_device\_\_ \_\_half \_\_ldg (const \_\_half \*ptr)

#### **Parameters**

ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_half2 \_\_ldg (const \_\_half2 \*ptr)

Generates a `ld.global.nc` load instruction.

Generates a `ld.global.nc` load instruction.

#### **Parameters**

ptr

- memory location

#### Returns

The value pointed by `ptr`

## Description

defined(\_\_CUDA\_ARCH\_\_) || (\_\_CUDA\_ARCH\_\_ >= 300)

Generates a `ld.global.lu` load instruction.

#### **Parameters**

ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_half2 \_\_ldlu (const \_\_half2 \*ptr)

Generates a `ld.global.lu` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_half \_\_ll2half\_rd (const long long int i)

Convert a signed 64-bit integer to a half in round-down mode.

#### **Parameters**

i

- long long int. Is only being read.

#### Returns

half

i converted to half.

## Description

Convert the signed 64-bit integer value  $\mathtt{i}$  to a half-precision floating-point value in round-down mode.

\_\_host\_\_\_\_device\_\_ \_half \_\_ll2half\_rn (const long long int i)

Convert a signed 64-bit integer to a half in round-to-nearest-even mode.

#### **Parameters**

i

- long long int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the signed 64-bit integer value i to a half-precision floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_half \_\_ll2half\_ru (const long long int i)

Convert a signed 64-bit integer to a half in round-up mode.

#### **Parameters**

i

- long long int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the signed 64-bit integer value i to a half-precision floating-point value in round-up mode.

# \_\_device\_\_ \_half \_\_ll2half\_rz (const long long int i)

Convert a signed 64-bit integer to a half in round-towards-zero mode.

#### **Parameters**

i

- long long int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the signed 64-bit integer value  $\mathtt{i}$  to a half-precision floating-point value in round-towards-zero mode.

# \_\_host\_\_\_device\_\_float \_\_low2float (const \_\_half2 a)

Converts low 16 bits of half2 to float and returns the result.

#### **Parameters**

a

- half2. Is only being read.

#### Returns

float

► The low 16 bits of a converted to float.

#### Description

Converts low 16 bits of half2 input a to 32-bit floating-point number and returns the result.

# \_\_device\_\_ \_half \_\_low2half (const \_\_half2 a)

Returns low 16 bits of half2 input.

#### **Parameters**

а

- half2. Is only being read.

#### Returns

half

▶ Returns half which contains low 16 bits of the input a.

#### Description

Returns low 16 bits of half2 input a.

# \_\_device\_\_ \_half2 \_\_low2half2 (const \_\_half2 a)

Extracts low 16 bits from half2 input.

#### **Parameters**

a

- half2. Is only being read.

#### Returns

half2

▶ The half2 with both halves equal to the low 16 bits of the input.

#### Description

Extracts low 16 bits from half2 input a and returns a new half2 number which has both halves equal to the extracted bits.

\_\_device\_\_ \_half2 \_\_lowhigh2highlow (const \_\_half2 a) Swaps both halves of the half2 input.

#### **Parameters**

a

- half2. Is only being read.

#### Returns

half2

a with its halves being swapped.

#### Description

Swaps both halves of the half2 input and returns a new half2 number with swapped halves.

\_\_device\_\_ \_half2 \_\_lows2half2 (const \_\_half2 a, const half2 b)

Extracts low 16 bits from each of the two half2 inputs and combines into one half2 number.

#### **Parameters**

а

- half2. Is only being read.

b

- half2. Is only being read.

#### Returns

half2

► The low 16 bits of a and of b.

## Description

Extracts low 16 bits from each of the two half2 inputs and combines into one half2 number. Low 16 bits from input a is stored in low 16 bits of the return value, low 16 bits from input b is stored in high 16 bits of the return value.

# \_\_device\_\_ \_half \_\_shfl\_down\_sync (const unsigned mask, const \_\_half var, const unsigned int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread with higher ID relative to the caller.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- half. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 2-byte word referenced by var from the source thread ID as half. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by adding delta to the caller's thread ID. The value of var held by the resulting thread ID is returned: this has the effect of shifting var down the warp by delta threads. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. As for <u>shfl up sync()</u>, the ID number of the source thread will not wrap around the value of width and so the upper delta threads will remain unchanged.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_\_half2 \_\_shfl\_down\_sync (const unsigned mask, const \_\_half2 var, const unsigned int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread with higher ID relative to the caller.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- half2. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 4-byte word referenced by var from the source thread ID as half2. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by adding delta to the caller's thread ID. The value of var held by the resulting thread ID is returned: this has the effect of shifting var down the warp by delta threads. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. As for <u>shfl up sync()</u>, the ID number of the source thread will not wrap around the value of width and so the upper delta threads will remain unchanged.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_half \_\_shfl\_sync (const unsigned mask, const \_half var, const int delta, const int width)

Exchange a variable between threads within a warp. Direct copy from indexed thread.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- half. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 2-byte word referenced by var from the source thread ID as half. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Returns the value of var held by the thread whose ID is given by delta. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. If delta is outside the range [0:width-1], the value returned corresponds to the value of var held by the delta modulo width (i.e. within the same subsection). width must have a value which is a power of 2; results are undefined if width is not a power of 2, or is a number greater than warpSize.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

\_\_device\_\_ \_half2 \_\_shfl\_sync (const unsigned mask, const half2 var, const int delta, const int width)

Exchange a variable between threads within a warp. Direct copy from indexed thread.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- half2. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 4-byte word referenced by var from the source thread ID as half2. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Returns the value of var held by the thread whose ID is given by delta. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. If delta is outside the range [0:width-1], the value returned corresponds to the value of var held by the delta modulo width (i.e. within the same subsection). width must have a value which is a power of 2; results are undefined if width is not a power of 2, or is a number greater than warpSize.

# \_\_device\_\_ \_half \_\_shfl\_up\_sync (const unsigned mask, const half var, const unsigned int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread with lower ID relative to the caller.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- half. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 2-byte word referenced by var from the source thread ID as half. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by subtracting delta from the caller's lane ID. The value of var held by the resulting lane ID is returned: in effect, var is shifted up the warp by delta threads. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. The source thread index will not wrap around the value of width, so effectively the lower delta threads will be unchanged. width must have a value which is a power of 2; results are undefined if width is not a power of 2, or is a number greater than warpSize.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

\_\_device\_\_ \_half2 \_\_shfl\_up\_sync (const unsigned mask, const \_\_half2 var, const unsigned int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread with lower ID relative to the caller.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- half2. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 4-byte word referenced by var from the source thread ID as half2. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

## Description

Calculates a source thread ID by subtracting delta from the caller's lane ID. The value of var held by the resulting lane ID is returned: in effect, var is shifted up the warp by delta threads. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. The source thread index will not wrap around the value of width, so effectively the lower delta threads will be unchanged. width must have a value which

is a power of 2; results are undefined if width is not a power of 2, or is a number greater than warpSize.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_half \_\_shfl\_xor\_sync (const unsigned mask, const \_\_half var, const int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread based on bitwise XOR of own thread ID.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- half. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 2-byte word referenced by var from the source thread ID as half. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

## Description

Calculates a source thread ID by performing a bitwise XOR of the caller's thread ID with mask: the value of var held by the resulting thread ID is returned. If width is less than warpSize then each group of width consecutive threads are able to access elements from earlier groups of threads, however if they attempt to access elements from later groups of threads their own value of var will be returned. This mode implements a butterfly addressing pattern such as is used in tree reduction and broadcast.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_\_half2 \_\_shfl\_xor\_sync (const unsigned mask, const \_\_half2 var, const int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread based on bitwise XOR of own thread ID.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- half2. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 4-byte word referenced by var from the source thread ID as half2. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by performing a bitwise XOR of the caller's thread ID with mask: the value of var held by the resulting thread ID is returned. If width is less than warpSize then each group of width consecutive threads are able to access elements from earlier groups of threads, however if they attempt to access elements from later groups of threads their own value of var will be returned. This mode implements a butterfly addressing pattern such as is used in tree reduction and broadcast.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

## device half short2half rd (const short int i)

Convert a signed short integer to a half in round-down mode.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the signed short integer value  $\mathtt{i}$  to a half-precision floating-point value in round-down mode.

# \_\_host\_\_\_device\_\_ \_half \_\_short2half\_rn (const short int i)

Convert a signed short integer to a half in round-to-nearest-even mode.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

half

▶ i converted to half.

## Description

Convert the signed short integer value  $\mathtt{i}$  to a half-precision floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_half \_\_short2half\_ru (const short int i)

Convert a signed short integer to a half in round-up mode.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the signed short integer value i to a half-precision floating-point value in round-up mode.

# \_\_device\_\_ \_half \_\_short2half\_rz (const short int i)

Convert a signed short integer to a half in round-towards-zero mode.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the signed short integer value i to a half-precision floating-point value in round-towards-zero mode.

# \_\_device\_\_ \_half \_\_short\_as\_half (const short int i)

Reinterprets bits in a signed short integer as a half.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

half

► The reinterpreted value.

## Description

Reinterprets the bits in the signed short integer i as a half-precision floating-point number.

# \_\_device\_\_ void \_\_stcg (const \_\_half \*ptr, const \_\_half value)

Generates a `st.global.cg` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ void \_\_stcg (const \_\_half2 \*ptr, const \_\_half2 value)

Generates a `st.global.cg` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ void \_\_stcs (const \_\_half \*ptr, const \_\_half value)

Generates a `st.global.cs` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ void \_\_stcs (const \_\_half2 \*ptr, const \_\_half2 value)

Generates a `st.global.cs` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ void \_\_stwb (const \_\_half \*ptr, const \_\_half value)

Generates a `st.global.wb` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ void \_\_stwb (const \_\_half2 \*ptr, const \_\_half2 value)

Generates a `st.global.wb` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ void \_\_stwt (const \_\_half \*ptr, const \_\_half value)

Generates a `st.global.wt` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ void \_\_stwt (const \_\_half2 \*ptr, const \_\_half2 value)

Generates a `st.global.wt` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ \_half \_\_uint2half\_rd (const unsigned int i)

Convert an unsigned integer to a half in round-down mode.

#### **Parameters**

i

- unsigned int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the unsigned integer value  $\mathtt{i}$  to a half-precision floating-point value in round-down mode.

# \_\_host\_\_\_\_device\_\_ \_half \_\_uint2half\_rn (const unsigned int i)

Convert an unsigned integer to a half in round-to-nearest-even mode.

#### **Parameters**

i

- unsigned int. Is only being read.

#### Returns

half

▶ i converted to half.

## Description

Convert the unsigned integer value i to a half-precision floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_half \_\_uint2half\_ru (const unsigned int i)

Convert an unsigned integer to a half in round-up mode.

#### **Parameters**

i

- unsigned int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the unsigned integer value  $\mathtt{i}$  to a half-precision floating-point value in round-up mode.

\_\_device\_\_ \_half \_\_uint2half\_rz (const unsigned int i)

Convert an unsigned integer to a half in round-towards-zero mode.

#### **Parameters**

i

- unsigned int. Is only being read.

#### Returns

half

▶ i converted to half.

## Description

Convert the unsigned integer value  $\mathtt{i}$  to a half-precision floating-point value in round-towards-zero mode.

# \_\_device\_\_ \_half \_\_ull2half\_rd (const unsigned long long int i)

Convert an unsigned 64-bit integer to a half in round-down mode.

#### **Parameters**

i

- unsigned long long int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the unsigned 64-bit integer value i to a half-precision floating-point value in round-down mode.

# \_\_host\_\_\_\_device\_\_ \_half \_\_ull2half\_rn (const unsigned long long int i)

Convert an unsigned 64-bit integer to a half in round-to-nearest-even mode.

#### **Parameters**

i

- unsigned long long int. Is only being read.

#### Returns

half

i converted to half.

#### Description

Convert the unsigned 64-bit integer value i to a half-precision floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_half \_\_ull2half\_ru (const unsigned long long int i)

Convert an unsigned 64-bit integer to a half in round-up mode.

#### **Parameters**

i

- unsigned long long int. Is only being read.

#### Returns

half

▶ i converted to half.

## Description

Convert the unsigned 64-bit integer value i to a half-precision floating-point value in round-up mode.

# \_\_device\_\_ \_half \_\_ull2half\_rz (const unsigned long long int i)

Convert an unsigned 64-bit integer to a half in round-towards-zero mode.

#### **Parameters**

i

- unsigned long long int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the unsigned 64-bit integer value i to a half-precision floating-point value in round-towards-zero mode.

# \_\_device\_\_ \_half \_\_ushort2half\_rd (const unsigned short int i)

Convert an unsigned short integer to a half in round-down mode.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

half

▶ i converted to half.

## **Description**

Convert the unsigned short integer value i to a half-precision floating-point value in round-down mode.

# \_\_host\_\_\_\_device\_\_ \_half \_\_ushort2half\_rn (const unsigned short int i)

Convert an unsigned short integer to a half in round-to-nearest-even mode.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the unsigned short integer value i to a half-precision floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_half \_\_ushort2half\_ru (const unsigned short int i)

Convert an unsigned short integer to a half in round-up mode.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

half

▶ i converted to half.

## **Description**

Convert the unsigned short integer value i to a half-precision floating-point value in round-up mode.

# \_\_device\_\_ \_half \_\_ushort2half\_rz (const unsigned short int i)

Convert an unsigned short integer to a half in round-towards-zero mode.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

half

▶ i converted to half.

#### Description

Convert the unsigned short integer value i to a half-precision floating-point value in round-towards-zero mode.

# \_\_device\_\_ \_half \_\_ushort\_as\_half (const unsigned short int i)

Reinterprets bits in an unsigned short integer as a half.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

half

► The reinterpreted value.

## Description

Reinterprets the bits in the unsigned short integer i as a half-precision floating-point number.

## 1.2.6. Half Math Functions

Half Precision Intrinsics

To use these functions, include the header file cuda fp16.h in your program.

# \_\_device\_\_ \_half hceil (const \_\_half h)

Calculate ceiling of the input argument.

#### **Parameters**

h

- half. Is only being read.

#### Returns

half

► The smallest integer value not less than h.

#### Description

Compute the smallest integer value not less than h.

# \_\_device\_\_ \_half hcos (const \_\_half a)

Calculates half cosine in round-to-nearest-even mode.

#### **Parameters**

а

- half. Is only being read.

#### Returns

half

► The cosine of a.

## Description

Calculates half cosine of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half hexp (const \_\_half a)

Calculates half natural exponential function in round-to-nearest mode.

#### **Parameters**

а

- half. Is only being read.

#### Returns

half

► The natural exponential function on a.

#### Description

Calculates half natural exponential function of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half hexp10 (const \_\_half a)

Calculates half decimal exponential function in round-to-nearest mode.

#### **Parameters**

а

- half. Is only being read.

#### Returns

half

► The decimal exponential function on a.

#### Description

Calculates half decimal exponential function of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half hexp2 (const \_\_half a)

Calculates half binary exponential function in round-to-nearest mode.

#### **Parameters**

a

- half. Is only being read.

#### Returns

half

► The binary exponential function on a.

#### Description

Calculates half binary exponential function of input a in round-to-nearest-even mode.

## \_\_device\_\_ \_half hfloor (const \_\_half h)

Calculate the largest integer less than or equal to h.

#### **Parameters**

h

- half. Is only being read.

#### Returns

half

The largest integer value which is less than or equal to h.

## Description

Calculate the largest integer value which is less than or equal to h.

# \_\_device\_\_ \_half hlog (const \_\_half a)

Calculates half natural logarithm in round-to-nearest-even mode.

#### **Parameters**

a

- half. Is only being read.

#### Returns

half

► The natural logarithm of a.

#### Description

Calculates half natural logarithm of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half hlog10 (const \_\_half a)

Calculates half decimal logarithm in round-to-nearest-even mode.

#### **Parameters**

a

- half. Is only being read.

#### Returns

half

► The decimal logarithm of a.

#### Description

Calculates half decimal logarithm of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half hlog2 (const \_\_half a)

Calculates half binary logarithm in round-to-nearest-even mode.

## **Parameters**

а

- half. Is only being read.

#### Returns

half

The binary logarithm of a.

# Description

Calculates half binary logarithm of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half hrcp (const \_\_half a)

Calculates half reciprocal in round-to-nearest-even mode.

### **Parameters**

а

- half. Is only being read.

## Returns

half

► The reciprocal of a.

# Description

Calculates half reciprocal of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half hrint (const \_\_half h)

Round input to nearest integer value in half-precision floating-point number.

#### **Parameters**

h

- half. Is only being read.

#### Returns

half

► The nearest integer to h.

Round h to the nearest integer value in half-precision floating-point format, with halfway cases rounded to the nearest even integer value.

# \_\_device\_\_ \_half hrsqrt (const \_\_half a)

Calculates half reciprocal square root in round-to-nearest-even mode.

## **Parameters**

а

- half. Is only being read.

### Returns

half

► The reciprocal square root of a.

# Description

Calculates half reciprocal square root of input a in round-to-nearest mode.

# \_\_device\_\_ \_half hsin (const \_\_half a)

Calculates half sine in round-to-nearest-even mode.

### **Parameters**

а

- half. Is only being read.

#### Returns

half

► The sine of a.

# Description

Calculates half sine of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half hsqrt (const \_\_half a)

Calculates half square root in round-to-nearest-even mode.

## **Parameters**

a

- half. Is only being read.

#### Returns

half

The square root of a.

# Description

Calculates half square root of input a in round-to-nearest-even mode.

# \_\_device\_\_ \_half htrunc (const \_\_half h)

Truncate input argument to the integral part.

### **Parameters**

h

- half. Is only being read.

#### Returns

half

► The truncated integer value.

# Description

Round h to the nearest integer value that does not exceed h in magnitude.

# 1.2.7. Half2 Math Functions

Half Precision Intrinsics

To use these functions, include the header file cuda\_fp16.h in your program.

# \_\_device\_\_ \_half2 h2ceil (const \_\_half2 h)

Calculate half2 vector ceiling of the input argument.

## **Parameters**

h

- half2. Is only being read.

#### Returns

half2

▶ The vector of smallest integers not less than h.

# Description

For each component of vector h compute the smallest integer value not less than h.

# \_\_device\_\_ half2 h2cos (const \_\_half2 a)

Calculates half2 vector cosine in round-to-nearest-even mode.

### **Parameters**

a

- half2. Is only being read.

#### Returns

half2

► The elementwise cosine on vector a.

# Description

Calculates half2 cosine of input vector a in round-to-nearest-even mode.

# \_\_device\_ \_ half2 h2exp (const \_\_half2 a)

Calculates half2 vector exponential function in round-to-nearest mode.

#### **Parameters**

а

- half2. Is only being read.

#### Returns

half2

► The elementwise exponential function on vector a.

Calculates half2 exponential function of input vector a in round-to-nearest-even mode.

# \_\_device\_\_ \_half2 h2exp10 (const \_\_half2 a)

Calculates half2 vector decimal exponential function in round-to-nearest-even mode.

#### **Parameters**

а

- half2. Is only being read.

#### Returns

half2

The elementwise decimal exponential function on vector a.

# Description

Calculates half2 decimal exponential function of input vector a in round-to-nearest-even mode.

# \_\_device\_\_ \_half2 h2exp2 (const \_\_half2 a)

Calculates half2 vector binary exponential function in round-to-nearest-even mode.

### **Parameters**

а

- half2. Is only being read.

## Returns

half2

▶ The elementwise binary exponential function on vector a.

# Description

Calculates half2 binary exponential function of input vector a in round-to-nearest-even mode.

# device half2 h2floor (const half2 h)

Calculate the largest integer less than or equal to h.

## **Parameters**

h

- half2. Is only being read.

#### Returns

half2

▶ The vector of largest integers which is less than or equal to h.

# Description

For each component of vector h calculate the largest integer value which is less than or equal to h

# \_\_device\_\_ \_half2 h2log (const \_\_half2 a)

Calculates half2 vector natural logarithm in round-to-nearest-even mode.

#### **Parameters**

а

- half2. Is only being read.

#### Returns

half2

► The elementwise natural logarithm on vector a.

# Description

Calculates half2 natural logarithm of input vector a in round-to-nearest-even mode.

# 

Calculates half2 vector decimal logarithm in round-to-nearest-even mode.

## **Parameters**

a

- half2. Is only being read.

#### Returns

half2

► The elementwise decimal logarithm on vector a.

# Description

Calculates half2 decimal logarithm of input vector a in round-to-nearest-even mode.

# \_\_device\_\_ \_half2 h2log2 (const \_\_half2 a)

Calculates half2 vector binary logarithm in round-to-nearest-even mode.

#### **Parameters**

а

- half2. Is only being read.

### Returns

half2

▶ The elementwise binary logarithm on vector a.

# Description

Calculates half2 binary logarithm of input vector a in round-to-nearest mode.

# \_\_device\_\_ \_half2 h2rcp (const \_\_half2 a)

Calculates half2 vector reciprocal in round-to-nearest-even mode.

### **Parameters**

a

- half2. Is only being read.

## Returns

half2

► The elementwise reciprocal on vector a.

# **Description**

Calculates half2 reciprocal of input vector a in round-to-nearest-even mode.

# device half2 h2rint (const half2 h)

Round input to nearest integer value in half-precision floating-point number.

## **Parameters**

h

- half2. Is only being read.

#### Returns

half2

The vector of rounded integer values.

# Description

Round each component of half2 vector h to the nearest integer value in half-precision floating-point format, with halfway cases rounded to the nearest even integer value.

# \_\_device\_\_ \_half2 h2rsqrt (const \_\_half2 a)

Calculates half2 vector reciprocal square root in round-to-nearest mode.

#### **Parameters**

а

- half2. Is only being read.

#### Returns

half2

► The elementwise reciprocal square root on vector a.

# Description

Calculates half2 reciprocal square root of input vector a in round-to-nearest-even mode.

# \_\_device\_\_ \_half2 h2sin (const \_\_half2 a)

Calculates half2 vector sine in round-to-nearest-even mode.

## **Parameters**

а

- half2. Is only being read.

#### Returns

half2

► The elementwise sine on vector a.

# Description

Calculates half2 sine of input vector a in round-to-nearest-even mode.

# \_\_device\_\_ \_half2 h2sqrt (const \_\_half2 a)

Calculates half2 vector square root in round-to-nearest-even mode.

#### **Parameters**

a

- half2. Is only being read.

#### Returns

half2

► The elementwise square root on vector a.

# Description

Calculates half2 square root of input vector a in round-to-nearest mode.

# \_\_device\_\_ \_half2 h2trunc (const \_\_half2 h)

Truncate half2 vector input argument to the integral part.

### **Parameters**

h

- half2. Is only being read.

## Returns

half2

► The truncated h.

# Description

Round each component of vector h to the nearest integer value that does not exceed h in magnitude.

# 1.3. Bfloat16 Precision Intrinsics

This section describes nv\_bfloat16 precision intrinsic functions that are only supported in device code. To use these functions, include the header file cuda\_bf16.h in your program.

The following macros are available to help users selectively enable/disable various definitions present in the header file:

- CUDA\_NO\_BFLOAT16 If defined, this macro will prevent the definition of additional type aliases in the global namespace, helping to avoid potential conflicts with symbols defined in the user program.
- ► \_\_CUDA\_NO\_BFLOAT16\_CONVERSIONS\_\_ If defined, this macro will prevent the use of the C++ type conversions (converting constructors and conversion operators) that are common for built-in floating-point types, but may be undesirable for \_\_nv\_bfloat16 which is essentially a user-defined type.
- \_\_CUDA\_NO\_BFLOAT16\_OPERATORS\_\_ and \_\_CUDA\_NO\_BFLOAT162\_OPERATORS\_\_
   If defined, these macros will prevent the inadvertent use of usual arithmetic and comparison operators. This enforces the storage-only type semantics and prevents C++ style computations on \_\_nv\_bfloat16 and \_\_nv\_bfloat162 types.

Bfloat16 Arithmetic Functions

Bfloat162 Arithmetic Functions

**Bfloat16 Comparison Functions** 

Bfloat162 Comparison Functions

Bfloat16 Precision Conversion and Data Movement

Bfloat16 Math Functions

Bfloat162 Math Functions

# 1.3.1. Bfloat16 Arithmetic Functions

Bfloat16 Precision Intrinsics

To use these functions, include the header file cuda bf16.h in your program.

# \_\_device\_\_ \_\_nv\_bfloat162 \_\_h2div (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv\_bfloat162 vector division in round-to-nearest-even mode.

# Description

Divides nv bfloat162 input vector a by input vector b in round-to-nearest mode.

\_\_device\_\_ \_nv\_bfloat16 \_\_habs (const \_\_nv\_bfloat16 a)

Calculates the absolute value of input nv bfloat16 number and returns the result.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

## Returns

nv bfloat16

► The absolute value of a.

# Description

Calculates the absolute value of input  $nv\_bfloat16$  number and returns the result.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_hadd (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b)

Performs nv\_bfloat16 addition in round-to-nearest-even mode.

# Description

Performs nv\_bfloat16 addition of inputs a and b, in round-to-nearest-even mode.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_hadd\_rn (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b)

Performs nv bfloat16 addition in round-to-nearest-even mode.

# Description

Performs nv\_bfloat16 addition of inputs a and b, in round-to-nearest-even mode. Prevents floating-point contractions of mul+add into fma.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_hadd\_sat (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b)

Performs nv bfloat16 addition in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

▶ The sum of a and b, with respect to saturation.

# Description

Performs  $nv_bfloat16$  add of inputs a and b, in round-to-nearest-even mode, and clamps the result to range [0.0, 1.0]. NaN results are flushed to +0.0.

Performs nv bfloat16 division in round-to-nearest-even mode.

# Description

Divides nv bfloat16 input a by input b in round-to-nearest mode.

Performs nv bfloat16 fused multiply-add in round-to-nearest-even mode.

# Description

Performs nv\_bfloat16 multiply on inputs a and b, then performs a nv\_bfloat16 add of the result with c, rounding the result once in round-to-nearest-even mode.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_hfma\_relu (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b, const \_\_nv\_bfloat16 c)

Performs nv\_bfloat16 fused multiply-add in round-to-nearest-even mode with relu saturation.

### **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

C

- nv bfloat16. Is only being read.

#### Returns

nv bfloat16

The result of fused multiply-add operation on a, b, and c with relu saturation.

# Description

Performs nv\_bfloat16 multiply on inputs a and b, then performs a nv\_bfloat16 add of the result with c, rounding the result once in round-to-nearest-even mode. Then negative result is clamped to 0. NaN result is converted to canonical NaN.

\_\_device\_\_ \_nv\_bfloat16 \_\_hfma\_sat (const \_\_nv\_bfloat16 a, const nv bfloat16 b, const nv bfloat16 c)

Performs  $nv_bfloat16$  fused multiply-add in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

C

- nv\_bfloat16. Is only being read.

## Returns

nv\_bfloat16

The result of fused multiply-add operation on a, b, and c, with respect to saturation.

Performs nv\_bfloat16 multiply on inputs a and b, then performs a nv\_bfloat16 add of the result with c, rounding the result once in round-to-nearest-even mode, and clamps the result to range [0.0, 1.0]. NaN results are flushed to +0.0.

Performs nv bfloat16 multiplication in round-to-nearest-even mode.

# Description

Performs nv bfloat16 multiplication of inputs a and b, in round-to-nearest mode.

Performs nv bfloat16 multiplication in round-to-nearest-even mode.

# Description

Performs nv\_bfloat16 multiplication of inputs a and b, in round-to-nearest mode. Prevents floating-point contractions of mul+add or sub into fma.

Performs nv\_bfloat16 multiplication in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

nv bfloat16

▶ The result of multiplying a and b, with respect to saturation.

# Description

Performs  $nv\_bfloat16$  multiplication of inputs a and b, in round-to-nearest mode, and clamps the result to range [0.0, 1.0]. NaN results are flushed to +0.0.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_hneg (const \_\_nv\_bfloat16 a)

Negates input nv bfloat16 number and returns the result.

# Description

Negates input nv bfloat16 number and returns the result.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_hsub (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b)

Performs nv\_bfloat16 subtraction in round-to-nearest-even mode.

# Description

Subtracts nv bfloat16 input b from input a in round-to-nearest mode.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_hsub\_rn (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b)

Performs nv bfloat16 subtraction in round-to-nearest-even mode.

# Description

Subtracts nv\_bfloat16 input b from input a in round-to-nearest mode. Prevents floating-point contractions of mul+sub into fma.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_hsub\_sat (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b)

Performs  $nv\_bfloat16$  subtraction in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

nv bfloat16

▶ The result of subtraction of b from a, with respect to saturation.

Subtracts nv\_bfloat16 input b from input a in round-to-nearest mode, and clamps the result to range [0.0, 1.0]. NaN results are flushed to +0.0.

# \_\_device\_\_ \_\_nv\_bfloat16 atomicAdd (const \_\_nv\_bfloat16 \*address, const \_\_nv\_bfloat16 val)

Adds val to the value stored at address in global or shared memory, and writes this value back to address. This operation is performed in one atomic operation.

#### **Parameters**

#### address

- \_\_nv\_bfloat16\*. An address in global or shared memory.

#### val

- \_\_nv\_bfloat16. The value to be added.

#### Returns

\_\_nv\_bfloat16

▶ The old value read from address.

# Description

The location of address must be in global or shared memory. This operation has undefined behavior otherwise. This operation is only supported by devices of compute capability 8.x and higher.



#### Note:

For more details for this function see the Atomic Functions section in the CUDA C++ Programming Guide.

# 1.3.2. Bfloat162 Arithmetic Functions

Bfloat16 Precision Intrinsics

To use these functions, include the header file cuda bf16.h in your program.

Calculates the absolute value of both halves of the input nv\_bfloat162 number and returns the result.

## **Parameters**

a

- nv\_bfloat162. Is only being read.

#### Returns

bfloat2

Returns a with the absolute value of both halves.

# Description

Calculates the absolute value of both halves of the input nv\_bfloat162 number and returns the result.

Performs nv bfloat162 vector addition in round-to-nearest-even mode.

# Description

Performs nv bfloat162 vector add of inputs a and b, in round-to-nearest mode.

Performs nv bfloat162 vector addition in round-to-nearest-even mode.

# Description

Performs  $nv\_bfloat162$  vector add of inputs a and b, in round-to-nearest mode. Prevents floating-point contractions of mul+add into fma.

Performs  $nv_bfloat162$  vector addition in round-to-nearest-even mode, with saturation to [0.0, 1.0].

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

nv bfloat162

The sum of a and b, with respect to saturation.

# Description

Performs nv\_bfloat162 vector add of inputs a and b, in round-to-nearest mode, and clamps the results to range [0.0, 1.0]. NaN results are flushed to +0.0.

\_\_device\_\_ \_\_nv\_bfloat162 \_\_hcmadd (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b, const \_\_nv\_bfloat162 c)

Performs fast complex multiply-accumulate.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

C

- nv bfloat162. Is only being read.

#### Returns

nv\_bfloat162

The result of complex multiply-accumulate operation on complex numbers a, b, and c

# Description

Interprets vector nv\_bfloat162 input pairs a, b, and c as complex numbers in nv bfloat16 precision and performs complex multiply-accumulate operation: a\*b + c

Performs nv bfloat162 vector fused multiply-add in round-to-nearest-even mode.

# Description

Performs nv\_bfloat162 vector multiply on inputs a and b, then performs a nv\_bfloat162 vector add of the result with c, rounding the result once in round-to-nearest-even mode.

```
__device__ __nv_bfloat162 __hfma2_relu (const
__nv_bfloat162 a, const __nv_bfloat162 b, const
__nv_bfloat162 c)
```

Performs nv\_bfloat162 vector fused multiply-add in round-to-nearest-even mode with relu saturation.

# **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

C

- nv\_bfloat162. Is only being read.

#### Returns

nv bfloat162

The result of elementwise fused multiply-add operation on vectors a, b, and c with relu saturation.

# Description

Performs nv\_bfloat162 vector multiply on inputs a and b, then performs a nv\_bfloat162 vector add of the result with c, rounding the result once in round-to-nearest-even mode. Then negative result is clamped to 0. NaN result is converted to canonical NaN.

Performs nv\_bfloat162 vector fused multiply-add in round-to-nearest-even mode, with saturation to [0.0, 1.0].

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

C

- nv\_bfloat162. Is only being read.

## Returns

nv bfloat162

The result of elementwise fused multiply-add operation on vectors a, b, and c, with respect to saturation.

# Description

Performs nv\_bfloat162 vector multiply on inputs a and b, then performs a nv\_bfloat162 vector add of the result with c, rounding the result once in round-to-nearest-even mode, and clamps the results to range [0.0, 1.0]. NaN results are flushed to +0.0.

Performs nv bfloat162 vector multiplication in round-to-nearest-even mode.

# Description

Performs nv\_bfloat162 vector multiplication of inputs a and b, in round-to-nearest-even mode.

Performs nv bfloat162 vector multiplication in round-to-nearest-even mode.

# Description

Performs nv\_bfloat162 vector multiplication of inputs a and b, in round-to-nearest-even mode. Prevents floating-point contractions of mul+add or sub into fma.

Performs nv\_bfloat162 vector multiplication in round-to-nearest-even mode, with saturation to [0.0, 1.0].

## **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

nv bfloat162

The result of elementwise multiplication of vectors a and b, with respect to saturation.

# Description

Performs nv\_bfloat162 vector multiplication of inputs a and b, in round-to-nearest-even mode, and clamps the results to range [0.0, 1.0]. NaN results are flushed to +0.0.

Negates both halves of the input nv bfloat162 number and returns the result.

# Description

Negates both halves of the input nv\_bfloat162 number a and returns the result.

Performs nv\_bfloat162 vector subtraction in round-to-nearest-even mode.

# Description

Subtracts nv bfloat162 input vector b from input vector a in round-to-nearest-even mode.

```
__device__ __nv_bfloat162 __hsub2_rn (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector subtraction in round-to-nearest-even mode.

# Description

Subtracts nv\_bfloat162 input vector b from input vector a in round-to-nearest-even mode. Prevents floating-point contractions of mul+sub into fma.

Performs nv\_bfloat162 vector subtraction in round-to-nearest-even mode, with saturation to [0.0, 1.0].

### **Parameters**

а

- nv bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

nv bfloat162

▶ The subtraction of vector b from a, with respect to saturation.

# Description

Subtracts nv\_bfloat162 input vector b from input vector a in round-to-nearest-even mode, and clamps the results to range [0.0, 1.0]. NaN results are flushed to +0.0.

Vector add val to the value stored at address in global or shared memory, and writes this value back to address. The atomicity of the add operation is guaranteed separately for each

of the two nv\_bfloat16 elements; the entire \_\_nv\_bfloat162 is not guaranteed to be atomic as a single 32-bit access.

## **Parameters**

#### address

- \_\_nv\_bfloat162\*. An address in global or shared memory.

#### val

- \_\_nv\_bfloat162. The value to be added.

#### Returns

\_\_nv\_bfloat162

▶ The old value read from address.

# Description

The location of address must be in global or shared memory. This operation has undefined behavior otherwise. This operation is only supported by devices of compute capability 8.x and higher.



#### Note:

For more details for this function see the Atomic Functions section in the CUDA C++ Programming Guide.

# 1.3.3. Bfloat16 Comparison Functions

Bfloat16 Precision Intrinsics

To use these functions, include the header file cuda bf16.h in your program.

```
__device__ bool __heq (const __nv_bfloat16 a, const
__nv_bfloat16 b)
```

Performs nv bfloat16 if-equal comparison.

#### **Parameters**

а

- nv bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

The boolean result of if-equal comparison of a and b.

# Description

Performs nv\_bfloat16 if-equal comparison of inputs a and b. NaN inputs generate false results.

```
__device__ bool __hequ (const __nv_bfloat16 a, const
__nv_bfloat16 b)
```

Performs nv bfloat16 unordered if-equal comparison.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

The boolean result of unordered if-equal comparison of a and b.

# Description

Performs nv\_bfloat16 if-equal comparison of inputs a and b. NaN inputs generate true results.

```
__device__ bool __hge (const __nv_bfloat16 a, const
__nv_bfloat16 b)
```

Performs nv bfloat16 greater-equal comparison.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

b

- nv bfloat16. Is only being read.

#### Returns

bool

The boolean result of greater-equal comparison of a and b.

Performs nv\_bfloat16 greater-equal comparison of inputs a and b. NaN inputs generate false results.

Performs nv bfloat16 unordered greater-equal comparison.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

▶ The boolean result of unordered greater-equal comparison of a and b.

# Description

Performs nv\_bfloat16 greater-equal comparison of inputs a and b. NaN inputs generate true results.

```
__device__ bool __hgt (const __nv_bfloat16 a, const
__nv_bfloat16 b)
```

Performs nv bfloat16 greater-than comparison.

## **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

The boolean result of greater-than comparison of a and b.

Performs nv\_bfloat16 greater-than comparison of inputs a and b. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hgtu (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b)

Performs nv bfloat16 unordered greater-than comparison.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

▶ The boolean result of unordered greater-than comparison of a and b.

# Description

Performs nv\_bfloat16 greater-than comparison of inputs a and b. NaN inputs generate true results.

# \_\_device\_\_ int \_\_hisinf (const \_\_nv\_bfloat16 a)

Checks if the input nv bfloat16 number is infinite.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

#### Returns

int

- -1 iff a is equal to negative infinity,
- 1 iff a is equal to positive infinity,
- ▶ 0 otherwise.

# Description

Checks if the input nv bfloat16 number a is infinite.

# \_\_device\_\_ bool \_\_hisnan (const \_\_nv\_bfloat16 a)

Determine whether nv bfloat16 argument is a NaN.

## **Parameters**

а

- nv\_bfloat16. Is only being read.

#### Returns

bool

true iff argument is NaN.

# Description

Determine whether nv\_bfloat16 value a is a NaN.

# \_\_device\_\_ bool \_\_hle (const \_\_nv\_bfloat16 a, const nv bfloat16 b)

Performs nv bfloat16 less-equal comparison.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

h

- nv\_bfloat16. Is only being read.

#### Returns

bool

▶ The boolean result of less-equal comparison of a and b.

# Description

Performs nv\_bfloat16 less-equal comparison of inputs a and b. NaN inputs generate false results.

Performs nv bfloat16 unordered less-equal comparison.

## **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

The boolean result of unordered less-equal comparison of a and b.

# Description

Performs nv\_bfloat16 less-equal comparison of inputs a and b. NaN inputs generate true results.

Performs nv bfloat16 less-than comparison.

## **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

▶ The boolean result of less-than comparison of a and b.

# Description

Performs nv\_bfloat16 less-than comparison of inputs a and b. NaN inputs generate false results.

Performs nv\_bfloat16 unordered less-than comparison.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

The boolean result of unordered less-than comparison of a and b.

# Description

Performs nv\_bfloat16 less-than comparison of inputs a and b. NaN inputs generate true results.

Calculates nv bfloat16 maximum of two input values.

# Description

Calculates nv bfloat16 max(a, b) defined as (a > b)? a : b.

- If either of inputs is NaN, the other input is returned.
- If both inputs are NaNs, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_hmax\_nan (const \_\_nv\_bfloat16 a, const \_\_nv\_bfloat16 b)

Calculates nv bfloat16 maximum of two input values, NaNs pass through.

## Description

Calculates nv bfloat16 max(a, b) defined as (a > b)? a : b.

- If either of inputs is NaN, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0

Calculates nv bfloat16 minimum of two input values.

# Description

Calculates nv bfloat16 min(a, b) defined as (a < b)? a : b.

- If either of inputs is NaN, the other input is returned.
- If both inputs are NaNs, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0

Calculates nv bfloat16 minimum of two input values, NaNs pass through.

# Description

Calculates nv bfloat16 min(a, b) defined as (a < b)? a : b.

- If either of inputs is NaN, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0

Performs nv bfloat16 not-equal comparison.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

h

- nv bfloat16. Is only being read.

#### Returns

bool

The boolean result of not-equal comparison of a and b.

# Description

Performs nv\_bfloat16 not-equal comparison of inputs a and b. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hneu (const \_\_nv\_bfloat16 a, const nv bfloat16 b)

Performs nv bfloat16 unordered not-equal comparison.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

#### Returns

bool

The boolean result of unordered not-equal comparison of a and b.

# Description

Performs nv\_bfloat16 not-equal comparison of inputs a and b. NaN inputs generate true results.

# 1.3.4. Bfloat162 Comparison Functions

Bfloat16 Precision Intrinsics

To use these functions, include the header file cuda bf16.h in your program.

Performs nv\_bfloat162 vector if-equal comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

bool

- true if both nv bfloat16 results of if-equal comparison of vectors a and b are true;
- false otherwise.

Performs nv\_bfloat162 vector if-equal comparison of inputs a and b. The bool result is set to true only if both nv\_bfloat16 if-equal comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbequ2 (const \_\_nv\_bfloat162 a, const nv bfloat162 b)

Performs nv\_bfloat162 vector unordered if-equal comparison and returns boolean true iff both nv\_bfloat16 results are true, boolean false otherwise.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

bool

- true if both nv\_bfloat16 results of unordered if-equal comparison of vectors a and b are true;
- false otherwise.

# Description

Performs nv\_bfloat162 vector if-equal comparison of inputs a and b. The bool result is set to true only if both nv\_bfloat16 if-equal comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

# \_\_device\_\_ bool \_\_hbge2 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv\_bfloat162 vector greater-equal comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

bool

- true if both nv\_bfloat16 results of greater-equal comparison of vectors a and b are true;
- false otherwise.

# Description

Performs  $nv_bfloat162$  vector greater-equal comparison of inputs a and b. The bool result is set to true only if both  $nv_bfloat16$  greater-equal comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbgeu2 (const \_\_nv\_bfloat162 a, const nv bfloat162 b)

Performs nv\_bfloat162 vector unordered greater-equal comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

## **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv bfloat162. Is only being read.

#### Returns

bool

- true if both nv\_bfloat16 results of unordered greater-equal comparison of vectors a and b are true;
- false otherwise.

# Description

Performs  $nv_bfloat162$  vector greater-equal comparison of inputs a and b. The bool result is set to true only if both  $nv_bfloat16$  greater-equal comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

# \_\_device\_\_ bool \_\_hbgt2 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv\_bfloat162 vector greater-than comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

bool

- true if both nv bfloat16 results of greater-than comparison of vectors a and b are true;
- false otherwise.

# Description

Performs  $nv_bfloat162$  vector greater-than comparison of inputs a and b. The bool result is set to true only if both  $nv_bfloat16$  greater-than comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbgtu2 (const \_\_nv\_bfloat162 a, const nv bfloat162 b)

Performs nv\_bfloat162 vector unordered greater-than comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

#### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

## Returns

bool

- true if both nv\_bfloat16 results of unordered greater-than comparison of vectors a and b are true;
- ► false otherwise.

Performs  $nv_bfloat162$  vector greater-than comparison of inputs a and b. The bool result is set to true only if both  $nv_bfloat16$  greater-than comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

# \_\_device\_\_ bool \_\_hble2 (const \_\_nv\_bfloat162 a, const nv bfloat162 b)

Performs  $nv\_bfloat162$  vector less-equal comparison and returns boolean true iff both  $nv\_bfloat16$  results are true, boolean false otherwise.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

bool

- true if both nv bfloat16 results of less-equal comparison of vectors a and b are true;
- false otherwise.

# Description

Performs  $nv_bfloat162$  vector less-equal comparison of inputs a and b. The bool result is set to true only if both  $nv_bfloat16$  less-equal comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbleu2 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv\_bfloat162 vector unordered less-equal comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

bool

- true if both nv\_bfloat16 results of unordered less-equal comparison of vectors a and b are true;
- false otherwise.

# Description

Performs  $nv_bfloat162$  vector less-equal comparison of inputs a and b. The bool result is set to true only if both  $nv_bfloat16$  less-equal comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

# \_\_device\_\_ bool \_\_hblt2 (const \_\_nv\_bfloat162 a, const nv bfloat162 b)

Performs nv\_bfloat162 vector less-than comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

## **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

bool

- true if both nv bfloat16 results of less-than comparison of vectors a and b are true;
- ▶ false otherwise.

# Description

Performs  $nv\_bfloat162$  vector less-than comparison of inputs a and b. The bool result is set to true only if both  $nv\_bfloat16$  less-than comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbltu2 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv\_bfloat162 vector unordered less-than comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

bool

- true if both nv\_bfloat16 results of unordered less-than comparison of vectors a and b are true;
- false otherwise.

### Description

Performs nv\_bfloat162 vector less-than comparison of inputs a and b. The bool result is set to true only if both nv\_bfloat16 less-than comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

# \_\_device\_\_ bool \_\_hbne2 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv\_bfloat162 vector not-equal comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

bool

- true if both nv\_bfloat16 results of not-equal comparison of vectors a and b are true,
- ► false otherwise.

## Description

Performs  $nv_bfloat162$  vector not-equal comparison of inputs a and b. The bool result is set to true only if both  $nv_bfloat16$  not-equal comparisons evaluate to true, or false otherwise. NaN inputs generate false results.

# \_\_device\_\_ bool \_\_hbneu2 (const \_\_nv\_bfloat162 a, const nv bfloat162 b)

Performs nv\_bfloat162 vector unordered not-equal comparison and returns boolean true iff both nv bfloat16 results are true, boolean false otherwise.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

bool

- true if both nv\_bfloat16 results of unordered not-equal comparison of vectors a and b are true:
- false otherwise.

# Description

Performs  $nv_bfloat162$  vector not-equal comparison of inputs a and b. The bool result is set to true only if both  $nv_bfloat16$  not-equal comparisons evaluate to true, or false otherwise. NaN inputs generate true results.

```
__device__ __nv_bfloat162 __heq2 (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv\_bfloat162 vector if-equal comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

nv bfloat162

▶ The vector result of if-equal comparison of vectors a and b.

## Description

Performs nv\_bfloat162 vector if-equal comparison of inputs a and b. The corresponding nv\_bfloat16 results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

\_\_device\_\_ unsigned \_\_heq2\_mask (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv\_bfloat162 vector if-equal comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

unsigned int

▶ The vector mask result of if-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector if-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

\_\_device\_\_ \_nv\_bfloat162 \_\_hequ2 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv bfloat162 vector unordered if-equal comparison.

### **Parameters**

a

- nv bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

nv bfloat162

▶ The vector result of unordered if-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector if-equal comparison of inputs a and b. The corresponding nv\_bfloat16 results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

\_\_device\_\_ unsigned \_\_hequ2\_mask (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv bfloat162 vector unordered if-equal comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

unsigned int

▶ The vector mask result of unordered if-equal comparison of vectors a and b.

# Description

Performs  $nv_bfloat162$  vector if-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

\_\_device\_\_ \_\_nv\_bfloat162 \_\_hge2 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv bfloat162 vector greater-equal comparison.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

nv bfloat162

► The vector result of greater-equal comparison of vectors a and b.

## Description

Performs  $nv_bfloat162$  vector greater-equal comparison of inputs a and b. The corresponding  $nv_bfloat16$  results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

```
__device__ unsigned __hge2_mask (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector greater-equal comparison.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

unsigned int

▶ The vector mask result of greater-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector greater-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

```
__device__ _nv_bfloat162 __hgeu2 (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector unordered greater-equal comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv bfloat162. Is only being read.

nv bfloat162

The nv\_bfloat162 vector result of unordered greater-equal comparison of vectors a and b.

### Description

Performs  $nv_bfloat162$  vector greater-equal comparison of inputs a and b. The corresponding  $nv_bfloat16$  results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

# \_\_device\_\_ unsigned \_\_hgeu2\_mask (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv bfloat162 vector unordered greater-equal comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

unsigned int

The vector mask result of unordered greater-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector greater-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

```
__device__ __nv_bfloat162 __hgt2 (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector greater-than comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

nv bfloat162

▶ The vector result of greater-than comparison of vectors a and b.

## Description

Performs  $nv_bfloat162$  vector greater-than comparison of inputs a and b. The corresponding  $nv_bfloat16$  results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

```
__device__ unsigned __hgt2_mask (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv\_bfloat162 vector greater-than comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

unsigned int

▶ The vector mask result of greater-than comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector greater-than comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

```
__device__ __nv_bfloat162 __hgtu2 (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector unordered greater-than comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv bfloat162. Is only being read.

nv bfloat162

The nv\_bfloat162 vector result of unordered greater-than comparison of vectors a and b.

# Description

Performs  $nv\_bfloat162$  vector greater-than comparison of inputs a and b. The corresponding  $nv\_bfloat16$  results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

# \_\_device\_\_ unsigned \_\_hgtu2\_mask (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Performs nv bfloat162 vector unordered greater-than comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

unsigned int

The vector mask result of unordered greater-than comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector greater-than comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

# \_\_device\_\_ \_nv\_bfloat162 \_\_hisnan2 (const \_\_nv\_bfloat162 a)

Determine whether nv bfloat162 argument is a NaN.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

nv\_bfloat162

► The nv\_bfloat162 with the corresponding nv\_bfloat16 results set to 1.0 for NaN, 0.0 otherwise.

# Description

Determine whether each nv\_bfloat16 of input nv\_bfloat162 number a is a NaN.

```
__device__ __nv_bfloat162 __hle2 (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector less-equal comparison.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

nv bfloat162

▶ The nv bfloat162 result of less-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector less-equal comparison of inputs a and b. The corresponding nv\_bfloat16 results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

```
__device__ unsigned __hle2_mask (const __nv_bfloat162 a,
const __nv_bfloat162 b)
```

Performs nv bfloat162 vector less-equal comparison.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

unsigned int

▶ The vector mask result of less-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector less-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

Performs nv bfloat162 vector unordered less-equal comparison.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

nv bfloat162

▶ The vector result of unordered less-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector less-equal comparison of inputs a and b. The corresponding nv\_bfloat16 results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

```
__device__ unsigned __hleu2_mask (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector unordered less-equal comparison.

### **Parameters**

a

- nv bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

unsigned int

▶ The vector mask result of unordered less-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector less-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

```
__device__ __nv_bfloat162 __hlt2 (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector less-than comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

nv bfloat162

The nv\_bfloat162 vector result of less-than comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector less-than comparison of inputs a and b. The corresponding nv\_bfloat16 results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

```
__device__ unsigned __hlt2_mask (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector less-than comparison.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

unsigned int

▶ The vector mask result of less-than comparison of vectors a and b.

## Description

Performs nv\_bfloat162 vector less-than comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

Performs nv bfloat162 vector unordered less-than comparison.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

nv bfloat162

▶ The vector result of unordered less-than comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector less-than comparison of inputs a and b. The corresponding nv\_bfloat16 results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

```
__device__ unsigned __hltu2_mask (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector unordered less-than comparison.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

unsigned int

The vector mask result of unordered less-than comparison of vectors a and b.

## Description

Performs nv\_bfloat162 vector less-than comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

```
__device__ _nv_bfloat162 __hmax2 (const __nv_bfloat162 a, const _nv_bfloat162 b)
```

Calculates nv bfloat162 vector maximum of two inputs.

# Description

Calculates nv\_bfloat162 vector max(a, b). Elementwise nv\_bfloat16 operation is defined as (a > b)? a : b.

- ▶ If either of inputs is NaN, the other input is returned.
- ▶ If both inputs are NaNs, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0
- ▶ The result of elementwise maximum of vectors a and b

```
__device__ __nv_bfloat162 __hmax2_nan (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Calculates nv bfloat162 vector maximum of two inputs, NaNs pass through.

# Description

Calculates  $nv_bfloat162$  vector max(a, b). Elementwise  $nv_bfloat16$  operation is defined as (a > b)? a : b.

- If either of inputs is NaN, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0
- ▶ The result of elementwise maximum of vectors a and b, with NaNs pass through

Calculates nv bfloat162 vector minimum of two inputs.

## Description

Calculates  $nv_bfloat162$  vector min(a, b). Elementwise  $nv_bfloat16$  operation is defined as (a < b)? a : b.

- If either of inputs is NaN, the other input is returned.
- If both inputs are NaNs, then canonical NaN is returned.
- ► If values of both inputs are 0.0, then +0.0 > -0.0
- The result of elementwise minimum of vectors a and b

Calculates nv bfloat162 vector minimum of two inputs, NaNs pass through.

## Description

Calculates nv\_bfloat162 vector min(a, b). Elementwise nv\_bfloat16 operation is defined as (a < b) ? a : b.

- If either of inputs is NaN, then canonical NaN is returned.
- ▶ If values of both inputs are 0.0, then +0.0 > -0.0
- The result of elementwise minimum of vectors a and b, with NaNs pass through

```
__device__ __nv_bfloat162 __hne2 (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector not-equal comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

nv bfloat162

▶ The vector result of not-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector not-equal comparison of inputs a and b. The corresponding nv\_bfloat16 results are set to 1.0 for true, or 0.0 for false. NaN inputs generate false results.

# \_\_device\_\_ unsigned \_\_hne2\_mask (const \_\_nv\_bfloat162 a, const \_ nv\_bfloat162 b)

Performs nv bfloat162 vector not-equal comparison.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

unsigned int

The vector mask result of not-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector not-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate false results.

```
__device__ _nv_bfloat162 __hneu2 (const __nv_bfloat162 a, const __nv_bfloat162 b)
```

Performs nv bfloat162 vector unordered not-equal comparison.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv bfloat162. Is only being read.

#### Returns

nv\_bfloat162

The vector result of unordered not-equal comparison of vectors a and b.

## Description

Performs nv\_bfloat162 vector not-equal comparison of inputs a and b. The corresponding nv\_bfloat16 results are set to 1.0 for true, or 0.0 for false. NaN inputs generate true results.

Performs nv bfloat162 vector unordered not-equal comparison.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

### Returns

unsigned int

The vector mask result of unordered not-equal comparison of vectors a and b.

# Description

Performs nv\_bfloat162 vector not-equal comparison of inputs a and b. The corresponding unsigned bits are set to 0xFFFF for true, or 0x0 for false. NaN inputs generate true results.

# 1.3.5. Bfloat16 Precision Conversion and Data Movement

Bfloat16 Precision Intrinsics

To use these functions, include the header file cuda bf16.h in your program.

```
__host____device__ float2 __bfloat1622float2 (const __nv_bfloat162 a)
```

Converts both halves of nv bfloat162 to float2 and returns the result.

### **Parameters**

а

- nv bfloat162. Is only being read.

float2

a converted to float2.

# Description

Converts both halves of nv\_bfloat162 input a to float2 and returns the result.

Returns nv\_bfloat162 with both halves equal to the input value.

### **Parameters**

а

- nv\_bfloat16. Is only being read.

### Returns

nv\_bfloat162

The vector which has both its halves equal to the input a.

# Description

Returns nv\_bfloat162 number with both halves equal to the input a nv\_bfloat16 number.

```
__host____device__ float __bfloat162float (const
__nv_bfloat16 a)
```

Converts nv bfloat16 number to float.

### **Parameters**

а

- float. Is only being read.

### Returns

float

a converted to float.

# Description

Converts nv\_bfloat16 number a to float.

# \_\_device\_\_ int \_\_bfloat162int\_rd (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to a signed integer in round-down mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

int

h converted to a signed integer.

### Description

Convert the  $nv_bfloat16$  floating-point value h to a signed integer in round-down mode. NaN inputs are converted to 0.

# \_\_device\_\_ int \_\_bfloat162int\_rn (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to a signed integer in round-to-nearest-even mode.

### **Parameters**

h

- nv bfloat16. Is only being read.

#### Returns

int

► h converted to a signed integer.

# Description

Convert the nv\_bfloat16 floating-point value h to a signed integer in round-to-nearest-even mode. NaN inputs are converted to 0.

# \_\_device\_\_ int \_\_bfloat162int\_ru (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to a signed integer in round-up mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

int

▶ h converted to a signed integer.

# Description

Convert the nv\_bfloat16 floating-point value h to a signed integer in round-up mode. NaN inputs are converted to 0.

Convert a nv\_bfloat16 to a signed integer in round-towards-zero mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

int

h converted to a signed integer.

# Description

Convert the  $nv_bfloat16$  floating-point value h to a signed integer in round-towards-zero mode. NaN inputs are converted to 0.

```
__device__ long long int __bfloat162ll_rd (const
__nv_bfloat16 h)
```

Convert a nv\_bfloat16 to a signed 64-bit integer in round-down mode.

### **Parameters**

h

- nv bfloat16. Is only being read.

### Returns

long long int

▶ h converted to a signed 64-bit integer.

# Description

Convert the nv\_bfloat16 floating-point value h to a signed 64-bit integer in round-down mode. NaN inputs return a long long int with hex value of 0x800000000000000.

Convert a nv\_bfloat16 to a signed 64-bit integer in round-to-nearest-even mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

long long int

▶ h converted to a signed 64-bit integer.

# Description

Convert the nv\_bfloat16 floating-point value h to a signed 64-bit integer in round-to-nearest-even mode. NaN inputs return a long long int with hex value of 0x8000000000000000.

# \_\_device\_\_ long long int \_\_bfloat162ll\_ru (const nv bfloat16 h)

Convert a nv\_bfloat16 to a signed 64-bit integer in round-up mode.

#### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

long long int

▶ h converted to a signed 64-bit integer.

# Description

Convert the nv\_bfloat16 floating-point value h to a signed 64-bit integer in round-up mode. NaN inputs return a long long int with hex value of 0x800000000000000.

# \_\_host\_\_\_\_device\_\_ long long int \_\_bfloat162ll\_rz (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to a signed 64-bit integer in round-towards-zero mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

long long int

▶ h converted to a signed 64-bit integer.

# Description

Convert the nv\_bfloat16 floating-point value h to a signed 64-bit integer in round-towards-zero mode. NaN inputs return a long long int with hex value of 0x800000000000000.

Convert a nv\_bfloat16 to a signed short integer in round-down mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

short int

▶ h converted to a signed short integer.

# Description

Convert the nv\_bfloat16 floating-point value  ${\tt h}$  to a signed short integer in round-down mode. NaN inputs are converted to 0.

# \_\_device\_\_ short int \_\_bfloat162short\_rn (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to a signed short integer in round-to-nearest-even mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

short int

▶ h converted to a signed short integer.

# Description

Convert the nv\_bfloat16 floating-point value h to a signed short integer in round-to-nearest-even mode. NaN inputs are converted to 0.

Convert a nv\_bfloat16 to a signed short integer in round-up mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

short int

▶ h converted to a signed short integer.

# Description

Convert the  $nv_bfloat16$  floating-point value h to a signed short integer in round-up mode. NaN inputs are converted to 0.

# \_\_host\_\_\_\_device\_\_ short int \_\_bfloat162short\_rz (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to a signed short integer in round-towards-zero mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

short int

▶ h converted to a signed short integer.

# Description

Convert the nv\_bfloat16 floating-point value h to a signed short integer in round-towards-zero mode. NaN inputs are converted to 0.

Convert a nv\_bfloat16 to an unsigned integer in round-down mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned int

▶ h converted to an unsigned integer.

# Description

Convert the nv\_bfloat16 floating-point value h to an unsigned integer in round-down mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned int \_\_bfloat162uint\_rn (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned integer in round-to-nearest-even mode.

### **Parameters**

h

- nv bfloat16. Is only being read.

### Returns

unsigned int

▶ h converted to an unsigned integer.

# Description

Convert the  $nv_bfloat16$  floating-point value h to an unsigned integer in round-to-nearest-even mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned int \_\_bfloat162uint\_ru (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned integer in round-up mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned int

▶ h converted to an unsigned integer.

# Description

Convert the nv\_bfloat16 floating-point value h to an unsigned integer in round-up mode. NaN inputs are converted to 0.

# \_\_host\_\_\_\_device\_\_ unsigned int \_\_bfloat162uint\_rz (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned integer in round-towards-zero mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned int

h converted to an unsigned integer.

## Description

Convert the nv\_bfloat16 floating-point value h to an unsigned integer in round-towards-zero mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned long long int \_\_bfloat162ull\_rd (const nv bfloat16 h)

Convert a nv\_bfloat16 to an unsigned 64-bit integer in round-down mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned long long int

▶ h converted to an unsigned 64-bit integer.

# Description

# \_\_device\_\_ unsigned long long int \_\_bfloat162ull\_rn (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned 64-bit integer in round-to-nearest-even mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned long long int

▶ h converted to an unsigned 64-bit integer.

## Description

Convert the nv\_bfloat16 floating-point value h to an unsigned 64-bit integer in round-to-nearest-even mode. NaN inputs return 0x80000000000000.

# \_\_device\_\_ unsigned long long int \_\_bfloat162ull\_ru (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned 64-bit integer in round-up mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned long long int

▶ h converted to an unsigned 64-bit integer.

# Description

Convert the nv\_bfloat16 floating-point value h to an unsigned 64-bit integer in round-up mode. NaN inputs return 0x80000000000000.

# \_\_host\_\_\_\_device\_\_ unsigned long long int \_\_bfloat162ull\_rz (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned 64-bit integer in round-towards-zero mode.

### **Parameters**

h

- nv bfloat16. Is only being read.

### Returns

unsigned long long int

▶ h converted to an unsigned 64-bit integer.

# Description

Convert the nv\_bfloat16 floating-point value h to an unsigned 64-bit integer in round-towards-zero mode. NaN inputs return 0x80000000000000.

# \_\_device\_\_ unsigned short int \_\_bfloat162ushort\_rd (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned short integer in round-down mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned short int

▶ h converted to an unsigned short integer.

# Description

Convert the nv\_bfloat16 floating-point value h to an unsigned short integer in round-down mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned short int \_\_bfloat162ushort\_rn (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned short integer in round-to-nearest-even mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned short int

h converted to an unsigned short integer.

# Description

Convert the nv\_bfloat16 floating-point value h to an unsigned short integer in round-to-nearest-even mode. NaN inputs are converted to 0.

# \_\_device\_\_ unsigned short int \_\_bfloat162ushort\_ru (const \_\_nv\_bfloat16 h)

Convert a nv\_bfloat16 to an unsigned short integer in round-up mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned short int

▶ h converted to an unsigned short integer.

# Description

Convert the nv\_bfloat16 floating-point value h to an unsigned short integer in round-up mode. NaN inputs are converted to 0.

Convert a nv\_bfloat16 to an unsigned short integer in round-towards-zero mode.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned short int

▶ h converted to an unsigned short integer.

# Description

Convert the nv\_bfloat16 floating-point value h to an unsigned short integer in round-towards-zero mode. NaN inputs are converted to 0.

Reinterprets bits in a nv bfloat16 as a signed short integer.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

short int

► The reinterpreted value.

# Description

Reinterprets the bits in the nv\_bfloat16 floating-point number h as a signed short integer.

# \_\_device\_\_ unsigned short int \_\_bfloat16\_as\_ushort (const \_\_nv\_bfloat16 h)

Reinterprets bits in a nv bfloat16 as an unsigned short integer.

### **Parameters**

h

- nv\_bfloat16. Is only being read.

### Returns

unsigned short int

► The reinterpreted value.

## Description

Reinterprets the bits in the nv\_bfloat16 floating-point h as an unsigned short number.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat16 \_\_double2bfloat16 (const double a)

Converts double number to nv\_bfloat16 precision in round-to-nearest-even mode and returns nv bfloat16 with converted value.

### **Parameters**

а

- double. Is only being read.

### Returns

nv\_bfloat16

a converted to nv\_bfloat16.

# Description

Converts double number a to nv\_bfloat16 precision in round-to-nearest-even mode.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat162 \_\_float22bfloat162\_rn (const float2 a)

Converts both components of float2 number to nv\_bfloat16 precision in round-to-nearest-even mode and returns nv bfloat162 with converted values.

### **Parameters**

a

- float2. Is only being read.

#### Returns

nv bfloat162

► The nv\_bfloat162 which has corresponding halves equal to the converted float2 components.

### Description

Converts both components of float2 to  $nv_bfloat16$  precision in round-to-nearest mode and combines the results into one  $nv_bfloat162$  number. Low 16 bits of the return value correspond to a.x and high 16 bits of the return value correspond to a.y.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat16 \_\_float2bfloat16 (const float a)

Converts float number to  $nv_bfloat16$  precision in round-to-nearest-even mode and returns  $nv_bfloat16$  with converted value.

#### **Parameters**

а

- float. Is only being read.

### Returns

nv bfloat16

a converted to nv\_bfloat16.

# Description

Converts float number a to nv\_bfloat16 precision in round-to-nearest-even mode.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat162 \_\_float2bfloat162\_rn (const float a)

Converts input to nv\_bfloat16 precision in round-to-nearest-even mode and populates both halves of nv bfloat162 with converted value.

### **Parameters**

a

- float. Is only being read.

### Returns

nv bfloat162

► The nv\_bfloat162 value with both halves equal to the converted nv\_bfloat16 precision number.

# Description

Converts input a to nv\_bfloat16 precision in round-to-nearest-even mode and populates both halves of nv\_bfloat162 with converted value.

# \_\_host\_\_\_device\_\_ \_nv\_bfloat16 \_\_float2bfloat16\_rd (const float a)

Converts float number to  $nv_bfloat16$  precision in round-down mode and returns  $nv_bfloat16$  with converted value.

### **Parameters**

а

- float. Is only being read.

#### Returns

nv\_bfloat16

a converted to nv\_bfloat16.

# Description

Converts float number a to nv\_bfloat16 precision in round-down mode.

# \_\_host\_\_\_\_device\_\_ \_\_nv\_bfloat16 \_\_float2bfloat16\_rn (const float a)

Converts float number to nv\_bfloat16 precision in round-to-nearest-even mode and returns nv bfloat16 with converted value.

### **Parameters**

a

- float. Is only being read.

### Returns

nv bfloat16

a converted to nv\_bfloat16.

# Description

Converts float number a to nv\_bfloat16 precision in round-to-nearest-even mode.

# \_\_host\_\_\_\_device\_\_ \_\_nv\_bfloat16 \_\_float2bfloat16\_ru (const float a)

Converts float number to nv\_bfloat16 precision in round-up mode and returns nv\_bfloat16 with converted value.

### **Parameters**

a

- float. Is only being read.

### Returns

nv bfloat16

a converted to nv\_bfloat16.

# Description

Converts float number a to nv\_bfloat16 precision in round-up mode.

# \_\_host\_\_\_\_device\_\_ \_\_nv\_bfloat16 \_\_float2bfloat16\_rz (const float a)

Converts float number to nv\_bfloat16 precision in round-towards-zero mode and returns nv\_bfloat16 with converted value.

### **Parameters**

a

- float. Is only being read.

### Returns

nv\_bfloat16

a converted to nv\_bfloat16.

# Description

Converts float number a to nv\_bfloat16 precision in round-towards-zero mode.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat162 \_\_floats2bfloat162\_rn (const float a, const float b)

Converts both input floats to nv\_bfloat16 precision in round-to-nearest-even mode and returns nv bfloat162 with converted values.

### **Parameters**

а

- float. Is only being read.

b

- float. Is only being read.

#### Returns

nv\_bfloat162

▶ The nv bfloat162 value with corresponding halves equal to the converted input floats.

## Description

Converts both input floats to nv\_bfloat16 precision in round-to-nearest-even mode and combines the results into one nv\_bfloat162 number. Low 16 bits of the return value correspond to the input a, high 16 bits correspond to the input b.

Combines two nv\_bfloat16 numbers into one nv\_bfloat162 number.

### **Parameters**

а

- nv\_bfloat16. Is only being read.

b

- nv\_bfloat16. Is only being read.

### Returns

nv\_bfloat162

► The nv\_bfloat162 with one nv\_bfloat16 equal to a and the other to b.

# Description

Combines two input nv\_bfloat16 number a and b into one nv\_bfloat162 number. Input a is stored in low 16 bits of the return value, input b is stored in high 16 bits of the return value.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_high2bfloat16 (const \_\_nv\_bfloat162 a)

Returns high 16 bits of nv\_bfloat162 input.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

### Returns

nv bfloat16

► The high 16 bits of the input.

### Description

Returns high 16 bits of nv\_bfloat162 input a.

Extracts high 16 bits from nv bfloat162 input.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

### Returns

nv\_bfloat162

► The nv\_bfloat162 with both halves equal to the high 16 bits of the input.

# Description

Extracts high 16 bits from nv\_bfloat162 input a and returns a new nv\_bfloat162 number which has both halves equal to the extracted bits.

Converts high 16 bits of nv\_bfloat162 to float and returns the result.

### **Parameters**

а

- nv\_bfloat162. Is only being read.

### Returns

float

► The high 16 bits of a converted to float.

# Description

Converts high 16 bits of  $nv_bfloat162$  input a to 32-bit floating-point number and returns the result.

# \_\_device\_\_ \_\_nv\_bfloat162 \_\_highs2bfloat162 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Extracts high 16 bits from each of the two  $nv\_bfloat162$  inputs and combines into one  $nv\_bfloat162$  number.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

nv bfloat162

The high 16 bits of a and of b.

#### Description

Extracts high 16 bits from each of the two nv\_bfloat162 inputs and combines into one nv\_bfloat162 number. High 16 bits from input a is stored in low 16 bits of the return value, high 16 bits from input b is stored in high 16 bits of the return value.

### device nv bfloat16 int2bfloat16 rd (const int i)

Convert a signed integer to a nv\_bfloat16 in round-down mode.

#### **Parameters**

i

- int. Is only being read.

#### Returns

nv bfloat16

▶ i converted to nv bfloat16.

#### Description

Convert the signed integer value i to a nv\_bfloat16 floating-point value in round-down mode.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat16 \_\_int2bfloat16\_rn (const int i)

Convert a signed integer to a nv\_bfloat16 in round-to-nearest-even mode.

#### **Parameters**

i

- int. Is only being read.

#### Returns

nv bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the signed integer value i to a nv\_bfloat16 floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_nv\_bfloat16 \_\_int2bfloat16\_ru (const int i)

Convert a signed integer to a nv\_bfloat16 in round-up mode.

#### **Parameters**

i

- int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the signed integer value i to a nv\_bfloat16 floating-point value in round-up mode.

## \_\_device\_\_ \_nv\_bfloat16 \_\_int2bfloat16\_rz (const int i)

Convert a signed integer to a nv\_bfloat16 in round-towards-zero mode.

#### **Parameters**

i

- int. Is only being read.

nv bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the signed integer value i to a nv\_bfloat16 floating-point value in round-towards-zero mode.

\_\_device\_\_ \_nv\_bfloat16 \_\_ldca (const \_\_nv\_bfloat16 \*ptr)
Generates a `ld.global.ca` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_\_nv\_bfloat162 \_\_ldca (const \_\_nv\_bfloat162
\*ptr)

Generates a `ld.global.ca` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_nv\_bfloat16 \_\_ldcg (const \_\_nv\_bfloat16 \*ptr)

Generates a `ld.global.cg` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_\_nv\_bfloat162 \_\_ldcg (const \_\_nv\_bfloat162
\*ptr)

Generates a `ld.global.cg` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_nv\_bfloat16 \_\_ldcs (const \_\_nv\_bfloat16 \*ptr)
Generates a `ld.global.cs` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_\_nv\_bfloat162 \_\_ldcs (const \_\_nv\_bfloat162
\*ptr)

Generates a `ld.global.cs` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_nv\_bfloat16 \_\_ldcv (const \_\_nv\_bfloat16 \*ptr)

Generates a `ld.global.cv` load instruction.

#### **Parameters**

#### ptr

- memory location

The value pointed by `ptr`

\_\_device\_\_ \_\_nv\_bfloat162 \_\_ldcv (const \_\_nv\_bfloat162
\*ptr)

Generates a `ld.global.cv` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_nv\_bfloat16 \_\_ldg (const \_\_nv\_bfloat16 \*ptr)

Generates a `ld.global.nc` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_\_nv\_bfloat162 \_\_ldg (const \_\_nv\_bfloat162 \*ptr)

Generates a `ld.global.nc` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_nv\_bfloat16 \_\_ldlu (const \_\_nv\_bfloat16 \*ptr)

Generates a `ld.global.lu` load instruction.

#### **Parameters**

#### ptr

- memory location

The value pointed by `ptr`

\_\_device\_\_ \_\_nv\_bfloat162 \_\_ldlu (const \_\_nv\_bfloat162 \*ptr)

Generates a `ld.global.lu` load instruction.

#### **Parameters**

#### ptr

- memory location

#### Returns

The value pointed by `ptr`

\_\_device\_\_ \_nv\_bfloat16 \_\_ll2bfloat16\_rd (const long long int i)

Convert a signed 64-bit integer to a nv\_bfloat16 in round-down mode.

#### **Parameters**

i

- long long int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the signed 64-bit integer value i to a nv\_bfloat16 floating-point value in round-down mode.

\_\_host\_\_\_\_device\_\_ \_nv\_bfloat16 \_\_ll2bfloat16\_rn (const long long int i)

Convert a signed 64-bit integer to a nv\_bfloat16 in round-to-nearest-even mode.

#### **Parameters**

i

- long long int. Is only being read.

nv\_bfloat16

i converted to nv bfloat16.

#### Description

Convert the signed 64-bit integer value i to a nv\_bfloat16 floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_nv\_bfloat16 \_\_ll2bfloat16\_ru (const long long int i)

Convert a signed 64-bit integer to a nv\_bfloat16 in round-up mode.

#### **Parameters**

i

- long long int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

### Description

Convert the signed 64-bit integer value i to a nv\_bfloat16 floating-point value in round-up mode.

# \_\_device\_\_ \_nv\_bfloat16 \_\_ll2bfloat16\_rz (const long long int i)

Convert a signed 64-bit integer to a nv\_bfloat16 in round-towards-zero mode.

#### **Parameters**

i

- long long int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the signed 64-bit integer value i to a nv\_bfloat16 floating-point value in round-towards-zero mode.

Returns low 16 bits of nv bfloat162 input.

#### **Parameters**

a

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat16

▶ Returns nv bfloat16 which contains low 16 bits of the input a.

#### Description

Returns low 16 bits of nv bfloat162 input a.

```
__device__ __nv_bfloat162 __low2bfloat162 (const __nv_bfloat162 a)
```

Extracts low 16 bits from nv bfloat162 input.

#### **Parameters**

а

- nv bfloat162. Is only being read.

#### Returns

nv\_bfloat162

► The nv\_bfloat162 with both halves equal to the low 16 bits of the input.

#### Description

Extracts low 16 bits from nv\_bfloat162 input a and returns a new nv\_bfloat162 number which has both halves equal to the extracted bits.

\_\_host\_\_\_\_device\_\_ float \_\_low2float (const \_\_nv\_bfloat162 a)

Converts low 16 bits of nv\_bfloat162 to float and returns the result.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

#### Returns

float

► The low 16 bits of a converted to float.

#### Description

Converts low 16 bits of nv\_bfloat162 input a to 32-bit floating-point number and returns the result.

Swaps both halves of the nv\_bfloat162 input.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

a with its halves being swapped.

#### Description

Swaps both halves of the nv\_bfloat162 input and returns a new nv\_bfloat162 number with swapped halves.

# \_\_device\_\_ \_\_nv\_bfloat162 \_\_lows2bfloat162 (const \_\_nv\_bfloat162 a, const \_\_nv\_bfloat162 b)

Extracts low 16 bits from each of the two  $nv\_bfloat162$  inputs and combines into one  $nv\_bfloat162$  number.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

b

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

► The low 16 bits of a and of b.

#### Description

Extracts low 16 bits from each of the two nv\_bfloat162 inputs and combines into one nv\_bfloat162 number. Low 16 bits from input a is stored in low 16 bits of the return value, low 16 bits from input b is stored in high 16 bits of the return value.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_shfl\_down\_sync (const unsigned mask, const \_\_nv\_bfloat16 var, const unsigned int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread with higher ID relative to the caller.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- nv\_bfloat16. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

Returns the 2-byte word referenced by var from the source thread ID as nv\_bfloat16. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by adding delta to the caller's thread ID. The value of var held by the resulting thread ID is returned: this has the effect of shifting var down the warp by delta threads. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. As for <u>shfl up sync()</u>, the ID number of the source thread will not wrap around the value of width and so the upper delta threads will remain unchanged.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

\_\_device\_\_ \_\_nv\_bfloat162 \_\_shfl\_down\_sync (const unsigned mask, const \_\_nv\_bfloat162 var, const unsigned int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread with higher ID relative to the caller.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- nv bfloat162. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 4-byte word referenced by var from the source thread ID as nv\_bfloat162. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by adding delta to the caller's thread ID. The value of var held by the resulting thread ID is returned: this has the effect of shifting var down the warp by delta threads. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. As for <u>shfl up sync()</u>, the ID number of the source thread will not wrap around the value of width and so the upper delta threads will remain unchanged.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

\_\_device\_\_ \_\_nv\_bfloat16 \_\_shfl\_sync (const unsigned mask, const \_\_nv\_bfloat16 var, const int delta, const int width)

Exchange a variable between threads within a warp. Direct copy from indexed thread.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- nv\_bfloat16. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 2-byte word referenced by var from the source thread ID as nv\_bfloat16. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Returns the value of var held by the thread whose ID is given by delta. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. If delta is outside the range [0:width-1], the value returned corresponds to the value of var held by the delta modulo width (i.e. within the same subsection), width must have

a value which is a power of 2; results are undefined if width is not a power of 2, or is a number greater than warpSize.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

\_\_device\_\_ \_\_nv\_bfloat162 \_\_shfl\_sync (const unsigned mask, const \_\_nv\_bfloat162 var, const int delta, const int width)

Exchange a variable between threads within a warp. Direct copy from indexed thread.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- nv\_bfloat162. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 4-byte word referenced by var from the source thread ID as nv\_bfloat162. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

### Description

Returns the value of var held by the thread whose ID is given by delta. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. If delta is outside the range [0:width-1], the value returned corresponds to the value of var held by the delta modulo width (i.e. within the same subsection). width must have a value which is a power of 2; results are undefined if width is not a power of 2, or is a number greater than warpSize.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_shfl\_up\_sync (const unsigned mask, const \_\_nv\_bfloat16 var, const unsigned int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread with lower ID relative to the caller.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- nv\_bfloat16. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 2-byte word referenced by var from the source thread ID as nv\_bfloat16. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by subtracting delta from the caller's lane ID. The value of var held by the resulting lane ID is returned: in effect, var is shifted up the warp by delta threads. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. The source thread index will not wrap around the value of width, so effectively the lower delta threads will be unchanged. width must have a value which is a power of 2; results are undefined if width is not a power of 2, or is a number greater than warpSize.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_\_nv\_bfloat162 \_\_shfl\_up\_sync (const unsigned mask, const \_\_nv\_bfloat162 var, const unsigned int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread with lower ID relative to the caller.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- nv\_bfloat162. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 4-byte word referenced by var from the source thread ID as nv\_bfloat162. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by subtracting delta from the caller's lane ID. The value of var held by the resulting lane ID is returned: in effect, var is shifted up the warp by delta threads. If width is less than warpSize then each subsection of the warp behaves as a separate entity with a starting logical thread ID of 0. The source thread index will not wrap around the value of width, so effectively the lower delta threads will be unchanged. width must have a value which is a power of 2; results are undefined if width is not a power of 2, or is a number greater than warpSize.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_shfl\_xor\_sync (const unsigned mask, const \_\_nv\_bfloat16 var, const int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread based on bitwise XOR of own thread ID.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- nv\_bfloat16. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 2-byte word referenced by var from the source thread ID as nv\_bfloat16. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by performing a bitwise XOR of the caller's thread ID with mask: the value of var held by the resulting thread ID is returned. If width is less than warpSize then each group of width consecutive threads are able to access elements from earlier groups of threads, however if they attempt to access elements from later groups of threads their own value of var will be returned. This mode implements a butterfly addressing pattern such as is used in tree reduction and broadcast.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_\_nv\_bfloat162 \_\_shfl\_xor\_sync (const unsigned mask, const \_\_nv\_bfloat162 var, const int delta, const int width)

Exchange a variable between threads within a warp. Copy from a thread based on bitwise XOR of own thread ID.

#### **Parameters**

#### mask

- unsigned int. Is only being read.

#### var

- nv\_bfloat162. Is only being read.

#### delta

- int. Is only being read.

#### width

- int. Is only being read.

#### Returns

Returns the 4-byte word referenced by var from the source thread ID as nv\_bfloat162. If the source thread ID is out of range or the source thread has exited, the calling thread's own var is returned.

#### Description

Calculates a source thread ID by performing a bitwise XOR of the caller's thread ID with mask: the value of var held by the resulting thread ID is returned. If width is less than warpSize then each group of width consecutive threads are able to access elements from earlier groups of threads, however if they attempt to access elements from later groups of threads their own value of var will be returned. This mode implements a butterfly addressing pattern such as is used in tree reduction and broadcast.



#### Note:

For more details for this function see the Warp Shuffle Functions section in the CUDA C++ Programming Guide.

# \_\_device\_\_ \_nv\_bfloat16 \_\_short2bfloat16\_rd (const short int i)

Convert a signed short integer to a nv\_bfloat16 in round-down mode.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

nv bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the signed short integer value i to a nv\_bfloat16 floating-point value in round-down mode.

# \_\_host\_\_\_device\_\_ \_nv\_bfloat16 \_\_short2bfloat16\_rn (const short int i)

Convert a signed short integer to a nv\_bfloat16 in round-to-nearest-even mode.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the signed short integer value i to a nv\_bfloat16 floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_nv\_bfloat16 \_\_short2bfloat16\_ru (const short int i)

Convert a signed short integer to a nv\_bfloat16 in round-up mode.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

nv\_bfloat16

i converted to nv\_bfloat16.

#### Description

Convert the signed short integer value i to a nv\_bfloat16 floating-point value in round-up mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_short2bfloat16\_rz (const short int i)

Convert a signed short integer to a nv\_bfloat16 in round-towards-zero mode.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the signed short integer value i to a nv\_bfloat16 floating-point value in round-towards-zero mode.

# \_\_device\_\_ \_nv\_bfloat16 \_\_short\_as\_bfloat16 (const short int i)

Reinterprets bits in a signed short integer as a nv\_bfloat16.

#### **Parameters**

i

- short int. Is only being read.

#### Returns

nv\_bfloat16

► The reinterpreted value.

#### Description

Reinterprets the bits in the signed short integer i as a nv\_bfloat16 floating-point number.

Generates a `st.global.cg` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

# \_\_device\_\_ void \_\_stcg (const \_\_nv\_bfloat162 \*ptr, const \_\_nv\_bfloat162 value)

Generates a `st.global.cg` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

\_\_device\_\_ void \_\_stcs (const \_\_nv\_bfloat16 \*ptr, const \_\_nv\_bfloat16 value)

Generates a `st.global.cs` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

\_\_device\_\_ void \_\_stcs (const \_\_nv\_bfloat162 \*ptr, const \_\_nv\_bfloat162 value)

Generates a `st.global.cs` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

\_\_device\_\_ void \_\_stwb (const \_\_nv\_bfloat16 \*ptr, const nv bfloat16 value)

Generates a `st.global.wb` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

\_\_device\_\_ void \_\_stwb (const \_\_nv\_bfloat162 \*ptr, const \_\_nv\_bfloat162 value)

Generates a `st.global.wb` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

\_\_device\_\_ void \_\_stwt (const \_\_nv\_bfloat16 \*ptr, const \_\_nv\_bfloat16 value)

Generates a `st.global.wt` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

\_\_device\_\_ void \_\_stwt (const \_\_nv\_bfloat162 \*ptr, const \_\_nv\_bfloat162 value)

Generates a `st.global.wt` store instruction.

#### **Parameters**

#### ptr

- memory location

#### value

- the value to be stored

\_\_device\_\_ \_\_nv\_bfloat16 \_\_uint2bfloat16\_rd (const unsigned int i)

Convert an unsigned integer to a nv bfloat16 in round-down mode.

#### **Parameters**

i

- unsigned int. Is only being read.

#### Returns

nv\_bfloat16

i converted to nv\_bfloat16.

#### Description

Convert the unsigned integer value i to a nv\_bfloat16 floating-point value in round-down mode.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat16 \_\_uint2bfloat16\_rn (const unsigned int i)

Convert an unsigned integer to a nv\_bfloat16 in round-to-nearest-even mode.

#### **Parameters**

i

- unsigned int. Is only being read.

#### Returns

nv\_bfloat16

i converted to nv\_bfloat16.

#### Description

Convert the unsigned integer value i to a nv\_bfloat16 floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_uint2bfloat16\_ru (const unsigned int i)

Convert an unsigned integer to a nv\_bfloat16 in round-up mode.

#### **Parameters**

i

- unsigned int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned integer value i to a nv\_bfloat16 floating-point value in round-up mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_uint2bfloat16\_rz (const unsigned int i)

Convert an unsigned integer to a nv\_bfloat16 in round-towards-zero mode.

#### **Parameters**

i

- unsigned int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned integer value i to a nv\_bfloat16 floating-point value in round-towards-zero mode.

# \_\_device\_\_ \_nv\_bfloat16 \_\_ull2bfloat16\_rd (const unsigned long long int i)

Convert an unsigned 64-bit integer to a nv\_bfloat16 in round-down mode.

#### **Parameters**

i

- unsigned long long int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned 64-bit integer value  $\mathtt{i}$  to a nv\_bfloat16 floating-point value in round-down mode.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat16 \_\_ull2bfloat16\_rn (const unsigned long long int i)

Convert an unsigned 64-bit integer to a nv\_bfloat16 in round-to-nearest-even mode.

#### **Parameters**

i

- unsigned long long int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned 64-bit integer value i to a nv\_bfloat16 floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_ull2bfloat16\_ru (const unsigned long long int i)

Convert an unsigned 64-bit integer to a nv\_bfloat16 in round-up mode.

#### **Parameters**

i

- unsigned long long int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned 64-bit integer value i to a nv\_bfloat16 floating-point value in round-up mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_ull2bfloat16\_rz (const unsigned long long int i)

Convert an unsigned 64-bit integer to a nv\_bfloat16 in round-towards-zero mode.

#### **Parameters**

i

- unsigned long long int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned 64-bit integer value i to a nv\_bfloat16 floating-point value in round-towards-zero mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_ushort2bfloat16\_rd (const unsigned short int i)

Convert an unsigned short integer to a nv\_bfloat16 in round-down mode.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned short integer value i to a nv\_bfloat16 floating-point value in round-down mode.

# \_\_host\_\_\_\_device\_\_ \_nv\_bfloat16 \_\_ushort2bfloat16\_rn (const unsigned short int i)

Convert an unsigned short integer to a nv\_bfloat16 in round-to-nearest-even mode.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned short integer value i to a nv\_bfloat16 floating-point value in round-to-nearest-even mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_ushort2bfloat16\_ru (const unsigned short int i)

Convert an unsigned short integer to a nv\_bfloat16 in round-up mode.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned short integer value i to a nv\_bfloat16 floating-point value in round-up mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_ushort2bfloat16\_rz (const unsigned short int i)

Convert an unsigned short integer to a nv\_bfloat16 in round-towards-zero mode.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

nv\_bfloat16

▶ i converted to nv\_bfloat16.

#### Description

Convert the unsigned short integer value i to a nv\_bfloat16 floating-point value in round-towards-zero mode.

# \_\_device\_\_ \_\_nv\_bfloat16 \_\_ushort\_as\_bfloat16 (const unsigned short int i)

Reinterprets bits in an unsigned short integer as a nv bfloat16.

#### **Parameters**

i

- unsigned short int. Is only being read.

#### Returns

nv\_bfloat16

► The reinterpreted value.

#### Description

Reinterprets the bits in the unsigned short integer i as a nv\_bfloat16 floating-point number.

### 1.3.6. Bfloat16 Math Functions

Bfloat16 Precision Intrinsics

To use these functions, include the header file cuda bf16.h in your program.

### \_\_device\_\_ \_nv\_bfloat16 hceil (const \_\_nv\_bfloat16 h)

Calculate ceiling of the input argument.

#### **Parameters**

h

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

▶ The smallest integer value not less than h.

#### Description

Compute the smallest integer value not less than h.

### \_\_device\_\_ \_nv\_bfloat16 hcos (const \_\_nv\_bfloat16 a)

Calculates nv bfloat16 cosine in round-to-nearest-even mode.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

#### Returns

nv bfloat16

The cosine of a.

#### Description

Calculates nv\_bfloat16 cosine of input a in round-to-nearest-even mode.

### \_\_device\_\_ \_nv\_bfloat16 hexp (const \_\_nv\_bfloat16 a)

Calculates nv bfloat16 natural exponential function in round-to-nearest mode.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

► The natural exponential function on a.

#### Description

Calculates nv\_bfloat16 natural exponential function of input a in round-to-nearest-even mode.

### \_\_device\_\_ \_nv\_bfloat16 hexp10 (const \_\_nv\_bfloat16 a)

Calculates nv bfloat16 decimal exponential function in round-to-nearest mode.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

► The decimal exponential function on a.

#### Description

Calculates nv\_bfloat16 decimal exponential function of input a in round-to-nearest-even mode.

## \_\_device\_\_ \_nv\_bfloat16 hexp2 (const \_\_nv\_bfloat16 a)

Calculates nv bfloat16 binary exponential function in round-to-nearest mode.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

► The binary exponential function on a.

#### Description

Calculates  $nv\_bfloat16$  binary exponential function of input a in round-to-nearest-even mode.

### device nv bfloat16 hfloor (const nv bfloat16 h)

Calculate the largest integer less than or equal to h.

#### **Parameters**

h

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

▶ The largest integer value which is less than or equal to h.

#### Description

Calculate the largest integer value which is less than or equal to h.

### 

 ${\tt Calculates} \ {\tt nv\_bfloat16} \ {\tt natural} \ {\tt logarithm} \ {\tt in} \ {\tt round-to-nearest-even} \ {\tt mode}.$ 

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

#### Returns

nv bfloat16

► The natural logarithm of a.

#### Description

Calculates nv bfloat16 natural logarithm of input a in round-to-nearest-even mode.

### \_\_device\_\_ \_nv\_bfloat16 hlog10 (const \_\_nv\_bfloat16 a)

Calculates nv bfloat16 decimal logarithm in round-to-nearest-even mode.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

► The decimal logarithm of a.

#### Description

Calculates nv\_bfloat16 decimal logarithm of input a in round-to-nearest-even mode.

### 

Calculates nv bfloat16 binary logarithm in round-to-nearest-even mode.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

► The binary logarithm of a.

#### Description

Calculates nv bfloat16 binary logarithm of input a in round-to-nearest-even mode.

### \_\_device\_\_ \_ nv\_bfloat16 hrcp (const \_\_nv\_bfloat16 a)

Calculates nv bfloat16 reciprocal in round-to-nearest-even mode.

#### **Parameters**

a

- nv bfloat16. Is only being read.

#### Returns

nv\_bfloat16

► The reciprocal of a.

#### Description

Calculates nv bfloat16 reciprocal of input a in round-to-nearest-even mode.

### \_\_device\_\_ \_nv\_bfloat16 hrint (const \_\_nv\_bfloat16 h)

Round input to nearest integer value in nv\_bfloat16 floating-point number.

#### **Parameters**

h

- nv\_bfloat16. Is only being read.

nv bfloat16

► The nearest integer to h.

#### Description

Round h to the nearest integer value in nv\_bfloat16 floating-point format, with bfloat16way cases rounded to the nearest even integer value.

### \_\_device\_\_ \_nv\_bfloat16 hrsqrt (const \_\_nv\_bfloat16 a)

Calculates nv\_bfloat16 reciprocal square root in round-to-nearest-even mode.

#### **Parameters**

а

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

► The reciprocal square root of a.

#### Description

Calculates nv\_bfloat16 reciprocal square root of input a in round-to-nearest mode.

## \_\_device\_\_ \_nv\_bfloat16 hsin (const \_\_nv\_bfloat16 a)

Calculates nv bfloat16 sine in round-to-nearest-even mode.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

The sine of a.

#### Description

Calculates nv bfloat16 sine of input a in round-to-nearest-even mode.

## \_\_device\_\_ \_nv\_bfloat16 hsqrt (const \_\_nv\_bfloat16 a)

Calculates nv\_bfloat16 square root in round-to-nearest-even mode.

#### **Parameters**

a

- nv\_bfloat16. Is only being read.

#### Returns

nv\_bfloat16

The square root of a.

#### Description

Calculates nv\_bfloat16 square root of input a in round-to-nearest-even mode.

## \_\_device\_\_ \_nv\_bfloat16 htrunc (const \_\_nv\_bfloat16 h)

Truncate input argument to the integral part.

#### **Parameters**

h

- nv\_bfloat16. Is only being read.

#### Returns

nv bfloat16

► The truncated integer value.

#### Description

Round h to the nearest integer value that does not exceed h in magnitude.

### 1.3.7. Bfloat162 Math Functions

Bfloat16 Precision Intrinsics

To use these functions, include the header file cuda\_bf16.h in your program.

### \_\_device\_\_ \_nv\_bfloat162 h2ceil (const \_ nv\_bfloat162 h)

Calculate nv bfloat162 vector ceiling of the input argument.

#### **Parameters**

h

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

▶ The vector of smallest integers not less than h.

#### Description

For each component of vector h compute the smallest integer value not less than h.

### \_\_device\_\_ \_nv\_bfloat162 h2cos (const \_\_nv\_bfloat162 a)

Calculates nv bfloat162 vector cosine in round-to-nearest-even mode.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

#### Returns

nv bfloat162

► The elementwise cosine on vector a.

#### Description

Calculates nv\_bfloat162 cosine of input vector a in round-to-nearest-even mode.

### \_\_device\_\_ \_nv\_bfloat162 h2exp (const \_\_nv\_bfloat162 a)

Calculates nv bfloat162 vector exponential function in round-to-nearest mode.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

▶ The elementwise exponential function on vector a.

#### Description

Calculates nv\_bfloat162 exponential function of input vector a in round-to-nearest-even mode.

### 

Calculates  $nv\_bfloat162$  vector decimal exponential function in round-to-nearest-even mode.

#### **Parameters**

a

- nv\_bfloat162. Is only being read.

#### Returns

nv bfloat162

▶ The elementwise decimal exponential function on vector a.

#### Description

Calculates nv\_bfloat162 decimal exponential function of input vector a in round-to-nearest-even mode.

## \_\_device\_\_ \_nv\_bfloat162 h2exp2 (const \_\_nv\_bfloat162 a)

Calculates  $nv\_bfloat162$  vector binary exponential function in round-to-nearest-even mode.

#### **Parameters**

a

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

▶ The elementwise binary exponential function on vector a.

#### Description

Calculates nv\_bfloat162 binary exponential function of input vector a in round-to-nearest-even mode.

# \_\_device\_\_ \_nv\_bfloat162 h2floor (const \_\_nv\_bfloat162 h)

Calculate the largest integer less than or equal to h.

### **Parameters**

h

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

▶ The vector of largest integers which is less than or equal to h.

### Description

For each component of vector h calculate the largest integer value which is less than or equal to h

# \_device\_\_ \_nv\_bfloat162 h2log (const \_\_nv\_bfloat162 a)

Calculates nv bfloat162 vector natural logarithm in round-to-nearest-even mode.

#### **Parameters**

а

- nv bfloat162. Is only being read.

#### Returns

nv bfloat162

► The elementwise natural logarithm on vector a.

## Description

Calculates nv\_bfloat162 natural logarithm of input vector a in round-to-nearest-even mode

# \_\_device\_\_ \_\_nv\_bfloat162 h2log10 (const \_\_nv\_bfloat162 a)

Calculates nv bfloat162 vector decimal logarithm in round-to-nearest-even mode.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

► The elementwise decimal logarithm on vector a.

### Description

Calculates  $nv\_bfloat162$  decimal logarithm of input vector a in round-to-nearest-even mode.

\_\_device\_\_ \_nv\_bfloat162 h2log2 (const \_\_nv\_bfloat162 a)

Calculates nv bfloat162 vector binary logarithm in round-to-nearest-even mode.

#### **Parameters**

а

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

► The elementwise binary logarithm on vector a.

### Description

Calculates nv\_bfloat162 binary logarithm of input vector a in round-to-nearest mode.

\_\_device\_\_ \_nv\_bfloat162 h2rcp (const \_\_nv\_bfloat162 a)

Calculates nv bfloat162 vector reciprocal in round-to-nearest-even mode.

#### **Parameters**

a

- nv\_bfloat162. Is only being read.

### Returns

nv\_bfloat162

► The elementwise reciprocal on vector a.

### Description

Calculates nv bfloat162 reciprocal of input vector a in round-to-nearest-even mode.

# device nv bfloat162 h2rint (const nv bfloat162 h)

Round input to nearest integer value in nv\_bfloat16 floating-point number.

### **Parameters**

h

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

The vector of rounded integer values.

### Description

Round each component of nv\_bfloat162 vector h to the nearest integer value in nv\_bfloat16 floating-point format, with bfloat16way cases rounded to the nearest even integer value.

# 

Calculates nv bfloat162 vector reciprocal square root in round-to-nearest mode.

#### **Parameters**

а

- nv bfloat162. Is only being read.

#### Returns

nv bfloat162

► The elementwise reciprocal square root on vector a.

# Description

Calculates nv\_bfloat162 reciprocal square root of input vector a in round-to-nearest-even mode

# \_\_device\_\_ \_\_nv\_bfloat162 h2sin (const \_\_nv\_bfloat162 a)

Calculates nv bfloat162 vector sine in round-to-nearest-even mode.

### **Parameters**

a

- nv\_bfloat162. Is only being read.

#### Returns

nv bfloat162

► The elementwise sine on vector a.

### Description

Calculates nv\_bfloat162 sine of input vector a in round-to-nearest-even mode.

# \_\_device\_\_ \_nv\_bfloat162 h2sqrt (const \_\_nv\_bfloat162 a)

Calculates nv bfloat162 vector square root in round-to-nearest-even mode.

#### **Parameters**

a

- nv\_bfloat162. Is only being read.

#### Returns

nv\_bfloat162

► The elementwise square root on vector a.

### Description

Calculates nv\_bfloat162 square root of input vector a in round-to-nearest mode.

# \_\_device\_\_ \_nv\_bfloat162 h2trunc (const \_\_nv\_bfloat162 h)

Truncate nv bfloat162 vector input argument to the integral part.

#### **Parameters**

h

- nv\_bfloat162. Is only being read.

#### Returns

nv bfloat162

► The truncated h.

### Description

Round each component of vector h to the nearest integer value that does not exceed h in magnitude.

# 1.4. Mathematical Functions

CUDA mathematical functions are always available in device code.

Host implementations of the common mathematical functions are mapped in a platform-specific way to standard math library functions, provided by the host compiler and respective host libr where available. Some functions, not available with the host compilers, are implemented in crt/math\_functions.hpp header file. For example, see <a href="erfinv()">erfinv()</a>. Other, less common functions, like <a href="rhypot()">rhypot()</a>, <a href="cyclessel\_io()">cyl\_bessel\_io()</a> are only available in device code.

Note that many floating-point and integer functions names are overloaded for different argument types. For example, the <u>log()</u> function has the following prototypes:

```
f double log(double x);
float log(float x);
float logf(float x);
```

Note also that due to implementation constraints, certain math functions from std:: namespace may be callable in device code even via explicitly qualified std:: names. However, such use is discouraged, since this capability is unsupported, unverified, undocumented, not portable, and may change without notice.

# 1.5. Single Precision Mathematical Functions

This section describes single precision mathematical functions. To use these functions you do not need to include any additional header files in your program.

# device float acosf (float x)

Calculate the arc cosine of the input argument.

#### Returns

Result will be in radians, in the interval  $[0, \pi]$  for x inside [-1, +1].

- ightharpoonup acosf(1) returns +0.
- acosf(x) returns NaN for x outside [-1, +1].

### Description

Calculate the principal value of the arc cosine of the input argument x.

# •

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float acoshf (float x)

Calculate the nonnegative inverse hyperbolic cosine of the input argument.

#### Returns

Result will be in the interval  $[0, +\infty]$ .

- acoshf(1) returns 0.
- ▶ acoshf(x) returns NaN for x in the interval  $[-\infty, 1]$ .
- ▶  $a\cosh(+\infty)$  returns  $+\infty$ .

### Description

Calculate the nonnegative inverse hyperbolic cosine of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float asinf (float x)

Calculate the arc sine of the input argument.

#### Returns

Result will be in radians, in the interval  $[-\pi/2, +\pi/2]$  for x inside [-1, +1].

- ▶  $asinf(\pm 0)$  returns  $\pm 0$ .
- asinf(x) returns NaN for x outside [-1, +1].

### Description

Calculate the principal value of the arc sine of the input argument x.



#### Note:



For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_\_ float asinhf (float x)

Calculate the inverse hyperbolic sine of the input argument.

#### Returns

- ▶ asinhf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ asinhf(  $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Calculate the inverse hyperbolic sine of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float atan2f (float y, float x)

Calculate the arc tangent of the ratio of first and second input arguments.

#### Returns

Result will be in radians, in the interval  $[-\pi, +\pi]$ .

- ▶ atan2f(  $\pm 0$ , -0) returns  $\pm \pi$ .
- $\blacktriangleright$  atan2f(  $\pm 0$ , +0) returns  $\pm 0$ .
- ▶ atan2f(  $\pm 0$ , x) returns  $\pm \pi$  for x < 0.
- ▶ atan2f(  $\pm 0$ , x) returns  $\pm 0$  for x > 0.
- ▶ atan2f(y,  $\pm 0$ ) returns  $-\pi/2$  for y < 0.
- ▶ atan2f(y,  $\pm 0$ ) returns  $\pi$  /2 for y > 0.
- ▶ atan2f(  $\pm y$ ,  $-\infty$ ) returns  $\pm \pi$  for finite y > 0.
- ▶ atan2f(  $\pm y$ ,  $+ \infty$ ) returns  $\pm 0$  for finite y > 0.
- ▶ atan2f(  $\pm \infty$ , x) returns  $\pm \pi$  /2 for finite x.
- ▶ atan2f(  $\pm \infty$ ,  $-\infty$ ) returns  $\pm 3\pi/4$ .
- ▶ atan2f(  $\pm \infty$ ,  $+ \infty$ ) returns  $\pm \pi/4$ .

### Description

Calculate the principal value of the arc tangent of the ratio of first and second input arguments y / x. The quadrant of the result is determined by the signs of inputs y and x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float atanf (float x)

Calculate the arc tangent of the input argument.

#### Returns

Result will be in radians, in the interval  $[-\pi/2, +\pi/2]$ .

- $\blacktriangleright$  atanf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ atanf(  $\pm \infty$ ) returns  $\pm \pi/2$ .

### Description

Calculate the principal value of the arc tangent of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float atanhf (float x)

Calculate the inverse hyperbolic tangent of the input argument.

#### Returns

- ightharpoonup atanhf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ atanhf(  $\pm 1$ ) returns  $\pm \infty$ .
- ightharpoonup atanhf(x) returns NaN for x outside interval [-1, 1].

### Description

Calculate the inverse hyperbolic tangent of the input argument x.

# •

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float cbrtf (float x)

Calculate the cube root of the input argument.

#### Returns

Returns  $x^{1/3}$ .

- $\triangleright$  cbrtf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ cbrtf(  $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Calculate the cube root of x,  $\chi^{1/3}$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_\_device\_\_\_ float ceilf (float x)

Calculate ceiling of the input argument.

#### Returns

Returns [x] expressed as a floating-point number.

- $\triangleright$  ceilf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ ceilf(  $\pm \infty$ ) returns  $\pm \infty$ .

## Description

Compute the smallest integer value not less than x.

# \_device\_\_ float copysignf (float x, float y)

Create value with given magnitude, copying sign of second value.

#### Returns

Returns a value with the magnitude of x and the sign of y.

### Description

Create a floating-point value with the magnitude x and the sign of y.

# \_\_device\_\_\_ float cosf (float x)

Calculate the cosine of the input argument.

#### Returns

- $\triangleright$  cosf(  $\pm 0$ ) returns 1.
- ▶  $cosf(\pm \infty)$  returns NaN.

### Description

Calculate the cosine of the input argument x (measured in radians).



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- ► This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# device float coshf (float x)

Calculate the hyperbolic cosine of the input argument.

#### Returns

- $\triangleright$  coshf(  $\pm 0$ ) returns 1.
- ▶ coshf(  $\pm \infty$ ) returns  $+ \infty$ .

### Description

Calculate the hyperbolic cosine of the input argument x.

# ,

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float cospif (float x)

Calculate the cosine of the input argument  $imes \pi$ .

#### Returns

- ightharpoonup cospif(  $\pm 0$ ) returns 1.
- ▶ cospif(  $\pm \infty$ ) returns NaN.

### Description

Calculate the cosine of  $x \times \pi$  (measured in radians), where x is the input argument.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float cyl\_bessel\_i0f (float x)

Calculate the value of the regular modified cylindrical Bessel function of order 0 for the input argument.

#### Returns

Returns the value of the regular modified cylindrical Bessel function of order 0.

### Description

Calculate the value of the regular modified cylindrical Bessel function of order 0 for the input argument x,  $I_0(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_\_ float cyl\_bessel\_i1f (float x)

Calculate the value of the regular modified cylindrical Bessel function of order 1 for the input argument.

#### Returns

Returns the value of the regular modified cylindrical Bessel function of order 1.

### Description

Calculate the value of the regular modified cylindrical Bessel function of order 1 for the input argument x,  $I_1(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float erfcf (float x)

Calculate the complementary error function of the input argument.

#### Returns

- ▶ erfcf(  $-\infty$ ) returns 2.
- ▶ erfcf(  $+ \infty$ ) returns +0.

### Description

Calculate the complementary error function of the input argument x, 1 - erf(x).



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float erfcinvf (float x)

Calculate the inverse complementary error function of the input argument.

#### Returns

- erfcinvf(  $\pm 0$ ) returns  $+ \infty$ .
- erfcinvf(2) returns -∞.

erfcinvf(x) returns NaN for x outside [0, 2].

### Description

Calculate the inverse complementary error function  $\operatorname{erfc}^{-1}(x)$ , of the input argument x in the interval [0, 2].



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float erfcxf (float x)

Calculate the scaled complementary error function of the input argument.

#### Returns

- ▶  $\operatorname{erfcxf}(-\infty)\operatorname{returns} + \infty$ .
- ▶ erfcxf(  $+\infty$ ) returns +0.

### Description

Calculate the scaled complementary error function of the input argument x,  $e^{x^2} \cdot \operatorname{erfc}(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float erff (float x)

Calculate the error function of the input argument.

#### Returns

- erff(  $\pm 0$ ) returns  $\pm 0$ .
- erff(  $\pm \infty$ ) returns  $\pm 1$ .

### Description

Calculate the value of the error function for the input argument x,  $\frac{2}{\sqrt{\pi}} \int_{0}^{x} e^{-t^2} dt$ .

# •

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_float erfinvf (float x)

Calculate the inverse error function of the input argument.

#### Returns

- erfinvf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ erfinvf(1) returns  $+\infty$ .
- ▶ erfinvf(-1) returns  $-\infty$ .
- erfinvf(x) returns NaN for x outside [-1, +1].

### Description

Calculate the inverse error function  $\operatorname{erf}^{-1}(x)$ , of the input argument x in the interval [-1, 1].



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float exp10f (float x)

Calculate the base 10 exponential of the input argument.

#### Returns

- $\triangleright$  exp10f(  $\pm 0$  ) returns 1.
- ▶  $exp10f(-\infty)$  returns +0.
- ▶  $\exp 10f(+\infty)$  returns  $+\infty$ .

## Description

Calculate  $10^x$ , the base 10 exponential of the input argument x.



#### Note:

- ľ
  - For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
  - ► This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_\_device\_\_ float exp2f (float x)

Calculate the base 2 exponential of the input argument.

#### Returns

- $\triangleright$  exp2f(  $\pm 0$  ) returns 1.
- ▶  $\exp 2f(-\infty)$  returns +0.
- ▶  $\exp 2f(+\infty)$  returns  $+\infty$ .

### Description

Calculate  $2^x$ , the base 2 exponential of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float expf (float x)

Calculate the base e exponential of the input argument.

#### Returns

- $\triangleright$  expf(  $\pm 0$ ) returns 1.
- ▶  $\exp\{(-\infty)\}$  returns +0.
- ▶  $\exp\{(+\infty)\}$  returns  $+\infty$ .

# Description

Calculate  $e^x$ , the base e exponential of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.



This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_\_device\_\_\_ float expm1f (float x)

Calculate the base e exponential of the input argument, minus 1.

#### Returns

- $\triangleright$  expm1f(  $\pm 0$  ) returns  $\pm 0$ .
- ▶ expm1f( $-\infty$ ) returns -1.
- ▶ expm1f(  $+\infty$ ) returns  $+\infty$ .

### Description

Calculate  $e^x$  -1, the base e exponential of the input argument x, minus 1.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float fabsf (float x)

Calculate the absolute value of its argument.

#### Returns

Returns the absolute value of its argument.

- ▶ fabsf(  $\pm \infty$ ) returns  $+ \infty$ .
- fabsf(  $\pm 0$ ) returns +0.
- ► fabsf(NaN) returns an unspecified NaN.

## Description

Calculate the absolute value of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_\_ float fdimf (float x, float y)

Compute the positive difference between x and y.

#### Returns

Returns the positive difference between x and y.

- fdimf(x, y) returns x y if x > y.
- fdimf(x, y) returns +0 if  $x \le y$ .

### Description

Compute the positive difference between x and y. The positive difference is x - y when x > y and +0 otherwise.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float fdividef (float x, float y)

Divide two floating-point values.

#### Returns

Returns x / y.

### Description

Compute x divided by y. If --use\_fast\_math is specified, use \_\_fdividef() for higher performance, otherwise use normal division.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- ► This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_device\_\_\_ float floorf (float x)

Calculate the largest integer less than or equal to x.

#### Returns

Returns [x] expressed as a floating-point number.

- ▶ floorf(  $\pm \infty$ ) returns  $\pm \infty$ .
- floorf(  $\pm 0$ ) returns  $\pm 0$ .

### Description

Calculate the largest integer value which is less than or equal to x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float fmaf (float x, float y, float z)

Compute  $x \times y + z$  as a single operation.

#### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- ▶ fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ▶ fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- ▶ fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$ .
- ▶ fmaf(x, y,  $+\infty$ ) returns NaN if  $x \times y$  is an exact  $-\infty$ .

### Description

Compute the value of  $x \times y + z$  as a single ternary operation. After computing the value to infinite precision, the value is rounded once.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_\_ float fmaxf (float x, float y)

Determine the maximum numeric value of the arguments.

#### Returns

Returns the maximum numeric values of the arguments x and y.

- If both arguments are NaN, returns NaN.
- If one argument is NaN, returns the numeric argument.

### Description

Determines the maximum numeric value of the arguments x and y. Treats NaN arguments as missing data. If one argument is a NaN and the other is legitimate numeric value, the numeric value is chosen.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_\_ float fminf (float x, float y)

Determine the minimum numeric value of the arguments.

#### Returns

Returns the minimum numeric value of the arguments x and y.

- If both arguments are NaN, returns NaN.
- If one argument is NaN, returns the numeric argument.

# Description

Determines the minimum numeric value of the arguments x and y. Treats NaN arguments as missing data. If one argument is a NaN and the other is legitimate numeric value, the numeric value is chosen.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float fmodf (float x, float y)

Calculate the floating-point remainder of x / y.

#### Returns

- ► Returns the floating-point remainder of x / y.
- fmodf(  $\pm 0$ , y) returns  $\pm 0$  if y is not zero.
- fmodf(x,  $\pm \infty$ ) returns x if x is finite.
- ▶ fmodf(x, y) returns NaN if x is  $\pm \infty$  or y is zero.
- If either argument is NaN, NaN is returned.

### Description

Calculate the floating-point remainder of x / y. The floating-point remainder of the division operation x / y calculated by this function is exactly the value x - n\*y, where n is x / y with its fractional part truncated. The computed value will have the same sign as x, and its magnitude will be less than the magnitude of y.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float frexpf (float x, int \*nptr)

Extract mantissa and exponent of a floating-point value.

#### Returns

Returns the fractional component m.

- frexpf(  $\pm 0$ , nptr) returns  $\pm 0$  and stores zero in the location pointed to by nptr.
- ▶ frexpf(  $\pm \infty$ , nptr) returns  $\pm \infty$  and stores an unspecified value in the location to which nptr points.
- frexpf(NaN, y) returns a NaN and stores an unspecified value in the location to which nptr points.

### Description

Decomposes the floating-point value x into a component m for the normalized fraction element and another term n for the exponent. The absolute value of m will be greater than or equal to

0.5 and less than 1.0 or it will be equal to 0;  $x = m \cdot 2^n$ . The integer exponent n will be stored in the location to which nptr points.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float hypotf (float x, float y)

Calculate the square root of the sum of squares of two arguments.

#### Returns

Returns the length of the hypotenuse  $\sqrt{x^2 + y^2}$ .

- hypotf(x,y), hypotf(y,x), and hypotf(x, -y) are equivalent.
- hypotf(x,  $\pm 0$ ) is equivalent to fabsf(x).
- ▶ hypotf(  $\pm \infty$ ,y) returns  $+ \infty$ , even if y is a NaN.

### Description

Calculates the length of the hypotenuse of a right triangle whose two sides have lengths  $\mathbf{x}$  and  $\mathbf{y}$  without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ int ilogbf (float x)

Compute the unbiased integer exponent of the argument.

#### Returns

- If successful, returns the unbiased exponent of the argument.
- ilogbf(  $\pm 0$  ) returns INT MIN.
- ► ilogbf(NaN) returns INT MIN.
- ▶ ilogbf(  $\pm \infty$ ) returns INT MAX.
- ▶ Note: above behavior does not take into account FP ILOGBO nor FP ILOGBNAN.

### Description

Calculates the unbiased integer exponent of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ \_\_RETURN\_TYPE isfinite (float a)

Determine whether argument is finite.

#### Returns

- ▶ With Visual Studio 2013 host compiler: \_\_RETURN\_TYPE is 'bool'. Returns true if and only if a is a finite value.
- With other host compilers: \_\_RETURN\_TYPE is 'int'. Returns a nonzero value if and only if a is a finite value.

### Description

Determine whether the floating-point value a is a finite value (zero, subnormal, or normal and not infinity or NaN).

# \_\_device\_\_ \_\_RETURN\_TYPE isinf (float a)

Determine whether argument is infinite.

#### Returns

- ▶ With Visual Studio 2013 host compiler: \_\_RETURN\_TYPE is 'bool'. Returns true if and only if a is an infinite value.
- ▶ With other host compilers: \_\_RETURN\_TYPE is 'int'. Returns a nonzero value if and only if a is an infinite value.

### Description

Determine whether the floating-point value a is an infinite value (positive or negative).

# device RETURN TYPE isnan (float a)

Determine whether argument is a NaN.

#### Returns

- ▶ With Visual Studio 2013 host compiler: \_\_RETURN\_TYPE is 'bool'. Returns true if and only if a is a NaN value.
- With other host compilers: \_\_RETURN\_TYPE is 'int'. Returns a nonzero value if and only if a is a NaN value.

### Description

Determine whether the floating-point value a is a NaN.

# \_\_device\_\_ float j0f (float x)

Calculate the value of the Bessel function of the first kind of order 0 for the input argument.

#### Returns

Returns the value of the Bessel function of the first kind of order 0.

- ▶  $j0f(\pm \infty)$  returns +0.
- ▶ j0f(NaN) returns NaN.

### Description

Calculate the value of the Bessel function of the first kind of order 0 for the input argument x,  $J_0(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float j1f (float x)

Calculate the value of the Bessel function of the first kind of order 1 for the input argument.

#### Returns

Returns the value of the Bessel function of the first kind of order 1.

- $\triangleright$  j1f(  $\pm 0$  ) returns  $\pm 0$ .
- ▶ j1f(  $\pm \infty$ ) returns  $\pm 0$ .

▶ j1f(NaN) returns NaN.

### Description

Calculate the value of the Bessel function of the first kind of order 1 for the input argument x,  $J_1(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_\_ float jnf (int n, float x)

Calculate the value of the Bessel function of the first kind of order n for the input argument.

#### Returns

Returns the value of the Bessel function of the first kind of order n.

- ▶ jnf(n, NaN) returns NaN.
- inf(n, x) returns NaN for n < 0.
- ▶  $\inf(n, +\infty)$  returns +0.

## Description

Calculate the value of the Bessel function of the first kind of order n for the input argument x,  $J_n(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_\_device\_\_\_ float ldexpf (float x, int exp)

Calculate the value of  $x \cdot 2^{exp}$ .

#### Returns

 $\blacktriangleright$  ldexpf(x, exp) is equivalent to scalbnf(x, exp).

### Description

Calculate the value of  $x \cdot 2^{exp}$  of the input arguments x and exp.

# •

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float lgammaf (float x)

Calculate the natural logarithm of the absolute value of the gamma function of the input argument.

#### Returns

- ▶ lgammaf(1) returns +0.
- ▶ lgammaf(2) returns +0.
- ▶ lgammaf(x) returns  $+\infty$  if  $x \le 0$  and x is an integer.
- ▶ lgammaf( $-\infty$ ) returns  $+\infty$ .
- ▶ lgammaf(  $+ \infty$ ) returns  $+ \infty$ .

### Description

Calculate the natural logarithm of the absolute value of the gamma function of the input argument x, namely the value of  $\log_e \left| \int_0^\infty e^{-t} t^{x-1} dt \right|$ 



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ long long int llrintf (float x)

Round input to nearest integer value.

### Returns

Returns rounded integer value.

### Description

Round x to the nearest integer value, with halfway cases rounded to the nearest even integer value. If the result is outside the range of the return type, the behavior is undefined.

# \_device\_\_\_ long long int llroundf (float x)

Round to nearest integer value.

#### Returns

Returns rounded integer value.

### Description

Round x to the nearest integer value, with halfway cases rounded away from zero. If the result is outside the range of the return type, the behavior is undefined.



#### Note:

This function may be slower than alternate rounding methods. See <u>llrintf()</u>.

# \_device\_\_ float log10f (float x)

Calculate the base 10 logarithm of the input argument.

#### Returns

- log10f(  $\pm 0$  ) returns  $-\infty$ .
- $\triangleright$  log10f(1) returns +0.
- log10f(x) returns NaN for x < 0.
- ▶  $log10f(+\infty)$  returns  $+\infty$ .

### Description

Calculate the base 10 logarithm of the input argument x.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- ► This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_device\_\_ float log1pf (float x)

Calculate the value of  $\log_{a}(1+x)$ .

#### Returns

- log1pf(  $\pm 0$  ) returns  $\pm 0$ .
- log1pf(-1) returns  $-\infty$ .
- ▶ log1pf(x) returns NaN for x < -1.
- ▶  $log1pf(+\infty)$  returns  $+\infty$ .

### Description

Calculate the value of  $\log_{\rho}(1+x)$  of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float log2f (float x)

Calculate the base 2 logarithm of the input argument.

#### Returns

- log2f(  $\pm 0$ ) returns  $-\infty$ .
- $\triangleright$  log2f(1) returns +0.
- $\triangleright$  log2f(x) returns NaN for x < 0.
- ▶  $\log 2f(+\infty)$  returns  $+\infty$ .

### Description

Calculate the base 2 logarithm of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.



This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_device\_\_ float logbf (float x)

Calculate the floating-point representation of the exponent of the input argument.

#### Returns

- ▶ logbf(  $\pm 0$ ) returns  $-\infty$ .
- ▶ logbf(  $\pm \infty$ ) returns  $+ \infty$ .

### Description

Calculate the floating-point representation of the exponent of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float logf (float x)

Calculate the natural logarithm of the input argument.

#### Returns

- ▶  $logf(\pm 0)$  returns  $-\infty$ .
- $\blacktriangleright$  logf(1) returns +0.
- $\blacktriangleright$  logf(x) returns NaN for x < 0.
- ▶  $logf(+\infty)$  returns  $+\infty$ .

### Description

Calculate the natural logarithm of the input argument  $\mathbf{x}$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.



This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_\_device\_\_ long int lrintf (float x)

Round input to nearest integer value.

#### Returns

Returns rounded integer value.

### Description

Round x to the nearest integer value, with halfway cases rounded to the nearest even integer value. If the result is outside the range of the return type, the behavior is undefined.

# \_\_device\_\_ long int lroundf (float x)

Round to nearest integer value.

#### Returns

Returns rounded integer value.

## Description

Round x to the nearest integer value, with halfway cases rounded away from zero. If the result is outside the range of the return type, the behavior is undefined.



#### Note:

This function may be slower than alternate rounding methods. See <a href="lintfl">lrintf()</a>.

# \_\_device\_\_ float max (const float a, const float b)

Calculate the maximum value of the input float arguments.

### Description

Calculate the maximum value of the arguments a and b. Behavior is equivalent to <a href="maxfl">function</a>.

Note, this is different from std:: specification

# \_device\_\_\_ float min (const float a, const float b)

Calculate the minimum value of the input float arguments.

### Description

Calculate the minimum value of the arguments a and b. Behavior is equivalent to <a href="minimum">fminf()</a> function.

Note, this is different from std:: specification

# \_device\_\_\_ float modff (float x, float \*iptr)

Break down the input argument into fractional and integral parts.

#### Returns

- ightharpoonup modff(  $\pm x$ , iptr) returns a result with the same sign as x.
- ▶ modff(  $\pm \infty$ , iptr) returns  $\pm 0$  and stores  $\pm \infty$  in the object pointed to by iptr.
- modff(NaN, iptr) stores a NaN in the object pointed to by iptr and returns a NaN.

### Description

Break down the argument x into fractional and integral parts. The integral part is stored in the argument iptr. Fractional and integral parts are given the same sign as the argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float nanf (const char \*tagp)

Returns "Not a Number" value.

#### Returns

nanf(tagp) returns NaN.

### Description

Return a representation of a quiet NaN. Argument tagp selects one of the possible representations.

# •

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float nearbyintf (float x)

Round the input argument to the nearest integer.

#### Returns

- nearbyintf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ nearbyintf(  $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Round argument x to an integer value in single precision floating-point format. Uses round to nearest rounding, with ties rounding to even.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float nextafterf (float x, float y)

Return next representable single-precision floating-point value after argument  $\mathbf{x}$  in the direction of  $\mathbf{y}$ .

#### Returns

- nextafterf(x, y) = y if x equals y.
- nextafterf(x, y) = NaN if either x or y are NaN.

### Description

Calculate the next representable single-precision floating-point value following  $\mathbf{x}$  in the direction of  $\mathbf{y}$ . For example, if  $\mathbf{y}$  is greater than  $\mathbf{x}$ ,  $\underline{\mathsf{nextafterf()}}$  returns the smallest representable number greater than  $\mathbf{x}$ 



#### Note:



For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float norm3df (float a, float b, float c)

Calculate the square root of the sum of squares of three coordinates of the argument.

#### Returns

Returns the length of the 3D vector  $\sqrt{a^2 + b^2 + c^2}$ .

▶ In the presence of an exactly infinite coordinate  $+\infty$  is returned, even if there are NaNs.

### Description

Calculates the length of three dimensional vector in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float norm4df (float a, float b, float c, float d)

Calculate the square root of the sum of squares of four coordinates of the argument.

#### Returns

Returns the length of the 4D vector  $\sqrt{a^2+b^2+c^2+d^2}$ .

▶ In the presence of an exactly infinite coordinate  $+\infty$  is returned, even if there are NaNs.

### Description

Calculates the length of four dimensional vector in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float normcdff (float x)

Calculate the standard normal cumulative distribution function.

#### Returns

- ▶ normcdff( $+\infty$ ) returns 1.
- ▶ normcdff( $-\infty$ ) returns +0

## Description

Calculate the cumulative distribution function of the standard normal distribution for input argument x,  $\Phi(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_\_device\_\_\_ float normcdfinvf (float x)

Calculate the inverse of the standard normal cumulative distribution function.

#### Returns

- ▶ normcdfinvf(  $\pm 0$ ) returns  $-\infty$ .
- ▶ normcdfinvf(1) returns  $+\infty$ .
- normcdfinvf(x) returns NaN if x is not in the interval [0,1].

# Description

Calculate the inverse of the standard normal cumulative distribution function for input argument x,  $\Phi^{-1}(x)$ . The function is defined for input values in the interval (0, 1).



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_\_ float normf (int dim, const float \*p)

Calculate the square root of the sum of squares of any number of coordinates.

#### Returns

Returns the length of the dim-D vector  $\sqrt{p_0^2 + p_1^2 + ... + p_{\text{dim-1}}^2}$ .

▶ In the presence of an exactly infinite coordinate  $+\infty$  is returned, even if there are NaNs.

### Description

Calculates the length of a vector p, dimension of which is passed as an argument without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float powf (float x, float y)

Calculate the value of first argument to the power of second argument.

#### Returns

- ▶ powf(  $\pm 0$ , y) returns  $\pm \infty$  for y an odd integer less than 0.
- ▶ powf(  $\pm 0$ , y) returns  $+ \infty$  for y less than 0 and not an odd integer.
- powf( $\pm 0$ , y) returns  $\pm 0$  for y an odd integer greater than 0.
- powf( $\pm 0$ , y) returns +0 for y > 0 and not an odd integer.
- ▶ powf(-1,  $\pm \infty$ ) returns 1.
- powf(+1, y) returns 1 for any y, even a NaN.
- ightharpoonup powf(x,  $\pm 0$ ) returns 1 for any x, even a NaN.
- ightharpoonup powf(x, y) returns a NaN for finite x < 0 and finite non-integer y.
- ▶ powf(x,  $-\infty$ ) returns  $+\infty$  for |x| < 1.
- ▶ powf(x,  $-\infty$ ) returns +0 for |x| > 1.
- ▶ powf(x,  $+\infty$ ) returns +0 for |x| < 1.
- ▶ powf(x,  $+\infty$ ) returns  $+\infty$  for |x| > 1.
- ▶ powf( $-\infty$ , y) returns -0 for y an odd integer less than 0.

- ▶ powf( $-\infty$ , y) returns +0 for y < 0 and not an odd integer.
- ▶ powf( $-\infty$ , y) returns  $-\infty$  for y an odd integer greater than 0.
- ▶ powf( $-\infty$ , y) returns  $+\infty$  for y > 0 and not an odd integer.
- ▶ powf(  $+\infty$ , y) returns +0 for y < 0.
- ▶ powf(  $+\infty$ , y) returns  $+\infty$  for y > 0.

### Description

Calculate the value of x to the power of y.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- ► This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_device\_\_\_ float rcbrtf (float x)

Calculate reciprocal cube root function.

#### Returns

- rcbrt( $\pm 0$ ) returns  $\pm \infty$ .
- rcbrt( $\pm \infty$ ) returns  $\pm 0$ .

### Description

Calculate reciprocal cube root function of x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_\_ float remainderf (float x, float y)

Compute single-precision floating-point remainder.

#### Returns

- remainderf(x,  $\pm 0$ ) returns NaN.
- remainderf(  $\pm \infty$ , y) returns NaN.
- remainderf(x,  $\pm \infty$ ) returns x for finite x.

### Description

Compute single-precision floating-point remainder  $\mathbf{r}$  of dividing  $\mathbf{x}$  by  $\mathbf{y}$  for nonzero  $\mathbf{y}$ . Thus  $r = \mathbf{x} - n\mathbf{y}$ . The value  $\mathbf{n}$  is the integer value nearest  $\frac{\mathbf{X}}{\mathbf{Y}}$ . In the case when  $|n - \frac{\mathbf{X}}{\mathbf{Y}}| = \frac{1}{2}$ , the even  $\mathbf{n}$  value is chosen.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float remquof (float x, float y, int \*quo)

Compute single-precision floating-point remainder and part of quotient.

#### Returns

Returns the remainder.

- remquof(x,  $\pm 0$ , quo) returns NaN and stores an unspecified value in the location to which quo points.
- remquof(  $\pm \infty$ , y, quo) returns NaN and stores an unspecified value in the location to which quo points.
- remquof(x, y, quo) returns NaN and stores an unspecified value in the location to which quo points if either of x or y is NaN.
- remquof(x,  $\pm \infty$ , quo) returns x and stores zero in the location to which quo points for finite x.

# Description

Compute a single-precision floating-point remainder in the same way as the  $\underline{remainderf()}$  function. Argument quo returns part of quotient upon division of x by y. Value quo has the

same sign as  $\frac{x}{y}$  and may not be the exact quotient but agrees with the exact quotient in the low order 3 bits.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_\_ float rhypotf (float x, float y)

Calculate one over the square root of the sum of squares of two arguments.

#### Returns

Returns one over the length of the hypotenuse  $\frac{1}{\sqrt{x^2+y^2}}$ .

- rhypotf(x,y), rhypotf(y,x), and rhypotf(x, -y) are equivalent.
- rhypotf( $\pm \infty$ ,y) returns +0, even if y is a NaN.

### Description

Calculates one over the length of the hypotenuse of a right triangle whose two sides have lengths x and y without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float rintf (float x)

Round input to nearest integer value in floating-point.

#### Returns

Returns rounded integer value.

- rintf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ rintf(  $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Round  $\mathbf{x}$  to the nearest integer value in floating-point format, with halfway cases rounded to the nearest even integer value.

# device float rnorm3df (float a, float b, float c)

Calculate one over the square root of the sum of squares of three coordinates.

#### Returns

Returns one over the length of the 3D vector  $\frac{1}{\sqrt{a^2+b^2+c^2}}$ .

In the presence of an exactly infinite coordinate +0 is returned, even if there are NaNs.

### Description

Calculates one over the length of three dimension vector in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float rnorm4df (float a, float b, float c, float d)

Calculate one over the square root of the sum of squares of four coordinates.

#### Returns

Returns one over the length of the 3D vector  $\frac{1}{\sqrt{a^2+b^2+c^2+d^2}}$ .

In the presence of an exactly infinite coordinate +0 is returned, even if there are NaNs.

### Description

Calculates one over the length of four dimension vector in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float rnormf (int dim, const float \*p)

Calculate the reciprocal of square root of the sum of squares of any number of coordinates.

#### Returns

Returns one over the length of the vector  $\frac{1}{\sqrt{p_0^2 + p_1^2 + ... + p_{\text{dim-}1}^2}}$ .

In the presence of an exactly infinite coordinate +0 is returned, even if there are NaNs.

### Description

Calculates one over the length of vector p, dimension of which is passed as an argument, in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float roundf (float x)

Round to nearest integer value in floating-point.

#### Returns

Returns rounded integer value.

- roundf( $\pm 0$ ) returns  $\pm 0$ .
- roundf( $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Round x to the nearest integer value in floating-point format, with halfway cases rounded away from zero.



#### Note:

This function may be slower than alternate rounding methods. See <u>rintf()</u>.

# \_device\_\_ float rsqrtf (float x)

Calculate the reciprocal of the square root of the input argument.

#### Returns

Returns  $1/\sqrt{x}$ .

- ► rsqrtf(  $+\infty$ ) returns +0.
- rsqrtf(  $\pm 0$  ) returns  $\pm \infty$ .
- rsqrtf(x) returns NaN if x is less than 0.

### Description

Calculate the reciprocal of the nonnegative square root of x,  $1/\sqrt{x}$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float scalblnf (float x, long int n)

Scale floating-point input by integer power of two.

#### Returns

Returns  $x * 2^n$ .

- $\triangleright$  scalblnf(  $\pm 0$ , n) returns  $\pm 0$ .
- $\triangleright$  scalblnf(x, 0) returns x.
- ▶ scalblnf( $\pm \infty$ , n) returns  $\pm \infty$ .

### Description

Scale x by  $2^n$  by efficient manipulation of the floating-point exponent.

# \_device\_\_ float scalbnf (float x, int n)

Scale floating-point input by integer power of two.

#### Returns

Returns  $x * 2^n$ .

- $\triangleright$  scalbnf(  $\pm 0$ , n) returns  $\pm 0$ .
- ightharpoonup scalbnf(x, 0) returns x.
- ▶ scalbnf( $\pm \infty$ , n) returns  $\pm \infty$ .

### Description

Scale x by  $2^n$  by efficient manipulation of the floating-point exponent.

# 

Return the sign bit of the input.

#### Returns

Reports the sign bit of all values including infinities, zeros, and NaNs.

- ▶ With Visual Studio 2013 host compiler: \_\_RETURN\_TYPE is 'bool'. Returns true if and only if a is negative.
- With other host compilers: \_\_RETURN\_TYPE is 'int'. Returns a nonzero value if and only if a is negative.

### Description

Determine whether the floating-point value a is negative.

# \_\_device\_\_ void sincosf (float x, float \*sptr, float \*cptr)

Calculate the sine and cosine of the first input argument.

#### Returns

none

### Description

Calculate the sine and cosine of the first input argument x (measured in radians). The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.

#### See also:

sinf() and cosf().



#### Note:

- - For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
  - ► This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_\_device\_\_ void sincospif (float x, float \*sptr, float \*cptr)

Calculate the sine and cosine of the first input argument  $\times \pi$ .

#### Returns

none

### Description

Calculate the sine and cosine of the first input argument, x (measured in radians), x  $\pi$ . The results for sine and cosine are written into the second argument, ptr, and, respectively, third argument, ptr.

#### See also:

sinpif() and cospif().



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float sinf (float x)

Calculate the sine of the input argument.

#### Returns

- $\triangleright$  sinf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶  $sinf(\pm \infty)$  returns NaN.

### Description

Calculate the sine of the input argument x (measured in radians).

#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- ► This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_device\_\_ float sinhf (float x)

Calculate the hyperbolic sine of the input argument.

#### Returns

- $\triangleright$  sinhf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶  $\sinh(\pm \infty) \text{ returns } \pm \infty$ .

### Description

Calculate the hyperbolic sine of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_\_ float sinpif (float x)

Calculate the sine of the input argument  $\times \pi$ .

#### Returns

- $\triangleright$  sinpif(  $\pm 0$  ) returns  $\pm 0$ .
- ▶ sinpif(  $\pm \infty$ ) returns NaN.

### Description

Calculate the sine of  $x \times \pi$  (measured in radians), where x is the input argument.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float sqrtf (float x)

Calculate the square root of the input argument.

#### Returns

Returns  $\sqrt{x}$ .

- ▶ sqrtf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶  $sqrtf(+\infty)$  returns  $+\infty$ .
- ightharpoonup sqrtf(x) returns NaN if x is less than 0.

### Description

Calculate the nonnegative square root of x,  $\sqrt{x}$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float tanf (float x)

Calculate the tangent of the input argument.

#### Returns

- $\blacktriangleright$  tanf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶  $tanf(\pm \infty)$  returns NaN.

### Description

Calculate the tangent of the input argument x (measured in radians).



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- ► This function is affected by the --use\_fast\_math compiler flag. See the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section for a complete list of functions affected.

# \_device\_\_ float tanhf (float x)

Calculate the hyperbolic tangent of the input argument.

#### Returns

- ▶  $tanhf(\pm 0)$  returns  $\pm 0$ .
- ▶  $tanhf(\pm \infty)$  returns  $\pm 1$ .

### Description

Calculate the hyperbolic tangent of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float tgammaf (float x)

Calculate the gamma function of the input argument.

#### Returns

- ▶ tgammaf(  $\pm 0$ ) returns  $\pm \infty$ .
- tgammaf(2) returns +1.
- tgammaf(x) returns NaN if x < 0 and x is an integer.
- ▶ tgammaf( $-\infty$ ) returns NaN.
- ▶ tgammaf(  $+\infty$ ) returns  $+\infty$ .

### Description

Calculate the gamma function of the input argument x, namely the value of  $\int_0^\infty e^{-t}t^{x-1}dt$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float truncf (float x)

Truncate input argument to the integral part.

#### Returns

Returns truncated integer value.

- truncf(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ truncf(  $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Round x to the nearest integer value that does not exceed x in magnitude.

# \_\_device\_\_ float y0f (float x)

Calculate the value of the Bessel function of the second kind of order 0 for the input argument.

#### Returns

Returns the value of the Bessel function of the second kind of order 0.

- ▶ y0f(  $\pm 0$ ) returns  $-\infty$ .
- $\triangleright$  y0f(x) returns NaN for x < 0.
- ▶  $y0f(+\infty)$  returns +0.
- y0f(NaN) returns NaN.

### Description

Calculate the value of the Bessel function of the second kind of order 0 for the input argument x,  $Y_0(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float y1f (float x)

Calculate the value of the Bessel function of the second kind of order 1 for the input argument.

#### Returns

Returns the value of the Bessel function of the second kind of order 1.

- ▶ y1f(  $\pm 0$ ) returns  $-\infty$ .
- ightharpoonup y1f(x) returns NaN for x < 0.
- ▶  $y1f(+\infty)$  returns +0.
- ▶ y1f(NaN) returns NaN.

### Description

Calculate the value of the Bessel function of the second kind of order 1 for the input argument x,  $Y_1(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float ynf (int n, float x)

Calculate the value of the Bessel function of the second kind of order n for the input argument.

#### Returns

Returns the value of the Bessel function of the second kind of order n.

- $\triangleright$  ynf(n, x) returns NaN for n < 0.
- ▶  $ynf(n, \pm 0)$  returns  $-\infty$ .
- $\triangleright$  ynf(n, x) returns NaN for x < 0.
- ▶  $ynf(n, +\infty)$  returns +0.
- ynf(n, NaN) returns NaN.

### Description

Calculate the value of the Bessel function of the second kind of order n for the input argument x,  $Y_n(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# 1.6. Double Precision Mathematical Functions

This section describes double precision mathematical functions. To use these functions you do not need to include any additional header files in your program.

# \_device\_\_\_ double acos (double x)

Calculate the arc cosine of the input argument.

#### Returns

Result will be in radians, in the interval  $[0, \pi]$  for x inside [-1, +1].

- ightharpoonup acos(1) returns +0.
- ightharpoonup acos(x) returns NaN for x outside [-1, +1].

### Description

Calculate the principal value of the arc cosine of the input argument x.



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_\_ double acosh (double x)

Calculate the nonnegative inverse hyperbolic cosine of the input argument.

#### Returns

Result will be in the interval  $[0, +\infty]$ .

- acosh(1) returns 0.
- ▶ acosh(x) returns NaN for x in the interval  $[-\infty, 1]$ .
- ▶  $a\cosh(+\infty)$  returns  $+\infty$ .

### Description

Calculate the nonnegative inverse hyperbolic cosine of the input argument x.

# ,

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double asin (double x)

Calculate the arc sine of the input argument.

#### Returns

Result will be in radians, in the interval [-  $\pi$  /2, +  $\pi$  /2] for x inside [-1, +1].

- ightharpoonup asin(  $\pm 0$  ) returns  $\pm 0$ .
- ▶ asin(x) returns NaN for x outside [-1, +1].

### Description

Calculate the principal value of the arc sine of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

## \_device\_\_ double asinh (double x)

Calculate the inverse hyperbolic sine of the input argument.

#### Returns

- ightharpoonup asinh(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ asinh( $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Calculate the inverse hyperbolic sine of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double atan (double x)

Calculate the arc tangent of the input argument.

#### Returns

Result will be in radians, in the interval  $[-\pi/2, +\pi/2]$ .

- $\blacktriangleright$  atan(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ atan(  $\pm \infty$ ) returns  $\pm \pi/2$ .

### Description

Calculate the principal value of the arc tangent of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_\_ double atan2 (double y, double x)

Calculate the arc tangent of the ratio of first and second input arguments.

#### Returns

Result will be in radians, in the interval [-  $\pi$  , +  $\pi$  ].

- ightharpoonup atan2(  $\pm 0$ , -0) returns  $\pm \pi$ .
- $\blacktriangleright$  atan2( +0 . +0) returns +0.
- ▶ atan2(  $\pm 0$ , x) returns  $\pm \pi$  for x < 0.
- ▶ atan2(  $\pm 0$ , x) returns  $\pm 0$  for x > 0.
- ▶ atan2(y,  $\pm 0$ ) returns  $-\pi/2$  for y < 0.
- ▶ atan2(y,  $\pm 0$ ) returns  $\pi/2$  for y > 0.
- ▶ atan2(  $\pm y$ ,  $-\infty$ ) returns  $\pm \pi$  for finite y > 0.
- ▶ atan2(  $\pm y$ ,  $+ \infty$ ) returns  $\pm 0$  for finite y > 0.
- ▶ atan2(  $\pm \infty$ , x) returns  $\pm \pi$  /2 for finite x.
- ▶ atan2(  $\pm \infty$ ,  $-\infty$ ) returns  $\pm 3\pi/4$ .
- ▶ atan2(  $\pm \infty$ ,  $+ \infty$ ) returns  $\pm \pi/4$ .

### Description

Calculate the principal value of the arc tangent of the ratio of first and second input arguments y / x. The quadrant of the result is determined by the signs of inputs y and x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double atanh (double x)

Calculate the inverse hyperbolic tangent of the input argument.

#### Returns

- ightharpoonup atanh(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ atanh(  $\pm 1$ ) returns  $\pm \infty$ .
- atanh(x) returns NaN for x outside interval [-1, 1].

### Description

Calculate the inverse hyperbolic tangent of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_\_ double cbrt (double x)

Calculate the cube root of the input argument.

#### Returns

Returns  $x^{1/3}$ .

- $\triangleright$  cbrt(  $\pm 0$ ) returns  $\pm 0$ .
- ► cbrt(  $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Calculate the cube root of x,  $x^{1/3}$ .

# **,**

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double ceil (double x)

Calculate ceiling of the input argument.

#### Returns

Returns [x] expressed as a floating-point number.

- ightharpoonup ceil(  $\pm 0$  ) returns  $\pm 0$ .
- ► ceil(  $\pm \infty$ ) returns  $\pm \infty$ .

### Description

Compute the smallest integer value not less than x.

# \_\_device\_\_ double copysign (double x, double y)

Create value with given magnitude, copying sign of second value.

#### Returns

Returns a value with the magnitude of x and the sign of y.

### Description

Create a floating-point value with the magnitude x and the sign of y.

# \_\_device\_\_ double cos (double x)

Calculate the cosine of the input argument.

#### Returns

- $\triangleright$  cos(  $\pm 0$ ) returns 1.
- ▶  $cos(\pm \infty)$  returns NaN.

### Description

Calculate the cosine of the input argument x (measured in radians).

# •

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double cosh (double x)

Calculate the hyperbolic cosine of the input argument.

#### Returns

- $\triangleright$  cosh(  $\pm 0$ ) returns 1.
- ▶  $\cosh(\pm \infty)$  returns  $+ \infty$ .

### Description

Calculate the hyperbolic cosine of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double cospi (double x)

Calculate the cosine of the input argument  $\times \pi$ .

#### Returns

- ightharpoonup cospi(  $\pm 0$  ) returns 1.
- ► cospi(  $\pm \infty$ ) returns NaN.

### Description

Calculate the cosine of  $x \times \pi$  (measured in radians), where x is the input argument.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_\_ double cyl\_bessel\_i0 (double x)

Calculate the value of the regular modified cylindrical Bessel function of order 0 for the input argument.

#### Returns

Returns the value of the regular modified cylindrical Bessel function of order 0.

### Description

Calculate the value of the regular modified cylindrical Bessel function of order 0 for the input argument x,  $I_0(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double cyl\_bessel\_i1 (double x)

Calculate the value of the regular modified cylindrical Bessel function of order 1 for the input argument.

#### Returns

Returns the value of the regular modified cylindrical Bessel function of order 1.

### Description

Calculate the value of the regular modified cylindrical Bessel function of order 1 for the input argument x,  $I_1(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

## \_device\_\_\_ double erf (double x)

Calculate the error function of the input argument.

#### Returns

- $\triangleright$  erf(  $\pm 0$ ) returns  $\pm 0$ .
- erf(  $\pm \infty$ ) returns  $\pm 1$ .

### Description

Calculate the value of the error function for the input argument x,  $\frac{2}{\sqrt{\pi}} \int_{0}^{x} e^{-t^2} dt$ .

# **,**

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

## device double erfc (double x)

Calculate the complementary error function of the input argument.

#### Returns

- ▶ erfc( $-\infty$ ) returns 2.
- ▶  $\operatorname{erfc}(+\infty)$  returns +0.

### Description

Calculate the complementary error function of the input argument x, 1 - erf(x).



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device\_\_ double erfcinv (double x)

Calculate the inverse complementary error function of the input argument.

#### Returns

- ▶ erfcinv(  $\pm 0$ ) returns  $+\infty$ .
- ▶ erfcinv(2) returns  $-\infty$ .
- erfcinv(x) returns NaN for x outside [0, 2].

### Description

Calculate the inverse complementary error function  $\operatorname{erfc}^{-1}(x)$ , of the input argument x in the interval [0, 2].

# **,**

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double erfcx (double x)

Calculate the scaled complementary error function of the input argument.

#### Returns

- ▶  $\operatorname{erfcx}(-\infty)\operatorname{returns} + \infty$ .
- ▶ erfcx(  $+\infty$ ) returns +0.

### Description

Calculate the scaled complementary error function of the input argument x,  $e^{x^2} \cdot \operatorname{erfc}(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double erfinv (double x)

Calculate the inverse error function of the input argument.

#### Returns

- erfinv(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ erfinv(1) returns  $+\infty$ .
- ▶ erfinv(-1) returns  $-\infty$ .
- erfinv(x) returns NaN for x outside [-1, +1].

### Description

Calculate the inverse error function  $\operatorname{erf}^{-1}(x)$ , of the input argument x in the interval [-1, 1].



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_\_ double exp (double x)

Calculate the base e exponential of the input argument.

#### Returns

- $\triangleright$  exp(  $\pm 0$ ) returns 1.
- ▶  $\exp(-\infty)$  returns +0.
- ▶  $\exp(+\infty)$  returns  $+\infty$ .

### Description

Calculate  $e^x$ , the base e exponential of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double exp10 (double x)

Calculate the base 10 exponential of the input argument.

#### Returns

- $\triangleright$  exp10(  $\pm 0$  ) returns 1.
- ▶  $\exp 10(-\infty)$  returns +0.
- ▶  $\exp 10(+\infty)$  returns  $+\infty$ .

## Description

Calculate  $10^x$ , the base 10 exponential of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double exp2 (double x)

Calculate the base 2 exponential of the input argument.

#### Returns

- $\triangleright$  exp2(  $\pm 0$ ) returns 1.
- ▶  $\exp 2(-\infty)$  returns +0.
- ▶  $\exp 2(+\infty)$  returns  $+\infty$ .

### Description

Calculate  $2^x$ , the base 2 exponential of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double expm1 (double x)

Calculate the base e exponential of the input argument, minus 1.

#### Returns

- $\triangleright$  expm1(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ expm1( $-\infty$ ) returns -1.
- ▶ expm1(  $+\infty$ ) returns  $+\infty$ .

### Description

Calculate  $e^x$  -1, the base e exponential of the input argument x, minus 1.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double fabs (double x)

Calculate the absolute value of the input argument.

#### Returns

Returns the absolute value of the input argument.

- ▶ fabs(  $\pm \infty$ ) returns  $+ \infty$ .
- fabs(  $\pm 0$ ) returns  $\pm 0$ .

### Description

Calculate the absolute value of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double fdim (double x, double y)

Compute the positive difference between x and y.

#### Returns

Returns the positive difference between x and y.

- fdim(x, y) returns x y if x > y.
- fdim(x, y) returns +0 if  $x \le y$ .

### Description

Compute the positive difference between x and y. The positive difference is x - y when x > y and  $\pm 0$  otherwise.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device double floor (double x)

Calculate the largest integer less than or equal to x.

#### Returns

Returns [x] expressed as a floating-point number.

- ▶ floor( $\pm \infty$ ) returns  $\pm \infty$ .
- floor  $(\pm 0)$  returns  $\pm 0$ .

### Description

Calculates the largest integer value which is less than or equal to x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double fma (double x, double y, double z)

Compute  $x \times y + z$  as a single operation.

#### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- ▶ fma(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ▶ fma(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- ▶ fma(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$ .
- ▶ fma(x, y, +∞) returns NaN if  $x \times y$  is an exact -∞.

### Description

Compute the value of  $x \times y + z$  as a single ternary operation. After computing the value to infinite precision, the value is rounded once.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double fmax (double, double)

Determine the maximum numeric value of the arguments.

#### Returns

Returns the maximum numeric values of the arguments x and y.

- If both arguments are NaN, returns NaN.
- If one argument is NaN, returns the numeric argument.

### Description

Determines the maximum numeric value of the arguments x and y. Treats NaN arguments as missing data. If one argument is a NaN and the other is legitimate numeric value, the numeric value is chosen.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double fmin (double x, double y)

Determine the minimum numeric value of the arguments.

#### Returns

Returns the minimum numeric value of the arguments x and y.

- If both arguments are NaN, returns NaN.
- If one argument is NaN, returns the numeric argument.

## Description

Determines the minimum numeric value of the arguments x and y. Treats NaN arguments as missing data. If one argument is a NaN and the other is legitimate numeric value, the numeric value is chosen.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double fmod (double x, double y)

Calculate the double-precision floating-point remainder of x / y.

#### Returns

- $\triangleright$  Returns the floating-point remainder of x / y.
- fmod(  $\pm 0$ , y) returns  $\pm 0$  if y is not zero.
- ▶ fmod(x,  $\pm \infty$ ) returns x if x is finite.
- ▶ fmod(x, y) returns NaN if x is  $\pm \infty$  or y is zero.
- If either argument is NaN, NaN is returned.

### Description

Calculate the double-precision floating-point remainder of x / y. The floating-point remainder of the division operation x / y calculated by this function is exactly the value x - n\*y, where n is x / y with its fractional part truncated. The computed value will have the same sign as x, and its magnitude will be less than the magnitude of y.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double frexp (double x, int \*nptr)

Extract mantissa and exponent of a floating-point value.

#### Returns

Returns the fractional component m.

- frexp( $\pm 0$ , nptr) returns  $\pm 0$  and stores zero in the location pointed to by nptr.
- ▶ frexp(  $\pm \infty$ , nptr) returns  $\pm \infty$  and stores an unspecified value in the location to which nptr points.
- frexp(NaN, y) returns a NaN and stores an unspecified value in the location to which nptr points.

### Description

Decompose the floating-point value x into a component m for the normalized fraction element and another term n for the exponent. The absolute value of m will be greater than or equal to

0.5 and less than 1.0 or it will be equal to 0;  $x = m \cdot 2^n$ . The integer exponent n will be stored in the location to which nptr points.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double hypot (double x, double y)

Calculate the square root of the sum of squares of two arguments.

#### Returns

Returns the length of the hypotenuse  $\sqrt{x^2 + y^2}$ .

- hypot(x,y), hypot(y,x), and hypot(x, -y) are equivalent.
- hypot(x,  $\pm 0$ ) is equivalent to fabs(x).
- hypot( $\pm \infty$ ,y) returns + ∞, even if y is a NaN.

### Description

Calculate the length of the hypotenuse of a right triangle whose two sides have lengths  $\mathbf{x}$  and  $\mathbf{y}$  without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ int ilogb (double x)

Compute the unbiased integer exponent of the argument.

#### Returns

- If successful, returns the unbiased exponent of the argument.
- ▶ ilogb(  $\pm 0$ ) returns INT MIN.
- ▶ ilogb(NaN) returns INT MIN.
- ▶ ilogb(  $\pm \infty$ ) returns INT MAX.
- ▶ Note: above behavior does not take into account FP ILOGBO nor FP ILOGBNAN.

### Description

Calculates the unbiased integer exponent of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ \_\_RETURN\_TYPE isfinite (double a)

Determine whether argument is finite.

#### Returns

- ▶ With Visual Studio 2013 host compiler: \_\_RETURN\_TYPE is 'bool'. Returns true if and only if a is a finite value.
- ▶ With other host compilers: \_\_RETURN\_TYPE is 'int'. Returns a nonzero value if and only if a is a finite value.

### Description

Determine whether the floating-point value a is a finite value (zero, subnormal, or normal and not infinity or NaN).

# \_\_device\_\_ \_\_RETURN\_TYPE isinf (double a)

Determine whether argument is infinite.

#### Returns

- With Visual Studio 2013 host compiler: Returns true if and only if a is an infinite value.
- With other host compilers: Returns a nonzero value if and only if a is an infinite value.

## Description

Determine whether the floating-point value a is an infinite value (positive or negative).

# device RETURN TYPE isnan (double a)

Determine whether argument is a NaN.

#### Returns

- ▶ With Visual Studio 2013 host compiler: \_\_RETURN\_TYPE is 'bool'. Returns true if and only if a is a NaN value.
- With other host compilers: \_\_RETURN\_TYPE is 'int'. Returns a nonzero value if and only if a is a NaN value.

### Description

Determine whether the floating-point value a is a NaN.

# \_\_device\_\_ double j0 (double x)

Calculate the value of the Bessel function of the first kind of order 0 for the input argument.

#### Returns

Returns the value of the Bessel function of the first kind of order 0.

- ▶  $j0(\pm \infty)$  returns +0.
- ▶ j0(NaN) returns NaN.

### Description

Calculate the value of the Bessel function of the first kind of order 0 for the input argument x,  $J_0(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double j1 (double x)

Calculate the value of the Bessel function of the first kind of order 1 for the input argument.

#### Returns

Returns the value of the Bessel function of the first kind of order 1.

- $\blacktriangleright$  j1(  $\pm 0$ ) returns  $\pm 0$ .
- ▶  $j1(\pm \infty)$  returns  $\pm 0$ .

▶ j1(NaN) returns NaN.

### Description

Calculate the value of the Bessel function of the first kind of order 1 for the input argument x,  $J_1(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double jn (int n, double x)

Calculate the value of the Bessel function of the first kind of order n for the input argument.

#### Returns

Returns the value of the Bessel function of the first kind of order n.

- ▶ jn(n, NaN) returns NaN.
- in(n, x) returns NaN for n < 0.
- in(n, +∞) returns +0.

### Description

Calculate the value of the Bessel function of the first kind of order n for the input argument x,  $J_n(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_\_device\_\_\_ double ldexp (double x, int exp)

Calculate the value of  $x \cdot 2^{exp}$ .

#### Returns

ldexp(x, exp) is equivalent to scalbn(x, exp).

### Description

Calculate the value of  $x \cdot 2^{exp}$  of the input arguments x and exp.

# •

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double lgamma (double x)

Calculate the natural logarithm of the absolute value of the gamma function of the input argument.

#### Returns

- ▶ lgamma(1) returns +0.
- ▶ lgamma(2) returns +0.
- ▶ lgamma(x) returns  $+\infty$  if  $x \le 0$  and x is an integer.
- lgamma(-∞) returns +∞.
- ▶  $lgamma(+\infty) returns + \infty$ .

### Description

Calculate the natural logarithm of the absolute value of the gamma function of the input argument x, namely the value of  $\log_e \left| \int_0^\infty e^{-t} t^{x-1} dt \right|$ 



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ long long int llrint (double x)

Round input to nearest integer value.

#### Returns

Returns rounded integer value.

## Description

Round x to the nearest integer value, with halfway cases rounded to the nearest even integer value. If the result is outside the range of the return type, the behavior is undefined.

# \_device\_\_ long long int llround (double x)

Round to nearest integer value.

#### Returns

Returns rounded integer value.

### Description

Round x to the nearest integer value, with halfway cases rounded away from zero. If the result is outside the range of the return type, the behavior is undefined.



#### Note:

This function may be slower than alternate rounding methods. See <a href="lllrint()">llrint()</a>.

# \_device\_\_ double log (double x)

Calculate the base e logarithm of the input argument.

#### Returns

- ▶  $\log(\pm 0)$  returns  $-\infty$ .
- $\triangleright$  log(1) returns +0.
- log(x) returns NaN for x < 0.
- ▶  $log(+\infty)$  returns  $+\infty$ .

## Description

Calculate the base e logarithm of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double log10 (double x)

Calculate the base 10 logarithm of the input argument.

#### Returns

log10(  $\pm 0$ ) returns  $-\infty$ .

- $\blacktriangleright$  log10(1) returns +0.
- ▶ log10(x) returns NaN for x < 0.
- ▶  $log10(+\infty)$  returns  $+\infty$ .

### Description

Calculate the base 10 logarithm of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double log1p (double x)

Calculate the value of  $\log_{o}(1+x)$ .

#### Returns

- $\triangleright$  log1p(  $\pm 0$  ) returns  $\pm 0$ .
- log1p(-1) returns  $-\infty$ .
- log1p(x) returns NaN for x < -1.
- log1p( + ∞) returns + ∞.

### Description

Calculate the value of  $\log_a(1+x)$  of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double log2 (double x)

Calculate the base 2 logarithm of the input argument.

#### Returns

- log2(  $\pm 0$ ) returns  $-\infty$ .
- $\triangleright$  log2(1) returns +0.

- ▶ log2(x) returns NaN for x < 0.
- ▶  $\log 2(+\infty)$  returns  $+\infty$ .

### Description

Calculate the base 2 logarithm of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double logb (double x)

Calculate the floating-point representation of the exponent of the input argument.

#### Returns

- ▶  $logb(\pm 0)$  returns  $-\infty$ .
- ▶  $logb(\pm \infty)$  returns  $+ \infty$ .

### Description

Calculate the floating-point representation of the exponent of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ long int lrint (double x)

Round input to nearest integer value.

#### Returns

Returns rounded integer value.

### Description

Round x to the nearest integer value, with halfway cases rounded to the nearest even integer value. If the result is outside the range of the return type, the behavior is undefined.

# \_device\_\_ long int lround (double x)

Round to nearest integer value.

#### Returns

Returns rounded integer value.

### Description

Round x to the nearest integer value, with halfway cases rounded away from zero. If the result is outside the range of the return type, the behavior is undefined.



#### Note:

This function may be slower than alternate rounding methods. See <a href="lint()">lrint()</a>.

# device double max (const double a, const float b)

Calculate the maximum value of the input double and float arguments.

### Description

Convert float argument b to double, followed by fmax().

Note, this is different from std:: specification

## device double max (const float a, const double b)

Calculate the maximum value of the input float and double arguments.

### Description

Convert float argument a to double, followed by fmax().

Note, this is different from std:: specification

# \_\_device\_\_ double max (const double a, const double b)

Calculate the maximum value of the input float arguments.

## Description

Calculate the maximum value of the arguments a and b. Behavior is equivalent to fmax() function.

Note, this is different from std:: specification

# \_\_device\_\_ double min (const double a, const float b)

Calculate the minimum value of the input double and float arguments.

### Description

Convert float argument b to double, followed by fmin().

Note, this is different from std:: specification

# \_\_device\_\_ double min (const float a, const double b)

Calculate the minimum value of the input float and double arguments.

### Description

Convert float argument a to double, followed by fmin().

Note, this is different from std:: specification

# \_\_device\_\_ double min (const double a, const double b)

Calculate the minimum value of the input float arguments.

### Description

Calculate the minimum value of the arguments a and b. Behavior is equivalent to <u>fmin()</u> function.

Note, this is different from std:: specification

# \_\_device\_\_ double modf (double x, double \*iptr)

Break down the input argument into fractional and integral parts.

#### Returns

- $\blacktriangleright$  modf( $\pm x$ , iptr) returns a result with the same sign as x.
- ▶ modf(  $\pm \infty$ , iptr) returns  $\pm 0$  and stores  $\pm \infty$  in the object pointed to by iptr.
- modf(NaN, iptr) stores a NaN in the object pointed to by iptr and returns a NaN.

### Description

Break down the argument x into fractional and integral parts. The integral part is stored in the argument iptr. Fractional and integral parts are given the same sign as the argument x.

# •

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double nan (const char \*tagp)

Returns "Not a Number" value.

#### Returns

nan(tagp) returns NaN.

## Description

Return a representation of a quiet NaN. Argument tagp selects one of the possible representations.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double nearbyint (double x)

Round the input argument to the nearest integer.

#### Returns

- nearbyint(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ nearbyint(  $\pm \infty$ ) returns  $\pm \infty$ .

# Description

Round argument x to an integer value in double precision floating-point format. Uses round to nearest rounding, with ties rounding to even.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_\_ double nextafter (double x, double y)

Return next representable double-precision floating-point value after argument  $\mathbf{x}$  in the direction of  $\mathbf{y}$ .

#### Returns

- nextafter(x, y) = y if x equals y.
- nextafter(x, y) = NaN if either x or y are NaN.

# Description

Calculate the next representable double-precision floating-point value following x in the direction of y. For example, if y is greater than x,  $\underline{nextafter()}$  returns the smallest representable number greater than x



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double norm (int dim, const double \*p)

Calculate the square root of the sum of squares of any number of coordinates.

### Returns

Returns the length of the dim-D vector  $\sqrt{p_0^2 + p_1^2 + ... + p_{\text{dim-1}}^2}$ .

▶ In the presence of an exactly infinite coordinate  $+\infty$  is returned, even if there are NaNs.

## Description

Calculate the length of a vector p, dimension of which is passed as an argument without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double norm3d (double a, double b, double c)

Calculate the square root of the sum of squares of three coordinates of the argument.

#### Returns

Returns the length of 3D vector  $\sqrt{a^2 + b^2 + c^2}$ .

▶ In the presence of an exactly infinite coordinate  $+\infty$  is returned, even if there are NaNs.

## Description

Calculate the length of three dimensional vector in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double norm4d (double a, double b, double c, double d)

Calculate the square root of the sum of squares of four coordinates of the argument.

#### Returns

Returns the length of 4D vector  $\sqrt{a^2 + b^2 + c^2 + d^2}$ .

▶ In the presence of an exactly infinite coordinate  $+\infty$  is returned, even if there are NaNs.

## Description

Calculate the length of four dimensional vector in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double normcdf (double x)

Calculate the standard normal cumulative distribution function.

#### Returns

- ▶ normcdf(  $+\infty$ ) returns 1.
- ▶ normcdf( $-\infty$ ) returns +0.

# Description

Calculate the cumulative distribution function of the standard normal distribution for input argument x,  $\Phi(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_\_device\_\_\_ double normcdfinv (double x)

Calculate the inverse of the standard normal cumulative distribution function.

#### Returns

- ▶ normcdfinv(  $\pm 0$ ) returns  $-\infty$ .
- ▶ normcdfinv(1) returns  $+\infty$ .
- normcdfinv(x) returns NaN if x is not in the interval [0,1].

# Description

Calculate the inverse of the standard normal cumulative distribution function for input argument x,  $\Phi^{-1}(x)$ . The function is defined for input values in the interval (0, 1).



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_\_ double pow (double x, double y)

Calculate the value of first argument to the power of second argument.

#### Returns

- ▶ pow(  $\pm 0$ , y) returns  $\pm \infty$  for y an odd integer less than 0.
- ▶ pow(  $\pm 0$ , y) returns  $+ \infty$  for y less than 0 and not an odd integer.
- pow(  $\pm 0$ , y) returns  $\pm 0$  for y an odd integer greater than 0.
- ightharpoonup pow(  $\pm 0$ , y) returns +0 for y > 0 and not an odd integer.
- ▶ pow(-1,  $\pm \infty$ ) returns 1.
- pow(+1, y) returns 1 for any y, even a NaN.
- ightharpoonup pow(x,  $\pm 0$ ) returns 1 for any x, even a NaN.
- $\triangleright$  pow(x, y) returns a NaN for finite x < 0 and finite non-integer y.
- ▶ pow(x,  $-\infty$ ) returns  $+\infty$  for |x| < 1.
- ▶ pow(x,  $-\infty$ ) returns +0 for |x| > 1.
- ▶ pow(x, +∞) returns +0 for |x| < 1.
- ▶ pow(x, +∞) returns + ∞ for |x| > 1.
- ▶ pow( $-\infty$ , y) returns -0 for y an odd integer less than 0.
- ▶ pow( $-\infty$ , y) returns +0 for y < 0 and not an odd integer.
- ▶ pow( $-\infty$ , y) returns  $-\infty$  for y an odd integer greater than 0.
- ▶ pow( $-\infty$ , y) returns  $+\infty$  for y > 0 and not an odd integer.
- ▶ pow(  $+\infty$ , y) returns +0 for y < 0.
- ▶ pow(  $+\infty$ , y) returns  $+\infty$  for y > 0.

## Description

Calculate the value of x to the power of y.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double rcbrt (double x)

Calculate reciprocal cube root function.

#### Returns

- rcbrt( $\pm 0$ ) returns  $\pm \infty$ .
- rcbrt( $\pm \infty$ ) returns  $\pm 0$ .

# Description

Calculate reciprocal cube root function of x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double remainder (double x, double y)

Compute double-precision floating-point remainder.

#### Returns

- remainder(x,  $\pm 0$ ) returns NaN.
- remainder( $\pm \infty$ , y) returns NaN.
- remainder(x,  $\pm \infty$ ) returns x for finite x.

## Description

Compute double-precision floating-point remainder  $\mathbf{r}$  of dividing  $\mathbf{x}$  by  $\mathbf{y}$  for nonzero  $\mathbf{y}$ . Thus  $r = \mathbf{x} - n\mathbf{y}$ . The value  $\mathbf{n}$  is the integer value nearest  $\frac{\mathbf{X}}{\mathbf{Y}}$ . In the case when  $|n - \frac{\mathbf{X}}{\mathbf{Y}}| = \frac{1}{2}$ , the even  $\mathbf{n}$  value is chosen.



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double remquo (double x, double y, int \*quo)

Compute double-precision floating-point remainder and part of quotient.

#### Returns

Returns the remainder.

- remquo(x,  $\pm 0$ , quo) returns NaN and stores an unspecified value in the location to which quo points.
- remquo(  $\pm \infty$ , y, quo) returns NaN and stores an unspecified value in the location to which quo points.
- remquo(x, y, quo) returns NaN and stores an unspecified value in the location to which quo points if either of x or y is NaN.
- remquo(x,  $\pm \infty$ , quo) returns x and stores zero in the location to which quo points for finite x.

## Description

Compute a double-precision floating-point remainder in the same way as the <u>remainder()</u> function. Argument quo returns part of quotient upon division of x by y. Value quo has the same sign as  $\frac{X}{Y}$  and may not be the exact quotient but agrees with the exact quotient in the low order 3 bits.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double rhypot (double x, double y)

Calculate one over the square root of the sum of squares of two arguments.

#### Returns

Returns one over the length of the hypotenuse  $\frac{1}{\sqrt{x^2+y^2}}$ .

- rhypot(x,y), rhypot(y,x), and rhypot(x, -y) are equivalent.
- rhypot(  $\pm \infty$ ,y) returns +0, even if y is a NaN.

Calculate one over the length of the hypotenuse of a right triangle whose two sides have lengths x and y without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double rint (double x)

Round to nearest integer value in floating-point.

#### Returns

Returns rounded integer value.

- rint(  $\pm 0$ ) returns  $\pm 0$ .
- ▶ rint(  $\pm \infty$ ) returns  $\pm \infty$ .

## Description

Round  $\mathbf{x}$  to the nearest integer value in floating-point format, with halfway cases rounded to the nearest even integer value.

# \_\_device\_\_ double rnorm (int dim, const double \*p)

Calculate the reciprocal of square root of the sum of squares of any number of coordinates.

#### Returns

Returns one over the length of the vector  $\frac{1}{\sqrt{p_0^2 + p_1^2 + ... + p_{\text{dim-1}}^2}}$ .

In the presence of an exactly infinite coordinate +0 is returned, even if there are NaNs.

# Description

Calculates one over the length of vector p, dimension of which is passed as an argument, in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double rnorm3d (double a, double b, double c)

Calculate one over the square root of the sum of squares of three coordinates.

#### Returns

Returns one over the length of the 3D vector  $\frac{1}{\sqrt{a^2+b^2+c^2}}$ .

ightharpoonup In the presence of an exactly infinite coordinate +0 is returned, even if there are NaNs.

## Description

Calculate one over the length of three dimensional vector in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double rnorm4d (double a, double b, double c, double d)

Calculate one over the square root of the sum of squares of four coordinates.

#### Returns

Returns one over the length of the 3D vector  $\frac{1}{\sqrt{2+b^2+c^2+d^2}}$ .

In the presence of an exactly infinite coordinate +0 is returned, even if there are NaNs.

## Description

Calculate one over the length of four dimensional vector in Euclidean space without undue overflow or underflow.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double round (double x)

Round to nearest integer value in floating-point.

#### Returns

Returns rounded integer value.

- round( $\pm 0$ ) returns  $\pm 0$ .
- ▶ round(  $\pm \infty$ ) returns  $\pm \infty$ .

## Description

Round x to the nearest integer value in floating-point format, with halfway cases rounded away from zero.



#### Note:

This function may be slower than alternate rounding methods. See <u>rint()</u>.

# \_device\_\_ double rsqrt (double x)

Calculate the reciprocal of the square root of the input argument.

#### Returns

Returns  $1/\sqrt{x}$ .

- ► rsgrt(  $+\infty$ ) returns +0.
- rsqrt(  $\pm 0$ ) returns  $\pm \infty$ .
- rsqrt(x) returns NaN if x is less than 0.

## Description

Calculate the reciprocal of the nonnegative square root of x,  $1/\sqrt{x}$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double scalbln (double x, long int n)

Scale floating-point input by integer power of two.

#### Returns

Returns  $x * 2^n$ .

- $\triangleright$  scalbln(  $\pm 0$ , n) returns  $\pm 0$ .
- $\triangleright$  scalbln(x, 0) returns x.
- ▶ scalbln( $\pm \infty$ , n) returns  $\pm \infty$ .

# Description

Scale x by  $2^n$  by efficient manipulation of the floating-point exponent.

# \_device\_\_ double scalbn (double x, int n)

Scale floating-point input by integer power of two.

#### Returns

Returns  $x * 2^n$ .

- $\triangleright$  scalbn(  $\pm 0$ , n) returns  $\pm 0$ .
- $\triangleright$  scalbn(x, 0) returns x.
- ▶ scalbn(  $\pm \infty$ , n) returns  $\pm \infty$ .

## Description

Scale x by  $2^n$  by efficient manipulation of the floating-point exponent.

# \_device\_\_ \_RETURN\_TYPE signbit (double a)

Return the sign bit of the input.

#### Returns

Reports the sign bit of all values including infinities, zeros, and NaNs.

- ▶ With Visual Studio 2013 host compiler: \_\_RETURN\_TYPE is 'bool'. Returns true if and only if a is negative.
- With other host compilers: \_\_RETURN\_TYPE is 'int'. Returns a nonzero value if and only if a is negative.

Determine whether the floating-point value a is negative.

# \_\_device\_\_ double sin (double x)

Calculate the sine of the input argument.

#### Returns

- $\triangleright$  sin(  $\pm 0$ ) returns  $\pm 0$ .
- ▶  $sin(\pm \infty)$  returns NaN.

## Description

Calculate the sine of the input argument x (measured in radians).



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ void sincos (double x, double \*sptr, double \*cptr)

Calculate the sine and cosine of the first input argument.

#### Returns

none

## Description

Calculate the sine and cosine of the first input argument x (measured in radians). The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.

#### See also:

sin() and cos().



#### Note:



For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ void sincospi (double x, double \*sptr, double \*cptr)

Calculate the sine and cosine of the first input argument  $\times \pi$ .

#### Returns

none

## Description

Calculate the sine and cosine of the first input argument, x (measured in radians), x  $\pi$ . The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.

#### See also:

sinpi() and cospi().



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double sinh (double x)

Calculate the hyperbolic sine of the input argument.

### Returns

- $\triangleright$  sinh(  $\pm 0$ ) returns  $\pm 0$ .
- ▶  $\sinh(\pm \infty)$  returns  $\pm \infty$ .

# Description

Calculate the hyperbolic sine of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double sinpi (double x)

Calculate the sine of the input argument  $imes \pi$ .

#### Returns

- ▶  $sinpi(\pm 0)$  returns  $\pm 0$ .
- ▶ sinpi(  $\pm \infty$ ) returns NaN.

# Description

Calculate the sine of  $x \times \pi$  (measured in radians), where x is the input argument.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double sqrt (double x)

Calculate the square root of the input argument.

#### Returns

Returns  $\sqrt{x}$ .

- ightharpoonup sqrt(  $\pm 0$  ) returns  $\pm 0$ .
- ▶  $sqrt(+\infty)$  returns  $+\infty$ .
- ightharpoonup sqrt(x) returns NaN if x is less than 0.

# Description

Calculate the nonnegative square root of x,  $\sqrt{x}$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double tan (double x)

Calculate the tangent of the input argument.

#### Returns

- $\blacktriangleright$  tan(  $\pm 0$ ) returns  $\pm 0$ .
- ▶  $tan(\pm \infty)$  returns NaN.

## Description

Calculate the tangent of the input argument x (measured in radians).



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# device double tanh (double x)

Calculate the hyperbolic tangent of the input argument.

#### Returns

- $\blacktriangleright$  tanh( +0) returns +0.
- ▶  $tanh(\pm \infty)$  returns  $\pm 1$ .

## Description

Calculate the hyperbolic tangent of the input argument x.



## Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double tgamma (double x)

Calculate the gamma function of the input argument.

#### Returns

- ▶ tgamma(  $\pm 0$ ) returns  $\pm \infty$ .
- ▶ tgamma(2) returns +1.

- tgamma(x) returns NaN if x < 0 and x is an integer.
- tgamma( ∞) returns NaN.
- ▶ tgamma(  $+ \infty$ ) returns  $+ \infty$ .

Calculate the gamma function of the input argument x, namely the value of  $\int_{0}^{\infty} e^{-t}t^{x-1}dt$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double trunc (double x)

Truncate input argument to the integral part.

### Returns

Returns truncated integer value.

- trunc(  $\pm 0$ ) returns  $\pm 0$ .
- ► trunc(  $\pm \infty$ ) returns  $\pm \infty$ .

## Description

Round x to the nearest integer value that does not exceed x in magnitude.

# device double y0 (double x)

Calculate the value of the Bessel function of the second kind of order 0 for the input argument.

#### Returns

Returns the value of the Bessel function of the second kind of order 0.

- ▶ y0(  $\pm 0$ ) returns  $-\infty$ .
- $\triangleright$  y0(x) returns NaN for x < 0.
- ▶  $y0(+\infty)$  returns +0.
- ▶ y0(NaN) returns NaN.

Calculate the value of the Bessel function of the second kind of order 0 for the input argument x,  $Y_0(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double y1 (double x)

Calculate the value of the Bessel function of the second kind of order 1 for the input argument.

### Returns

Returns the value of the Bessel function of the second kind of order 1.

- ▶ y1(  $\pm 0$ ) returns  $-\infty$ .
- $\triangleright$  y1(x) returns NaN for x < 0.
- ▶  $y1(+\infty)$  returns +0.
- ▶ y1(NaN) returns NaN.

## Description

Calculate the value of the Bessel function of the second kind of order 1 for the input argument x,  $Y_1(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_device\_\_ double yn (int n, double x)

Calculate the value of the Bessel function of the second kind of order n for the input argument.

#### Returns

Returns the value of the Bessel function of the second kind of order n.

- $\triangleright$  yn(n, x) returns NaN for n < 0.
- yn(n,  $\pm 0$ ) returns  $-\infty$ .

- ightharpoonup yn(n, x) returns NaN for x < 0.
- ▶  $yn(n, +\infty)$  returns +0.
- yn(n, NaN) returns NaN.

Calculate the value of the Bessel function of the second kind of order n for the input argument x,  $Y_n(x)$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# 1.7. Integer Mathematical Functions

This section describes integer mathematical functions. To use these functions you do not need to include any additional header files in your program.

# \_\_device\_\_ int abs (int a)

Calculate the absolute value of the input int argument.

## Description

Calculate the absolute value of the input argument a.

# \_\_device\_\_ long int labs (long int a)

Calculate the absolute value of the input long int argument.

## Description

Calculate the absolute value of the input argument a.

# \_\_device\_\_ long long int llabs (long long int a)

Calculate the absolute value of the input long long int argument.

## Description

Calculate the absolute value of the input argument a.

# \_\_device\_\_ long long int llmax (const long long int a, const long long int b)

Calculate the maximum value of the input long long int arguments.

## Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ long long int llmin (const long long int a, const long long int b)

Calculate the minimum value of the input long long int arguments.

## Description

Calculate the minimum value of the arguments a and b.

# \_\_device\_\_ unsigned long long int max (const unsigned long long int a, const long long int b)

Calculate the maximum value of the input unsigned long long int and long long int arguments.

# Description

Calculate the maximum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned long long int max (const long long int a, const unsigned long long int b)

Calculate the maximum value of the input long long int and unsigned long long int arguments.

## Description

Calculate the maximum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned long long int max (const unsigned long long int a, const unsigned long long int b)

Calculate the maximum value of the input unsigned long long int arguments.

## Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ long long int max (const long long int a, const long long int b)

Calculate the maximum value of the input long long int arguments.

## Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ unsigned long int max (const unsigned long int a, const long int b)

Calculate the maximum value of the input unsigned long int and long int arguments.

# Description

Calculate the maximum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned long int max (const long int a, const unsigned long int b)

Calculate the maximum value of the input long int and unsigned long int arguments.

# Description

Calculate the maximum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned long int max (const unsigned long int a, const unsigned long int b)

Calculate the maximum value of the input unsigned long int arguments.

# Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ long int max (const long int a, const long int b)

Calculate the maximum value of the input long int arguments.

## Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ unsigned int max (const unsigned int a, const int b)

Calculate the maximum value of the input unsigned int and int arguments.

## Description

Calculate the maximum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned int max (const int a, const unsigned int b)

Calculate the maximum value of the input int and unsigned int arguments.

## Description

Calculate the maximum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned int max (const unsigned int a, const unsigned int b)

Calculate the maximum value of the input unsigned int arguments.

# Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ int max (const int a, const int b)

Calculate the maximum value of the input int arguments.

# Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ unsigned long long int min (const unsigned long long int a, const long long int b)

Calculate the minimum value of the input unsigned long long int and long long int arguments.

## Description

Calculate the minimum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned long long int min (const long long int a, const unsigned long long int b)

Calculate the minimum value of the input long long int and unsigned long long int arguments.

## Description

Calculate the minimum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned long long int min (const unsigned long long int a, const unsigned long long int b)

Calculate the minimum value of the input unsigned long long int arguments.

# Description

Calculate the minimum value of the arguments a and b.

# \_\_device\_\_ long long int min (const long long int a, const long long int b)

Calculate the minimum value of the input long long int arguments.

## Description

Calculate the minimum value of the arguments a and b.

# \_\_device\_\_ unsigned long int min (const unsigned long int a, const long int b)

Calculate the minimum value of the input unsigned long int and long int arguments.

## Description

Calculate the minimum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned long int min (const long int a, const unsigned long int b)

Calculate the minimum value of the input long int and unsigned long int arguments.

## Description

Calculate the minimum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned long int min (const unsigned long int a, const unsigned long int b)

Calculate the minimum value of the input unsigned long int arguments.

# Description

Calculate the minimum value of the arguments a and b.

# \_\_device\_\_ long int min (const long int a, const long int b)

Calculate the minimum value of the input long int arguments.

# Description

Calculate the minimum value of the arguments a and b.

# \_\_device\_\_ unsigned int min (const unsigned int a, const int b)

Calculate the minimum value of the input unsigned int and int arguments.

# Description

Calculate the minimum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned int min (const int a, const unsigned int b)

Calculate the minimum value of the input int and unsigned int arguments.

## Description

Calculate the minimum value of the arguments a and b, perform integer promotion first.

# \_\_device\_\_ unsigned int min (const unsigned int a, const unsigned int b)

Calculate the minimum value of the input unsigned int arguments.

## Description

Calculate the minimum value of the arguments a and b.

# \_\_\_device\_\_\_ int min (const int a, const int b)

Calculate the minimum value of the input int arguments.

## Description

Calculate the minimum value of the arguments a and b.

# \_\_device\_\_ unsigned long long int ullmax (const unsigned long long int a, const unsigned long long int b)

Calculate the maximum value of the input unsigned long long int arguments.

# Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ unsigned long long int ullmin (const unsigned long long int a, const unsigned long long int b)

Calculate the minimum value of the input unsigned long long int arguments.

# Description

Calculate the minimum value of the arguments a and b.

# \_\_device\_\_ unsigned int umax (const unsigned int a, const unsigned int b)

Calculate the maximum value of the input unsigned int arguments.

## Description

Calculate the maximum value of the arguments a and b.

# \_\_device\_\_ unsigned int umin (const unsigned int a, const unsigned int b)

Calculate the minimum value of the input unsigned int arguments.

## Description

Calculate the minimum value of the arguments a and b.

# 1.8. Single Precision Intrinsics

This section describes single precision intrinsic functions that are only supported in device code. To use these functions you do not need to include any additional header files in your program.

# \_\_device\_\_ float \_\_cosf (float x)

Calculate the fast approximate cosine of the input argument.

#### Returns

Returns the approximate cosine of x.

## Description

Calculate the fast approximate cosine of the input argument x, measured in radians.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.

# \_device\_\_ float \_\_exp10f (float x)

Calculate the fast approximate base 10 exponential of the input argument.

#### Returns

Returns an approximation to  $10^x$ .

# Description

Calculate the fast approximate base 10 exponential of the input argument x,  $10^x$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.

# \_\_device\_\_ float \_\_expf (float x)

Calculate the fast approximate base e exponential of the input argument.

## Returns

Returns an approximation to  $e^x$ .

## Description

Calculate the fast approximate base e exponential of the input argument x,  $e^x$ .



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.

# \_device\_\_ float \_\_fadd\_rd (float x, float y)

Add two floating-point values in round-down mode.

#### Returns

Returns x + y.

## Description

Compute the sum of x and y in round-down (to negative infinity) mode.

# P

#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_device\_\_ float \_\_fadd\_rn (float x, float y)

Add two floating-point values in round-to-nearest-even mode.

### Returns

Returns x + y.

## Description

Compute the sum of x and y in round-to-nearest-even rounding mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_device\_\_ float \_\_fadd\_ru (float x, float y)

Add two floating-point values in round-up mode.

## Returns

Returns x + y.

## Description

Compute the sum of x and y in round-up (to positive infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_device\_\_ float \_\_fadd\_rz (float x, float y)

Add two floating-point values in round-towards-zero mode.

#### Returns

Returns x + y.

## Description

Compute the sum of x and y in round-towards-zero mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_\_device\_\_\_ float \_\_\_fdiv\_rd (float x, float y)

Divide two floating-point values in round-down mode.

#### Returns

Returns x / y.

## Description

Divide two floating-point values x by y in round-down (to negative infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float \_\_fdiv\_rn (float x, float y)

Divide two floating-point values in round-to-nearest-even mode.

#### Returns

Returns x / y.

## Description

Divide two floating-point values x by y in round-to-nearest-even mode.

# ,

#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float \_\_fdiv\_ru (float x, float y)

Divide two floating-point values in round-up mode.

### Returns

Returns x / y.

## Description

Divide two floating-point values x by y in round-up (to positive infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float \_\_\_fdiv\_rz (float x, float y)

Divide two floating-point values in round-towards-zero mode.

#### Returns

Returns x / y.

## Description

Divide two floating-point values x by y in round-towards-zero mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# device float fdividef (float x, float y)

Calculate the fast approximate division of the input arguments.

#### Returns

Returns x / y.

- fdividef( $\infty$ , y) returns NaN for  $2^{126} < |y| < 2^{128}$ .
- fdividef(x, y) returns 0 for  $2^{126} < |y| < 2^{128}$  and finite x.

Calculate the fast approximate division of x by y.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.

# \_\_device\_\_ float \_\_fmaf\_ieee\_rd (float x, float y, float z)

Compute fused multiply-add operation in round-down mode, ignore -ftz=true compiler flag.

## Description

Behavior is the same as  $\underline{\text{fmaf rd}}(x, y, z)$ , the difference is in handling denormalized inputs and outputs: -ftz compiler flag has no effect.

Compute fused multiply-add operation in round-to-nearest-even mode, ignore -ftz=true compiler flag.

# Description

Behavior is the same as  $\underline{\text{fmaf rn}}(x, y, z)$ , the difference is in handling denormalized inputs and outputs: -ftz compiler flag has no effect.

Compute fused multiply-add operation in round-up mode, ignore -ftz=true compiler flag.

## Description

Behavior is the same as  $\underline{\text{fmaf ru}}(x, y, z)$ , the difference is in handling denormalized inputs and outputs: -ftz compiler flag has no effect.

# \_\_device\_\_ float \_\_fmaf\_ieee\_rz (float x, float y, float z)

Compute fused multiply-add operation in round-towards-zero mode, ignore -ftz=true compiler flag.

## Description

Behavior is the same as  $\underline{\text{fmaf rz}}(x, y, z)$ , the difference is in handling denormalized inputs and outputs: -ftz compiler flag has no effect.

# \_\_device\_\_ float \_\_fmaf\_rd (float x, float y, float z)

Compute  $x \times y + z$  as a single operation, in round-down mode.

### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ▶ fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- ▶ fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$ .
- ▶ fmaf(x, y, +∞) returns NaN if  $x \times y$  is an exact -∞.

# Description

Computes the value of  $x \times y + z$  as a single ternary operation, rounding the result once in round-down (to negative infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float \_\_fmaf\_rn (float x, float y, float z)

Compute  $x \times y + z$  as a single operation, in round-to-nearest-even mode.

#### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- ► fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ▶ fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.

- ▶ fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$ .
- ▶ fmaf(x, y,  $+\infty$ ) returns NaN if  $x \times y$  is an exact  $-\infty$ .

Computes the value of  $x \times y + z$  as a single ternary operation, rounding the result once in round-to-nearest-even mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_\_ float \_\_\_fmaf\_ru (float x, float y, float z)

Compute  $x \times y + z$  as a single operation, in round-up mode.

### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ▶ fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- ▶ fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$ .
- ▶ fmaf(x, y, +∞) returns NaN if  $x \times y$  is an exact -∞.

## Description

Computes the value of  $x \times y + z$  as a single ternary operation, rounding the result once in round-up (to positive infinity) mode.



## Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_device\_\_ float \_\_fmaf\_rz (float x, float y, float z)

Compute  $x \times y + z$  as a single operation, in round-towards-zero mode.

#### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

▶ fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.

- ▶ fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- ▶ fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$ .
- ▶ fmaf(x, y, +∞) returns NaN if  $x \times y$  is an exact -∞.

Computes the value of  $x \times y + z$  as a single ternary operation, rounding the result once in round-towards-zero mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float \_\_fmul\_rd (float x, float y)

Multiply two floating-point values in round-down mode.

#### Returns

Returns x \* y.

## Description

Compute the product of x and y in round-down (to negative infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_device\_\_ float \_\_fmul\_rn (float x, float y)

Multiply two floating-point values in round-to-nearest-even mode.

#### Returns

Returns x \* y.

## Description

Compute the product of x and y in round-to-nearest-even mode.

# •

#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_device\_\_ float \_\_fmul\_ru (float x, float y)

Multiply two floating-point values in round-up mode.

### Returns

Returns x \* y.

## Description

Compute the product of x and y in round-up (to positive infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# device \_ float \_\_fmul\_rz (float x, float y)

Multiply two floating-point values in round-towards-zero mode.

## Returns

Returns x \* y.

## Description

Compute the product of x and y in round-towards-zero mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

\_\_device\_\_ float \_\_frcp\_rd (float x)

Compute  $\frac{1}{X}$  in round-down mode.

### Returns

Returns  $\frac{1}{x}$ .

## Description

Compute the reciprocal of x in round-down (to negative infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

\_\_device\_\_ float \_\_frcp\_rn (float x)

Compute  $\frac{1}{X}$  in round-to-nearest-even mode.

### Returns

Returns  $\frac{1}{X}$ .

# Description

Compute the reciprocal of x in round-to-nearest-even mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

\_device\_\_ float \_\_\_frcp\_ru (float x)

Compute  $\frac{1}{X}$  in round-up mode.

### Returns

Returns  $\frac{1}{x}$ .

Compute the reciprocal of x in round-up (to positive infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float \_\_frcp\_rz (float x)

Compute  $\frac{1}{X}$  in round-towards-zero mode.

### Returns

Returns  $\frac{1}{X}$ .

## Description

Compute the reciprocal of x in round-towards-zero mode.



## Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float \_\_frsqrt\_rn (float x)

Compute  $1/\sqrt{x}$  in round-to-nearest-even mode.

#### Returns

Returns  $1/\sqrt{x}$ .

# Description

Compute the reciprocal square root of  $\mathbf{x}$  in round-to-nearest-even mode.



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

\_\_device\_\_ float \_\_fsqrt\_rd (float x)

Compute  $\sqrt{x}$  in round-down mode.

### Returns

Returns  $\sqrt{x}$ .

# Description

Compute the square root of x in round-down (to negative infinity) mode.



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

\_\_\_device\_\_\_ float \_\_\_fsqrt\_rn (float x)

Compute  $\sqrt{x}$  in round-to-nearest-even mode.

### Returns

Returns  $\sqrt{x}$ .

# Description

Compute the square root of x in round-to-nearest-even mode.



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

\_\_device\_\_ float \_\_fsqrt\_ru (float x)

Compute  $\sqrt{x}$  in round-up mode.

### Returns

Returns  $\sqrt{x}$ .

Compute the square root of x in round-up (to positive infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_\_ float \_\_\_fsqrt\_rz (float x)

Compute  $\sqrt{x}$  in round-towards-zero mode.

### Returns

Returns  $\sqrt{x}$ .

# Description

Compute the square root of x in round-towards-zero mode.



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.

# \_\_device\_\_ float \_\_fsub\_rd (float x, float y)

Subtract two floating-point values in round-down mode.

### Returns

Returns x - y.

# Description

Compute the difference of x and y in round-down (to negative infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_device\_\_ float \_\_fsub\_rn (float x, float y)

Subtract two floating-point values in round-to-nearest-even mode.

#### Returns

Returns x - y.

### Description

Compute the difference of x and y in round-to-nearest-even rounding mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_\_device\_\_\_float \_\_\_fsub\_ru (float x, float y)

Subtract two floating-point values in round-up mode.

### Returns

Returns x - y.

# Description

Compute the difference of x and y in round-up (to positive infinity) mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- ▶ This operation will never be merged into a single multiply-add instruction.

# \_device\_\_\_ float \_\_\_fsub\_rz (float x, float y)

Subtract two floating-point values in round-towards-zero mode.

### Returns

Returns x - y.

Compute the difference of x and y in round-towards-zero mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Single-Precision Floating-Point Functions section.
- ▶ This operation will never be merged into a single multiply-add instruction.

# \_device\_\_ float \_\_log10f (float x)

Calculate the fast approximate base 10 logarithm of the input argument.

#### Returns

Returns an approximation to  $\log_{10}(x)$ .

### Description

Calculate the fast approximate base 10 logarithm of the input argument x.



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.

# \_\_device\_\_ float \_\_log2f (float x)

Calculate the fast approximate base 2 logarithm of the input argument.

### Returns

Returns an approximation to  $\log_2(x)$ .

# Description

Calculate the fast approximate base 2 logarithm of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.

# device float logf (float x)

Calculate the fast approximate base e logarithm of the input argument.

### Returns

Returns an approximation to  $\log_{\rho}(x)$ .

### Description

Calculate the fast approximate base e logarithm of the input argument x.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.

# \_\_device\_\_ float \_\_powf (float x, float y)

Calculate the fast approximate of  $x^{y}$ .

#### Returns

Returns an approximation to  $x^y$ .

# Description

Calculate the fast approximate of x, the first input argument, raised to the power of y, the second input argument,  $x^y$ .



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.

# device float saturatef (float x)

Clamp the input argument to [+0.0, 1.0].

#### Returns

- saturatef(x) returns 0 if x < 0.
- saturatef(x) returns 1 if x > 1.
- ► \_saturatef(x) returns x if  $0 \le x \le 1$ .

saturatef(NaN) returns 0.

## Description

Clamp the input argument x to be within the interval [+0.0, 1.0].

# \_\_device\_\_ void \_\_sincosf (float x, float \*sptr, float \*cptr)

Calculate the fast approximate of sine and cosine of the first input argument.

### Returns

none

# Description

Calculate the fast approximate of sine and cosine of the first input argument x (measured in radians). The results for sine and cosine are written into the second argument, sptr, and, respectively, third argument, cptr.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.
- Denorm input/output is flushed to sign preserving 0.0.

# \_\_device\_\_ float \_\_sinf (float x)

Calculate the fast approximate sine of the input argument.

### Returns

Returns the approximate sine of x.

# Description

Calculate the fast approximate sine of the input argument x, measured in radians.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.
- Output in the denormal range is flushed to sign preserving 0.0.

# \_device\_\_ float \_\_tanf (float x)

Calculate the fast approximate tangent of the input argument.

### Returns

Returns the approximate tangent of x.

### Description

Calculate the fast approximate tangent of the input argument x, measured in radians.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Intrinsic Functions section.
- The result is computed as the fast divide of <u>sinf()</u> by <u>cosf()</u>. Denormal output is flushed to sign-preserving 0.0.

# 1.9. Double Precision Intrinsics

This section describes double precision intrinsic functions that are only supported in device code. To use these functions you do not need to include any additional header files in your program.

\_\_device\_\_ double \_\_dadd\_rd (double x, double y)

Add two floating-point values in round-down mode.

#### Returns

Returns x + y.

### Description

Adds two floating-point values x and y in round-down (to negative infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_device\_\_ double \_\_dadd\_rn (double x, double y)

Add two floating-point values in round-to-nearest-even mode.

### Returns

Returns x + y.

### Description

Adds two floating-point values x and y in round-to-nearest-even mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_device\_\_ double \_\_dadd\_ru (double x, double y)

Add two floating-point values in round-up mode.

### Returns

Returns x + y.

# Description

Adds two floating-point values x and y in round-up (to positive infinity) mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ▶ This operation will never be merged into a single multiply-add instruction.

# \_device\_\_\_ double \_\_\_dadd\_rz (double x, double y)

Add two floating-point values in round-towards-zero mode.

### Returns

Returns x + y.

Adds two floating-point values x and y in round-towards-zero mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ▶ This operation will never be merged into a single multiply-add instruction.

# \_device\_\_ double \_\_ddiv\_rd (double x, double y)

Divide two floating-point values in round-down mode.

#### Returns

Returns x / y.

### Description

Divides two floating-point values x by y in round-down (to negative infinity) mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- Requires compute capability >= 2.0.

# \_device\_\_ double \_\_ddiv\_rn (double x, double y)

Divide two floating-point values in round-to-nearest-even mode.

#### Returns

Returns x / y.

## Description

Divides two floating-point values x by y in round-to-nearest-even mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.



Requires compute capability >= 2.0.

# \_\_device\_\_ double \_\_ddiv\_ru (double x, double y)

Divide two floating-point values in round-up mode.

### Returns

Returns x / y.

## Description

Divides two floating-point values x by y in round-up (to positive infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ► Requires compute capability >= 2.0.

# \_\_device\_\_\_ double \_\_\_ddiv\_rz (double x, double y)

Divide two floating-point values in round-towards-zero mode.

### Returns

Returns x / y.

# Description

Divides two floating-point values x by y in round-towards-zero mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ► Requires compute capability >= 2.0.

# \_device\_\_ double \_\_dmul\_rd (double x, double y)

Multiply two floating-point values in round-down mode.

### Returns

Returns x \* y.

Multiplies two floating-point values x and y in round-down (to negative infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# device double dmul rn (double x, double y)

Multiply two floating-point values in round-to-nearest-even mode.

#### Returns

Returns x \* y.

### Description

Multiplies two floating-point values x and y in round-to-nearest-even mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_device\_\_ double \_\_dmul\_ru (double x, double y)

Multiply two floating-point values in round-up mode.

#### Returns

Returns x \* y.

# Description

Multiplies two floating-point values x and y in round-up (to positive infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.



This operation will never be merged into a single multiply-add instruction.

# \_device\_\_ double \_\_dmul\_rz (double x, double y)

Multiply two floating-point values in round-towards-zero mode.

### Returns

Returns x \* y.

## Description

Multiplies two floating-point values x and y in round-towards-zero mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_device\_\_ double \_\_drcp\_rd (double x)

Compute  $\frac{1}{X}$  in round-down mode.

### Returns

Returns  $\frac{1}{X}$ .

### Description

Compute the reciprocal of x in round-down (to negative infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- Requires compute capability >= 2.0.

# \_\_device\_\_ double \_\_drcp\_rn (double x)

Compute  $\frac{1}{X}$  in round-to-nearest-even mode.

### Returns

Returns  $\frac{1}{X}$ .

# Description

Compute the reciprocal of x in round-to-nearest-even mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ► Requires compute capability >= 2.0.

# \_\_device\_\_ double \_\_drcp\_ru (double x)

Compute  $\frac{1}{x}$  in round-up mode.

### Returns

Returns  $\frac{1}{x}$ .

# Description

Compute the reciprocal of  $\mathbf{x}$  in round-up (to positive infinity) mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ► Requires compute capability >= 2.0.

# \_\_device\_\_ double \_\_drcp\_rz (double x)

Compute  $\frac{1}{X}$  in round-towards-zero mode.

### Returns

Returns  $\frac{1}{X}$ .

Compute the reciprocal of x in round-towards-zero mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ► Requires compute capability >= 2.0.

# \_\_device\_\_ double \_\_dsqrt\_rd (double x)

Compute  $\sqrt{x}$  in round-down mode.

### Returns

Returns  $\sqrt{x}$ .

# Description

Compute the square root of x in round-down (to negative infinity) mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ► Requires compute capability >= 2.0.

# \_\_device\_\_ double \_\_dsqrt\_rn (double x)

Compute  $\sqrt{x}$  in round-to-nearest-even mode.

### Returns

Returns  $\sqrt{x}$ .

# Description

Compute the square root of x in round-to-nearest-even mode.



### Note:



- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ► Requires compute capability >= 2.0.

# \_\_\_device\_\_ double \_\_\_dsqrt\_ru (double x)

Compute  $\sqrt{x}$  in round-up mode.

### Returns

Returns  $\sqrt{x}$ .

### Description

Compute the square root of x in round-up (to positive infinity) mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ► Requires compute capability >= 2.0.

# \_\_device\_\_ double \_\_dsqrt\_rz (double x)

Compute  $\sqrt{x}$  in round-towards-zero mode.

### Returns

Returns  $\sqrt{x}$ .

# Description

Compute the square root of x in round-towards-zero mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- Requires compute capability >= 2.0.

# \_device\_\_ double \_ dsub\_rd (double x, double y)

Subtract two floating-point values in round-down mode.

### Returns

Returns x - y.

### Description

Subtracts two floating-point values x and y in round-down (to negative infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_device\_\_ double \_\_dsub\_rn (double x, double y)

Subtract two floating-point values in round-to-nearest-even mode.

### Returns

Returns x - y.

# Description

Subtracts two floating-point values x and y in round-to-nearest-even mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ▶ This operation will never be merged into a single multiply-add instruction.

# \_device\_\_\_ double \_\_\_dsub\_ru (double x, double y)

Subtract two floating-point values in round-up mode.

### Returns

Returns x - y.

Subtracts two floating-point values x and y in round-up (to positive infinity) mode.



#### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- ▶ This operation will never be merged into a single multiply-add instruction.

# \_device\_\_ double \_\_dsub\_rz (double x, double y)

Subtract two floating-point values in round-towards-zero mode.

#### Returns

Returns x - y.

### Description

Subtracts two floating-point values x and y in round-towards-zero mode.



### Note:

- For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.
- This operation will never be merged into a single multiply-add instruction.

# \_\_device\_\_ double \_\_fma\_rd (double x, double y, double z)

Compute  $x \times y + z$  as a single operation in round-down mode.

### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- ▶ fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ▶ fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- ▶ fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$
- ▶ fmaf(x, y, +∞) returns NaN if  $x \times y$  is an exact -∞

Computes the value of  $x \times y + z$  as a single ternary operation, rounding the result once in round-down (to negative infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double \_\_fma\_rn (double x, double y, double z)

Compute  $x \times y + z$  as a single operation in round-to-nearest-even mode.

#### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ► fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- ▶ fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$
- ► fmaf(x, y,  $+\infty$ ) returns NaN if  $x \times y$  is an exact  $-\infty$

### Description

Computes the value of  $x \times y + z$  as a single ternary operation, rounding the result once in round-to-nearest-even mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double \_\_fma\_ru (double x, double y, double z)

Compute  $x \times y + z$  as a single operation in round-up mode.

#### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- ▶ fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ▶ fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$
- fmaf(x, y,  $+\infty$ ) returns NaN if  $x \times y$  is an exact  $-\infty$

Computes the value of  $x \times y + z$  as a single ternary operation, rounding the result once in round-up (to positive infinity) mode.



#### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# \_\_device\_\_ double \_\_fma\_rz (double x, double y, double z)

Compute  $x \times y + z$  as a single operation in round-towards-zero mode.

#### Returns

Returns the rounded value of  $x \times y + z$  as a single operation.

- fmaf(  $\pm \infty$ ,  $\pm 0$ , z) returns NaN.
- ▶ fmaf(  $\pm 0$ ,  $\pm \infty$ , z) returns NaN.
- fmaf(x, y,  $-\infty$ ) returns NaN if  $x \times y$  is an exact  $+\infty$
- ▶ fmaf(x, y, +∞) returns NaN if  $x \times y$  is an exact -∞

# Description

Computes the value of  $x \times y + z$  as a single ternary operation, rounding the result once in round-towards-zero mode.



### Note:

For accuracy information see the CUDA C++ Programming Guide, Mathematical Functions Appendix, Double-Precision Floating-Point Functions section.

# 1.10. Integer Intrinsics

This section describes integer intrinsic functions that are only supported in device code. To use these functions you do not need to include any additional header files in your program.

# \_\_\_device\_\_ unsigned int \_\_\_brev (unsigned int x)

Reverse the bit order of a 32-bit unsigned integer.

#### Returns

Returns the bit-reversed value of x. i.e. bit N of the return value corresponds to bit 31-N of x.

## Description

Reverses the bit order of the 32-bit unsigned integer x.

# \_\_device\_\_ unsigned long long int \_\_brevll (unsigned long long int x)

Reverse the bit order of a 64-bit unsigned integer.

#### Returns

Returns the bit-reversed value of x. i.e. bit N of the return value corresponds to bit 63-N of x.

# **Description**

Reverses the bit order of the 64-bit unsigned integer x.

# \_\_device\_\_ unsigned int \_\_byte\_perm (unsigned int x, unsigned int y, unsigned int s)

Return selected bytes from two 32-bit unsigned integers.

#### Returns

Returns a 32-bit integer consisting of four bytes from eight input bytes provided in the two input integers x and y, as specified by a selector, s.

# Description

Create 8-byte source

•  $uint64_t tmp64 = ((uint64_t)y << 32) | x;$ 

### Extract selector bits

- selector0 = (s >> 0) & 0x7:
- selector1 = (s >> 4) & 0x7;
- selector2 = (s >> 8) & 0x7:
- selector3 = (s >> 12) & 0x7;

Return 4 selected bytes from 8-byte source:

- res[07:00] = tmp64[selector0];
- res[15:08] = tmp64[selector1];
- res[23:16] = tmp64[selector2];
- res[31:24] = tmp64[selector3];

# \_\_device\_\_ int \_\_clz (int x)

Return the number of consecutive high-order zero bits in a 32-bit integer.

#### Returns

Returns a value between 0 and 32 inclusive representing the number of zero bits.

### Description

Count the number of consecutive leading zero bits, starting at the most significant bit (bit 31) of x.

# \_\_\_device\_\_ int \_\_\_clzll (long long int x)

Count the number of consecutive high-order zero bits in a 64-bit integer.

#### Returns

Returns a value between 0 and 64 inclusive representing the number of zero bits.

# Description

Count the number of consecutive leading zero bits, starting at the most significant bit (bit 63) of x.

# device int ffs (int x)

Find the position of the least significant bit set to 1 in a 32-bit integer.

#### Returns

Returns a value between 0 and 32 inclusive representing the position of the first bit set.

► ffs(0) returns 0.

## Description

Find the position of the first (least significant) bit set to 1 in x, where the least significant bit position is 1.

# \_\_device\_\_ int \_\_ffsll (long long int x)

Find the position of the least significant bit set to 1 in a 64-bit integer.

#### Returns

Returns a value between 0 and 64 inclusive representing the position of the first bit set.

\_\_ffsll(0) returns 0.

### Description

Find the position of the first (least significant) bit set to 1 in x, where the least significant bit position is 1.

# \_\_device\_\_ unsigned int \_\_funnelshift\_l (unsigned int lo, unsigned int hi, unsigned int shift)

Concatenate hi: lo, shift left by shift & 31 bits, return the most significant 32 bits.

### Returns

Returns the most significant 32 bits of the shifted 64-bit value.

# Description

Shift the 64-bit value formed by concatenating argument 10 and hi left by the amount specified by the argument shift. Argument 10 holds bits 31:0 and argument hi holds bits 63:32 of the 64-bit source value. The source is shifted left by the wrapped value of shift (shift & 31). The most significant 32-bits of the result are returned.

# \_\_device\_\_ unsigned int \_\_funnelshift\_lc (unsigned int lo, unsigned int hi, unsigned int shift)

Concatenate hi: lo, shift left by min(shift, 32) bits, return the most significant 32 bits.

#### Returns

Returns the most significant 32 bits of the shifted 64-bit value.

Shift the 64-bit value formed by concatenating argument 10 and hi left by the amount specified by the argument shift. Argument 10 holds bits 31:0 and argument hi holds bits 63:32 of the 64-bit source value. The source is shifted left by the clamped value of shift (min(shift, 32)). The most significant 32-bits of the result are returned.

# \_\_device\_\_ unsigned int \_\_funnelshift\_r (unsigned int lo, unsigned int hi, unsigned int shift)

Concatenate hi: lo, shift right by shift & 31 bits, return the least significant 32 bits.

### Returns

Returns the least significant 32 bits of the shifted 64-bit value.

### Description

Shift the 64-bit value formed by concatenating argument 10 and hi right by the amount specified by the argument shift. Argument 10 holds bits 31:0 and argument hi holds bits 63:32 of the 64-bit source value. The source is shifted right by the wrapped value of shift (shift & 31). The least significant 32-bits of the result are returned.

# \_\_device\_\_ unsigned int \_\_funnelshift\_rc (unsigned int lo, unsigned int hi, unsigned int shift)

Concatenate hi: lo, shift right by min(shift, 32) bits, return the least significant 32 bits.

#### Returns

Returns the least significant 32 bits of the shifted 64-bit value.

# Description

Shift the 64-bit value formed by concatenating argument 10 and hi right by the amount specified by the argument shift. Argument 10 holds bits 31:0 and argument hi holds bits 63:32 of the 64-bit source value. The source is shifted right by the clamped value of shift (min(shift, 32)). The least significant 32-bits of the result are returned.

# \_\_device\_\_ int \_\_hadd (int x, int y)

Compute average of signed input arguments, avoiding overflow in the intermediate sum.

#### Returns

Returns a signed integer value representing the signed average value of the two inputs.

Compute average of signed input arguments x and y as (x + y) >> 1, avoiding overflow in the intermediate sum.

# \_\_device\_\_ int \_\_mul24 (int x, int y)

Calculate the least significant 32 bits of the product of the least significant 24 bits of two integers.

#### Returns

Returns the least significant 32 bits of the product x \* y.

### Description

Calculate the least significant 32 bits of the product of the least significant 24 bits of x and y. The high order 8 bits of x and y are ignored.

# \_\_device\_\_ long long int \_\_mul64hi (long long int x, long long int y)

Calculate the most significant 64 bits of the product of the two 64-bit integers.

### Returns

Returns the most significant 64 bits of the product x \* y.

# Description

Calculate the most significant 64 bits of the 128-bit product x \* y, where x and y are 64-bit integers.

# \_\_\_device\_\_ int \_\_\_mulhi (int x, int y)

Calculate the most significant 32 bits of the product of the two 32-bit integers.

### Returns

Returns the most significant 32 bits of the product x \* y.

### Description

Calculate the most significant 32 bits of the 64-bit product x \* y, where x and y are 32-bit integers.

# \_device\_\_ int \_\_popc (unsigned int x)

Count the number of bits that are set to 1 in a 32-bit integer.

### Returns

Returns a value between 0 and 32 inclusive representing the number of set bits.

## Description

Count the number of bits that are set to 1 in x.

# \_\_\_device\_\_ int \_\_\_popcll (unsigned long long int x)

Count the number of bits that are set to 1 in a 64-bit integer.

### Returns

Returns a value between 0 and 64 inclusive representing the number of set bits.

# Description

Count the number of bits that are set to 1 in x.

# \_\_\_device\_\_ int \_\_\_rhadd (int x, int y)

Compute rounded average of signed input arguments, avoiding overflow in the intermediate sum.

#### Returns

Returns a signed integer value representing the signed rounded average value of the two inputs.

# Description

Compute average of signed input arguments x and y as (x + y + 1) >> 1, avoiding overflow in the intermediate sum.

# \_\_device\_\_ unsigned int \_\_sad (int x, int y, unsigned int z)

Calculate |x-y|+z, the sum of absolute difference.

#### Returns

Returns |x-y|+z.

Calculate |x-y|+z, the 32-bit sum of the third argument z plus and the absolute value of the difference between the first argument, x, and second argument, y.

Inputs x and y are signed 32-bit integers, input z is a 32-bit unsigned integer.

# \_\_device\_\_ unsigned int \_\_uhadd (unsigned int x, unsigned int y)

Compute average of unsigned input arguments, avoiding overflow in the intermediate sum.

#### Returns

Returns an unsigned integer value representing the unsigned average value of the two inputs.

## Description

Compute average of unsigned input arguments x and y as (x + y) >> 1, avoiding overflow in the intermediate sum.

# \_\_device\_\_ unsigned int \_\_umul24 (unsigned int x, unsigned int y)

Calculate the least significant 32 bits of the product of the least significant 24 bits of two unsigned integers.

#### Returns

Returns the least significant 32 bits of the product x \* y.

# Description

Calculate the least significant 32 bits of the product of the least significant 24 bits of x and y. The high order 8 bits of x and y are ignored.

# \_\_device\_\_ unsigned long long int \_\_umul64hi (unsigned long long int x, unsigned long long int y)

Calculate the most significant 64 bits of the product of the two 64 unsigned bit integers.

#### Returns

Returns the most significant 64 bits of the product x \* y.

Calculate the most significant 64 bits of the 128-bit product x \* y, where x and y are 64-bit unsigned integers.

# \_\_device\_\_ unsigned int \_\_umulhi (unsigned int x, unsigned int y)

Calculate the most significant 32 bits of the product of the two 32-bit unsigned integers.

### Returns

Returns the most significant 32 bits of the product x \* y.

## Description

Calculate the most significant 32 bits of the 64-bit product x \* y, where x and y are 32-bit unsigned integers.

# \_\_device\_\_ unsigned int \_\_urhadd (unsigned int x, unsigned int y)

Compute rounded average of unsigned input arguments, avoiding overflow in the intermediate

### Returns

Returns an unsigned integer value representing the unsigned rounded average value of the two inputs.

# Description

Compute average of unsigned input arguments x and y as (x + y + 1) >> 1, avoiding overflow in the intermediate sum.

# \_\_device\_\_ unsigned int \_\_usad (unsigned int x, unsigned int y, unsigned int z)

Calculate |x-y|+z, the sum of absolute difference.

#### Returns

Returns |x-y|+z.

Calculate |x-y|+z, the 32-bit sum of the third argument z plus and the absolute value of the difference between the first argument, x, and second argument, y.

Inputs x, y, and z are unsigned 32-bit integers.

# 1.11. Type Casting Intrinsics

This section describes type casting intrinsic functions that are only supported in device code. To use these functions you do not need to include any additional header files in your program.

Convert a double to a float in round-down mode.

### Returns

Returns converted value.

## Description

Convert the double-precision floating-point value  $\mathbf{x}$  to a single-precision floating-point value in round-down (to negative infinity) mode.

# \_\_device\_\_ float \_\_double2float\_rn (double x)

Convert a double to a float in round-to-nearest-even mode.

### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value  ${\bf x}$  to a single-precision floating-point value in round-to-nearest-even mode.

# \_\_\_device\_\_\_ float \_\_\_double2float\_ru (double x)

Convert a double to a float in round-up mode.

### Returns

Returns converted value.

Convert the double-precision floating-point value x to a single-precision floating-point value in round-up (to positive infinity) mode.

# \_\_\_device\_\_\_ float \_\_\_double2float\_rz (double x)

Convert a double to a float in round-towards-zero mode.

### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value  $\mathbf{x}$  to a single-precision floating-point value in round-towards-zero mode.

# \_\_\_device\_\_ int \_\_\_double2hiint (double x)

Reinterpret high 32 bits in a double as a signed integer.

### Returns

Returns reinterpreted value.

# Description

Reinterpret the high 32 bits in the double-precision floating-point value x as a signed integer.

# \_\_device\_\_ int \_\_double2int\_rd (double x)

Convert a double to a signed int in round-down mode.

#### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value  $\mathbf{x}$  to a signed integer value in round-down (to negative infinity) mode.

# \_\_device\_\_ int \_\_double2int\_rn (double x)

Convert a double to a signed int in round-to-nearest-even mode.

#### Returns

Returns converted value.

### Description

Convert the double-precision floating-point value  $\mathbf{x}$  to a signed integer value in round-to-nearest-even mode.

# \_\_device\_\_ int \_\_double2int\_ru (double x)

Convert a double to a signed int in round-up mode.

#### Returns

Returns converted value.

## Description

Convert the double-precision floating-point value x to a signed integer value in round-up (to positive infinity) mode.

# device int double2int rz (double x)

Convert a double to a signed int in round-towards-zero mode.

### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value  $\mathbf{x}$  to a signed integer value in round-towards-zero mode.

# \_\_\_device\_\_\_ long long int \_\_\_double2ll\_rd (double x)

Convert a double to a signed 64-bit int in round-down mode.

#### Returns

Returns converted value.

Convert the double-precision floating-point value x to a signed 64-bit integer value in round-down (to negative infinity) mode.

# \_\_device\_\_ long long int \_\_double2ll\_rn (double x)

Convert a double to a signed 64-bit int in round-to-nearest-even mode.

### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value x to a signed 64-bit integer value in round-to-nearest-even mode.

# \_\_device\_\_ long long int \_\_double2ll\_ru (double x)

Convert a double to a signed 64-bit int in round-up mode.

### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value x to a signed 64-bit integer value in round-up (to positive infinity) mode.

# \_\_device\_\_ long long int \_\_double2ll\_rz (double x)

Convert a double to a signed 64-bit int in round-towards-zero mode.

### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value  $\mathbf{x}$  to a signed 64-bit integer value in round-towards-zero mode.

# device int double2loint (double x)

Reinterpret low 32 bits in a double as a signed integer.

#### Returns

Returns reinterpreted value.

## Description

Reinterpret the low 32 bits in the double-precision floating-point value x as a signed integer.

# \_\_\_device\_\_ unsigned int \_\_\_double2uint\_rd (double x)

Convert a double to an unsigned int in round-down mode.

#### Returns

Returns converted value.

## Description

Convert the double-precision floating-point value  $\mathbf{x}$  to an unsigned integer value in round-down (to negative infinity) mode.

# \_\_device\_\_ unsigned int \_\_double2uint\_rn (double x)

Convert a double to an unsigned int in round-to-nearest-even mode.

#### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value  ${\bf x}$  to an unsigned integer value in round-to-nearest-even mode.

# \_\_device\_\_ unsigned int \_\_double2uint\_ru (double x)

Convert a double to an unsigned int in round-up mode.

### Returns

Returns converted value.

Convert the double-precision floating-point value x to an unsigned integer value in round-up (to positive infinity) mode.

# \_\_\_device\_\_ unsigned int \_\_\_double2uint\_rz (double x)

Convert a double to an unsigned int in round-towards-zero mode.

### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value  $\mathbf{x}$  to an unsigned integer value in round-towards-zero mode.

# \_\_device\_\_ unsigned long long int \_\_double2ull\_rd (double x)

Convert a double to an unsigned 64-bit int in round-down mode.

### Returns

Returns converted value.

## Description

Convert the double-precision floating-point value  $\mathbf{x}$  to an unsigned 64-bit integer value in round-down (to negative infinity) mode.

# \_\_device\_\_ unsigned long long int \_\_double2ull\_rn (double x)

Convert a double to an unsigned 64-bit int in round-to-nearest-even mode.

### Returns

Returns converted value.

## Description

Convert the double-precision floating-point value  $\mathbf{x}$  to an unsigned 64-bit integer value in round-to-nearest-even mode.

# \_\_device\_\_ unsigned long long int \_\_double2ull\_ru (double x)

Convert a double to an unsigned 64-bit int in round-up mode.

### Returns

Returns converted value.

### Description

Convert the double-precision floating-point value x to an unsigned 64-bit integer value in round-up (to positive infinity) mode.

# \_\_device\_\_ unsigned long long int \_\_double2ull\_rz (double x)

Convert a double to an unsigned 64-bit int in round-towards-zero mode.

#### Returns

Returns converted value.

# Description

Convert the double-precision floating-point value  $\mathbf{x}$  to an unsigned 64-bit integer value in round-towards-zero mode.

# \_\_device\_\_ long long int \_\_double\_as\_longlong (double x)

Reinterpret bits in a double as a 64-bit signed integer.

#### Returns

Returns reinterpreted value.

## Description

Reinterpret the bits in the double-precision floating-point value  ${\bf x}$  as a signed 64-bit integer.

# \_device\_\_ int \_\_float2int\_rd (float x)

Convert a float to a signed integer in round-down mode.

### Returns

Returns converted value.

## Description

Convert the single-precision floating-point value  $\mathbf{x}$  to a signed integer in round-down (to negative infinity) mode.

# \_\_device\_\_ int \_\_float2int\_rn (float x)

Convert a float to a signed integer in round-to-nearest-even mode.

#### Returns

Returns converted value.

### Description

Convert the single-precision floating-point value  $\mathbf{x}$  to a signed integer in round-to-nearest-even mode.

# device int float2int ru (float)

Convert a float to a signed integer in round-up mode.

### Returns

Returns converted value.

# Description

Convert the single-precision floating-point value  ${\bf x}$  to a signed integer in round-up (to positive infinity) mode.

# \_\_\_device\_\_\_ int \_\_\_float2int\_rz (float x)

Convert a float to a signed integer in round-towards-zero mode.

#### Returns

Returns converted value.

Convert the single-precision floating-point value  ${\bf x}$  to a signed integer in round-towards-zero mode.

# \_\_\_device\_\_\_ long long int \_\_\_float2ll\_rd (float x)

Convert a float to a signed 64-bit integer in round-down mode.

### Returns

Returns converted value.

# Description

Convert the single-precision floating-point value  $\mathbf{x}$  to a signed 64-bit integer in round-down (to negative infinity) mode.

# \_\_device\_\_ long long int \_\_float2ll\_rn (float x)

Convert a float to a signed 64-bit integer in round-to-nearest-even mode.

### Returns

Returns converted value.

# Description

Convert the single-precision floating-point value  ${\bf x}$  to a signed 64-bit integer in round-to-nearest-even mode.

# \_\_device\_\_ long long int \_\_float2ll\_ru (float x)

Convert a float to a signed 64-bit integer in round-up mode.

### Returns

Returns converted value.

# Description

Convert the single-precision floating-point value x to a signed 64-bit integer in round-up (to positive infinity) mode.

## \_\_device\_\_ long long int \_\_float2ll\_rz (float x)

Convert a float to a signed 64-bit integer in round-towards-zero mode.

#### Returns

Returns converted value.

## Description

Convert the single-precision floating-point value  ${\bf x}$  to a signed 64-bit integer in round-towards-zero mode.

## \_\_device\_\_ unsigned int \_\_float2uint\_rd (float x)

Convert a float to an unsigned integer in round-down mode.

#### Returns

Returns converted value.

## Description

Convert the single-precision floating-point value x to an unsigned integer in round-down (to negative infinity) mode.

## \_\_\_device\_\_ unsigned int \_\_\_float2uint\_rn (float x)

Convert a float to an unsigned integer in round-to-nearest-even mode.

## Returns

Returns converted value.

## Description

Convert the single-precision floating-point value  $\mathbf{x}$  to an unsigned integer in round-to-nearest-even mode.

## \_\_\_device\_\_\_ unsigned int \_\_\_float2uint\_ru (float x)

Convert a float to an unsigned integer in round-up mode.

#### Returns

Returns converted value.

## Description

Convert the single-precision floating-point value x to an unsigned integer in round-up (to positive infinity) mode.

## \_\_\_device\_\_ unsigned int \_\_\_float2uint\_rz (float x)

Convert a float to an unsigned integer in round-towards-zero mode.

## Returns

Returns converted value.

## Description

Convert the single-precision floating-point value  $\mathbf{x}$  to an unsigned integer in round-towards-zero mode.

## \_\_device\_\_ unsigned long long int \_\_float2ull\_rd (float x)

Convert a float to an unsigned 64-bit integer in round-down mode.

## Returns

Returns converted value.

## Description

Convert the single-precision floating-point value  $\mathbf{x}$  to an unsigned 64-bit integer in round-down (to negative infinity) mode.

## \_\_device\_\_ unsigned long long int \_\_float2ull\_rn (float x)

Convert a float to an unsigned 64-bit integer in round-to-nearest-even mode.

## Returns

Returns converted value.

## Description

Convert the single-precision floating-point value  ${\bf x}$  to an unsigned 64-bit integer in round-to-nearest-even mode.

## \_\_device\_\_ unsigned long long int \_\_float2ull\_ru (float x)

Convert a float to an unsigned 64-bit integer in round-up mode.

## Returns

Returns converted value.

## Description

Convert the single-precision floating-point value x to an unsigned 64-bit integer in round-up (to positive infinity) mode.

## \_\_device\_\_ unsigned long long int \_\_float2ull\_rz (float x)

Convert a float to an unsigned 64-bit integer in round-towards-zero mode.

#### Returns

Returns converted value.

## Description

Convert the single-precision floating-point value  $\mathbf{x}$  to an unsigned 64-bit integer in round-towards-zero mode.

## \_\_device\_\_ int \_\_float\_as\_int (float x)

Reinterpret bits in a float as a signed integer.

#### Returns

Returns reinterpreted value.

## Description

Reinterpret the bits in the single-precision floating-point value x as a signed integer.

## \_\_\_device\_\_ unsigned int \_\_\_float\_as\_uint (float x)

Reinterpret bits in a float as a unsigned integer.

#### Returns

Returns reinterpreted value.

## Description

Reinterpret the bits in the single-precision floating-point value x as a unsigned integer.

## \_\_device\_\_ double \_\_hiloint2double (int hi, int lo)

Reinterpret high and low 32-bit integer values as a double.

### Returns

Returns reinterpreted value.

## Description

Reinterpret the integer value of hi as the high 32 bits of a double-precision floating-point value and the integer value of lo as the low 32 bits of the same double-precision floating-point value.

## \_\_\_device\_\_ double \_\_int2double\_rn (int x)

Convert a signed int to a double.

## Returns

Returns converted value.

## Description

Convert the signed integer value x to a double-precision floating-point value.

## \_\_device\_\_ float \_\_int2float\_rd (int x)

Convert a signed integer to a float in round-down mode.

#### Returns

Returns converted value.

## Description

Convert the signed integer value x to a single-precision floating-point value in round-down (to negative infinity) mode.

## \_device\_\_ float \_\_int2float\_rn (int x)

Convert a signed integer to a float in round-to-nearest-even mode.

#### Returns

Returns converted value.

## Description

Convert the signed integer value  $\mathbf{x}$  to a single-precision floating-point value in round-to-nearest-even mode.

## \_\_\_device\_\_\_float \_\_\_int2float\_ru (int x)

Convert a signed integer to a float in round-up mode.

#### Returns

Returns converted value.

## Description

Convert the signed integer value x to a single-precision floating-point value in round-up (to positive infinity) mode.

## device float int2float rz (int x)

Convert a signed integer to a float in round-towards-zero mode.

## Returns

Returns converted value.

## Description

Convert the signed integer value  $\mathbf{x}$  to a single-precision floating-point value in round-towards-zero mode.

## \_\_\_device\_\_\_ float \_\_\_int\_as\_float (int x)

Reinterpret bits in an integer as a float.

#### Returns

Returns reinterpreted value.

## Description

Reinterpret the bits in the signed integer value x as a single-precision floating-point value.

## \_\_\_device\_\_ double \_\_ll2double\_rd (long long int x)

Convert a signed 64-bit int to a double in round-down mode.

### Returns

Returns converted value.

## Description

Convert the signed 64-bit integer value x to a double-precision floating-point value in round-down (to negative infinity) mode.

## \_\_device\_\_ double \_\_ll2double\_rn (long long int x)

Convert a signed 64-bit int to a double in round-to-nearest-even mode.

## Returns

Returns converted value.

## Description

Convert the signed 64-bit integer value  $\mathbf{x}$  to a double-precision floating-point value in round-to-nearest-even mode.

## \_\_device\_\_ double \_\_ll2double\_ru (long long int x)

Convert a signed 64-bit int to a double in round-up mode.

#### Returns

Returns converted value.

## Description

Convert the signed 64-bit integer value x to a double-precision floating-point value in round-up (to positive infinity) mode.

## \_\_device\_\_double \_\_ll2double\_rz (long long int x)

Convert a signed 64-bit int to a double in round-towards-zero mode.

## Returns

Returns converted value.

## Description

Convert the signed 64-bit integer value  $\mathbf{x}$  to a double-precision floating-point value in round-towards-zero mode.

## \_\_device\_\_ float \_\_ll2float\_rd (long long int x)

Convert a signed integer to a float in round-down mode.

#### Returns

Returns converted value.

## Description

Convert the signed integer value x to a single-precision floating-point value in round-down (to negative infinity) mode.

## \_\_\_device\_\_\_ float \_\_\_ll2float\_rn (long long int x)

Convert a signed 64-bit integer to a float in round-to-nearest-even mode.

## Returns

Returns converted value.

## Description

Convert the signed 64-bit integer value  $\mathbf{x}$  to a single-precision floating-point value in round-to-nearest-even mode.

## \_\_\_device\_\_\_ float \_\_\_ll2float\_ru (long long int x)

Convert a signed integer to a float in round-up mode.

#### Returns

Returns converted value.

## Description

Convert the signed integer value  $\mathbf{x}$  to a single-precision floating-point value in round-up (to positive infinity) mode.

Convert a signed integer to a float in round-towards-zero mode.

## Returns

Returns converted value.

## Description

Convert the signed integer value  $\mathbf{x}$  to a single-precision floating-point value in round-towards-zero mode.

## \_\_device\_\_ double \_\_longlong\_as\_double (long long int x)

Reinterpret bits in a 64-bit signed integer as a double.

## Returns

Returns reinterpreted value.

## Description

Reinterpret the bits in the 64-bit signed integer value  $\mathbf{x}$  as a double-precision floating-point value.

\_\_device\_\_ double \_\_uint2double\_rn (unsigned int x)

Convert an unsigned int to a double.

## Returns

Returns converted value.

## Description

Convert the unsigned integer value x to a double-precision floating-point value.

## \_\_\_device\_\_\_ float \_\_\_uint2float\_rd (unsigned int x)

Convert an unsigned integer to a float in round-down mode.

## Returns

Returns converted value.

## Description

Convert the unsigned integer value x to a single-precision floating-point value in round-down (to negative infinity) mode.

## \_\_device\_\_ float \_\_uint2float\_rn (unsigned int x)

Convert an unsigned integer to a float in round-to-nearest-even mode.

#### Returns

Returns converted value.

## Description

Convert the unsigned integer value  $\mathbf{x}$  to a single-precision floating-point value in round-to-nearest-even mode.

## \_\_\_device\_\_\_ float \_\_\_uint2float\_ru (unsigned int x)

Convert an unsigned integer to a float in round-up mode.

## Returns

Returns converted value.

## Description

Convert the unsigned integer value  ${\bf x}$  to a single-precision floating-point value in round-up (to positive infinity) mode.

## \_\_\_device\_\_\_ float \_\_\_uint2float\_rz (unsigned int x)

Convert an unsigned integer to a float in round-towards-zero mode.

#### Returns

Returns converted value.

## Description

Convert the unsigned integer value  $\mathbf{x}$  to a single-precision floating-point value in round-towards-zero mode.

Reinterpret bits in an unsigned integer as a float.

## Returns

Returns reinterpreted value.

## Description

Reinterpret the bits in the unsigned integer value x as a single-precision floating-point value.

## \_\_device\_\_ double \_\_ull2double\_rd (unsigned long long int x)

Convert an unsigned 64-bit int to a double in round-down mode.

## Returns

Returns converted value.

## Description

Convert the unsigned 64-bit integer value  $\mathbf{x}$  to a double-precision floating-point value in round-down (to negative infinity) mode.

## \_\_device\_\_ double \_\_ull2double\_rn (unsigned long long int x)

Convert an unsigned 64-bit int to a double in round-to-nearest-even mode.

#### Returns

Returns converted value.

## Description

Convert the unsigned 64-bit integer value  ${\bf x}$  to a double-precision floating-point value in round-to-nearest-even mode.

## \_\_device\_\_ double \_\_ull2double\_ru (unsigned long long int x)

Convert an unsigned 64-bit int to a double in round-up mode.

#### Returns

Returns converted value.

## Description

Convert the unsigned 64-bit integer value x to a double-precision floating-point value in round-up (to positive infinity) mode.

## \_\_device\_\_ double \_\_ull2double\_rz (unsigned long long int x)

Convert an unsigned 64-bit int to a double in round-towards-zero mode.

#### Returns

Returns converted value.

## Description

Convert the unsigned 64-bit integer value  $\mathbf{x}$  to a double-precision floating-point value in round-towards-zero mode.

## \_\_device\_\_ float \_\_ull2float\_rd (unsigned long long int x)

Convert an unsigned integer to a float in round-down mode.

#### Returns

Returns converted value.

## Description

Convert the unsigned integer value  $\mathbf{x}$  to a single-precision floating-point value in round-down (to negative infinity) mode.

## \_\_device\_\_ float \_\_ull2float\_rn (unsigned long long int x)

Convert an unsigned integer to a float in round-to-nearest-even mode.

## Returns

Returns converted value.

## Description

Convert the unsigned integer value x to a single-precision floating-point value in round-to-nearest-even mode.

## \_\_device\_\_ float \_\_ull2float\_ru (unsigned long long int x)

Convert an unsigned integer to a float in round-up mode.

#### Returns

Returns converted value.

## Description

Convert the unsigned integer value x to a single-precision floating-point value in round-up (to positive infinity) mode.

## \_\_device\_\_ float \_\_ull2float\_rz (unsigned long long int x)

Convert an unsigned integer to a float in round-towards-zero mode.

#### Returns

Returns converted value.

## Description

Convert the unsigned integer value  ${\bf x}$  to a single-precision floating-point value in round-towards-zero mode.

## 1.12. SIMD Intrinsics

This section describes SIMD intrinsic functions that are only supported in device code. To use these functions you do not need to include any additional header files in your program.

## \_\_\_device\_\_ unsigned int \_\_\_vabs2 (unsigned int a)

Computes per-halfword absolute value.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of argument into 2 parts, each consisting of 2 bytes, then computes absolute value for each of parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vabs4 (unsigned int a)

Computes per-byte absolute value.

## Returns

Returns computed value.

## Description

Splits argument by bytes. Computes absolute value of each byte. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vabsdiffs2 (unsigned int a, unsigned int b)

Computes per-halfword sum of absolute difference of signed integer.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each into 2 parts, each consisting of 2 bytes. For corresponding parts function computes absolute difference. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vabsdiffs4 (unsigned int a, unsigned int b)

Computes per-byte absolute difference of signed integer.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each into 4 parts, each consisting of 1 byte. For corresponding parts function computes absolute difference. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vabsdiffu2 (unsigned int a, unsigned int b)

Performs per-halfword absolute difference of unsigned integer computation: |a - b|.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes absolute difference. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vabsdiffu4 (unsigned int a, unsigned int b)

Computes per-byte absolute difference of unsigned integer.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes absolute difference. Partial results are recombined and returned as unsigned int.

## \_device\_\_ unsigned int \_\_vabsss2 (unsigned int a)

Computes per-halfword absolute value with signed saturation.

## Returns

Returns computed value.

## Description

Splits 4 bytes of argument into 2 parts, each consisting of 2 bytes, then computes absolute value with signed saturation for each of parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_\_vabsss4 (unsigned int a)

Computes per-byte absolute value with signed saturation.

### Returns

Returns computed value.

## Description

Splits 4 bytes of argument into 4 parts, each consisting of 1 byte, then computes absolute value with signed saturation for each of parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vadd2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed addition, with wrap-around: a + b.

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then performs unsigned addition on corresponding parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vadd4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed addition.

## Returns

Returns computed value.

## Description

Splits 'a' into 4 bytes, then performs unsigned addition on each of these bytes with the corresponding byte from 'b', ignoring overflow. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vaddss2 (unsigned int a, unsigned int b)

Performs per-halfword addition with signed saturation.

### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then performs addition with signed saturation on corresponding parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vaddss4 (unsigned int a, unsigned int b)

Performs per-byte addition with signed saturation.

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte, then performs addition with signed saturation on corresponding parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vaddus2 (unsigned int a, unsigned int b)

Performs per-halfword addition with unsigned saturation.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then performs addition with unsigned saturation on corresponding parts.

## \_\_device\_\_ unsigned int \_\_vaddus4 (unsigned int a, unsigned int b)

Performs per-byte addition with unsigned saturation.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte, then performs addition with unsigned saturation on corresponding parts.

## \_\_device\_\_ unsigned int \_\_vavgs2 (unsigned int a, unsigned int b)

Performs per-halfword signed rounded average computation.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then computes signed rounded average of corresponding parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vavgs4 (unsigned int a, unsigned int b)

Computes per-byte signed rounded average.

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. then computes signed rounded average of corresponding parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vavgu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned rounded average computation.

### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then computes unsigned rounded average of corresponding parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vavgu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned rounded average.

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. then computes unsigned rounded average of corresponding parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vcmpeq2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed comparison.

#### Returns

Returns Oxffff computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if they are equal, and 0000 otherwise. For example \_\_vcmpeq2(0x1234aba5, 0x1234aba6) returns 0xffff0000.

## \_\_device\_\_ unsigned int \_\_vcmpeq4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed comparison.

### Returns

Returns 0xff if a = b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if they are equal, and 00 otherwise. For example \_\_vcmpeq4(0x1234aba5, 0x1234aba6) returns 0xffffff00.

## \_\_device\_\_ unsigned int \_\_vcmpges2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison: a >= b ? 0xffff : 0.

## Returns

Returns 0xffff if a >= b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part >= 'b' part, and 0000 otherwise. For example \_\_vcmpges2(0x1234aba5, 0x1234aba6) returns 0xffff0000.

## \_\_device\_\_ unsigned int \_\_vcmpges4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

## Returns

Returns 0xff if a >= b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part >= 'b' part, and 00 otherwise. For example \_\_vcmpges4(0x1234aba5, 0x1234aba6) returns 0xffffff00.

## \_\_device\_\_ unsigned int \_\_vcmpgeu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison: a >= b ? 0xffff : 0.

### Returns

Returns 0xffff if a >= b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part >= 'b' part, and 0000 otherwise. For example \_\_vcmpqeu2(0x1234aba5, 0x1234aba6) returns 0xffff0000.

## \_\_device\_\_ unsigned int \_\_vcmpgeu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

## Returns

Returns 0xff if a = b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part >= 'b' part, and 00 otherwise. For example \_\_vcmpgeu4(0x1234aba5, 0x1234aba6) returns 0xffffff00.

## \_\_device\_\_ unsigned int \_\_vcmpgts2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison: a > b ? 0xffff : 0.

#### Returns

Returns 0xffff if a > b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part > 'b' part, and 0000 otherwise. For example \_\_vcmpqts2(0x1234aba5, 0x1234aba6) returns 0x00000000.

## \_\_device\_\_ unsigned int \_\_vcmpgts4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

### Returns

Returns 0xff if a > b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part > 'b' part, and 00 otherwise. For example \_\_vcmpgts4(0x1234aba5, 0x1234aba6) returns 0x000000000.

## \_\_device\_\_ unsigned int \_\_vcmpgtu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison: a > b ? 0xffff : 0.

## Returns

Returns 0xffff if a > b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part > 'b' part, and 0000 otherwise. For example \_\_vcmpgtu2(0x1234aba5, 0x1234aba6) returns 0x00000000.

## \_\_device\_\_ unsigned int \_\_vcmpgtu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

## Returns

Returns 0xff if a > b. else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part > 'b' part, and 00 otherwise. For example \_\_vcmpgtu4(0x1234aba5, 0x1234aba6) returns 0x000000000.

## \_\_device\_\_ unsigned int \_\_vcmples2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison: a <= b ? 0xffff : 0.

### Returns

Returns 0xffff if a <= b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part <= 'b' part, and 0000 otherwise. For example \_\_vcmples2(0x1234aba5, 0x1234aba6) returns 0xfffffff.

## \_\_device\_\_ unsigned int \_\_vcmples4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

## Returns

Returns 0xff if a <= b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part <= 'b' part, and 00 otherwise. For example \_\_vcmples4(0x1234aba5, 0x1234aba6) returns 0xffffffff.

## \_\_device\_\_ unsigned int \_\_vcmpleu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison: a <= b ? 0xffff : 0.

#### Returns

Returns 0xffff if a <= b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part <= 'b' part, and 0000 otherwise. For example \_\_vcmpleu2(0x1234aba5, 0x1234aba6) returns 0xfffffff.

## \_\_device\_\_ unsigned int \_\_vcmpleu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

## Returns

Returns 0xff if a <= b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part <= 'b' part, and 00 otherwise. For example \_\_vcmpleu4(0x1234aba5, 0x1234aba6) returns 0xffffffff.

## \_\_device\_\_ unsigned int \_\_vcmplts2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison: a < b ? 0xffff : 0.

## Returns

Returns 0xffff if a < b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part < 'b' part, and 0000 otherwise. For example \_\_vcmplts2(0x1234aba5, 0x1234aba6) returns 0x0000ffff.

## \_\_device\_\_ unsigned int \_\_vcmplts4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

#### Returns

Returns 0xff if a < b. else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part < 'b' part, and 00 otherwise. For example \_\_vcmplts4(0x1234aba5, 0x1234aba6) returns 0x000000ff.

## \_\_device\_\_ unsigned int \_\_vcmpltu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison: a < b ? 0xffff : 0.

### Returns

Returns 0xffff if a < b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part < 'b' part, and 0000 otherwise. For example \_\_vcmpltu2(0x1234aba5, 0x1234aba6) returns 0x0000ffff.

## \_\_device\_\_ unsigned int \_\_vcmpltu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

## Returns

Returns 0xff if a < b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part < 'b' part, and 00 otherwise. For example \_\_vcmpltu4(0x1234aba5, 0x1234aba6) returns 0x000000ff.

## \_\_device\_\_ unsigned int \_\_vcmpne2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed comparison: a != b ? 0xffff : 0.

## Returns

Returns 0xffff if a != b, else returns 0.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts result is ffff if 'a' part != 'b' part, and 0000 otherwise. For example \_\_vcmplts2(0x1234aba5, 0x1234aba6) returns 0x0000ffff.

## \_\_device\_\_ unsigned int \_\_vcmpne4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed comparison.

### Returns

Returns 0xff if a != b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts result is ff if 'a' part != 'b' part, and 00 otherwise. For example \_\_vcmplts4(0x1234aba5, 0x1234aba6) returns 0x000000ff.

## \_\_device\_\_ unsigned int \_\_vhaddu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned average computation.

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes, then computes unsigned average of corresponding parts. Partial results are recombined and returned as unsigned int.

## \_\_device\_\_ unsigned int \_\_vhaddu4 (unsigned int a, unsigned int b)

Computes per-byte unsigned average.

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. then computes unsigned average of corresponding parts. Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_viaddmax\_s16x2 (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword max(a + b, c).

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs an add and compare: max(a\_part + b\_part), c\_part) Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_viaddmax\_s16x2\_relu (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword max(max(a + b, c), 0).

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs an add, followed

by a max with relu: max(max(a\_part + b\_part), c\_part), 0) Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ int \_\_viaddmax\_s32 (const int a, const int b, const int c)

Computes max(a + b, c).

### Returns

Returns computed value.

## Description

Calculates the sum of signed integers a and b and takes the max with c.

\_\_host\_\_\_device\_\_ int \_\_viaddmax\_s32\_relu (const int a, const int b, const int c)

Computes max(max(a + b, c), 0).

#### Returns

Returns computed value.

## Description

Calculates the sum of signed integers a and b and takes the max with c. If the result is less than 0 then is returned.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_viaddmax\_u16x2 (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword max(a + b, c).

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as unsigned shorts. For corresponding parts function performs an add and compare: max(a\_part + b\_part), c\_part) Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_viaddmax\_u32 (const unsigned int a, const unsigned int b, const unsigned int c)

Computes max(a + b, c).

#### Returns

Returns computed value.

## Description

Calculates the sum of unsigned integers a and b and takes the max with c.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_viaddmin\_s16x2 (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword min(a + b, c).

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs an add and compare: min(a\_part + b\_part), c\_part) Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_viaddmin\_s16x2\_relu (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword max(min(a + b, c), 0).

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs an add, followed

by a min with relu: max(min(a\_part + b\_part), c\_part), 0) Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ int \_\_viaddmin\_s32 (const int a, const int b, const int c)

Computes min(a + b, c).

### Returns

Returns computed value.

## Description

Calculates the sum of signed integers a and b and takes the min with c.

\_\_host\_\_\_device\_\_ int \_\_viaddmin\_s32\_relu (const int a, const int b, const int c)

Computes max(min(a + b, c), 0).

#### Returns

Returns computed value.

## Description

Calculates the sum of signed integers a and b and takes the min with c. If the result is less than 0 then is returned.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_viaddmin\_u16x2 (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword min(a + b, c).

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as unsigned shorts. For corresponding parts function performs an add and compare: min(a\_part + b\_part), c\_part) Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_viaddmin\_u32 (const unsigned int a, const unsigned int b, const unsigned int c)

Computes min(a + b, c).

#### Returns

Returns computed value.

## Description

Calculates the sum of unsigned integers a and b and takes the min with c.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vibmax\_s16x2 (const unsigned int a, const unsigned int b, const bool \*pred\_hi, const bool \*pred\_lo)

Performs per-halfword max(a, b), also sets the value pointed to by pred\_hi and pred\_lo to the per-halfword result of (a >= b).

#### Returns

Returns computed values.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs a maximum ( = max(a\_part, b\_part)). Partial results are recombined and returned as unsigned int. Sets the value pointed to by pred\_hi to the value (a\_high\_part >= b\_high\_part). Sets the value pointed to by pred\_lo to the value (a low part >= b low part).

\_\_host\_\_\_\_device\_\_ int \_\_vibmax\_s32 (const int a, const int b, const bool \*pred)

Computes max(a, b), also sets the value pointed to by pred to (a >= b).

#### Returns

Returns computed values.

## Description

Calculates the maximum of a and b of two signed ints. Also sets the value pointed to by pred to the value (a >= b).

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vibmax\_u16x2 (const unsigned int a, const unsigned int b, const bool \*pred\_hi, const bool \*pred\_lo)

Performs per-halfword max(a, b), also sets the value pointed to by pred\_hi and pred\_lo to the per-halfword result of  $(a \ge b)$ .

#### Returns

Returns computed values.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as unsigned shorts. For corresponding parts function performs a maximum ( = max(a\_part, b\_part)). Partial results are recombined and returned as unsigned int. Sets the value pointed to by pred\_hi to the value (a\_high\_part >= b\_high\_part). Sets the value pointed to by pred\_lo to the value (a\_low\_part >= b\_low\_part).

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vibmax\_u32 (const unsigned int a, const unsigned int b, const bool \*pred)

Computes max(a, b), also sets the value pointed to by pred to (a >= b).

## Returns

Returns computed values.

## Description

Calculates the maximum of a and b of two unsigned ints. Also sets the value pointed to by pred to the value (a >= b).

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vibmin\_s16x2 (const unsigned int a, const unsigned int b, const bool \*pred\_hi, const bool \*pred\_lo)

Performs per-halfword min(a, b), also sets the value pointed to by pred\_hi and pred\_lo to the per-halfword result of (a  $\leq$  b).

## Returns

Returns computed values.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs a maximum ( = max(a\_part, b\_part)). Partial results are recombined and returned as unsigned int. Sets the value pointed to by pred\_hi to the value (a\_high\_part <= b\_high\_part). Sets the value pointed to by pred\_lo to the value (a\_low\_part <= b\_low\_part).

\_\_host\_\_\_\_device\_\_ int \_\_vibmin\_s32 (const int a, const int b, const bool \*pred)

Computes min(a, b), also sets the value pointed to by pred to (a <= b).

#### Returns

Returns computed values.

## Description

Calculates the minimum of a and b of two signed ints. Also sets the value pointed to by pred to the value (a <= b).

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vibmin\_u16x2 (const unsigned int a, const unsigned int b, const bool \*pred\_hi, const bool \*pred\_lo)

Performs per-halfword min(a, b), also sets the value pointed to by pred\_hi and pred\_lo to the per-halfword result of (a  $\leq$  b).

### Returns

Returns computed values.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as unsigned shorts. For corresponding parts function performs a maximum ( = max(a\_part, b\_part)). Partial results are recombined and returned as unsigned int. Sets the value pointed to by pred\_hi to the value (a\_high\_part <= b\_high\_part). Sets the value pointed to by pred\_lo to the value (a\_low\_part <= b\_low\_part).

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vibmin\_u32 (const unsigned int a, const unsigned int b, const bool \*pred)

Computes min(a, b), also sets the value pointed to by pred to (a <= b).

## Returns

Returns computed values.

## Description

Calculates the minimum of a and b of two unsigned ints. Also sets the value pointed to by pred to the value (a  $\neq$  b).

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vimax3\_s16x2 (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword max(max(a, b), c).

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs a 3-way max ( = max(max(a\_part, b\_part), c\_part) ). Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vimax3\_s16x2\_relu (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword max(max(a, b), c), 0).

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs a three-way max with relu (= max(a\_part, b\_part, c\_part, 0)). Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ int \_\_vimax3\_s32 (const int a, const int b, const int c)

Computes max(max(a, b), c).

### Returns

Returns computed value.

## **Description**

Calculates the 3-way max of signed integers a, b and c.

\_\_host\_\_\_device\_\_ int \_\_vimax3\_s32\_relu (const int a, const int b, const int c)

Computes max(max(a, b), c), 0).

#### Returns

Returns computed value.

## Description

Calculates the maximum of three signed ints, if this is less than 0 then 0 is returned.

# \_\_host\_\_\_\_device\_\_ unsigned int \_\_vimax3\_u16x2 (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword max(max(a, b), c).

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as unsigned shorts. For corresponding parts function performs a 3-way max ( = max(max(a\_part, b\_part), c\_part) ). Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vimax3\_u32 (const unsigned int a, const unsigned int b, const unsigned int c)

Computes max(max(a, b), c).

#### Returns

Returns computed value.

## Description

Calculates the 3-way max of unsigned integers a, b and c.

\_\_host\_\_\_device\_\_ unsigned int \_\_vimax\_s16x2\_relu (const unsigned int a, const unsigned int b)

Performs per-halfword max(max(a, b), 0).

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs a max with relu ( = max(a\_part, b\_part, 0)). Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ int \_\_vimax\_s32\_relu (const int a, const int b)

Computes max(max(a, b), 0).

#### Returns

Returns computed value.

## Description

Calculates the maximum of a and b of two signed ints, if this is less than 0 then 0 is returned.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vimin3\_s16x2 (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword min(min(a, b), c).

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs a 3-way min ( = min(min(a\_part, b\_part), c\_part)). Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vimin3\_s16x2\_relu (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword max(min(min(a, b), c), 0).

## Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs a three-way min with

relu ( = max(min(a\_part, b\_part, c\_part), 0) ). Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ int \_\_vimin3\_s32 (const int a, const int b, const int c)

Computes min(min(a, b), c).

#### Returns

Returns computed value.

### Description

Calculates the 3-way min of signed integers a, b and c.

\_\_host\_\_\_\_device\_\_ int \_\_vimin3\_s32\_relu (const int a, const int b, const int c)

Computes max(min(min(a, b), c), 0).

#### Returns

Returns computed value.

## Description

Calculates the minimum of three signed ints, if this is less than 0 then 0 is returned.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vimin3\_u16x2 (const unsigned int a, const unsigned int b, const unsigned int c)

Performs per-halfword min(min(a, b), c).

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as unsigned shorts. For corresponding parts function performs a 3-way min ( = min(min(a\_part, b\_part), c\_part) ). Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vimin3\_u32 (const unsigned int a, const unsigned int b, const unsigned int c)

Computes min(min(a, b), c).

#### Returns

Returns computed value.

### Description

Calculates the 3-way min of unsigned integers a, b and c.

\_\_host\_\_\_\_device\_\_ unsigned int \_\_vimin\_s16x2\_relu
(const unsigned int a, const unsigned int b)

Performs per-halfword max(min(a, b), 0).

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. These 2 byte parts are interpreted as signed shorts. For corresponding parts function performs a min with relu ( = max(min(a\_part, b\_part), 0)). Partial results are recombined and returned as unsigned int.

\_\_host\_\_\_\_device\_\_ int \_\_vimin\_s32\_relu (const int a, const int b)

Computes max(min(a, b), 0).

#### Returns

Returns computed value.

## Description

Calculates the minimum of a and b of two signed ints, if this is less than 0 then 0 is returned.

# \_\_device\_\_ unsigned int \_\_vmaxs2 (unsigned int a, unsigned int b)

Performs per-halfword signed maximum computation.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes signed maximum. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vmaxs4 (unsigned int a, unsigned int b)

Computes per-byte signed maximum.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes signed maximum. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vmaxu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned maximum computation.

### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes unsigned maximum. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vmaxu4 (unsigned int a, unsigned int b)

Computes per-byte unsigned maximum.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes unsigned maximum. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vmins2 (unsigned int a, unsigned int b)

Performs per-halfword signed minimum computation.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes signed minimum. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vmins4 (unsigned int a, unsigned int b)

Computes per-byte signed minimum.

### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes signed minimum. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vminu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned minimum computation.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes unsigned minimum. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vminu4 (unsigned int a, unsigned int b)

Computes per-byte unsigned minimum.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes unsigned minimum. Partial results are recombined and returned as unsigned int.

# \_\_\_device\_\_\_ unsigned int \_\_\_vneg2 (unsigned int a)

Computes per-halfword negation.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of argument into 2 parts, each consisting of 2 bytes. For each part function computes negation. Partial results are recombined and returned as unsigned int.

# \_\_\_device\_\_ unsigned int \_\_\_vneg4 (unsigned int a)

Performs per-byte negation.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of argument into 4 parts, each consisting of 1 byte. For each part function computes negation. Partial results are recombined and returned as unsigned int.

# \_\_\_device\_\_ unsigned int \_\_\_vnegss2 (unsigned int a)

Computes per-halfword negation with signed saturation.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of argument into 2 parts, each consisting of 2 bytes. For each part function computes negation. Partial results are recombined and returned as unsigned int.

# \_\_\_device\_\_ unsigned int \_\_\_vnegss4 (unsigned int a)

Performs per-byte negation with signed saturation.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of argument into 4 parts, each consisting of 1 byte. For each part function computes negation. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vsads2 (unsigned int a, unsigned int b)

Performs per-halfword sum of absolute difference of signed.

#### Returns

Returns computed value.

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes absolute difference and sum it up. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vsads4 (unsigned int a, unsigned int b)

Computes per-byte sum of abs difference of signed.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes absolute difference and sum it up. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vsadu2 (unsigned int a, unsigned int b)

Computes per-halfword sum of abs diff of unsigned.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function computes absolute differences and returns sum of those differences.

# \_\_device\_\_ unsigned int \_\_vsadu4 (unsigned int a, unsigned int b)

Computes per-byte sum of abs difference of unsigned.

#### Returns

Returns computed value.

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function computes absolute differences and returns sum of those differences.

# \_\_device\_\_ unsigned int \_\_vseteq2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed comparison.

#### Returns

Returns 1 if a = b, else returns 0.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part == 'b' part. If both equalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vseteq4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed comparison.

#### Returns

Returns 1 if a = b, else returns 0.

## Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part == 'b' part. If both equalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetges2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison.

#### Returns

Returns 1 if a >= b, else returns 0.

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part >= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetges4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

#### Returns

Returns 1 if a >= b, else returns 0.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part >= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetgeu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned minimum unsigned comparison.

#### Returns

Returns 1 if  $a \ge b$ , else returns 0.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part >= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetgeu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

#### Returns

Returns 1 if a >= b, else returns 0.

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part >= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetgts2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison.

#### Returns

Returns 1 if a > b, else returns 0.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part > 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetgts4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

#### Returns

Returns 1 if a > b, else returns 0.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part > 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetgtu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison.

#### Returns

Returns 1 if a > b, else returns 0.

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part > 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetgtu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

#### Returns

Returns 1 if a > b, else returns 0.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part > 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetles2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned minimum computation.

#### Returns

Returns 1 if a <= b, else returns 0.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetles4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

#### Returns

Returns 1 if a <= b, else returns 0.

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetleu2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison.

#### Returns

Returns 1 if a <= b, else returns 0.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetleu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

#### Returns

Returns 1 if a <= b, else returns 0.

### Description

Splits 4 bytes of each argument into 4 part, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetlts2 (unsigned int a, unsigned int b)

Performs per-halfword signed comparison.

#### Returns

Returns 1 if a < b, else returns 0.

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetlts4 (unsigned int a, unsigned int b)

Performs per-byte signed comparison.

#### Returns

Returns 1 if a < b, else returns 0.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetltu2 (unsigned int a, unsigned int b)

Performs per-halfword unsigned comparison.

#### Returns

Returns 1 if a < b, else returns 0.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetltu4 (unsigned int a, unsigned int b)

Performs per-byte unsigned comparison.

#### Returns

Returns 1 if a < b, else returns 0.

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part <= 'b' part. If both inequalities are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetne2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed comparison.

#### Returns

Returns 1 if a != b, else returns 0.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs comparison 'a' part != 'b' part. If both conditions are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsetne4 (unsigned int a, unsigned int b)

Performs per-byte (un)signed comparison.

#### Returns

Returns 1 if a != b, else returns 0.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs comparison 'a' part != 'b' part. If both conditions are satisfied, function returns 1.

# \_\_device\_\_ unsigned int \_\_vsub2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed subtraction, with wrap-around.

#### Returns

Returns computed value.

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs subtraction. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vsub4 (unsigned int a, unsigned int b)

Performs per-byte subtraction.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs subtraction. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vsubss2 (unsigned int a, unsigned int b)

Performs per-halfword (un)signed subtraction, with signed saturation.

#### Returns

Returns computed value.

## Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs subtraction with signed saturation. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vsubss4 (unsigned int a, unsigned int b)

Performs per-byte subtraction with signed saturation.

#### Returns

Returns computed value.

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs subtraction with signed saturation. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vsubus2 (unsigned int a, unsigned int b)

Performs per-halfword subtraction with unsigned saturation.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 2 parts, each consisting of 2 bytes. For corresponding parts function performs subtraction with unsigned saturation. Partial results are recombined and returned as unsigned int.

# \_\_device\_\_ unsigned int \_\_vsubus4 (unsigned int a, unsigned int b)

Performs per-byte subtraction with unsigned saturation.

#### Returns

Returns computed value.

### Description

Splits 4 bytes of each argument into 4 parts, each consisting of 1 byte. For corresponding parts function performs subtraction with unsigned saturation. Partial results are recombined and returned as unsigned int.

# Chapter 2. Data Structures

Here are the data structures with brief descriptions:

```
__nv_fp8_e4m3
__nv_fp8_e4m3 datatype
_nv_fp8_e5m2
__nv_fp8_e5m2 datatype
_nv_fp8x2_e4m3
__nv_fp8x2_e4m3 datatype
_nv_fp8x2_e5m2
__nv_fp8x2_e5m2 datatype
_nv_fp8x4_e4m3
__nv_fp8x4_e4m3 datatype
_nv_fp8x4_e5m2
__nv_fp8x4_e5m2 datatype
```

# 2.1. \_\_nv\_fp8\_e4m3 Struct Reference

\_\_nv\_fp8\_e4m3 datatype

This structure implements the datatype for storing fp8 floating-point numbers of e4m3 kind: with 1 sign, 4 exponent, 1 implicit and 3 explicit mantissa bits. The encoding doesn't support Infinity. NaNs are limited to 0x7F and 0xFF values.

The structure implements converting constructors and operators.

Storage variable contains the fp8 floating-point data.

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const long long int val

Constructor from long long int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const cppOperationPrimitive: storage=int\_val

Constructor from int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const short int\_val

Constructor from short int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const unsigned long long int val

Constructor from unsigned long long int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const cppOperationPrimitive: storage=unsignedint\_val

Constructor from unsigned int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const unsigned short int\_val

Constructor from unsigned short int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const cppOperationPrimitive: storage=double f

Constructor from double data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const cppOperationPrimitive: storage=float f

Constructor from float data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const \_\_nv\_bfloat16 f

Constructor from \_\_nv\_bfloat16 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const half f

Constructor from \_\_half data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e4m3

\_\_nv\_fp8\_e4m3 cppOperationVisibility: visibility=public

Constructor by default.

# \_\_host\_\_\_device\_\_operator \_\_half ()

### Description

Conversion operator to half data type.

\_\_host\_\_\_device\_\_operator \_\_nv\_bfloat16 ()

### Description

Conversion operator to \_\_nv\_bfloat16 data type.

\_\_host\_\_\_device\_\_operator bool ()

### Description

Conversion operator to bool data type. +0 and -0 inputs convert to false. Non-zero inputs convert to true.

\_\_host\_\_\_device\_operator double ()

### Description

Conversion operator to double data type.

\_\_host\_\_\_\_device\_\_operator float ()

### Description

Conversion operator to float data type.

\_\_host\_\_\_device\_operator int ()

## Description

Conversion operator to int data type. NaN inputs convert to zero.

\_\_host\_\_\_device\_\_operator long long int ()

## Description

Conversion operator to long long int data type. NaN inputs convert to 0x800000000000000LL.

\_\_host\_\_\_device\_operator short int ()

## Description

Conversion operator to short int data type. NaN inputs convert to zero.

# host device operator signed char ()

### Description

Conversion operator to signed char data type. Clamps too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_operator unsigned char ()

### Description

Conversion operator to unsigned char data type. Clamps negative and too large inputs to the output range. NaN inputs convert to zero.

\_\_\_host\_\_\_\_device\_\_operator unsigned int ()

### Description

Conversion operator to unsigned int data type. Clamps negative inputs to zero. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_operator unsigned long long int ()

## Description

Conversion operator to unsigned long long int data type. Clamps negative inputs to zero. NaN inputs convert to 0x80000000000000ULL.

\_\_host\_\_\_device\_\_operator unsigned short int ()

### Description

Conversion operator to unsigned short int data type. Clamps negative inputs to zero. NaN inputs convert to zero.

2.2. \_\_nv\_fp8\_e5m2 Struct Reference

\_\_nv\_fp8\_e5m2 datatype

This structure implements the datatype for handling fp8 floating-point numbers of e5m2 kind: with 1 sign, 5 exponent, 1 implicit and 2 explicit mantissa bits.

The structure implements converting constructors and operators.

# \_\_nv\_fp8\_storage\_t \_\_nv\_fp8\_e5m2::\_\_x

Storage variable contains the fp8 floating-point data.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const long long int val

Constructor from long long int data type, relies on \_\_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const cppOperationPrimitive: storage=int\_val

Constructor from int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const short int\_val

Constructor from short int data type.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const unsigned long long int val

Constructor from unsigned long long int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const cppOperationPrimitive: storage=unsignedint val

Constructor from unsigned int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const unsigned short int\_val

Constructor from unsigned short int data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const cppOperationPrimitive: storage=double f

Constructor from double data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const cppOperationPrimitive: storage=float f

Constructor from float data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const \_\_nv\_bfloat16 f

Constructor from \_\_nv\_bfloat16 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

\_\_nv\_fp8\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const \_\_half f

Constructor from \_\_half data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8\_e5m2

nv fp8 e5m2 cppOperationVisibility: visibility=public

Constructor by default.

\_\_\_host\_\_\_\_device\_\_operator \_\_half ()

### Description

Conversion operator to half data type.

\_\_host\_\_\_device\_\_operator \_\_nv\_bfloat16 ()

### Description

Conversion operator to \_\_nv\_bfloat16 data type.

\_\_host\_\_\_device\_operator bool ()

### Description

Conversion operator to bool data type. +0 and -0 inputs convert to false. Non-zero inputs convert to true.

\_\_host\_\_\_\_device\_\_operator double ()

## **Description**

Conversion operator to double data type.

\_\_host\_\_\_device\_operator float ()

## Description

Conversion operator to float data type.

\_\_host\_\_\_device\_\_operator int ()

## Description

Conversion operator to int data type. Clamps too large inputs to the output range. NaN inputs convert to zero.

# \_\_host\_\_\_device\_\_operator long long int ()

### Description

Conversion operator to long long int data type. Clamps too large inputs to the output range. NaN inputs convert to 0x80000000000000LL.

\_\_host\_\_\_device\_\_operator short int ()

### Description

Conversion operator to short int data type. Clamps too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_device\_\_operator signed char ()

### Description

Conversion operator to signed char data type. Clamps too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_operator unsigned char ()

## Description

Conversion operator to unsigned char data type. Clamps negative and too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_operator unsigned int ()

## Description

Conversion operator to unsigned int data type. Clamps negative and too large inputs to the output range. NaN inputs convert to zero.

\_\_host\_\_\_\_device\_\_operator unsigned long long int ()

## Description

Conversion operator to unsigned long long int data type. Clamps negative and too large inputs to the output range. NaN inputs convert to 0x800000000000000000.

# \_\_\_host\_\_\_\_device\_\_operator unsigned short int ()

### Description

Conversion operator to unsigned short int data type. Clamps negative and too large inputs to the output range. NaN inputs convert to zero.

\_\_nv\_fp8x2\_e4m3 datatype

This structure implements the datatype for storage and operations on the vector of two £p8 values of e4m3 kind each: with 1 sign, 4 exponent, 1 implicit and 3 explicit mantissa bits. The encoding doesn't support Infinity. NaNs are limited to 0x7F and 0xFF values.

Storage variable contains the vector of two fp8 floating-point data values.

\_\_nv\_fp8x2\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const double2 f

Constructor from double2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_nv\_fp8x2\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const float2 f

Constructor from float2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8x2\_e4m3

\_\_nv\_fp8x2\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const \_\_nv\_bfloat162 f

Constructor from  $\_nv\_bfloat162$  data type, relies on  $\_nv\_SATFINITE$  behavior for out-of-range values.

\_\_nv\_fp8x2\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const \_\_half2 f

Constructor from \_\_half2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_nv\_fp8x2\_e4m3 cpp0perationVisibility: visibility=public

Constructor by default.

### Description

Conversion operator to \_\_half2 data type.

### Description

Conversion operator to float2 data type.

# 2.4. \_\_nv\_fp8x2\_e5m2 Struct Reference

\_\_nv\_fp8x2\_e5m2 datatype

This structure implements the datatype for handling two fp8 floating-point numbers of e5m2 kind each: with 1 sign, 5 exponent, 1 implicit and 2 explicit mantissa bits.

The structure implements converting constructors and operators.

Storage variable contains the vector of two fp8 floating-point data values.

\_\_nv\_fp8x2\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const double2 f

Constructor from double2 data type, relies on \_\_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8x2\_e5m2

\_\_nv\_fp8x2\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const float2 f

Constructor from float2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8x2\_e5m2

\_\_nv\_fp8x2\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const \_\_nv\_bfloat162 f

Constructor from \_\_nv\_bfloat162 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8x2\_e5m2

\_\_nv\_fp8x2\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const \_\_half2 f

Constructor from \_\_half2 data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8x2\_e5m2

nv fp8x2 e5m2 cppOperationVisibility: visibility=public

Constructor by default.

\_\_host\_\_\_device\_\_operator \_\_half2 ()

### Description

Conversion operator to half2 data type.

\_\_host\_\_\_\_device\_\_operator float2 ()

## Description

Conversion operator to float2 data type.

# 2.5. \_\_nv\_fp8x4\_e4m3 Struct Reference

\_\_nv\_fp8x4\_e4m3 datatype

This structure implements the datatype for storage and operations on the vector of four fp8 values of e4m3 kind each: with 1 sign, 4 exponent, 1 implicit and 3 explicit mantissa bits. The encoding doesn't support Infinity. NaNs are limited to 0x7F and 0xFF values.

Storage variable contains the vector of four fp8 floating-point data values.

## \_\_nv\_fp8x4\_e4m3

\_\_nv\_fp8x4\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const double4 f

Constructor from double4 vector data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8x4\_e4m3

\_\_nv\_fp8x4\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const float4 f

Constructor from float4 vector data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8x4\_e4m3

\_\_nv\_fp8x4\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const \_\_nv\_bfloat162 flo cppOperationConst: const=const \_\_nv\_bfloat162 fhi

Constructor from a pair of  $\_nv\_bfloat162$  data type values, relies on  $\_nv\_satfinite$  behavior for out-of-range values.

# \_\_nv\_fp8x4\_e4m3

\_\_nv\_fp8x4\_e4m3 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_device\_\_ cppOperationConst: const=const half2 flo cppOperationConst: const=const half2 flo

Constructor from a pair of \_\_half2 data type values, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_nv\_fp8x4\_e4m3 cppOperationVisibility: visibility=public

Constructor by default.

### Description

Conversion operator to float4 vector data type.

\_\_nv\_fp8x4\_e5m2 datatype

This structure implements the datatype for handling four fp8 floating-point numbers of e5m2 kind each: with 1 sign, 5 exponent, 1 implicit and 2 explicit mantissa bits.

The structure implements converting constructors and operators.

Storage variable contains the vector of four fp8 floating-point data values.

\_\_nv\_fp8x4\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const double4 f

Constructor from double4 vector data type, relies on \_\_\_NV\_SATFINITE behavior for out-of-range values.

\_\_nv\_fp8x4\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const float4 f

Constructor from float4 vector data type, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

# \_\_nv\_fp8x4\_e5m2

\_\_nv\_fp8x4\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const \_\_nv\_bfloat162 flo cppOperationConst: const=const \_\_nv\_bfloat162 fhi

Constructor from a pair of  $\_nv\_bfloat162$  data type values, relies on  $\_nv\_satfinite$  behavior for out-of-range values.

# \_\_nv\_fp8x4\_e5m2

\_\_nv\_fp8x4\_e5m2 cppOperationVisibility: visibility=public cppOperationInline: inline=inline cppConstructorExplicit: explicit=explicit \_\_host\_\_ \_\_device\_\_ cppOperationConst: const=const \_\_half2 flo cppOperationConst: const=const \_\_half2 fhi

Constructor from a pair of \_\_half2 data type values, relies on \_\_NV\_SATFINITE behavior for out-of-range values.

\_\_nv\_fp8x4\_e5m2 cppOperationVisibility: visibility=public

Constructor by default.

\_\_host\_\_\_device\_\_operator float4 ()

### Description

Conversion operator to float4 vector data type.

# Chapter 3. Data Fields

Here is a list of all documented struct and union fields with links to the struct/union documentation for each field:

```
_nv_fp8_e4m3()
  <u>nv fp8 e4m3</u>
__nv_fp8_e5m2()
  <u>nv fp8 e5m2</u>
__nv_fp8x2_e4m3()
  <u>nv_fp8x2_e4m</u>3
__nv_fp8x2_e5m2()
   nv fp8x2 e5m2
__nv_fp8x4_e4m3()
  __nv_fp8x4_e4m3
__nv_fp8x4_e5m2()
  __nv_fp8x4_e5m2
  <u>nv_fp8x2_e5m2</u>
  __nv_fp8x4_e5m2
  <u>nv fp8 e5m2</u>
   <u>nv fp8 e4m3</u>
   __nv_fp8x2_e4m3
   <u>nv_fp8x4_e4m3</u>
0
operator __half()
  <u>nv fp8 e5m2</u>
   <u>nv_fp8_e4m3</u>
operator __half2()
  <u>nv_fp8x2_e4m3</u>
   <u>nv_fp8x2_e5m2</u>
operator __nv_bfloat16()
   nv fp8 e5m2
```

nv fp8 e4m3 operator bool() <u>nv fp8 e4m3</u> nv fp8 e5m2 operator double() <u>nv fp8 e5m2</u> nv fp8 e4m3 operator float() <u>nv fp8 e5m2</u> nv\_fp8\_e4m3 operator float2() <u>nv\_fp8x2\_e5m2</u> nv fp8x2 e4m3 operator float4() \_\_nv\_fp8x4\_e4m3 nv fp8x4 e5m2 operator int() <u>nv fp8 e5m2</u> <u>nv fp8 e4m3</u> operator long long int() <u>nv fp8 e5m</u>2 <u>nv\_fp8\_e4m3</u> operator short int() <u>nv fp8 e5m2</u> <u>nv fp8 e4m3</u> operator signed char() <u>nv fp8 e5m2</u> <u>nv\_fp8\_e4m3</u> operator unsigned char() \_\_nv\_fp8\_e4m3 <u>nv fp8 e5m2</u> operator unsigned int() nv fp8 e5m2 <u>nv\_fp8\_e4m3</u> operator unsigned long long int() <u>nv fp8 e4m3</u> <u>nv\_fp8\_e5m2</u> operator unsigned short int() <u>nv fp8 e5m2</u> <u>nv fp8 e4m3</u>

#### Notice

This document is provided for information purposes only and shall not be regarded as a warranty of a certain functionality, condition, or quality of a product. NVIDIA Corporation ("NVIDIA") makes no representations or warranties, expressed or implied, as to the accuracy or completeness of the information contained in this document and assumes no responsibility for any errors contained herein. NVIDIA shall have no liability for the consequences or use of such information or for any infringement of patents or other rights of third parties that may result from its use. This document is not a commitment to develop, release, or deliver any Material (defined below), code, or functionality.

NVIDIA reserves the right to make corrections, modifications, enhancements, improvements, and any other changes to this document, at any time without notice.

Customer should obtain the latest relevant information before placing orders and should verify that such information is current and complete.

NVIDIA products are sold subject to the NVIDIA standard terms and conditions of sale supplied at the time of order acknowledgement, unless otherwise agreed in an individual sales agreement signed by authorized representatives of NVIDIA and customer ("Terms of Sale"). NVIDIA hereby expressly objects to applying any customer general terms and conditions with regards to the purchase of the NVIDIA product referenced in this document. No contractual obligations are formed either directly or indirectly by this document.

#### OpenCL

OpenCL is a trademark of Apple Inc. used under license to the Khronos Group Inc.

#### Trademarks

NVIDIA and the NVIDIA logo are trademarks or registered trademarks of NVIDIA Corporation in the U.S. and other countries. Other company and product names may be trademarks of the respective companies with which they are associated.

### Copyright

© 2007-2022 NVIDIA Corporation & affiliates. All rights reserved.

