Flexible Opensource BOard for Sidechannel analysis

 $FOBOS \ {\rm Version} \ 0.1$

Table of Contents

1	Flex	ible Opensource workBench fOr Sidechannel analysis - FOBOS	3
	1.1	Introduction and Motivation	3
	1.2	Previous Work	3
	1.3	Our Approach 5	ó
	1.4	Architecture of FOBOS	;
	1.5	FOBOS Data Analysis Module:)
	1.6	CPA Attack on AES using FOBOS	l
2	Mod	lule Descriptions	l
	2.1	FOBOS - Analysis Module	l
	2.2	FOBOS - Capture Module	L
	2.3	FOBOS - Other Functions	;

1 Flexible Opensource workBench fOr Sidechannel analysis - FOBOS

1.1 Introduction and Motivation

While a few FPGA boards designed for SCA exist, many research groups from academia and industry use their own hardware harness, their own software for data acquisition and data analysis and sometimes their own FPGA boards or generic FPGA boards. This increases the complexity and effort needed to obtain a working SCA setup. Another, but costly option is the use of commercial SCA workstations.

Due to the importance of the topic of side channel attacks, they became part of the curriculum of cryptography courses in many universities. However, only very few have associated laboratory exercises and hands-on examples due to the cost and complexity of current SCA setups.

To our knowledge no complete software package exists that contains everything needed for evaluating the side-channel attack resistance of FPGA implementations from data acquisition to analysis (see Sect:1.2). In this chapter, we are presenting a framework for efficient side-channel evaluation of cryptographic implementations on hardware and software. Such an environment should be flexible, open-source and low cost and beneficial to both research and educational communities.

1.2 Previous Work

SCA - Hardware Platforms The Side Channel Analysis Board (SCAB) introduced in [?], was one of the early efforts in developing evaluation platforms for conducting SCA attacks on implementations of cryptographic algorithms. This board housed an FPGA on which the cryptographic algorithms can be implemented along with an unrestricted access to power and clock pins to perform the following SCA attacks: Differential Power Analysis (DPA) and fault analysis. Information about the board design and the status of the project is currently not available.

The Side Channel Attack Standard Evaluation Board (SASEBO) [?], [?] was developed by the Research Center for Information (RCIS) of National Institute of Advanced Industrial Science and Technology (AIST) and Tohoku University as a common platform for evaluating side channel attacks. These boards were developed with the intent of performing side channel attacks on various hardware platforms like FPGAs, ASICs and Smart cards. SASEBO boards are designed with two FPGAs, a cryptographic FPGA (or an ASIC/Smart card) where the algorithm can be implemented and a control FPGA which directs the data flow between the software and the cryptographic FPGA. The data acquisition software which comes with SASEBO is written in C#. It does not provide support for different brands of oscilloscopes. Hence the user is required to tweak the code to provide support for his/her own oscilloscope. Only four different types of SASEBO boards with FPGAs as victims (shown in Table 1) are available.

Table 1. SASEBO boards with FPGAs as victims

				Wires	
Board	Control	Victin	n	${f Control}-$	Host Data
	FPGA	FPGA	Techn.	Victim	Communication
SASEBO	Virtex-2 Pro	Virtex-2 Pro	$130\mathrm{nm}$	54	RS232
SASEBO-G	Virtex-2 Pro	Virtex-2 Pro	$130\mathrm{nm}$	53	RS232, $FT245RL$ (USB)
SASEBO-GII	Spartan-3A	Virtex-5	$65\mathrm{nm}$	46	FT2232D (USB)
SASEBO-B	Stratix-2	Stratix-2	$90\mathrm{nm}$	53	RS232, FT245RL (USB)

Early this year, AIST announced that it discontinued support for the SASEBO project. Morita Tech [?] recently announced SAKURA as a successor to SASEBO project.

SCA - Data Analysis Platforms The DPA Contest [?] organized jointly by VLSI research group of Telecom ParisTech university and AIST, is an online-based contest with the aim of having a fair confrontation between different attack methodologies. Currently three editions of this contest were introduced of which the first two deal primarily with attacking DES (v1) and AES (v2) using different techniques where as the goal of the third edition is to compare acquisition platforms and techniques. The results for the third edition was recently announced at COSADE 2012. For the v1 & v2 editions, the acquired data was provided by the contest organizers where as in v3 only the RTL description of AES was provided. Data acquisition was left to the the participant choice. This contest provides a wealth of information regarding DPA statistical techniques, although all the data acquisition is obtained from SASEBO GII only.

The OpenSCA Toolbox [?] is an open source project which consists of set of Matlab codes and objects to perform DPA attacks. Using this toolbox one can conduct not only first order power analysis attacks but also the higher order and template attacks. The toolbox also comes with several examples, demonstrating the attacks. Currently the supported statistical testing procedures are Difference-of-Means, Correlation Power Analysis and Baysian analysis. All codes are written in Matlab and does not include data acquisition. In short, we can perform only data analysis using OpenSCA.

The DPA Workstation[™] [?] is a state-of-the art proprietary SCA testing platform by Cryptography Research, Inc. DPA Workstation[™]can perform data acquisition, processing and analysis and also has the ability to generate hypothesis models for a range of ciphers like AES, DES, RSA, ECC etc. It also provides support for data capture for a wide range of sampling devices like oscilloscopes and PCI A/D converters. Additionally, it supports multiple hardware platforms (FPGAs, SoC etc.) and different sensors (current, field probes) and hence both power and EM attacks can be performed using this workstation. The major

drawback is that this tool is not freely available and licensing is very costly, thus not usable for educational purposes. Also, collaborations between research groups are difficult as they might not all have access to the DPA Workstation $^{\top M}$.

Drawbacks of Current SCA Evaluation Platforms An efficient SCA evaluation platform should have the following criteria:

- Flexibility: Able to support multiple hardware platforms/technologies/vendors.
- Open Source: Community support will allow for rapid development and adoption of the latest devices and technologies.
- Reproducibility: Results published in research should be reproducible to obtain a fair SCA analysis of cryptographic algorithms.
- Broad-Spectrum Acceptance: Should be accepted by both educational (low-cost) and research/industry (state-of-the-art) communities.

We have shown in Sect. 1.2 and Sect. 1.2 that a complete (acquisition to analysis), free and open source solution is not available. Therefore, research groups and industry who do not want to invest in the proprietary DPA Workstation™employ home grown scripts, programs and platforms. Their main disadvantages are that they are mostly written in an ad-hoc fashion and therefore difficult to maintain and extend. These scripts and platforms are also proprietary and hence, their results are not reproducible by other research groups. SASEBO currently has limited hardware support. OpenSCA toolbox can perform data analysis only. The DPA contest provides information about different attack strategies only.

Hence there is a need for a flexible and complete open-source framework for SCA that allows fair and comprehensive evaluation of implementations on hardware platforms with reproducible results.

1.3 Our Approach

We call our framework for efficient side-channel evaluation of hardware platforms - FOBOS. This abbreviation stands for Flexible Open-sources workBench for Side-channel analysis. FOBOS, loosely named after the Greek god Phobos $(\phi\delta\beta\sigma\varsigma)$ who personifies fear and can pierce shields. FOBOS is designed to be an inexpensive side channel analysis setup that includes a complete software package with programs for victim control, data acquisition and data analysis. In order to evaluate side-channel leakage of hardware platforms, FOBOS uses off-the shelf FPGA boards as control and victim which are less expensive than the traditional setup. Thus, it enables universities to add active side channel analysis laboratory exercises to their cryptography classes. Furthermore, FOBOS is designed in a modular fashion to allow for a multitude of victim devices while maintaining the remainder of the setup, hence making FOBOS flexible. The FOBOS software package, documentation, and hardware components will be released as open-source for quick adaptation of newer technologies. Designers of cryptographic implementations and countermeasures against DPA and DEMA

on FPGAs can test their design techniques on FPGAs from various vendors and with different technologies. As the hardware and software are open source, the results are reproducible by researchers from different groups.




Fig. 1. Components of FOBOS

Figure 1 shows various components of FOBOS. It consists of the FOBOS Hardware as well as software for Data Acquisition and Control and Data Analysis. The FOBOS Hardware consists of two FPGA boards that are connected to each other. It is also possible to use the SASEBO GII board instead. The user has to provide the hardware description of the cipher under investigation, the key, a set of inputs and a power model. The Data Acquisition and Control module configures and controls the FOBOS Hardware and the Oscilloscope. It takes the user provided key and inputs and sends them to the FOBOS Hardware which in turn encrypts the inputs with the key and returns the outputs (i.e. ciphertext). As soon as the FOBOS Hardware starts with the encryption, it sends a trigger signal to start data acquisition of the oscilloscope. The Data Analysis module uses the user supplied power model, which can be based on inputs and/or outputs, and the power traces collected by the oscilloscope to recover the key.

1.4 Architecture of FOBOS

FOBOS has two parts, the *FOBOS Hardware* and the *FOBOS Software*. The following sections describe the functionality of various components of FOBOS.

FOBOS Hardware A schematic diagram of the FOBOS hardware is shown in Fig. 2. It consists of two boards *Victim Board & Control Board* connected together by the so called bridge connector. The cryptographic algorithms whose security needs to be evaluated are to be implemented on the FPGA of the Victim board. Data i.e. plaintext and/or key is sent from the PC via USB to the control FPGA, which then forwards the data to the Victim FPGA. After processing,




Fig. 2. Schematic Diagram of FOBOS Hardware

the Victim FPGA sends the results back to the Control FPGA which in turn forwards the results to the PC for verification. The control board also sends a trigger signal to the oscilloscope to capture power measurement data.

Control Board: The control board used by FOBOS is either a Nexys2 or a Nexys3 board. Table 2 shows details of the both boards. The control board contains several modules (see Fig. 2) and two clock domains. It uses the onboard 50 MHz oscillator as base clock for the USB communication. The second clock is generated through a clock divider circuit which uses the Digital Clock Managers (DCMs) to generate a clock in the range of 350 KHz ~ 50 MHz from the 50 MHz oscillator on board depending upon the user's choice and the oscilloscope specification. This clock is used for communication with the victim FPGA and also provided to the victim FPGA board.

Board	FPGA	Technology	Connector	PC-Control	Cost
Nexys 2	Spartan-3E	90 nm	Hirose FX2 (43)	USB2	\$149
Nexys 3	Spartan 6	45 nm	VHDC (40)	USB2	\$199

Table 2. FOBOS FPGA Control Boards

The control board receives commands from the PC and returns a status. This is facilitated through the 8-bit Command and Status registers. We use them to implement a simple protocol between PC and Control FPGA which is explained in Sect. 1.4.

The Trigger module generates a reference point from which the oscilloscope should start measuring the power consumption of the victim FPGA. Depending upon the user's requirement, this reference point can be set through a command to the beginning of the cryptographic operation or to specific clock cycle during the computation. This reference point is later used to perform signal alignment of several power traces.

A Timeout module makes sure that PC receives a status (of TIMEOUT) if an exception occurs during the communication with the victim or if the victim does not respond within a given time. This timeout value can be specified through a command. The timeout counter is automatically reset each time the victim returns data.

The Reset module is used to send a reset signal to the crypto core implemented on the victim FPGA depending upon the value specified by the user. This is useful if for example a cryptographic operation takes 1,000 clock cycles to complete, however, the interesting event happens in the 30th clock cycle. The user can then reset the victim automatically every 35 clock cycles and start a new encryption without having to wait for the encryption to complete.

Victim Board: We are investigating several FPGA boards available in the market, which can be used as Victim boards for FOBOS. Table 3 shows some potential Victim boards. The column " $V_{\rm Core}$ Jumper" indicates whether the board contains a jumper on the core power line which allows for by-passing the on board core power supply and inserting a current sensor (resistor or current probe) to measure the power consumption of the victim FPGA. So far, we have successfully used the Spartan 3E Starter Kit, Spartan 3E-1600 Developer Board, and the Altera DE1 board as FOBOS Victim boards. As the Altera DE1 does not have $V_{\rm Core}$ Jumper, we had to de-solder the voltage regulator for core voltage. On all boards we also removed several capacitors. Our preliminary investigation (shown in Table 3) into the other boards have shown that it is possible to modify them in order to measure the current of the core supply.

For each victim board we plan on publishing instructions on how to modify it for DPA and the printed circuit board (PCB) layout of the bridge connector which connects the victim board securely to the control board.

FOBOS Control-Victim Protocol The FOBOS Control-Victim Protocol uses a simple FIFO interface to transfer data to and from the control and victim FPGAs. The functionality of the input and output ports of the protocol is described in [?], [?]. All data and key to and from the FPGA is broken into segments. The first 2 bytes (16-bit) of each segment is a command word, which decides the nature of the segment and the number of bytes being sent. The format of the 16-bit command words is shown in Fig 3. A '0' value in the LSB and a '0' value in the MSB of the command word indicates that a key is being sent. Similarly a '1' value in the LSB indicates that data is send. The bit in position '1' indicates with a '0' that more segments are following the current one, a '1' indicates that the current segment is the last. The MSB bit value '1' for a 16-bit command for loading the key is left explicitly for future use. This protocol does not require the control board to know what the block size of the cryptographic function is. The widths of the buses for 'k' and data 'd' indicated in Fig 2 can be defined by the user according to the requirement of the cryptographic implementation.

Table 3. FOBOS FPGA victims

		Techn-	$ m V_{Core}$	
Board	FPGA	ology	Jumper	Cost
Spartan 3E Starter	Spartan-3E	90 nm	yes	\$159
Spartan 3E-1600 Dvlp.	Spartan-3E	$90\mathrm{nm}$	yes	\$225
Altera DE1	Cyclone-II	$90\mathrm{nm}$	no	\$150
Cyclone III Starter	Cyclone-III	$65\mathrm{nm}$	yes	\$199
Genesys Board	Virtex-5	$65\mathrm{nm}$	no	\$449
Altera DE2-115	Cyclone-IV	$60\mathrm{nm}$	no	\$299
Altys Board	Spartan-6	$45\mathrm{nm}$	no	\$199
Altera DE4	Stratix-IV	$40\mathrm{nm}$	no	\$2,995
Xilinx ML605	Virtex-6	$40\mathrm{nm}$	no	\$1,795
Xilinx KC705	Virtex-7	$28\mathrm{nm}$	no	\$1,695

FOBOS Software FOBOS Software Control Flow: The FOBOS control flow is shown in Fig. 4. The control script parses the configuration files and initializes the FOBOS environment. It performs a simple tool check to verify whether the necessary library files essential for data transfer and oscilloscope control are installed and only continues when the check passes successfully. The control script then assigns the hardware and oscilloscope attribute values as specified by the user in the configuration files. The FOBOS hardware then performs a built-in self test to check whether all the attributes are set accordingly and issues an appropriate status message to the control script. The status message can be a success or an error code. If the control receives an error code it exits the program displaying proper error message. On receiving a success code, the control script instructs the oscilloscope to digitize its analog inputs which then in turn waits for the trigger signal from the control board to start capturing data. The plaintext and the key are then transferred to the FOBOS hardware and the control script waits until it receives data from the oscilloscope. Once the oscilloscope data is captured, the control script writes the outputs from the FOBOS hardware to a file.

FOBOS has support for two data capturing modes, called *Single Capture* and *Multi Capture* to capture the power traces. Single Capture mode, as shown in Fig. 5a), assumes that a power trace contains a single encryption whereas Multi Capture mode, as shown in Fig. 5b), contains multiple encryptions per power trace. Once all data has been captured the control is transferred to data analysis module.

FOBOS PC- Control Communication Protocol: FOBOS uses the command & status registers to control the PC- Control communication. The command register is used (shown in Fig. 2) to pass the option values to the modules




Fig. 3. FOBOS Protocol

inside the control FPGA and to signal the control board that PC is ready to transmit the data. The status register (shown in Fig. 2) on the other hand, is used for signaling the PC that the control FPGA is ready to transmit the data obtained from victim FPGA or to report errors.

FOBOS Data Acquisition Module: The data acquisition module configures the oscilloscope and retrieves its data. Its behaviour is determined by a configuration file which uses a generic, oscilloscope brand independent description. A special, oscilloscope dependent sub-module translates the configuration file to commands which are oscilloscope specific. The sub-module of our prototype uses the Virtual Instrument Software Architecture (VISA) library which is a standard for configuring and programming instruments using a variety of interfaces. Presently, the FOBOS prototype supports communication for oscilloscopes from Agilent Technologies. In future we plan to provide support for oscilloscopes from other manufacturers.

1.5 FOBOS Data Analysis Module:

The Data Analysis module consists of 3 sub-modules as shown below:

- Signal Alignment Module
- Post processing Module
- SCA Module
- Statistics Module

Signal Alignment Module As the name indicates, the main function of this module is to align all the measured power traces with respect to time using a reference signal called the "Trigger" signal. Depending upon the type of capture mode used i.e. Single capture or Multi capture its functionality varies. In Single capture mode as each measurement trace contains only one encryption, the power traces are aligned when the "Trigger" signal becomes logic high. In the




Fig. 4. FOBOS Control Flow

Multi capture mode, as each measurement trace contains multiple encryptions, the start of each encryption is indicates by the Trigger signal. To be exact, the measurement point from one trigger high to the subsequent trigger high is equivalent to one encryption. The measurement module chops up the trace accordingly and aligns them.

Post processing Module Currently FOBOS supports three Post processing sub modules. They are:

- 1. Sample Space Disposition
- 2. Compression
- 3. Trace Expunge

Sample Space Disposition allows user to select a part of the trace to perform further post processing or to perform statistical testing. This also reduces computation time during statistical testing.

The parameters which facilitate this selection are "WINDOW START POINT" and "SAMPLE WINDOW SIZE". As shown in Fig 6 "WINDOW START POINT" parameter indicate which point in time to further sample the trace and the "SAMPLE WINDOW SIZE" parameter indicates the number of points to be sampled and stored to a new trace.

Compression allows user compress the power trace in chunks or as a whole depending upon the user requirement by using the "COMPRESSION LENGTH"




Fig. 5. Capture Modes

Fig. 6. Sample Space Disposition

parameter as shown in Fig 7 The user can also the type of compression to be used. They are:

- Max: Can compress the user specified sample size to the maximum of the given sample set.
- Min: Can compress the user specified sample size to the minimum of the given sample set.
- Mean: Can compress the user specified sample size to the average of the given sample set.

This also reduces computation time during statistical testing.

Trace Expunge allows user to selectively "expunge" or discard one or more traces depending upon two different selection criteria:

- Variance: User specifies Upper and Lower bound values. A given trace is removed if its variance (of the entire trace) is above upper limit or below lower limit.
- Standard Deviation: User specifies Upper and Lower bound values. A given trace is removed if its standard deviation (of the entire trace) is above upper limit or below lower limit.

This will help in removing traces which are heavily influenced by factors like measurement artefacts etc,.

SCA Module Currently FOBOS supports following Side-channel distinguishers:

- Pearson's r
- Spearman's RHO




Fig. 7. Compression




Fig. 8. Trace Expunge

Pearson's r We assume a linear relationship between the power consumption of the device and the data being processed. Hence we use Pearson product-moment correlation coefficient (r), commonly known as Pearson's correlation to correlate instantaneous power consumption with hamming distance model [?].

The Pearson's correlation (r) between the power consumption of the device P and the hypothetical power model H is given by the Eq. 1

$$r(P,H) = \frac{n\sum_{i}^{n} P_{i}H_{i} - \sum_{i}^{n} P_{i}\sum_{i}^{n} H_{i}}{\sqrt{n\sum_{i}^{n} P_{i}^{2} - (\sum_{i}^{n} P_{i})^{2}} \sqrt{n\sum_{i}^{n} H_{i}^{2} - (\sum_{i}^{n} H_{i})^{2}}}$$
(1)

Correlation Power Analysis (CPA) is a form of DPA where we use a different statistical test to obtain the secret key. Henceforth, we use the term DPA and CPA alternatively throughout this document.

Spearman Rank coefficient, on the other hand, is a measure of monotonic relationship between two variables, in this case between power consumption and power model. The Rank correlation between power consumption samples P and power consumption hypothesis samples G is given by

$$RHO(P,G) = 1 - \frac{6\sum_{i=1}^{n} d_i^2}{n(n^2 - 1)}$$
 (2)

where $d_i = P_i - G_i$, and P_i , G_i are ranks of the variables P and G

Statistics Module FOBOS currently supports following statistic functions.

- Mean: Calculates mean of the trace, both trace and sample wise, as shown in Fig 9.
- Standard Deviation : Calculates Standard Deviation of the trace, both trace and sample wise, as shown in Fig 9.
- Variance: Calculates Variance of the trace, both trace and sample wise, as shown in Fig 9.



Fig. 9. Trace wise vs Sample wise

1.6 CPA Attack on AES using FOBOS

This section describes a Correlation Power Analysis (CPA) attack of an implementation of the Advanced Encryption Standard (AES) [?] using FOBOS. AES is an symmetric-key cipher used extensively in security sensitive applications world wide. AES applies four different transformations, SubBytes, ShiftRows, MixColumns, and AddRoundKey, per round and iterates through several such rounds depending upon the key size. An intermediate key called "round key" is generated and used per round which is derived from the original key through a reversible key scheduling function. We have implemented a basic iterative architecture i of AES with 128-bit key length and 128-bit wide datapath requiring 11 clock cycles for one encryption. Key scheduling is done on-the-fly




Fig. 10. Block Diagram of the AES Core

and the SubBytes function is realized through look-up-tables. The block diagram for this design is shown in Fig. 10.

We attack our AES design during the first round at the output of the register FF1 indicated by Ap in Fig. 10. The equation for calculating the Hamming Distance (HD) is shown in 3. We use Pearson's Correlation to correlate the instantaneous power consumption with the HD model.

$$P_{est.} = \text{HD}(\text{SBOX}(CT_i), \text{SBOX}(k_{quess} \oplus PT_{i+1}))$$
 (3)

Fig. 11. AES Core with Wrapper on Victim FPGA

Figure 12 shows a snippet of hardware attributes specified in the FOBOS configuration file. FOBOS Control sends data from datain.txt and a key from keyin.txt, which are both in the format of ASCII coded Hexadecimal values, to the victim. A snapshot of these files is shown in Fig. 13. FOBOS Control sets the timeout to 30,000 clock cycles and the trigger to 4 clock cycles after processing starts. The victim clock is set to run at 500 KHz and the result will be stored in hexadecimal values in the file outputs.txt

```
DATA_FILE = datain.txt
KEY_FILE = keyin.txt
CLK_FREQ = 500 KHz
TIME_OUT = 30000
TRIGGER = 4
CAPTURE_MODE = multi
```

Fig. 12. Snippet of config.txt

```
2B 7E 15 16 28 AE D2 A6 AB F7 15 88 09 CF 4F 3C

. . . .

0A 59 8B A5 3D B3 0D B6 34 B2 C2 7E 98 A8 DB 71
2E 13 7A 5F E2 F9 86 C0 15 9A 69 AB 6E 3F 04 01
FB D0 09 43 E7 71 59 4A 15 37 53 33 A3 EF 74 1B
```

Fig. 13. Plaintext, Key & Ciphertext sent to FOBOS in hex format

A snippet of oscilloscope attributes from osc_config.txt file is shown in Fig. 14. The FOBOS control connects to the instrument specified by the VISA address from the RESOURCE attribute. The voltage ranges of the channels of the oscilloscope are specified in terms of vertical full-scale value in volts. The time range of the channels are specified in terms of horizontal full-scale value in seconds. In general oscilloscopes are configured in 8x10 graticule, therefore channel-1 range is 0.0125 Volts/div, channel-2 range is set to 2 Volts/div. The time range is set to 0.01 Sec/div. We also set the trigger source to be channel-2 and the condition on trigger to be positive edge.

```
RESOURCE = GPIBO::7::INSTR #Instrument Resource

CHANNEL_RANGE1 = 0.1V #Specified in Volts per screen

CHANNEL_RANGE2 = 16V #Specified in Volts per screen

TIME_RANGE = 0.001 #Specified in seconds per screen

TRIGGER_SOURCE = CHANNEL2

TRIGGER_MODE = EDGE

TRIGGER_SLOPE = POSITIVE
```

Fig. 14. Snippet of osc_config.txt

The FOBOS control sends the data from the oscilloscope i.e. the power traces, inputs, and outputs to the data analysis module. The first step involves processing the raw power trace using the preamble information to obtain the *measured_power_trace*. We use Multi Capture mode to obtain the Raw power trace.

We use the Signal alignment module to process and align the traces as shown in Fig. $15\,$




Fig. 15. Aligned Power Trace

The parameters used for the signal processing module is shown in Fig. 16.

Table of Contents

18

```
CAPTURE_MODE = MULTI # MULTI|SINGLE

TRIGGER_THRESHOLD = 1.8

TRACE_EXPUNGE_PARAMS = VAR:0.0000025:0.0000035

SAMPLE_WINDOW = 1000


WINDOW_START_POINT = 100

COMPRESSION_LENGTH = 40

COMPRESSION_TYPE = MAX
```

Fig. 16. Snippet of Signal Processing module Parameters

We perform Trace Expunge sub routine on the processed power traces using the parameters shown in Fig. 16. The resultant power trace is shown in Fig. 17



 ${\bf Fig.\,17.}$ Power Trace after Trace Expunge

We further process the resultant power trace using sample space disposition and compression using the parameters shown in Fig. 16. The resultant power traces are shown in Fig. 18 and Fig. 19




Fig. 18. Power Trace after Sample Space Disposition




Fig. 19. Power Trace after Compression

The CPA attack is conducted on a sub-byte of the key depending upon the user choice. Hence there are 256 different key guess values and correspondingly 9 different HD values i.e. $0 \to 8$. A snippet of the est_power_traces per key guess value is shown in Fig 20.

The sca module than calculates the Pearson's Correlation and Spearman's Rank correlation for all the key guesses by correlating the <code>est_power_traces</code> and <code>processed_power_trace</code>. Snippets of the output logs of the Pearson's and Spearman's Correlation are shown in Fig. 21 and Fig. 22 respectively.

```
      4 6 3 4 5 1 5 4 4 2 4 3 5 6 3 4 4 3 4 2 . . . .

      3 2 7 6 5 6 5 5 7 3 5 4 4 2 6 5 2 3 2 5 . . . .

      5 4 3 6 4 5 3 4 3 3 6 5 3 0 2 5 6 5 6 5 . . . .
```

Fig. 20. Hypothetical Power Model

```
Window[0] Key Byte- 0x5d [93] Correlation- 0.080
Window[1] Key Byte- 0x9c [156] Correlation- 0.078
Window[2] Key Byte- 0x9c [156] Correlation- 0.086
Window[3] Key Byte- 0x6 [6] Correlation- 0.086
Window[4] Key Byte- 0x16 [22] Correlation- 0.109
Window[5] Key Byte- 0x16 [22] Correlation- 0.175
Window[6] Key Byte- 0xa3 [163] Correlation- 0.087
Window[7] Key Byte- 0xd7 [215] Correlation- 0.082
```

Fig. 21. CPA using Pearson's r Log file

```
Window[0] Key Byte- 0x5d [93] Correlation- 0.082
Window[1] Key Byte- 0x9c [156] Correlation- 0.083
Window[2] Key Byte- 0x78 [120] Correlation- 0.109
Window[3] Key Byte- 0x6 [6] Correlation- 0.083
Window[4] Key Byte- 0x16 [22] Correlation- 0.105
Window[5] Key Byte- 0x16 [22] Correlation- 0.176
Window[6] Key Byte- 0xa3 [163] Correlation- 0.086
Window[7] Key Byte- 0xd7 [215] Correlation- 0.091
```

Fig. 22. CPA using Spearman's RHO Log file

The sca module also plots two graphs, called the Correlation Plot shown in Fig. 23 for Pearson's r and Fig. 24 for Spearman's RHO respectively. The correlation plot shows how well each individual key guess correlates with the power trace. The peak value of this plot indicates the correct sub-key byte.




Fig. 23. Results of Pearson's r




Fig. 24. Results of Spearman's RHO

2 Module Descriptions

2.1 FOBOS - Analysis Module

FOBOS's analysis module uses a set of python scripts to post process the raw measurement data obtained from the oscilloscope and perform analysis on the obtained data. Various functions implemented in the Analysis module is described below:

 ${\bf Table~4.~get} A ligned Measured Power Data~Function$

${\bf signal Analysis Module. get Aligned Measured Power Data}$				
Usage	signalAnalysisModule.getAlignedMeasuredPowerData()			
Inputs	None			
Outputs	M x N Numpy matrix that holds aligned traces. Where M is the number of traces and N is the number of samples per trace.			
Description	Reads aligned traces from the \$Workspace/\$projectName/\$attempt/Measurement directory and loads it to an M x N Numpy matrix. This function calls signal-AnalysisModule.readAlignedDataFromFile().			

 Table 5.
 readAlignedDataFromFile Function

	${\bf signal Analysis Module. read Aligned Data From File}$			
Usage	${\tt signalAnalysisModule.readAlignedDataFromFile()}$			
Inputs	None			
Outputs	M x N Numpy matrix that holds aligned traces. Where M is the number of traces and N is number of samples per trace.			
Description	Reads aligned data from file and returns M x N Numpy matrix.			

 ${\bf Table~6.~detectSampleSize~Function}$

	${\bf signal Analysis Module. detect Sample Size}$			
Usage	${\tt signalAnalysisModule.detectSampleSize(fileName)}$			
Inputs	Aligned traces file name.			
Outputs	Number of samples in a trace.			
Description	Reads the first 10 traces and returns the number of samples in the largest trace. If the number of traces is less than 10 all traces are read. This is done to be able to adjust all traces to the same number of samples if some do not have the same size due to acquisition timing.			

 ${\bf Table~7.}~{\bf adjustSampleSize~Function}$

	${\bf signal Analysis Module. adjust Sample Size}$				
Usage	signalAnalysisModule.adjustSampleSize(sampleLength, dataArray)				
Inputs	 sample length to adjust to. N x 1 nympy array that represents one trace where N is the number of samples in the trace. 				
Outputs	Sample Lenght x 1 Numpy array that represents the adjusted trace.				
Description	Used to modify the number of samples in a trace. If the number of samples is less than SampleLength, the array is padded with zeros. If the number of samples is more than SampleLength, the array is truncated. The function does nothing if the number of samples is equal to SampleLength.				

 ${\bf Table~8.}~{\it acquire Power Model~Function}$

Usage	${\tt signalAnalysisModule.acquirePowerModel~(HyptheticalDataFileName,global)}$	bals.ADAPTIVE_CPA)
Inputs	Power model file nameCorrelation type	
Outputs	$\rm M~x~N$ Numpy array that holds the hypothetical power traces. Where N is the number of encryptions/decryptions and M is the number of key guesses.	
Description	Reads the hypothetical power data from file in $fobos/data$. Returns M x N Numpy array that holds the hypothetical power traces. Where N is the number of encryptions/decryptions and M is the number of key guesses.	

 $\textbf{Table 9.} \ \, \textbf{updatePowerModelUsingBCPA Function} \ \, \textbf{***********revise}$

	${\bf signal Analysis Module. update Power Model Using BCPA}$		
Usage signalAnalysisModule.updatePowerModelUsingBCPA(array1, array2, rowA)			
Inputs	- Array1 - Array2 - rowA		
Outputs			
Description	${\bf Called\ from\ signal Analysis Module. acquire Power Model ()}.$		

 ${\bf Table~10.}~{\bf compute Aligned Data~Function}$

	${\bf signal Analysis Module. compute Aligned Data}$
Usage	signalAnalysisModule.computeAlignedData(powerData, triggerData)
Inputs	 N x 1 Numpy array that holds measured power data. Where N is the number of samples. N x 1 Numpy array that holds trigger power data. Where N is the number of samples.
Outputs	Aligned power trace (K x 1 Numpy array where K is the number of samples).
Description	Uses powerData and triggerData to generate the aligned trace. The function looks for the rising edge of the trigger signal to determine the start of the trace.

 ${\bf Table~11.}~{\bf correlation_pearson~Function}$

	${f sca.correlation_pearson}$
Usage	sca.correlation_pearson(measuredPowerData, hypotheticalPowerData)
Inputs	 M x N Numpy matrix for power traces. Where M is the number of encryptions/decryptions, N the number of samples per trace. L x M array the represents the hypothetical power values. Where M is the number of encryptions/decryptions and L is the number of key guesses (i.e for byte guess, L=256).
Outputs	N x L Numpy correlation matrix where N is the number of samples per trace.
Description	Calculates Pearson correlation between the hypothetical data and measured data. Returns an N x L correlation matrix. When we guess byte values L = 256.

 $\textbf{Table 12.} \ \operatorname{findMinimumGuessingEntropy} \ \operatorname{Function}^{********} \operatorname{revise}$

	${\bf sca. find Minimum Guessing Entropy}$	
Usage	${\tt signalAnalysisModule.computeAlignedData(measuredPowerData,} \\ {\tt triggerData)}$	
Inputs	measured power data.hypotheticalPowerData.	
Outputs		
Description		

Table 13. calculate_autocorrelation Function ***** revise

${f sca. calculate_autocorrelation}$	
Usage	${\tt sca.calculate_autocorrelation(alignedData)}$
Inputs	M x N Numpy matrix that holds aligned power data. Where M is the number of traces and N is the number of samples per trace.
Outputs	
Description	

Table 14. plotTrace Function

	plottingModule.plotTrace	
Usage	<pre>plottingModule.plotTrace(dataToPlot, traceNos, plotType)</pre>	
Inputs	 M x N Numpy matrix that holds traces to plot. Where M is the number of traces and N is the number of samples. Trace number Plot type per trace. The traces to be plotted. 	
Outputs	None	
Description	Plots the traces represented by the Numpy matrix. The x-axis represents time and the y-axis represents voltage.	

Table 15. plotHist Function

	${\it plotting Module.plot Hist}$	
Usage	plottingModule.plotHist(corrMatrix, corrType)	
Inputs	 M x N Correlation Numpy matrix. Correlation type. 	
Outputs	None	
Description	Plots a histogram. The x-axis represents the key guess and the y-axis represenst the number of occurrences.	

Table 16. plotCorr Function

${\it plotting} {\it Module.plotCorr}$	
Usage	plottingModule.plotCorr(corrMatrix, corrType)
Inputs	 M x N Numpy correlation matrix Correlation type
Outputs	None
Description	Plots correlation data.

Table 17. sampleSpaceDisp Function

${\bf postProcessingModule.sampleSpaceDisp}$	
Usage	${\tt postProcessingModule.sampleSpaceDisp(alignedData)}$
Inputs	$M \times N$ Numpy matrix that holds aligned data. Where M is the number of traces and N is the number of samples per trace.
Outputs	${\bf M}$ x Window_Size Numpy array that holds the aligned data after removing samples
Description	Removes samples before WINDOW_START and after WINDOW_START $+$ WINDOW_SIZE - 1 from each trace.

 ${\bf Table~18.~compressData~Function}$

compressData	
Usage	compressData(measuredPowerData)
Inputs	$M \ge N$ Numpy array that represents traces. Where M is the number of traces and N is the number of samples per trace.
Outputs	M x K Numpy array that represents compressed traces. Where M is the number of traces and $K = \frac{N}{COMPRESSION_LENGTH}$.
	Summarizes COMPRESSION_LENGTH samples into one sample. The summarization type depends on the COMPRESSION_TYPE configuration parameter which can be MEAN, MIN or Max.

Table 19. compress Function

${\bf postProcessing Module. compress}$	
Usage	<pre>postProcessingModule.compress (a, compressionLenght, compressionType)</pre>
Inputs	 M x N Numpy array that represents traces. Where M is the number of traces and N is the number of samples per trace. Number of samples to compress into one sample. Compression type.
Outputs	M x K Numpy array that represents compressed traces. Where M is the number of traces and $K = \frac{N}{COMPRESSION_LENGTH}$.
Description	This function is called by postProcessingModule.compressData() to do the compression.

 ${\bf Table~20.}~{\bf trace Expunge~Function}$

	${\it postProcessingModule.traceExpunge}$	
Usage	${\tt postProcessingModule.traceExpunge(measuredPowerData)}$	
Inputs	$M \ge N$ Numpy array that represents traces. Where M is the number of traces and N is the number of samples per trace.	
Outputs	L x N Numpy array that represents traces after removing the traces that do not fall in acceptable range. Where L is the number of traces and N is the number of samples per trace.	
Description	Removes traces that do not fall in acceptable range.	

2.2 FOBOS - Capture Module

The Capture module is used to run encryptions on hardware and capture traces from the ocsilloscope.

 ${\bf Table~21.~open Oscilloscope Connection~Function}$

$Oscilloscope_core.openOscilloscopeConnection$	
Usage	Oscilloscope_core.openOscilloscopeConnection()
Inputs	None
Outputs	None
Description	Connects to oscilloscope. It opens a socket using the IP address OSCILLOSCOPE_IP and port number OSCILLOSCPOE_PORT. Also gets the oscilloscope identifier.

Table 22. setOscilloscopeConfigAttributes Function

$Oscilloscope_core.set Oscilloscope Config Attributes$	
Usage	Oscilloscope_core.setOscilloscopeConfigAttributes()
Inputs	None
Outputs	None
Description	Configures the oscilloscope by sending commands (in text format) to the oscilloscope.

Table 23. initializeOscilloscopeDataStorage Function

$Oscilloscope_core.initialize Oscilloscope Data Storage$	
Usage	Oscilloscope_core.initializeOscilloscopeDataStorage()
Inputs	None
Outputs	None
Description	Creates empty Numpy arrays for each enabled oscilloscope channel.

Table 24. armOscilloscope Function

Oscilloscope_core armOscilloscope	
Usage	Oscilloscope_core.armOscilloscope()
Inputs	None
Outputs	None
Description	Instructs the oscilloscope to digitize channels specified in FOBOS configuration.

 ${\bf Table~25.~populateOscilloscopeDataStorageAndAlign~Function}$

$Oscilloscope_core.populateOscilloscopeDataStorageAndAlign$	
Usage	Oscilloscope_core.populateOscilloscopeDataStorageAndAlign(traceCount
Inputs	The number of current trace.
Outputs	None
Description	Reads power data trace from oscilloscope and trigger signal trace. It then aligns the trace to the trigger signal and saves the aligned trace to file.

Table 26. closeOscilloscopeConnection Function

$Oscilloscope_core.close Oscilloscope Connection$	
Usage	Oscilloscope_core.closeOscilloscopeConnection()
Inputs	None
Outputs	None
Description	Closes socket that connects to oscilloscope.

 ${\bf Table~27.~open} Control Board Connection~Function$

$Oscilloscope_core.openControlBoardConnection$	
Usage	${\tt usbcomm_core.openControlBoardConnection()}$
Inputs	None
Outputs	None
Description	Initializes connection to control board, resets control board and reads control board and victim clocks.

Table 28. initializeControlBoardConnection Function

${\bf usbcomm_core.initialize Control Board Connection}$	
Usage	usbcomm_core.initializeControlBoardConnection()
Inputs	None
Outputs	None
Description	Initializes the USB connection to the board. Called from $\operatorname{OpenControlBoard-Connection}().$

Table 29. sendTriggerParamsToControlBoard Function

${\bf usbcomm_core.sendTriggerParamsToControlBoard}$	
Usage	usbcomm_core.sendTriggerParamsToControlBoard()
Inputs	None
Outputs	None
Description	Sends the trigger parameters to the control boards. Parameters are: TRIGGER_WAIT_CYCLES and TRIGGER_LENGTH_CYCLES.

 ${\bf Table~30.}~{\bf runEncrytionOnControlBoard~Function}$

${\bf usbcomm_core.runEncrytionOnControlBoard}$	
Usage	${\tt usbcomm_core.runEncrytionOnControlBoard(traceCount)}$
Inputs	The number of block used in encryption.
Outputs	None
Description	Sends a block of data to control board to do encryption. The key is sent before sending the frist block.

 ${\bf Table~31.}~{\bf send Key To Control Board~Function}$

${\bf usbcomm_core.send Key To Control Board ()}$		
Usage	usbcomm_core.sendKeyToControlBoard()	
Inputs	None	
Outputs	None	
Description	Sends the key to control board. This function is called from usb-comm_core.runEncrytionOnControlBoard().	

 ${\bf Table~32.}~{\rm sendBlockOfDataToControlBoard~Function}$

$usbcomm_core.sendBlockOfDataToControlBoard$	
Usage	<pre>usbcomm_core.usbcomm_core.sendBlockOfDataToControlBoard (traceCount)</pre>
Inputs	The number of block used in encryption
Outputs	None
Description	Sends a block of data to the control board. This function is called from usb-comm_core.runEncrytionOnControlBoard().

 ${\bf Table~33.}~{\bf save Control Board Output Data Storage~Function$

$usbcomm_core_core.s ave Control Board Output Data Storage$	
Usage	Oscilloscope_core.saveControlBoardOutputDataStorage()
Inputs	None
Outputs	None
Description	Saves output from control board (cipher text) to file. File is stored in $\$ workspace/\$projectName/\$attempt/output/

2.3 FOBOS - Other Functions

Here we list helper functions that are used by the Analysis and Capture modules.

Table 34. getKeyForAnalysis Function

${\rm data Generator. get Key For Analysis}$	
Usage	dataGenerator.getKeyForAnalysis()
Inputs	None
Outputs	Key formated as a list of hexadecimal bytes.
Description	Reads the key from file in \$Workspace/\$project/\$attempt/output/ directory.

Table 35. getPlainText Function

${\bf data Generator. get Plain Text}$	
Usage	dataGenerator.getPlainText()
Inputs	None
Outputs	A list of blocks that represents plain text.
Description	Generates random plain text or reads from file depending on configuration. Plain text file is located in \$fobos/\$sources/ directory.

Table 36. generateRandomKey Function

dataGenerator.generateRandomKey	
Usage	dataGenerator.generateRandomKey()
Inputs	None
Outputs	A list of key bytes. Each byte is represented as a hexadecimal string.
Description	Generates a random key in hexadecimal format. Key size is read form the KEY_SIZE configuration parameter.

 Table 37.
 convertToHex Function******revise

dataGenerator.convertToHex	
Usage	dataGenerator.convertToHex(hexString)
Inputs	Hexadecimal string
Outputs	
Description	

Table 38. configureWorkspace Function

${\bf configExtract.configure Workspace()}$	
Usage	configExtract.configureWorkspace()
Inputs	None
Outputs	None
Description	Creates the project directory in the workspace and creates directories to store measured power data, cipher text and plain text etc. It also copies some configuration files and other files into the project directory.

Table 39. extractConfigAttributes Function

${\bf configExtract.extractConfigAttributes()}$	
Usage	<pre>configExtract.extractConfigAttributes()</pre>
Inputs	None
Outputs	None
Description	Reads the main configuration file to get configuration attributes. It also reads the acquisition configuration file and extracts configuration attributes.

 Table 40. updatePowerAndTriggerFileNames Function

${\bf configExtract.update Power And Trigger File Names}$	
Usage	<pre>configExtract.updatePowerAndTriggerFileNames()</pre>
Inputs	None
Outputs	None
Description	Checks for the existance of measured data files and trigger data file and sets variables to the file names.

Table 41. configureAnalysisWorkspace Function

${\bf configExtract.configure Analysis Work space}$	
Usage	configExtract.configureAnalysisWorkspace()
Inputs	None
Outputs	None
Description	Configures the analysis workspace directory by creating directories to store analysis results and copies configuration files.

40 Table of Contents

 ${\bf Table~42.}~{\bf extractAnalysisConfigAttributes~Function}$

${\bf configExtract.extractAnalysisConfigAttributes}$	
Usage	configExtract.extractAnalysisConfigAttributes(fileName)
Inputs	Configuration file name.
Outputs	None
Description	Reads the file provided and gets configuration attributes. Also, copies the file to the projects local configuration directory for future reference.

Table 43. goToSleep Function

${\bf support.goToSleep}$	
Usage	<pre>support.goToSleep(value)</pre>
Inputs	Time to sleep in seconds.
Outputs	None
Description	Sleep for number of seconds.

 Table 44. exitProgram Function

${\rm support.exit Program}$	
Usage	<pre>support.exitProgram()</pre>
Inputs	None
Outputs	None
Description	Self-explanatory

Table 45. wait Function

support.wait	
Usage	support.wait()
Inputs	None
Outputs	None
Description	Waits for the user to press Enter to continue program execution.

Table 46. clear_screen Function

support.clear_screen	
Usage	support.clear_screen()
Inputs	None
Outputs	None
Description	Self-explanatory.

Table 47. convertToByteArray Function

${\bf support.convert To By te Array}$	
Usage	<pre>support.convertToByteArray(hexString)</pre>
Inputs	Hexadecimal string
Outputs	A byte array
Description	Converts a hexadecimal string to a byte array.

Table 48. array To
String Function

support.arrayToString(array)		
Usage	support.arrayToString(array)	
Inputs	Array to convert	
Outputs	A string that consist of array elements	
Description	Self-explanatory.	

Table 49. readFile Function

$\operatorname{support.readFile}$		
Usage	<pre>support.readFile(fileName)</pre>	
Inputs	File name	
Outputs	A string that holds file content.	
Description	Self-explanatory.	

Table 50. removeFile Function

${\bf Support.removeFile}$		
Usage	Support.removeFile(fileName)	
Inputs	File name	
Outputs	None	
Description	Self-explanatory.	

 Table 51. removeComments Function

${\bf Support.remove Comments (data list)}$		
Usage	Support.removeComments(datalist)	
Inputs	Data list	
Outputs	???	
Description	Removes comments (anything after a '#' sign) from a list of strings.	