- This homework assignment is not graded.
- You are encouraged to work in groups, and to use the Internet or any other tools available to learn the material in order to answer these questions.

In class, we talked about memory mapped I/O. In memory mapped I/O, peripherals are accessed by writing to certain addresses in memory, using the same instructions as for other memory access.

As embedded systems engineers, you may not always have the luxury of accessing GPIO peripherals using well-documented, mature libraries for popular microcontrollers. You may be asked to design a new embedded system, to write firmware libraries for accessing GPIO on a new embedded system, or to use poorly documented in-house libraries for accessing GPIO. The aim of this homework, therefore, is to help you gain a deeper understanding of how memory mapped I/O works so that you will be capable not only of using GPIO libraries, but also writing and documenting them.

- 1. Please refer to the Cortex M-4 Technical Reference Manual and the STM32F4 Discovery Reference Manual (given on website) to answer this question.
 - (a) Section 3.4 in the Cortex M-4 Technical Reference Manual defines the memory map for this processor. What range of memory addresses is reserved for use by peripherals?

Solution: 0x40000000 - 0x60000000

(b) Section 2.3 of the STM32F4 Discovery Reference Manual further defines the memory used by each individual peripheral. The GPIO peripherals are listed by port (GPIOA, GPIOB, GPIOC, GPIOD, etc.). What is the address range used by the GPIOD port?

Solution: 0x40020C00 - 0x40020FFF

- (c) On the STM32F4 Discovery board, each GPIO pin gets some dedicated configuration and data registers. These are described in Section 8, and especially Section 8.4, of the STM32F4 Discovery Technical Reference Manual. Please answer these questions for the following registers: MODER, OTYPER, OSPEEDR, PUPDR, IDR, ODR, and BSRR. For the BSRR register, you should further subdivide into BSRRL (BSRR low, used for bit set) and BSRRH (BSRR high, used for bit reset).
 - The functionality of the register; what is it used for (in one sentence)?
 - How much memory is used by this register for the entire port (typically 32 bits 4 bytes or 16 bits 2 bytes)? How much memory is used for each individual pin (typically 2 bits or 1 bit)?
 - What is the address offset of this register? The address offset, together with the port address, tells us exactly where in memory the register is located. For example, if the address offset of a register is 0x02 and the port uses the memory range 0x40022800 0x40022BFF, then the register is at address 0x40022800 + 0x02 = 0x40022802.

Solution:

MODER

- Use: configure the I/O direction mode (e.g., input, output)
- Uses 32 bits total, 2 bits for each pin
- Address offset: 0x00

OTYPER

- Use: configure the output type of the I/O port (push-pull or open drain)
- Uses 32 bits total. However, the top 16 bits are reserved. 1 bit is used for each pin
- Address offset: 0x04

OSPEEDR

- Use: configure the configure the I/O output speed
- Uses 32 bits total. 2 bits are used for each pin
- Address offset: 0x08

PUPDR

- Use: configure the I/O to use a pull-up or pull-down resistor
- Uses 32 bits total. 2 bits are used for each pin
- Address offset: 0x0C

IDR

- Use: read port input data
- Uses 32 bits total. However, the top 16 bits are reserved. 1 bit is used for each pin
- Address offset: 0x10

ODR

- Use: write port output data
- Uses 32 bits total. However, the top 16 bits are reserved. 1 bit is used for each pin
- Address offset: 0x14

BSRRL

- Use: set bit with atomic operation
- \bullet Uses 16 bits total. 1 bit is used for each pin
- \bullet Address offset: 0x18

BSRRH

- Use: reset bit with atomic operation
- Uses 16 bits total. 1 bit is used for each pin
- Address offset: 0x1a

2. This is a continuation of the previous question. Now that we know exactly where in memory each register is located, we can write C code to access these memory locations.

When you define a structure in C, the memory for elements of the structure will be laid out in the same order in which you defined them. Given that the registers are located sequentially in memory, we can use a structure in C to map registers to human readable names.

(a) We will use a GPIO_TypeDef struct to map memory for GPIO registers to human readable names. Here's a template, showing the struct definition and also how we define GPIOD using the struct:

```
typedef struct
{
...
} GPIO_TypeDef;

#define GPIOD_BASE (OxAAAAAAAA) // insert correct memory address here
#define GPIOD ((GPIO_TypeDef *) GPIOD_BASE)
```

Inside the typedef, we will add a line for each register that defines its total size for the entire port (32 bits - uint32_t - or 16 bits - uint16_t), its name, and a comment giving its functionality. In order to make sure the struct element is located at the correct memory offset, we need to make sure to define them *in order*. We will also define each element as volatile, to signal to the compiler that they may be modified outside of our code (e.g., by peripherals) and shouldn't be optimized away.

For example, the MODER register occupies 32 bits, and is located at an address offset of 0x00 (see 8.4.1 of the Technical Reference Manual). So we have to define it as the first element of the structure, and as a uint32_t. After adding MODER, our typedef would look like this:

and we would be able to access the GPIOD MODER register as GPIOD->MODER.

(b) Please fill out the following C template. Add an element to the structure for each of: MODER, OTYPER, OSPEEDR, PUPDR, IDR, ODR, BSRRL, and BSRRH. Also, set the correct value for the GPIOD_BASE address based on your answer to question 1(b).

```
Solution:
typedef struct
 volatile uint32_t MODER;
                             // mode register, offset: 0x00
                             // output type register, offset: 0x04
 volatile uint32 t OTYPER;
 volatile uint32_t OSPEEDR; // output speed register, offset: 0x08
 volatile uint32 t PUPDR;
                             // pull-up/pull-down register, offset: 0x0C
                             // input data register, offset: 0x10
 volatile uint32_t IDR;
 volatile uint32 t ODR;
                             // output data register, offset: 0x14
 volatile uint16 t BSRRL; // bit set/reset low register, offset: 0x18
 volatile uint16 t BSRRH;
                             // bit set/reset high register, offset: 0x1A
} GPIO_TypeDef;
#define GPIOD_BASE
                      (0x40020C00)
#define GPIOD
                      ((GPIO_TypeDef *) GPIOD_BASE)
```

Note that the elements *must* be defined in the right order and be the right sizes so that they will be located at the right memory location (based on the offset defined in the datasheet). For example, given the definition above:

- The struct begins at the memory location defined with GPIOD_BASE, 0x40020C00.
- The first element in the struct is at that memory location + 0x00 offset. So when we write to GPIOD->MODER, we are writing to the memory location 0x40020C00.
- The second element in the struct (OTYPER) is at 0x40020C00 + the additional bytes used by the MODER register. Since MODER is defined to use 32 bits (4 bytes), OTYPER will be at 0x40020C00 + 0x04 offset = 0x40020C04
- The third element in the struct (PUPDR) is at 0x40020C00 + the additional bytes used by the previous elements, the MODER and OTYPER registers. Since MODER and OTYPER are both defined to use 32 bits (4 bytes), 8 bytes total, PUPDR will be at 0x40020C00 + 0x08 offset = 0x40020C08
- Following a similar procedure, you can see that all of the struct elements will be located at the correct memory addresses. (Note that some elements are defined as 16 bits).

If you look in stm32f4xx.h you'll see a similar struct definition. So now we've learned how to write a basic GPIO peripheral driver, using just the datasheet for reference.

(c) Which element(s) of the struct do you think you might declare as a volatile const instead of just a volatile? Why?

Solution: We might declare IDR as volatile const because it should be read-only to us (we never write to an input data register).

(d) Do we need to use malloc() in C to allocate memory for GPIOD? Why or why not?

Solution: No, we do not need to use malloc() to allocate memory for GPIOD (and shouldn't). malloc() is used to allocate memory dynamically on the heap (this memory will be in SRAM, which is located at memory addresses starting at 0x20000000).

We are using memory in the peripherals address range (starting at 0x4000000). We don't want memory on the heap/in SRAM. We explicitly define our pointers to use the correct memory addresses, in the peripherals range.

- (e) Please answer these questions for the following registers: MODER, OTYPER, OSPEEDR, PUPDR, IDR, ODR, BSRRL, and BSRRH:
 - For all registers except IDR, write a line of C code that assigns the value '1' to this register for pin 3 of the GPIOD port, without affecting the values set for any other pins. For examples, see pages 12 and 14 of the lecture slides on peripherals.
 - For all registers except IDR, write a line of C code that assigns the value '1' to this register for all pins on the GPIOD port.
 - What does setting a value of '1' do on this register?

```
Solution: To set values only for pin 3:
// To reliably set '01' in a *two-bit* register, we have to
// clear the bits (or at least, the bit on the left)
// and then set the bit on the right to 1
// MODER has two bits per pin
GPIOD->MODER &= \sim (3 << 2*3);
GPIOD->MODER \mid= 1 << 2*3;
// OTYPER has one bit per pin
GPIOD->OTYPER |= 1 << 3;
// OSPEEDR has two bits per pin
GPIOD->OSPEEDR &= \sim(3 << 2*3);
GPIOD->OSPEEDR |= 1 << 2*3;
// PUPDR has two bits per pin
GPIOD->PUPDR &= \sim (3 << 2*3);
GPIOD->PUPDR \mid= 1 << 2*3;
// ODR has one bit per pin
GPIOD->ODR \mid = 1 << 3;
// BSRRL and BSRRH have one bit each per pin
// Note that for the BSRR registers, we don't really need
// to use /= - for these registers, we can just use =
// and the result will be the same
GPIOD->BSRRL |= 1 << 3;
GPIOD->BSRRH |= 1 << 3;
To set values for all pins on the port:
// MODER has two bits per pin
GPIOD->MODER = 0x555555555;
// OTYPER has one bit per pin, and we shouldn't touch
// the reserved bits - just set lower 16 bits
GPIOD->OTYPER |= Oxffff;
// OSPEEDR has two bits per pin
GPIOD \rightarrow OSPEEDR = 0x555555555;
// PUPDR has two bits per pin
GPIOD \rightarrow PUPDR = 0x555555555;
// ODR has one bit per pin, and we shouldn't touch
// the reserved bits - just set lower 16 bits
GPIOD->ODR |= Oxffff;
// BSRRL and BSRRH have one bit each per pin
GPIOD->BSRRL = Oxffff;
GPIOD->BSRRH = Oxffff;
```

Setting these to 1 has the following effect:

- \bullet MODER: Sets pin(s) to general purpose output mode
- \bullet OTYPER: Sets output pin(s) to open drain type
- OSPEEDR: Sets speed to medium speed
- PUPDR: Sets a pull-up resistor on pin(s)
- ODR: Writes a high value to output pin(s)
- \bullet BSRRL: Sets a value of 1 on output pin(s)
- \bullet BSRRH: Resets (sets a value of 0) on output pin(s)