Shared Memory Architectures

Chris Kauffman

Last Updated: Tue Mar 15 09:34:53 AM CDT 2022

Logistics Assignments + Grading

- Will combine A2 and A3 to do an MPI and OpenMP versions of K-Means clustering
- Post later this week again, apologies for the delay
- Mini-Exam 1 and 2 grades will be up by next week

Today

- ► Shared Memory Architecture Theory + Practicalities
- Cache Performance Effects
- Next Week: PThreads + OpenMP for shared memory machines

Reading

- ► Grama 2.4.1 (PRAM), 2.4.6 (cache)
- Gram 7.1-9 (PThreads)
- ► Grama 7.10 (OpenMP)
- ► OpenMP Tutorial at Laurence Livermore

PRAM: Parallel Random Access *Machine*, Grama Ch 2.4.1

RAM: Random Access Machine

- An unfortunate name as every other use of "RAM" is random access memory
- Single CPU attached to random access memory
- Simplistic model for a real machine: CPU reads memory, performs operations in registers, writes to memory, repeates

PRAM: Parallel Extension to RAM

- Again, theoretical model for a real parallel machine
- Multiple CPUs attached to memory, share clock but can execute different instructions
- Must clarify behavior of PRAM machine that is not possible in single PE situation: how are conflicts between processors resolve for simultaneous memory access

Theoretical Flavors of PRAM

Exclusive-Read, Exclusive-Write (EREW) PRAM

Multiple CPUs cannot touch same memory at all. No parallelism possible for reads / writes of the same memory location.

Concurrent-Read, Exclusive-Write (CREW) PRAM

Multiple CPUs may read same memory location at same time. Writes to same location must be resolved.

Exclusive-Read, Concurrent-Write (ERCW) PRAM

Multiple write accesses are allowed to a memory location, but multiple read accesses are serialized. (This is just weird)

Concurrent-Read, Concurrent-Write (CRCW) PRAM

Simultaenous Read AND Write of the same memory location: the most "powerful" PRAM model for some definition of "power". *Q: What else must be specified for the xxCW models?*

Resolution Schemes for Concurrent Reads/Writes

A: How concurrent writes resolve.

- ► **Common**: concurrent writes are allowed if all the values that the processors are attempting to write are identical.
- ► **Arbitrary:** an arbitrary processor is allowed to proceed with the write operation and the rest fail.
- Priority: procs are organized in a predefined prioritized list; proc with the highest priority writes its value while others fail.
- **Sum:** the sum of all the quantities is written

Above categories do not resolve concurrent read+write such as:

```
MEM[#1024] is 10
PO reads MEM[#1024] into REG1
P1 writes 20 to MEM[#1024]
```

Proper treatments of PRAM specify results for this such as

- ▶ All Reads resolve first, then Writes resolve
- Concurrent Reads/Writes occur in arbitrary order
- etc.

However, we'll proceed with more practical matters

Pros and Cons of PRAM

Why the PRAM Model?

- ► It's simple
- Much literature devoted to studying benefits of algorithms under different variants (e.g. Parallel Array Sum with CRCW + summing on concurrent write)
- Has significant theoretical importance

Why Not PRAM

- No real, general machines currently implement any PRAM models
- Seen some references that GPUs might sort of implement but would require some more work
- Conclusions one might draw about "good" algorithms is skewed (e.g. multi-core machines do NOT behave as a CRCW-summing machine; far from it)

Exercise: Recall the Memory Cache


- Parallel programs are driven towards performance
- Optimize serial performance first: requires understanding of the memory hierarchy

Questions


From your computer architecture experience...

- Describe a memory cache and why most CPUs have several layers of them
- Give an example of "strange" cache effects where similar algorithms have very different performance

Diagrams of Memory Interface and Cache Levels



Source: Bryant/O'Hallaron CS:APP 3rd Ed.



Source: SO "Where exactly L1, L2 and L3 Caches located in computer?"

Numbers Everyone (in Computing) Should Know

Edited Excerpt of Jeff Dean's talk on data centers.

| Operation | Time (ns) |
|-------------------------------------|-------------|
| L1 cache reference | 0.5 |
| Branch mispredict | 5 |
| L2 cache reference | 7 |
| Mutex lock/unlock | 100 |
| Main memory reference | 100 |
| Compress 1K bytes with Zippy | 10,000 |
| Send 2K bytes over 1 Gbps network | 20,000 |
| Read 1 MB sequentially from memory | 250,000 |
| Round trip within same datacenter | 500,000 |
| Disk seek | 10,000,000 |
| Read 1 MB sequentially from network | 10,000,000 |
| Read 1 MB sequentially from disk | 30,000,000 |
| Send packet CA->Netherlands->CA | 150,000,000 |

Numbers are likely out of date now but scales are worth knowing and explain why Cache is useful

Matrix Summing Examples

- What's the Big O complexity of each?
- What happens with cache?
- Will one be faster than the other?

Cache Affects Performance

As measured by hardware counters using linux's perf on

model name : Intel(R) Core(TM) i5-2400 CPU @ 3.10GHz

cache size : 6144 KB

with

perf stat \$opts java MatrixSums 8000 4000 row perf stat \$opts java MatrixSums 8000 4000 col


| Measurement | row | col |
|-----------------------|---------------|---------------|
| cycles | 3,507,364,715 | 5,605,621,966 |
| instructions | 2,353,887,029 | 2,543,165,478 |
| L1-dcache-loads | 527,694,054 | 561,540,169 |
| L1-dcache-load-misses | 25,638,014 | 122,663,199 |
| Runtime (seconds) | 1.001 | 1.620 |

L1 data cache load misses

▶ Row: 25K/548K = 4% main memory access

ightharpoonup Col: 122/585K = 20% main memory access

Cache Issues in Shard Memory Machines



Source: Multi-core, Threads & Message Passing by Ilya Grigorik

Consider the following sequence of operations:

```
// MEM[#1024] has value 5
P0: load R1 MEM[#1024] // slow, populates cache
P0: load R2 MEM[#1024] // fast, from cache
P0: ADD R1 R1 R2 // R1 is 10
P0: store R1 MEM[#1024] // cache dirty, MEM[#1024] unchanged
a short time later
P1: load R3 MEM[#1024] // read 5 or 10?
```

Illustrates **Cache Coherence** Problem: how do multiple PEs maintain the illusion of a single block of shared memory?

Cache Coherence Protocols

Grama 2.4.6 offers two theoretical protocols to maintain coherence

- ► **Invalidate**: shared memory written by one PE is marked as invalid in cache of others
- ► **Update**: shared memory written in by one PE is updated in other PEs

Invalidate and Update Protocol Diagrams




Figure 2.21 Cache coherence in multiprocessor systems: (a) Invalidate protocol; (b) Update protocol for shared variables.

Cache State and Coherence

Each element in the ProcX's cache is one of

Shared valid for to read/write

Dirty written by me, must eventually write to main memory

Invalid someone else wrote it in their cache, must reload




Figure 2.22 State diagram of a simple three-state coherence protocol.

Demonstration

| Time | Instruction at Processor 0 | Instruction at Processor 1 | Variables and their states at Processor 0 | Variables and their states at Processor 1 | Variables and their states in Global mem. |
|------|-------------------------------|-------------------------------|---|---|---|
| v | | | | | x = 5, D y = 12, D |
| | read x | read y | x = 5, S | y = 12, S | x = 5, S y = 12, S |
| | x = x + 1 | y = y + 1 | x = 6, D | y = 13, D | x = 5, I y = 12, I |
| | read y | | _ | y = 13, S x = 6, S | _ |
| | x = x + y | y = x + y | x = 19, D y = 13, I | x = 6, I y = 19, D | x = 6, I y = 13, I |
| | x = x + 1 | y = y + 1 | x = 20, D | y = 20, D | x = 6, I y = 13, I |

Figure 2.23 Example of parallel program execution with the simple three-state coherence protocol discussed in Section 2.4.6.

The Memory Bus

- Cache coherence protocols involve communication between procs, obtaining information about changes to memory
- ► The **Memory Bus** is the communication channel that enables Procs/Memory chips to "talk" to each other
- ► Hardware construct to move data around, usually across wires connected to each Proc and DRAM chip
- Memory Buses use a communication protocol which includes device identifiers so messages about changes are directed to individual PEs or DRAM
- ▶ Bus can get "crowded" if lots of Procs make memory requests
- ► All hardware can "see" messages on the bus: allows **snooping** of messages intended for others
- ► Example: PE1 sees that PE0 read address #1024 so PE0 knows it may share #1024 now

Diagram of Typical Memory Buses




Figure 2.7 Bus-based interconnects (a) with no local caches; (b) with local memory/caches.

Snoopy Cache




Figure 2.24 A simple snoopy bus based cache coherence system.

Basics

- Additional hardware watches messages on the bus
- Writing to cache invalidates global memory
- Message pertaining to a dirty memory address cause flush, state back to shared

Example

- x in P0 cache Dirty
- x in Global mem Invalid
- ▶ P1 reads x
 - ▶ P0 "snoops" request
 - Flushes x to global mem
 - ▶ P1 can read x from global
- x is now Shared

Different Variable but Same Cache Line \rightarrow Collisions


- Performance problem: two processors grinding on different but close variables
- Consider the following program: x,y are adjacent in main memory, likely to share same cache line
- Proc0 and Proc1 each have own cache, will interfere with one another despite working on different variables

```
void collide(){
  int x=42;
  int y=31;
  if(proc_id == 0){
    int i;
    for(i=0; i<1000; i++){
      x = (x+1)*(x+3)/x:
  else{
    int i;
    for(i=0; i<1000; i++){
      y = y/2;
      y = y+2*y;
```

Small Stacks for Threads \rightarrow False Sharing Collisions

```
#include <pthread.h>
#include <stdio.h>
void *fx(void *param) {
 int i, x=(int) param;
                                     int main(int argc, char *argv[]) {
 for(i=0; i<1000; i++){
                                       pthread_t thread_1;
   x = (x+1)*(x+3)/x;
                                       pthread t thread 2;
   printf("x %d\n",x);
                                       pthread_create(&thread_1, NULL,
                                                      fx. 42):
 return (void *) x;
                                       pthread_create(&thread_2, NULL,
                                                      fy, 31);
                                       int *xres, *yres;
void *fy(void *param){
                                       pthread_join(thread_1, &xres);
 int i, y=(int) param;
                                       pthread_join(thread_2, &yres);
 for(i=0; i<1000; i++){
                                       printf("x is %d\ny is %d\n",
   y = y/2;
                                              (int) xres,(int) yres);
   y = y+2*y;
   printf("y %d\n",y);
 return (void *) y;
```

False Sharing of Thread Stacks



Source: Building Parallel Programs, Kaminsky

boundaries

Compiler / Padding Can fix This




Figure 9.3 Memory layout with extra padding

```
#include <pthread.h>
#include <stdio.h>
void *fx(void *param) {
 int i, x=(int) param;
 int padding[32]; // PADDING
 for(i=0: i<1000: i++){
   x = (x+1)*(x+3)/x:
   printf("x %d\n",x);
 return (void *) x;
void *fy(void *param){
 int i, y=(int) param;
 int padding[32]; // PADDING
 for(i=0; i<1000; i++){
   v = v/2;
   y = y+2*y;
   printf("y %d\n",y);
 return (void *) y;
```

Cache Coherence Overall

- Caches speed up individual processor execution in most cases
- Coordinating caches across several PEs is complex
- Requires additional hardware such for Snooping, alternatively Directory-based approach (textbook)
- Hardware manages most of this but uses techniques that are smack of distributed memory systems
- ► To eek out more performance, programmers should be aware of these things when using Thread-based programs