# Shared Memory Architectures

Chris Kauffman

Last Updated: Wed Oct 27 09:36:08 AM CDT 2021

# Logistics

## Today

- Shared Memory Architecture Theory + Practicalities
- Cache Performance Effects
- Next Week: PThreads + OpenMP for shared memory machines

## Reading

- Grama 2.4.1 (PRAM), 2.4.6 (cache)
- Gram 7.1-9 (PThreads)
- Grama 7.10 (OpenMP)
- OpenMP Tutorial at Laurence Livermore

## PRAM: Parallel Random Access *Machine*, Grama Ch 2.4.1

#### RAM: Random Access Machine

- ► An unfortunate name as every other use of "RAM" is random access memory
- Single CPU attached to random access memory
- Simplistic model for a real machine: CPU reads memory, performs operations in registers, writes to memory, repeates

#### PRAM: Parallel Extension to RAM

- Again, theoretical model for a real parallel machine
- Multiple CPUs attached to memory, share clock but can execute different instructions
- Must clarify behavior of PRAM machine that is not possible in single PE situation: potential for conflicts between processors / memory

### Theoretical Flavors of PRAM

## Exclusive-Read, Exclusive-Write (EREW) PRAM

Multiple CPUs cannot touch same memory at all. No concurrency possible for reads / writes in single instructions.

## Concurrent-Read, Exclusive-Write (CREW) PRAM

Multiple CPUs can read same location at same time. Writes to same location must be resolved.

## Exclusive-Read, Concurrent-Write (ERCW) PRAM

Multiple write accesses are allowed to a memory location, but multiple read accesses are serialized. (This is just weird)

## Concurrent-Read, Concurrent-Write (CRCW) PRAM

Multiple read and write accesses to a common memory location. This is the most "powerful" PRAM model for some notion of "power".

Q: What is missing in the above descriptions of for the xxCW models?

# Resolution Schemes for Concurrent Reads/Writes

A: How are concurrent writes resolved?

- ► **Common**: concurrent writes are allowed if all the values that the processors are attempting to write are identical.
- ► **Arbitrary:** an arbitrary processor is allowed to proceed with the write operation and the rest fail.
- Priority: all processors are organized into a predefined prioritized list, and the processor with the highest priority succeeds and the rest fail.
- **Sum:** the sum of all the quantities is written

Above categories do not resolve concurrent read+write such as:

```
MEM[1024] is 10
P0 reads MEM[1024] into R1
P1 writes 20 to MEM[1024]
```

More thorough treatments of PRAM do specify results for this such as

- ▶ All procs reads resolve first, then writes resolve
- Concurrent reads occur and writes occur in arbitrary order

### Pros and Cons of PRAM

### Why the PRAM Model?

- ► It's simple
- Lots of study of different algorithms
- Has significant theoretical importance

### Why Not PRAM

- No general machine currently implements the model
- Seen some references that GPUs might sort of implement but would require some more work
- Conclusions one might draw about "good" algorithms is skewed

# Exercise: Recall the memory Cache

- Parallel programs are driven towards performance
- Optimize serial performance first: requires understanding of the memory hierarchy

### Questions

From your computer architecture experience...

- Describe a memory cache and why most CPUs have several layers of them
- Give an example of "strange" cache effects where similar algorithms have very different performance

# Matrix Summing Examples

### 

- What's the Big O complexity of each?
- What happens with cache?
- Will one be faster than the other?

# Numbers Everyone Should Know

Edited Excerpt of Jeff Dean's talk on data centers.

Operation	Time (ns)
L1 cache reference	0.5
Branch mispredict	5
L2 cache reference	7
Mutex lock/unlock	100
Main memory reference	100
Compress 1K bytes with Zippy	10,000
Send 2K bytes over 1 Gbps network	20,000
Read 1 MB sequentially from memory	250,000
Round trip within same datacenter	500,000
Disk seek	10,000,000
Read 1 MB sequentially from network	10,000,000
Read 1 MB sequentially from disk	30,000,000
Send packet CA->Netherlands->CA	150,000,000

Numbers are likely out of date now but scales are worth knowing and explain why Cache is useful

## Cache Affects Performance

As measured by hardware counters using linux's perf on

model name : Intel(R) Core(TM) i5-2400 CPU @ 3.10GHz

cache size : 6144 KB

with

perf stat \$opts java MatrixSums 8000 4000 row perf stat \$opts java MatrixSums 8000 4000 col


Measurement	row	col
cycles	3,507,364,715	5,605,621,966
instructions	2,353,887,029	2,543,165,478
L1-dcache-loads	527,694,054	561,540,169
L1-dcache-load-misses	25,638,014	122,663,199
Runtime (seconds)	1.001	1.620

#### L1 data cache load misses

▶ Row: 25K/548K = 4% main memory access

ightharpoonup Col: 122/585K = 20% main memory access

## Cache Issues in Shard Memory Machines



Source: Multi-core, Threads & Message Passing by Ilya Grigorik

#### Consider the following sequence of operations:

```
// MEM[#1024] has value 5
P0: load R1 MEM[#1024] // slow, populates cache
P0: load R2 MEM[#1024] // fast, from cache
P0: ADD R1 R1 R2 // R1 is 10
P0: store R1 MEM[#1024] // cache dirty, MEM[#1024] unchanged
a short time later
P1: load R3 MEM[#1024] // read 5 or 10?
```

Illustrates **Cache Coherence** Problem: how do multiple PEs maintain a the illusion of a single block of shared memory

#### Cache Coherence Protocols

Grama 2.4.6 offers two theoretical protocols to maintain coherence

- ► **Invalidate**: shared memory written by one PE is marked as invalid in cache of others
- ► **Update**: shared memory written in by one PE is updated in other PEs

## Invalidate and Update Protocol Diagrams




Figure 2.21 Cache coherence in multiprocessor systems: (a) Invalidate protocol; (b) Update protocol for shared variables.

## Cache State and Coherence

Each element in the ProcX's cache is one of

Shared valid for to read/write

Dirty written by me, must eventually write to main memory

Invalid someone else wrote it in their cache, must reload




Figure 2.22 State diagram of a simple three-state coherence protocol.

## Demonstration

Time	Instruction at Processor 0	Instruction at Processor 1	Variables and their states at Processor 0	Variables and their states at Processor 1	their states in
V					x = 5, $Dy = 12$ , $D$
	read x	read y	x = 5, S	y = 12, S	x = 5, S y = 12, S
	x = x + 1	y = y + 1	x = 6, D	y = 13, D	x = 5, I y = 12, I
	read y		y = 13, S x = 6, S	_	-
	x = x + y		x = 19, D y = 13, I		
	x = x + 1	y = y + 1	x = 20, D	y = 20, D	x = 6, I y = 13, I

**Figure 2.23** Example of parallel program execution with the simple three-state coherence protocol discussed in Section 2.4.6.

# The Memory Bus

- Cache coherence protocols involve communication between procs, obtaining information about changes to memory
- ► The **Memory Bus** is the communication channel that enables Procs/Memory chips to "talk" to each other
- ► Hardware construct to move data around, usually across wires connected to each Proc and DRAM chip
- Memory Buses use a communication protocol which includes device identifiers so messages about changes are directed to individual PEs or DRAM
- Bus can get crowded if there there are lots of activity
- ► All hardware can "see" messages on the bus: allows **snooping** of messages intended for others
- ► Example: PE1 sees that PE0 read address #1024 so PE0 knows it may share #1024 now

# Diagram of Typical Memory Buses




Figure 2.7 Bus-based interconnects (a) with no local caches; (b) with local memory/caches.

## **Snoopy Cache**




Figure 2.24 A simple snoopy bus based cache coherence system.

#### **Basics**

- Additional hardware watches messages on the bus
- Writing to cache invalidates global memory
- Message pertaining to a dirty memory address cause flush, state back to shared

### Example

- x in P0 cache Dirty
- x in Global mem Invalid
- ▶ P1 reads x
  - ▶ P0 "snoops" request
    - Flushes x to global mem
    - ▶ P1 can read x from global
- x is now Shared

## Different Variable but Same Cache Line $\rightarrow$ Collisions

- Performance problem: two processors grinding on different but close variables
- Consider the following program: x,y are adjacent in main memory, likely to share same cache line
- Proc0 and Proc1 each have own cache, will interfere with one another despite working on different variables

```
void collide(){
  int x=42;
  int y=31;
  if(proc_id == 0){
    int i;
    for(i=0; i<1000; i++){
      x = (x+1)*(x+3)/x:
  else{
    int i;
    for(i=0; i<1000; i++){
      y = y/2;
      y = y+2*y;
```

# Small Stacks for Threads $\rightarrow$ False Sharing Collisions

```
#include <pthread.h>
#include <stdio.h>
void *fx(void *param) {
 int i, x=(int) param;
                                     int main(int argc, char *argv[]) {
 for(i=0; i<1000; i++){
                                       pthread_t thread_1;
   x = (x+1)*(x+3)/x;
                                       pthread t thread 2;
   printf("x %d\n",x);
                                       pthread_create(&thread_1, NULL,
                                                      fx. 42):
 return (void *) x;
                                       pthread_create(&thread_2, NULL,
                                                      fy, 31);
                                       int *xres, *yres;
void *fy(void *param){
                                       pthread_join(thread_1, &xres);
 int i, y=(int) param;
                                       pthread_join(thread_2, &yres);
 for(i=0; i<1000; i++){
                                       printf("x is %d\ny is %d\n",
   y = y/2;
                                              (int) xres,(int) yres);
   y = y+2*y;
   printf("y %d\n",y);
 return (void *) y;
```

# False Sharing of Thread Stacks




Figure 9.1 Per-thread variable memory layout

**Figure 9.2** Memory layout showing cache line boundaries

Cache line

Source: Building Parallel Programs, Kaminsky

# Padding Can fix This




Figure 9.3 Memory layout with extra padding

```
#include <pthread.h>
#include <stdio.h>
void *fx(void *param) {
 int i, x=(int) param;
 int padding[32]; // PADDING
 for(i=0: i<1000: i++){
   x = (x+1)*(x+3)/x:
   printf("x %d\n",x);
 return (void *) x;
void *fy(void *param){
 int i, y=(int) param;
 int padding[32]; // PADDING
 for(i=0; i<1000; i++){
   v = v/2;
   y = y+2*y;
   printf("y %d\n",y);
 return (void *) y;
```

### Cache Coherence Overall

- Caches speed up individual processor execution in most cases
- Coordinating caches across several PEs is complex
- Requires additional hardware such for Snooping, alternatively Directory-based approach (textbook)
- Hardware manages most of this but uses techniques that are smack of distributed memory systems
- ► To eek out more performance, programmers should be aware of these things when using Thread-based programs