```
0 1.
   # To Determine the bearing capacity of soil with water table
   BulkDensity =float(input("Enter the value of Bulk Density of soil:"))
   SatDensity = float(input("Enter the value of Saturated Density of soil:"))
  WaterDensity = float(input("Enter the unit Weight of Water:"))
   Df= float(input("Enter the value of depth of footing:"))
   Dw = float(input("Enter the value of water table above footing level:"))
   Dw1= float(input("Enter the value of Water table below the level of footing:"))
   B = float(input("Enter the value of width of footing:"))
   Nq= float(input("Enter the vaiue of Nq:"))
   N = float(input("Enter the value of N ganna (N):"))
   SubDensity = SatDensity - WaterDensity
   print("Submerged Weight of soil is:", SubDensity)
   # The bearing capacity of soil when water table is at ground
   print("CASE A")
   qu= (SubDensity* Df*Nq) + (0.5*0.8*B*SubDensity*N)
   print("The value of ultimate bearing capacity of soil is:", qu)
   #Approximate calculation of Bearing capacity of soil is.
   Rw = 0.5 + 0.5*(Dw/B)
   print("The value of Rw is:", Rw)
   Rw1 = 0.5 + 0.5*(Dw1/B)
   print("The value of Rw1 is:", Rw1)
   qu= (BulkDensity*Df*Nq*Rw) + (0.5*0.8*B*BulkDensity *N*Rw1)
   print("The value ultimate bearing capacity of soil is:", qu)
   # Case B
   print ("CASE B")
   qu= (BulkDensity*Df*Nq) + (0.5*0.8*B*SubDensity*N)
   print("The value of ultimate bearing capacity is:", qu)
   Dw = float(input("Enter the value of water table above footing level:"))
   Dwl = float(input(" Enter the value of Water table below the level of footing: "))
   print("The approximate value of ultimate bearing capacity is: ", qu)
   RW = 0.5 + 0.5*(DW/B)
   print("The value of Rw is:", Rw)
   Rw1 = 0.5 + 0.5* (Dw1/B)
   print ("The value of Rw1 is:", Rw1)
   qu= (BulkDensity*Df*Nq*Rw) + (0.5*0.8*B*BulkDensity*N*Rw1)
   print("The approximate value of ultimate bearing capacity is: ", qu)
   # Case C
   print("CASE C")
   x = float(input("Enter the value of depth of water below footing:"))
   qu = (BulkDensity*Df*Nq) + (0.5*0.8* ((BulkDensity*x)+(SubDensity* (B-x))) *N)
   print("The value of ultimate bearing capacity is:", qu)
   Dw = float(input("Enter the value of water table above footing level:"))
   Dw1= float(input("Enter the value of Water table below the level of footing: ""))
   print("The approximate value of ultimate bearing capacity is:" , qu)
   Rw = 0.5 + 0.5*(Dw/B)
   print("The value of Rw is:", Rw)
   Rw1 = 0.5 + 0.5*(Dw1/B)
   print("The value of Rwl is: ", Rw1)
   qu= (BulkDensity*Df*Nq*Rw) + (0.5*0.8*B*BulkDensity*N*Rw1)
   print("the value of ultimate bearing capacity is:", qu)
      Enter the value of Bulk Density of soil:18
      Enter the value of Saturated Density of soil:20
      Enter the unit Weight of Water:10
      Enter the value of depth of footing:2
      Enter the value of water table above footing level:0
      Enter the value of Water table below the level of footing:0
https://colab.resetarch.alugge.cvi.ftpd.rive/famtiNzqlwxxlB5kHwsQjY3bCTZwJ8MLJ1#printMode=true
```

Dw = []

```
Enter the value of N ganna (N):34
       Submerged Weight of soil is: 10.0
       CASE A
       The value of ultimate bearing capacity of soil is: 1068.0
       The value of Rw is: 0.5
       The value of Rw1 is: 0.5
       The value ultimate bearing capacity of soil is: 961.2
       CASE B
       The value of ultimate bearing capacity is: 1596.0
       Enter the value of water table above footing level:3
        Enter the value of Water table below the level of footing: 0
       The approximate value of ultimate bearing capacity is: 1596.0
       The value of Rw is: 1.0
       The value of Rw1 is: 0.5
       The approximate value of ultimate bearing capacity is: 1555.2
       CASE C
       Enter the value of depth of water below footing:1
       The value of ultimate bearing capacity is: 1704.8000000000002
       Enter the value of water table above footing level:3
       Enter the value of Water table below the level of footing:'1
       The approximate value of ultimate bearing capacity is: 1704.8000000000002
       The value of Rw is: 1.0
       The value of Rwl is: 0.666666666666666
       the value of ultimate bearing capacity is: 1677.6
   Q 2.
   # To find the ultimate load carring capacity of pile
   UCS = float(input("Enter the value of UCS of soil:"))
   Cu = UCS/2
   B = float(input("Enter the value of dimension of pile:"))
   1 =float(input("Enter the length of pile:"))
   Alpha = float(input("Enter the value of adhesion factor:")
   Nc= float(input("The value of Nc: "))
   Ab = B*B
   print("the Base area of footing is:", Ab)
   As = 4*B*1
   print("The value of chohesion of soil is:"
   Qpu = Cu*Nc*Ab
   print("'Qpu:", Qpu)
   Qf = Alpha*Cu*As
   print("Qf:", Qf)
   Ou = Opu + Of
   print("the value of load carring capacity of pile is (Qu):", Qu)
      Enter the value of UCS of soil:75
       Enter the value of dimension of pile:0.45
       Enter the length of pile:15
       Enter the value of adhesion factor:0.8
       The value of Nc: 9
       the Base area of footing is: 0.2025
       The value of chohesion of soil is: 37.5
        'Qpu: 68.34375
       Of: 810.0
       the value of load carring capacity of pile is (Qu): 878.34375
   Q 3.
   # To Determine the bearing capacity of soil with water table
   BulkDensity = float (input ("Enter the value of Bulk Density of soil:"))
   SatDensity = float (input ("Enter the value of Saturated Density of soil:"))
   WaterDensity = float (input ("Enter the unit Weight of Water:"))
   Df = float (input ("Enter the value of depth of footing:"))
   B = float (input ("Enter the value of width of footing:"))
   Ng = float (input ("Enter the value of Ng:"))
   N_Gamma = float (input ("Enter the value of N gamma (N):"))
   SubDensity = SatDensity - WaterDensity
   print("Submerged Weight of soil is:", SubDensity)
   M = int(input("Number of data values of Water table above footing level: "))
https://colab.research.google.c/m/drive/fantinzquxxalbyaswsfiy3bttzwjtablf#phallowe=footing level: "))
```

```
Dw1 = []
for i in range (1, M+1):
  print("Enter the value of water table above footing level measured w.r.t.ground (Dw) : ")
  Depth_Dw = float (input ())
  Dw. append (Depth Dw)
  Rw = 0.5 + 0.5* (Depth Dw/B)
  print("The value of Rw is:", Rw)
for j in range (1, N+1):
  print("Enter the value of water table above footing level measured w.r.t.ground (Dw1): ")
  Depth_Dw1 = float (input())
  Dw.append (Depth_Dw1)
  Rw1 = 0.5 + 0.5*(Depth_Dw1/B)
  print("The value of Rw1 is:", Rw1)
  qu= (BulkDensity*Df*Nq*Rw) + (0.5*0.8*B*BulkDensity*N_Gamma*Rw1)
  print("'qu: ", qu, "kN/m^2")
    Enter the value of Bulk Density of soil:18
    Enter the value of Saturated Density of soil:20
    Enter the unit Weight of Water:10
    Enter the value of depth of footing:2
    Enter the value of width of footing:3
    Enter the value of Ng:33
    Enter the value of N gamma (N):34
    Submerged Weight of soil is: 10.0
    Number of data values of Water table above footing level: 3
    Number of data values of Water table below footing level: 3
    Enter the value of water table above footing level measured w.r.t.ground (Dw) :
    The value of Rw is: 0.5
    Enter the value of water table above footing level measured w.r.t.ground (Dw) :
    Enter the value of water table above footing level measured w.r.t.ground (Dw) :
    The value of Rw is: 0.8333333333333333
    Enter the value of water table above footing level measured w.r.t.ground (Dw1):
    The value of Rw1 is: 0.5
    'qu: 1357.19999999999 kN/m^2
    Enter the value of water table above footing level measured w.r.t.ground (Dw1):
    The value of Rw1 is: 0.5
    'qu: 1357.19999999999 kN/m^2
    Enter the value of water table above footing level measured w.r.t.ground (Dw1):
    'qu: 1479.6 kN/m^2
```