# **Data Communication**

TRANSMISSION IMPAIRMENTS

### **Transmission Impairments**

- signal received may differ from signal transmitted causing:
  - o analog degradation of signal quality
  - o digital bit errors
- most significant impairments are
  - o attenuation and attenuation distortion
  - Limited bandwidth
  - o delay distortion
  - noise


### Attenuation

- where signal strength falls off with distance
- depends on medium
- received signal strength must be:
  - o strong enough to be detected
  - o sufficiently higher than noise to receive without error
- so increase strength using amplifiers/repeaters
- is also an increasing function of frequency
- so equalize attenuation across band of frequencies used
  - o eg. using loading coils or amplifiers

### Attenuation-2

- Decibel- Relative Power Measurement
  - $\circ$  dB=10 log  $_{10}$  (P2/P1)
  - P1: transmitted signal power (watt)
  - o P2: received power (watt)
  - o if Negative it is attenuation
  - o if Positive it is gain

No dimension (unit) Original




### Limited Bandwidth


- A signal contains more frequency component.
- A transmission channel or medium has a limited bandwidth
- The signal, wanted to be transmitted, can be transmitted only the frequencies the channel or medium permits
- This impairment has a distortion on received signal

### **Delay Distortion**


- only occurs in guided media
- propagation velocity varies with frequency
- hence various frequency components arrive at different times
- particularly critical for digital data
- since parts of one bit spill over into others
- causing intersymbol interference

## Delay Distortion-2





At the sender



At the receiver

### Noise-1

- additional signals inserted between transmitter and receiver
- thermal
  - o due to thermal agitation of electrons
  - uniformly distributed
  - Can not be eliminated
- intermodulation
  - signals that are the sum and difference of original frequencies sharing a medium

### Noise-2

- crosstalk
  - o a signal from one line is picked up by another line
- impulse
  - o irregular pulses or spikes
    - **▼** eg. external electromagnetic interference
  - short duration
  - o high amplitude
  - o a minor problem for analog signals
  - o but a major source of error in digital data
    - ■ a noise spike could corrupt many bits


## Channel Capacity-1

- max possible data rate on comms channel
- is a function of
  - o data rate in bits per second
  - bandwidth in cycles per second or Hertz
  - o noise on comms link
  - error rate of corrupted bits
- limitations due to physical properties
- want most efficient use of capacity

## Channel Capacity-2

#### Concepts:

- data rate
  - o in bits per second
  - The transmit and receive speed of data
- Bandwidth
  - o in cycles per second or Hertz
  - Constrained by the transmitter and the nature of the medium.
- Noise
  - Average level of noise on communications link
- error rate
  - Rate of corrupted bits



### Nyquist Bandwidth

- consider noise free channels
- if rate of signal transmission is 2B then can carry signal with frequencies no greater than B
  - o ie. given bandwidth B, highest signal rate is 2B
  - o for binary signals, 2B bps needs bandwidth B Hz
- can increase rate by using M signal levels
- Nyquist Formula is: C = 2B log<sub>2</sub>M
- so increase rate by increasing signals
  - at cost of receiver complexity
  - o limited by noise & other impairments

Ex: M=8 (used in some modems) and for B=3100 Hz, C is calculated as C=18600 bps

### Shannon Capacity Formula

- consider relation of data rate, noise & error rate
  - faster data rate shortens each bit so bursts of noise affects more bits
  - o given noise level, higher rates means higher errors
- Shannon developed formula relating these to signal to noise ratio (in decibels)
- SNR<sub>db</sub>=10 log<sub>10</sub> (signal/noise)
- Capacity C=B log<sub>2</sub>(1+SNR)
  - o theoretical maximum capacity
  - o get lower in practise

## Shannon Capacity Formula

• Suppose for a telephone line, BW=3000 Hz and S/N=35 dB (3126). What is the max bit rate?

## Nyquist and Shannon Formula Example

For a channel spectrum between 3 Mhz and 4 Mhz, SNR is 24 dB.

Using Shannon formula:

$$C=10^{6*}log2(1+251)=10^{6*}8=8 Mbps$$


• What is M?

$$C=2*B*log_2M$$
  
 $8*10^6=2*10^6*log_2M$   $4=log_2M$ 

$$M=16$$

## Delay in Networks

- Delay is the time of data transmission between source and target.
- Delay is an important criteria of networks
- Delay varies according to traffic density, errors etc.
- Maximum delay, Mean delay, Delay Jitter (değişim, sapma)
- Delay sources:
  - Transmission Delay
  - Propagation Delay
  - ARQ Delay
  - o Process Delay
  - Queue Delay



## Transmission and Propagation Delay

- Propagation delay is usually constant on a network
- The best propagation is for light. it is 3x10^8 m/s
- For Twisted pair or coaxial cable it is about 2\*10^8 m/s
- Tp=length of bus (m) / Propagation Speed (m/s)
- Transmission delay is time delay of sending frame at bitrate of bus. It depends on frame length.
- Tx=number of transmitting bits (N) / Bus speed (bps)

### Example

- A frame bloke of 1000 bits is going to transmit between two DTE. Calculate the Tp and Tx for given mediums
  - o 100 m twisted pair and 10 kbps transmission speed
  - 10 km coaxial cable and 1 Mbps transmission speed
  - o 50000 km satallite line and 10 Mbps transmission speed
  - o For electrical signals propagation speed is 2\*10^8 m/s
  - o For satellite line propagation speed is 3\*10^8 m/s

### İletim ve Yayılım Gecikmeleri -Örnek

- Örnek1: 2.5kbyte bir e-mail için 1Gbps bant genişliği olan ağda yayılım ve iletim gecikmesi değerleri nedir? Alıcı verici arası mesafe 12000km ve yayılım hızı 2.4\*10<sup>8</sup>m/s'dir.
  - Yayılım gecikmesi =  $(12000*10^3)/2.4*10^8 = 50 \text{ ms}$
  - o İletim gecikmesi =  $(2500*8)/10^9 = 0.02 \text{ ms}$
  - Mesaj boyutu kısa, bant genişliği yüksek olduğu için dominant (baskın) faktör yayılım gecikmesidir. İletim gecikmesi ihmal edilebilir.
- Örnek2: 5Mbyte bir resim için 1Mbps bant genişliği olan ağda yayılım ve iletim gecikmesi değerleri nedir? Alıcı verici arası mesafe 12000km ve yayılım hızı 2.4\*10<sup>8</sup>m/s'dir.
  - Yayılım gecikmesi =  $(12000*10^3)/2.4*10^8 = 50 \text{ ms}$
  - İletim gecikmesi =  $(5000000^*8)/10^6 = 40 \text{ s}$
  - Mesaj boyutu büyük, bant genişliği düşük olduğu için dominant (baskın) faktör iletim gecikmesidir. Yayılım gecikmesi ihmal edilebilir.

#### Automatic Repeat Request Delay

Ağ içerisinde düğümler arasında güvenli veri iletiminin sağlanamaması (verilerin bozulması, zamanında hedefine ulaşmaması) durumunda ilgili paketin/çerçevenin tekrar iletimi gerekir.

- Idle RQ
  - Send and Wait (Stop and Wait)
- Continuous RQ
  - Selective Repeat
  - Go Back N