Binary Arithmetic, Logic and Addressing

Table of contents

	0.1	Objectives:	2
1	Add	ition and Subtraction	3
	1.1	INC and DEC Instructions	3
	1.2	ADD and SUB Instructions	3
	1.3	NEG Instruction	4
	1.4	Example	5
	1.5	Implementing Arithmetic Expressions	5
	1.6	Flags Affected by Arithmetic Instructions	8
		1.6.1 Carry Flag	9
		1.6.2 Overflow Flag	0
		1.6.3 How the ALU calculates the Overflow flag 1	0
	1.7		1
2	Mul	tiplication and Division 13	2
	2.1	Terms	2
	2.2	MUL Instruction	2
		2.2.1 Flags Affected	3
		2.2.2 Example	3
	2.3	·	3
		2.3.1 Single-Operand Form	3

		2.3.2	Two-Operand	Form .			 							14
		2.3.3	Three-Operand											14
		2.3.4	Flags Affected				 							15
		2.3.5	Examples				 							15
	2.4	DIV Ins	truction				 							16
		2.4.1	Flags Affected				 							17
	2.5	IDIV Ir	nstruction											17
		2.5.1	CBW Instruction											18
		2.5.2	CWD Instruction											18
		2.5.3	CDQ Instruction											18
3	Logi	c Instru	uctions											20
	J	3.0.1	Flags Affected				 							21
	3.1	Implem	nentations											22
		3.1.1	Clearing/Mask											22
		3.1.2	Setting Bits .											22
		3.1.3	Toggling Bits											23
		3.1.4	Testing a Bit											23
4	Indir	ect Ad	dressing Mod	es										24
	4.1		ement Address		de		 							24
	4.2		ddressing Mode											25
	4.3		Displacement A											25
	4.4		Addressing Mod											26
	4.5		Index Addressir											27
	4.6		Index + Displace											27
	4.7		ary											27
	1.7	Samme	,			 •	 	•	•	 •	•	•	•	_,

0.1 Objectives:

- In this lecture, we focus on *binary* arithmetic and logic instructions that operate on 8-, 16-, and 32-bit numeric data encoded as signed or unsigned binary integers. The instructions include
 - increment and decrement
 - addition and subtraction

- Multiplication and division
- Bitwise Boolean AND, OR, XOR and NOT
- Indirect addressing modes.

1 Addition and Subtraction

1.1 INC and DEC Instructions

```
INC <operand>
DEC <operand>
```

- INC (increment) and DEC (decrement) instructions add 1 and subtract 1 from an operand, respectively.
- The operand must be either a memory or register. The format is

```
inc reg/mem
dec reg/mem
```

1.2 ADD and SUB Instructions

```
ADD <destination>, <source>
SUB <destination>, <source>
```

• The ADD instruction adds a source operand to a destination operand. The sum is stored in the destination operand, and the source operand's value is unchanged.

• The SUB instruction subtracts a source operand from a destination operand. The result is stored in the destination operand. The source operand's value is unchanged




- 1. Both operands must be the same size
- 2. Both operands cannot be memory operands
- 3. The instruction pointer register (EIP, RIP) cannot be a destination operand

The following operand types are permitted for these instructions (both for ADD and SUB):

```
add reg, reg
add reg, mem
add reg, imm
add mem, reg
add mem, imm
```

1.3 NEG Instruction



• The NEG (negate) instruction reverses the sign of an operand by converting the number to its two's complement. The following operands are permitted:

```
neg reg/mem
```

 Intel implements NEG instruction by subtracting the operand from zero (i.e., <operand> = 0 - <operand>)

1.4 Example

```
section .data
                              ; 4096
var1
       dd
                1000h
var2
                              ; 8192
       dd
               2000h
       section .text
       mov
               eax, [var1]
                             ; EAX = 1000h
                             ; EAX = 1001h
        inc
                eax
               DWORD [var2] ; VAR2 = 1FFFh
       dec
        add
                eax, [var2] ; EAX = 1001h + 1FFFh = 3001h
               [var2], eax
                             ; [VAR2] = 1FFFh - 1001h = 0FFEh
        sub
                [var1]
                              ; [VAR1] = FFFF F000h (-4096)
       neg
```

1.5 Implementing Arithmetic Expressions

In the following examples, we are going to learn how to translate high-level expressions into assembly instructions:

Example 1.1.

```
b = a;
```

Solution:

```
mov eax, [a] ; EAX = a
mov [b], eax ; b = EAX
```

Example 1.2.

```
b = a + 1;
```

Solution:

```
mov eax, [a] ; EAX = a
inc eax ; EAX ++
mov [b], eax ; b = EAX
```

Another solution:

```
mov eax, [a]
add eax, 1
mov [b], eax
```

The following solution is not acceptable because it changes the value of variable a:

```
add [a], 1 ; ERROR: don't change the variable a mov eax, [a]
mov [b], eax
```

The following solution has syntax error: memory to memory operands

```
mov [b], [a] ; ERROR: memory to memory operands add [b], 1
```

Example 1.3.

```
c = b - a;
```

Solution:

```
mov eax, [a] ; EAX = a

mov ebx, [b] ; EBX = b

sub ebx, eax ; EBX -= EAX

mov [c], ebx ; c = EBX
```

Another solution:

```
mov eax, [b] ; EAX = b

sub eax, [a] ; EAX = EAX - a

mov [c], eax ; c = EAX
```

Example 1.4.

```
y = 5 - y;
```

Solution:

```
mov eax, 5 ; EAX = 5

sub eax, [y] ; EAX = EAX - y

mov [y], eax ; y = EAX
```

Another solution:

```
neg [y] ; y = -y add [y], 5 ; y \neq 5
```

Example 1.5.

```
c = 2 * (a + b) + 10;
```

Solution:

```
; evaluate (a + b)
mov         eax, [a]
add         eax, [b]

; 2 * (a + b)
add         eax, eax

; 2 * (a + b) + 10
add         eax, 10

; c = <expr>
mov         [c], eax
```

1.6 Flags Affected by Arithmetic Instructions

- When a CPU executes arithmetic instructions, it consequently updates the status flags. (see lecture 1)
- Status flags provide information whether the output is
 - Positive or negative
 - zero or not zero
 - too large or too small to fit into the destination operand
 - the parity of least significant byte
- The status flags can be used to activate conditional branching instructions (will be discussed in next lecture).

Status Flags	Is set when
CF	unsigned integer overflow
OF	signed integer overflow
ZF	the output is zero
SF	the output is negative

Status Flags	Is set when
PF	The least significant byte of the output have even number of 1 bits
AF	there a 1 bit carried out of position 3 in the least significant byte of the output

1.6.1 Carry Flag

Carry flag is set when:

• There is a carry <u>out</u> of the most significant bit (MSB) when adding two numbers:

$$\begin{array}{r}
01000001 \\
+11000010 \\
CF = 1 \quad 00000011
\end{array}$$

• There is a borrow into the MSB when subtracting two numbers

$$00000001 \\ -00000010 \\ \overline{CF = 1 \quad 11111111}$$

Remember

- In unsigned arithmetic, watch the carry flag to detect errors
- In signed arithmetic, the carry flag tells you nothing interesting

1.6.2 Overflow Flag

Overflow flag is when:

• the sum of two numbers with the sign bits off yields a result number with sign bit on.

$$\begin{array}{r}
00100001 \\
+01100010 \\
OF = 1 \quad 10000011
\end{array}$$

• the sum of two numbers with the sign bits on yields a result number with sign bit off.

1.6.3 How the ALU calculates the Overflow flag

This material is optional reading.

- The value that carries out of the MSB is exclusive ORed with the carry into the MSB of the result.
- The value that borrows out of the MSB is exclusive ORed with the borrow into the MSB of the result.
- The resulting value of XOR is placed in the Overflow flag.
- Example

$$\begin{array}{r}
100000000 \\
+11111111 \\
OF = 1 \quad 01111111
\end{array}$$

The carry into the MSB is 0 and the carry out of the MSB is 1, OF = 0 XOR 1 = 1

$$\begin{array}{r}
00000001 \\
-00000010 \\
\hline
OF = 0 & 11111111
\end{array}$$

The borrow into the MSB is 1 and the borrow out of the MSB is 1, OF = 1 XOR 1 = 0



Remember

- In signed arithmetic, watch the overflow flag to detect errors
- In unsigned arithmetic, the overflow flag tells you nothing interesting

1.7 Which Instructions Affect Flags

- In general, each time the processor executes an instruction, the flags are altered to reflect the result. However, some instructions don't affect any of the flags, affect only some of them, or may leave them undefined.
- Here is a summary of previous instructions:


Instructions	Flags
Transfer instructions (such as MOV, XCHG) ADD and SUB INC and DEC NEG	None All flags All flags except CF All flags (remember NEG = subtracting operand from zero)

2 Multiplication and Division

2.1 Terms

- When multiplying two numbers, the first number is **multiplicand**, the second number is **multiplier** and the result is **product**.
- If the size of multiplicand is n-bit and the size of multiplier is m-bit, then the size of product is at most (n+m)-bit.
- When dividing two numbers, the first number is dividend, the second number is divisor, and the result is quotient. So, the dividend is the number that is divided by the divisor. The number left behind after the division is called the remainder.

2.2 MUL Instruction




- This is the *unsigned* version of multiplication
- The multiplier can be either mem or reg.
- There are three formats depending on the size of multiplier (in 32-bit mode):

Multiplier	Multiplicand	Product			
reg/mem8		AX DX:AX			
reg/mem16 reg/mem32		EDX:EAX			
imm	NOT ALLOWED				

2.2.1 Flags Affected

The OF and CF flags are set to 0 if the upper half of the result is 0; otherwise, they are set to 1. The SF, ZF, AF, and PF flags are undefined.

2.2.2 Example



2.3 IMUL Instruction

2.3.1 Single-Operand Form

• This form is identical to that used by the MUL instruction.

2.3.2 Two-Operand Form

- The destination operand is multiplied by the source operand. The product is truncated and stored in the destination operand.
- The destination operand must be register (either reg16 or reg32 only)
- The valid formats are

```
IMUL reg16, reg/mem16
IMUL reg16, imm8
IMUL reg16, imm16

IMUL reg32, reg/mem32
IMUL reg32, imm8
IMUL reg32, imm8
```

2.3.3 Three-Operand Form

- The first source operand is multiplied by the second operand. The product is truncated and stored in the destination operand
- The destination operand must be register (either reg16 or reg32). The first operand must be a register or memory with same size as the destination operand. The second operand must be immediate operand
- The valid formats are:

```
IMUL reg16, reg/mem16, imm8
IMUL reg16, reg/mem16, imm16

IMUL reg32, reg/mem32, imm8
IMUL reg32, reg/mem32, imm32
```

2.3.4 Flags Affected

- For the one operand form of the instruction, the CF and OF flags are set when significant bits are carried into the upper half of the result and cleared when the result fits exactly in the lower half of the result.
- For the two- and three-operand forms of the instruction, the CF and OF flags are set when the result must be truncated to fit in the destination operand size and cleared when the result fits exactly in the destination operand size.
- The SF, ZF, AF, and PF flags are undefined.



Remember

With the two- and three- operand forms, the result is truncated to the length of the destination before it is stored in the destination register. Because of this truncation, the CF or OF flag should be tested to ensure that no significant bits are lost.

2.3.5 Examples

Example 2.1.

```
section .data
varW
        dw
              4
              4
varDW
        dd
        section .text
                ax, -16
                              AX = -16
        mov
                              ; BX = 2
                bx, 2
        mov
        imul
                bx, ax
                              ; BX = -32
                bx, 2
        imul
                              ; BX = -64
                            : BX = -256
                bx, [varW]
        imul
                eax, -16
        mov
```

```
mov ebx, 2

imul ebx, eax ; EBX = -32

imul ebx, 2 ; EBX = -64

imul ebx, [varDW] ; EBX = -256
```

Example 2.2. Translate y = x * 7 to Assembly, assuming that x and y are declared as singed integer.

```
mov eax, [x]

imul eax, 7 ; eax = eax * 7

mov [y], eax
```

Or

```
mov eax, [x]

mov ebx, 7

imul ebx ; eax = eax * ebx

mov [y], eax
```

Or

```
imul eax, [x], 7
mov [y], eax
```

2.4 DIV Instruction

```
Syntax

DIV <divisor>
```

• This the unsigned version of division

• There are three formats depending on the size of divisor (in 32-bit mode):

Divisor	Dividend	Quotient	Remainder			
reg/mem8	AX	AL	AH			
reg/mem16	DX:AX	AX	DX			
reg/mem32	EDX:EAX	EAX	EDX			
immediate	NOT ALLOWED					

•

Remember

If you did not set the upper half of the dividend, don't forget to clear it using one of the following instructions:

```
xor ax, ax
mov ah, 0
sub edx, edx
```

2.4.1 Flags Affected

The CF, OF, SF, ZF, AF, and PF flags are undefined.

2.5 IDIV Instruction

- This is the signed version of division
- It has the same syntax as DIV
- If q=a/b where q is the quotient, a is the dividend, and b is divisor, then $a=q\ast b+r$
- The sign of the remainder is always the same as the sign of the dividend
- \bullet If the divisor is 0, an interrupt called #DE is generated to terminate the program.

Remember

The dividend must be sign-extended before the division takes place. As such, x86 architecture provides CBW, CWD, and CDQ to sign extend the dividend.

2.5.1 CBW Instruction

- Convert Byte to Word. This instruction requires no operand.
- Impact: If MSB of AL is 1, then AH = 0xFF, otherwise AH = 0.

2.5.2 CWD Instruction

- Convert Word to Doubleword. This instruction requires no operand.
- Impact: If MSB of AX is 1, then DX = 0xFFFF, otherwise DX = 0.

2.5.3 CDQ Instruction

- Convert Doubleword to Quadword. This instruction requires no operand.
- Impact: If MSB of EAX is 1, then EDX = 0xFFFF-FFFF, otherwise EDX = 0.

Example 2.3.

```
mov al, 125 ; dividend = AL = 125

cbw ; AH = 0

mov bl, 2 ; BL = 2

div bl ; AL = 125/2 = 62 = 3Dh, AH = 01h

mov al, -125 ; AL = -125 = 83h

cbw ; AX = FF83h
```

```
bl, 2
mov
                   ; AL = -125/2 = -62 = 0C2h, AH = -1 = 0FFh
idiv
       bl
       dx, 0
                   ; clear dividend, high
mov
        ax, 8003h
                   : dividend, low
mov
                   ; divisor
        cx, 100h
mov
div
                   ; AX = 0080h, DX = 0003h
        CX
```

In the remaining examples, we are going to translate from high-level language to assembly language. All variables are 32-bit signed integers

Example 2.4.

```
f = 9/5*c + 32;
         eax, [c] ; EAX = c
 mov
                    ; EAX = 9 * c
 imul
         eax, 9
                    ; EBX = 5 (divisor)
 mov
         ebx, 5
                    ; Sign-extend EAX to EDX
 cdq
                    ; EAX = EAX / EBX
 idiv
         ebx
         [f], eax ; f = EAX
 mov
```

Example 2.5.

```
v4 = (v1 * 5) / (v2 - 3);
       eax, [v1]
 mov
                    ; EAX = v1
                    ; EAX = EAX * 5
  imul eax, 5
 mov ebx, [v2]
                    : EBX = v2
                    ; EBX = v2 - 3
  sub
       ebx, 3
                    ; Sign-extend EAX to EDX
  cdq
                     ; EAX = EAX / EDX
  idiv
       ebx
 mov
       [v4], eax
                    ; v4 = EAX
```

Example 2.6.

```
v4 = -v1 * 5/(-v2 \% v3)
       eax, [v1] ; EAX = v1
 mov
                   ; EAX = -v1
 neg
       eax
       ecx, eax, 5
                   ; ECX = -v1 * 5
 imul
       eax, [v2]
                   EAX = v2
 mov
                   ; EAX = -v2
 neg
       eax
       ebx, [v3] ; EBX = v3
 mov
 cdq
                    ; sign-extend EAX to EDX
 idiv
       ebx
                    ; EAX = EAX / EBX, Rem = EDX
                   ; Set EAX = ECX (enumerator)
      eax, ecx
 mov
       ebx, edx
                   : Set EBX = EDX (denominator)
 mov
 cdq
 idiv
                   ; EAX = EAX / EBX
       ebx
       [v4], eax ; v4 = EAX
 mov
```

3 Logic Instructions

• The Intel instruction set contains the AND, OR, XOR, NOT, and many more instructions, which directly implement boolean operations on binary bits.

```
AND <destination>, <source>
OR <destination>, <source>
XOR <destination>, <source>
NOT <destination>
```

• The following table describes the operation of each instruction

Instruction Description					
AND	Bitwise logical AND operation between a source operand and a destination operand				
OR	Bitwise logical OR operation between a source operand and a destination operand				
XOR	Bitwise logical exclusive-OR operation between a source operand and a destination operand				
NOT	Bitwise NOT operation on a destination operand				



Rules

- 1. Both operands must be the same size
- 2. Both operands cannot be memory operands
- 3. The instruction pointer register (EIP, RIP) cannot be a destination operand

The following operand types are permitted for these instructions:

```
and
      reg, reg
     reg, mem
and
and
     reg, imm
     mem, reg
and
and
      mem, imm
not
      reg
not
      mem
```

3.0.1 Flags Affected

- The OF and CF are cleared.
- The SF, ZF, and PF are set according to the result.
- The state of AF is undefined.

3.1 Implementations

3.1.1 Clearing/Masking Bits

- The AND instruction allows us to clear 1 or more bits in an operand without affecting other bits. This technique is called bit masking.
- To clear a bit (or more), use AND with a **mask** that has a 0 in the position which is to be cleared. All other positions in the mask contain 1.
- For example, suppose we have the bit string $1110\,0110$ and we want to clear bit 2 (change it to 0). We can use mask $1111\,1011_2$ as follows:

```
nasm
mov AL, 1110-0110b; bit string
and AL, 1111-1011b; AL=1110-0010
```

3.1.2 Setting Bits

- The OR instruction allows us to set 1 or more bits in an operand without affecting any other bits.
- To set a bit (or more), use OR with a mask that has 1 in the position which is to be set. All other positions in the mask contain 0.
- The following code:

```
or AL, 0000-0100b ; set bit 2
```

will set bit at position 2 to 1 and leave other bits unchanged.

3.1.3 Toggling Bits

- We can toggle or switch the value of individual bits from 1 to 0 or vice versa.
- To toggle a bit, use XOR with a mask that has 1 in the position which is to be toggled. All other positions in the mask contain 0.
- Consider the following example

```
\begin{array}{c} \text{Original Value} = 1\,0\,0\,1\,0\,1\,1\,0\\ \text{XOR'ed Value} = 0\,0\,0\,0\,1\,1\,1\,1\\ \hline \text{Toggled Value} = 1\,0\,0\,1\,1\,0\,0\,1 \end{array}
```

3.1.4 Testing a Bit

- To test a bit, use AND with a mask that has 1 in the position which is to be tested. All other positions in the mask contain 0.
- Example, suppose we have the bit string $1110\,0110$ and we want to test bit 5 (check its value). We can use mask $0010\,0000_2$ and the AND:

```
mov AL, 1110-0110b ; our bit string
and AL, 0010-0000b ; The result = 0010 0000
```

• Since bit 5 was set, the result is a nonzero value. However, suppose we want to test bit 4. We use mask $0001\ 0000$ and the AND operation:

```
mov AL, 1110-0110b ; our bit string
and AL, 0001-0000b ; The result = 0000 0000
```

- Since bit 4 was not set, the result is a zero value.
- So after the AND, we need to test the result; if the result is nonzero, the bit is set, otherwise it is not.

4 Indirect Addressing Modes

- Memory locations (where the objects are located) can be specified:
 - **Directly** as static value (also known as displacement)
 - Indirectly through an address computation made up of one or more of the following components:
 - 1. Displacement
 - 2. Base
 - 3. Index
 - 4. Scale-Factor
- The offset address which results from adding these components is called an effective address.

In the following section, we consider the following data definition

```
section .data
v1 db 50, 62
arrX dw 1, 2, 3, 4, 5
matr dd 10, 11, 12, 13
dd 20, 21, 22, 23
```

4.1 Displacement Addressing Mode

- A displacement is 8-, 16-, or 32-bit constant value or expression
- Displacement alone represents a direct offset to the operand.
- The syntax is:

```
[ <disp32> ]
where disp32 is 32-bit displacement value
```

• Example

```
mov al, [v1] ; AL = 50
add al, [v1 + 1] ; AL = 50 + 62 = 112
```

4.2 Base Addressing Mode

- Base alone represents an indirect offset to the operand.
- In this mode, the offset address is contained in a *general purpose register*. We say that the register acts as **a pointer** to the memory location.
- The syntax for 32-bit architecture is:

```
[ <reg32> ]
```

• Example:

```
; ESI points to the 1st element in arr
         esi, arrX
mov
                        ; set sum to zero
         ax, 0
mov
                        ; add \ arrX[0] \ to \ sum, \ AX = 1
         ax, [esi]
add
                        ; move pointer to next element
add
         esi, 2
                        ; add \ arrX[1] \ to \ sum, \ AX = 1+2 = 3
add
         ax, [esi]
                        ; move pointer to next element
add
         esi, 2
                        ; add \ arrX[2] \ to \ sum, \ AX = 3+3 = 6
         ax, [esi]
add
```

4.3 Base + Displacement Addressing Mode

- A base register and a displacement can be used together to access a field of a record. The base register holds the address of the beginning of the record, while the displacement holds a static offset to the field
- This mode is specially useful when we need to access parameters in a procedure activation record. We will elaborate this mode when we discuss procedures.

• The syntax is

```
[ <reg32> + <disp> ]
[ <reg32> - <disp> ]
```

• Example:

```
mov esi, v1 ; esi points to v1

mov al, [esi + 0] ; AL = 50

mov bl, [esi + 1] ; BL = 62
```

4.4 Index Addressing Mode

• In this mode, there are two forms:

```
[index + displacement]
[index*scale + displacement]
```

- The index is a general purpose register except ESP
- For 32-bit mode, the syntax:

```
[ <reg32> + <disp32> ]

[ <reg32>*<scale> + <disp32> ]
where <scale> can be either 1, 2, 4, or 8
```

- In index mode, the displacement locates the beginning of an array, the index register holds the subscript of the desired array element, and scale represents the data type.
- For example, arrX[3] can be translated to assembly as [ecx*2 + arrX] where the register ECX holds the value 3.
- Example

```
; set sum to zero
        ax, 0
mov
                            ; set array index to 0
        esi, 0
mov
        ax, [esi*2 + arrX]
                            ; add arrX[0] to sum, AX = 1
add
                            ; increment the index by 1
inc
        esi
                           ; add arrX[1] to sum, AX = 1+2 =
add
        ax, [esi*2 + arrX]
                            ; increment the index by 1
inc
        esi
        ax, [esi*2 + arrX]; add arrX[2] to sum, AX = 3+3
add
```

4.5 Base + Index Addressing Mode

- In this mode, the base register holds the address of a dynamic array, while the index register holds offset address or subscript index.
 - In 2D arrays, the base register holds the address of the beginning of a row. The index register holds the column's subscription
- The syntax is:

```
[ <base> + <index> ]


[ <base> + <index>*<scale> ]
where <base> and <index> are reg32.
```

4.6 Base + Index + Displacement Addressing Mode

- This mode is a combination of previous modes
- This mode is suitable for traversing array of records.

4.7 Summary

The following diagram, adopted from Intel manual summarizes the memory addressing modes:



oriset base (index sedie) bispiacement

Figure 1: Offset (or Effective Address) Computation

28