Digital PID

Kjartan Halvorsen

2021-07-12

Context

- ▶ Controller F(s) obtained from a design in continuous time.
- Need discrete approxmation in order to implement on a computer




Figure 8.1 Approximating a continuous-time transfer function, G(s), using a computer.

Åström and Wittenmark Computer-controlled systems

Mapping of the stable region of the s-plane




Figure 8.2 Mapping of the stability region in the *s*-plane on the z-plane for the transformations (8.4), (8.5), and (8.6).

Åström and Wittenmark Computer-controlled systems

ISA form of the PID

ISA - International Society of Automation

$$F(s) = K_c \left(1 + \frac{1}{T_i s} + T_d s \right)$$

With low-pass filter for the derivative part

$$F(s) = K_c \left(1 + \frac{1}{T_i s} + \frac{T_d s}{\frac{T_d}{N} s + 1} \right), \quad N \approx 3 - 10$$

ISA form of the PID - derivative part

$$F(s) = K_c \left(1 + \frac{1}{T_i s} + \frac{T_d s}{\frac{T_d}{N} s + 1} \right), \quad N \approx 3 - 10$$


Activity Sketch the Bode plot for the derivative part ($T_d=1$, N=10)

$$F_d(s) = \frac{T_d s}{\frac{T_d}{N} s + 1}$$

using the low-frequency and high-frequency approximations.


$$\omega$$
 small: $F_d(i\omega) \approx T_d i\omega$

$$\omega \text{ large: } F_d(i\omega) \approx \frac{T_d i\omega}{\frac{T_d}{M} i\omega} = N$$




ISA form of the PID - derivative part

PID with derivative action only on the process variable



$$U(s) = \underbrace{K_c \left(1 + \frac{1}{T_i s}\right)}_{F_{PI}(s)} E(s) - \underbrace{\frac{T_d s}{N} s + 1}_{F_D} Y(s)$$

Common discretization of the PID



$$U(s) = U_P(s) + U_I(s) - U_D(s) = K_c E(s) + K_c \frac{1}{T_i s} E(s) - \frac{T_d s}{\frac{T_d}{N} s + 1} Y(s)$$

Activity 1) Use Euler's method $s \approx \frac{z-1}{h}$ for the integral part, and the backward difference $s \approx \frac{z-1}{zh}$ for the derivative part. 2) Apply the inverse z-transform to obtain the controller in the form of a difference equation.

The discrete PID algorithm

Dado:
$$y(kh - h)$$
, $u_I(kh - h)$, $u_D(kh - h)$
Sample signals: $r(kh)$, $y(kh)$
 $e(kh) = r(kh) - y(kh)$
 $u_P(kh) = K_c e(kh)$
 $u_D(kh) = \frac{\frac{T_d}{N}}{\frac{T_d}{N} + h} u_D(kh - h) + K_c \frac{T_d}{\frac{T_d}{N} + h} (y(kh) - y(kh - h))$
 $u(kh) = u_P(kh) + u_I(kh - h) + u_D(kh)$, Send to DAC
 $u_I(kh) = u_I(kh - h) + K_c \frac{h}{T_i} e(kh)$

Sampling signals

