

# IP Surveillance API User Guide

Version 2.0 Revision 4 2013-12



COPYRIGHT ©2009, Hikvision Digital Technology Co., Ltd



<b>Revision History</b>	Revision History Description		Date
Version 2.0 Revision 1	Initial version	Hong Meng	2012-04
Version 2.0 Revision 2	merge qi's document	Hong Meng	2012-06
Version 2.0 Revision 3	add bond and holiday service	Minglei Yu	2012-10
	Combine front-end devices	Minglei Yu	
Version 2.0 Revision 4	and back-end devices	Linming He	2013-12
	together	Guangmu Ma	



© COPYRIGHT, Hikvision Digital Technology Co., Ltd



### **Notices**

The information in this documentation is subject to change without notice and does not represent any commitment on behalf of HIKVISION. HIKVISION disclaims any liability whatsoever for incorrect data that may appear in this documentation. The product(s) described in this documentation are furnished subject to a license and may only be used in accordance with the terms and conditions of such license.

Copyright © 2009-2014 by HIKVISION. All rights reserved. This documentation is issued in strict confidence and is to be used only for the purposes for which it is supplied. It may not be reproduced in whole or in part, in any form, or by any means or be used for any other purpose without prior written consent of HIKVISION and then only on the condition that this notice is included in any such reproduction. No information as to the contents or subject matter of this documentation, or any part thereof, or arising directly or indirectly therefrom, shall be given orally or in writing or shall be communicated in any manner whatsoever to any third party being an individual, firm, or company or any employee thereof without the prior written consent of HIKVISION. Use of this product is subject to acceptance of the HIKVISION agreement required to use this product. HIKVISION reserves the right to make changes to its products as circumstances may warrant, without notice.

This documentation is provided "as-is," without warranty of any kind. Please send any comments regarding the documentation to: overseabusiness@hikvision.com

Find out more about HIKVISION at www.hikvision.com



# Contents

1	Scope.		1
2	Referer	nces	1
3	Definition	ons and abbreviations	2
3.1	Definition	ons	2
3.2	Abbrev	iations	2
4	Archited	cture and Transmission Mechanism	2
4.1	REST a	and HTTP Methods	3
4.2	XML		3
4.3	Resour	ces overview	4
4.4	Protoco	ol URL	5
4.5	Messag	ges	5
	4.5.1	Connection Header Field	6
	4.5.2	Authorization and WWW-Authenticate Header Fields	6
	4.5.3	Entity Body	6
	4.5.4	Operations	7
	4.5.5	Error Handling	8
4.6	Names	paces	13
4.7	Security	y	14
5	Device	discovery	14
6	Resour	ce Description	15
6.1	Resour	ce Description Outline	15
6.2	Built-in	Types	16
6.3	Annota	tion	16
7	Standa	rd Resources	17
7.1	index		17
7.2	indexr		17
7.3	descrip	tion	18
7.4	capabil	ities	18
8	Service	es and General Resources	21
8.1	/ISAPI/	System	21
	8.1.1	/ISAPI/System/capabilities	21
	8.1.2	/ISAPI/System/reboot	22
	8.1.3	/ISAPI/System/updateFirmware	22
	8.1.4	/ISAPI/System/configurationData	23
	8.1.5	/ISAPI/System/factoryReset	23
	8.1.6	/ISAPI/System/deviceInfo	24
	8.1.7	/ISAPI/System/status	25
	8.1.8	/ISAPI/System/time	27
	8.1.9	/ISAPI/System/time/localTime	27
	8.1.10	/ISAPI/System/time/timeZone	28
	8.1.11	/ISAPI/System/time/NtpServers	29
	8.1.12	/ISAPI/System/time/ntpServers/ <id></id>	29



	8.1.13	/ISAPI/System/Holidays	30
	8.1.14	/ISAPI/System/Holidays/ <id></id>	31
	8.1.15	/ISAPI/System/upgradeStatus	32
8.2	/ISAPI/S	System/Network	33
	8.2.1	/ISAPI/System/Network/capabilities	33
	8.2.2	/ISAPI/System/Network/interfaces	34
	8.2.3	/ISAPI/System/Network/interfaces/ <id></id>	34
	8.2.4	/ISAPI/System/Network/interfaces/ <id>/ipAddress</id>	35
	8.2.5	/ISAPI/System/Network/interfaces/ <id>/wireless</id>	37
	8.2.6	/ISAPI/System/Network/interfaces/ <id>/wireless/accessPointList</id>	38
	8.2.7	/ISAPI/System/Network/interfaces/ <id>/wireless/accessPointList/<ii< td=""><td>D&gt; .</td></ii<></id>	D> .
			38
	8.2.8	/ISAPI/System/Network/interfaces/ <id>/discovery</id>	39
	8.2.9	/ISAPI/System/Network/interfaces/ <id>/Link</id>	40
	8.2.10	Examples	41
	8.2.11	/ISAPI/System/Network/interfaces/ <id>/WPS</id>	42
	8.2.12	/ISAPI/System/Network/interfaces/ID/WPS/AutoConnect	43
	8.2.13	/ISAPI/System/Network/interfaces/ID/WPS/devicePinCode	43
	8.2.14	$/ ISAPI/System/Network/interfaces/ID/WPS/devicePinCodeUpdate \dots \\$	44
	8.2.15	/ISAPI/System/Network/interfaces/ID/WPS/ApPinCode	44
	8.2.16	/ISAPI/System/Network/interfaces/ID/ieee802.1x	45
	8.2.17	/ISAPI/System/Network/PPPoE	46
	8.2.18	/ISAPI/System/Network/PPPoE/status	46
	8.2.19	/ISAPI/System/Network/PPPoE/ <id></id>	47
	8.2.20	/ISAPI/System/Network/PPPoE/ <id>/status</id>	48
	8.2.21	/ISAPI/System/Network/Bond	48
	8.2.22	/ISAPI/System/Network/Bond/ <id></id>	49
	8.2.23	/ISAPI/System/Network/extension	50
	8.2.24	/ISAPI/System/Network/DDNS	51
	8.2.25	/ISAPI/System/Network/DDNS/ <id></id>	51
	8.2.26	/ISAPI/System/Network/SNMP	52
	8.2.27	/ISAPI/System/Network/SNMP/v1c	53
	8.2.28	/ISAPI/System/Network/SNMP/v1c/trapReceivers	54
	8.2.29	/ISAPI/System/Network/SNMP/v1c/trapReceiver/ <id></id>	
	8.2.30	/ISAPI/System/Network/SNMP/v2c	
	8.2.31	/ISAPI/System/Network/SNMP/v2c/trapReceivers	
	8.2.32	/ISAPI/System/Network/SNMP/v2c/trapReceiver/ <id></id>	
	8.2.33	/ISAPI/System/Network/SNMP/advanced	
	8.2.34	/ISAPI/System/Network/SNMP/advanced/users	
	8.2.35	/ISAPI/System/Network/SNMP/advanced/users/ <id></id>	
	8.2.36	/ISAPI/System/Network/mailing	
	8.2.37	/ISAPI/System/Network/mailing/ <id></id>	
	8.2.38	/ISAPI/System/Network/UPnP	
	8.2.39	/ISAPI/System/Network/UPnP/ports	63



	8.2.40	/ISAPI/System/Network/UPnP/ports/status	63
	8.2.41	/ISAPI/System/Network/UPnP/ports/ <id></id>	64
	8.2.42	/ISAPI/System/Network/UPnP/ports/ <id>/status</id>	65
	8.2.43	/ISAPI/System/Network/ftp	65
	8.2.44	/ISAPI/System/Network/ftp/ <id></id>	66
	8.2.45	/ISAPI/System/Network/ipFilter	67
	8.2.46	/ISAPI/System/Network/ipFilter/filterAddresses	68
	8.2.47	/ISAPI/System/Network/ipFilter/filterAddresses/ <id></id>	69
	8.2.48	/ISAPI/System/Network/qos	70
	8.2.49	/ISAPI/System/Network/qos/cos	70
	8.2.50	/ISAPI/System/Network/qos/cos/ <id></id>	71
	8.2.51	/ISAPI/System/Network/qos/dscp	72
	8.2.52	/ISAPI/System/Network/qos/dscp/ <id></id>	73
	8.2.53	/ISAPI/System/Network/telnetd	74
	8.2.54	/ISAPI/System/Network/SIP	74
	8.2.55	/ISAPI/System/Network/SIP/ <id></id>	75
	8.2.56	/ISAPI/System/Network/SIP/ <id>/SIPInfo</id>	76
8.3	/ISAPI/	System/IO	77
	8.3.1	/ISAPI/System/IO/capabilities	78
	8.3.2	/ISAPI/System/IO/status	78
	8.3.3	/ISAPI/system/IO/inputs	79
	8.3.4	/ISAPI/System/IO/inputs/ <id></id>	79
	8.3.5	/ISAPI/System/IO/inputs/ <id>/status</id>	80
	8.3.6	/ISAPI/System/IO/outputs	80
	8.3.7	/ISAPI/System/IO/outputs/ <id></id>	80
	8.3.8	/ISAPI/System/IO/outputs/ <id>/status</id>	81
	8.3.9	/ISAPI/System/IO/outputs/ <id>/trigger</id>	82
8.4	/ISAPI/	System/Video	82
	8.4.1	/ISAPI/System/Video/capabilities	82
	8.4.2	/ISAPI/System/Video/inputs	83
	8.4.3	/ISAPI/System/Video/inputs/channels	83
	8.4.4	/ISAPI/System/Video/inputs/channels/ <id></id>	84
	8.4.5	/ISAPI/System/Video/inputs/channels/ <id>/focus</id>	84
	8.4.6	/ISAPI/System/Video/inputs/channels/ <id>/iris</id>	85
	8.4.7	/ISAPI/System/Video/inputs/channels/ <id>/privacyMask</id>	85
	8.4.8	/ISAPI/System/Video/inputs/channels/ <id>/privacyMask/regions</id>	86
	8.4.9	/ISAPI/System/Video/inputs/channels/ <id>/privacyMask/regions/-</id>	<id></id>
			87
	8.4.10	/ISAPI/System/Video/inputs/channels/ <id>/tamperDetection</id>	89
	8.4.11 8.4.12	/ISAPI/System/Video/inputs/channels/ <id>/tamperDetection/region</id>	ns 90
		/ISAPI/System/Video/inputs/channels/ <id>/tamperDetection/region</id>	ns/ <i< td=""></i<>
	D>		91
	8 4 13	/ISAPI/System/Video/inputs/channels/ <id>/motionDetection</id>	92



	8.4.14	/ISAPI/System/Video/inputs/channels/ <id>/motionDetection/layo</id>	out93
	8.4.15		
		/ISAPI/System/Video/inputs/channels/ <id>/motionDetection/layo</id>	•
	Layout		
	8.4.16	Motion Detection Example	
	8.4.17	/ISAPI/System/Video/inputs/channels/ <id>/motionDetectionExt.</id>	
	8.4.18	/ISAPI/System/Video/inputs/channels/ <id>/motionDetectionExt/</id>	•
	0.4.40		97
	8.4.19	//CADI/Cychama // indee / immy the /electrical delay / ID; /my etical Detection Detection Detection	
	/ <id></id>	/ISAPI/System/Video/inputs/channels/ <id>/motionDetectionExt/</id>	•
	8.4.20	/ISAPI/System/Video/inputs/channels/ <id>/motionDetectionExt/s</id>	
	8.4.21	/ISAPI/System/Video/inputs/channels/ <id>/overlays</id>	
	8.4.22	/ISAPI/System/Video/inputs/channels/ <id>/overlays/</id>	
	8.4.23	/ISAPI/System/Video/inputs/channels/ <id>/overlays/text/<id></id></id>	
	8.4.24	/IOAL I/Oystelli/ video/iliputs/challileis/\ID>/overlays/text/\ID>	101
	0.4.24	/ISAPI/System/Video/inputs/channels/ <id>/overlays/channelNar</id>	meOve
	rlay	/io/ ti // Oystorii/ Vidos/iiipats/orialiiiols/ tib//overlays/sitaliiiolival	
	8.4.25	/ISAPI/System/Video/inputs/channels/ <id>/overlays/dateTimeO</id>	
	01.1.20	, i.e., ii ii e yeteinii viaee, iii pale, enaimeie, ale e yeteinaye, aate iiin ee	•
	8.4.26	/ISAPI/System/Video/inputs/channels/ <id>/image</id>	
	8.4.27	/ISAPI/System/Video/inputs/channels/ <id>/image/<id></id></id>	
	8.4.28	/ISAPI/System/Video/inputs/channels/ <id>/image/picture</id>	
	8.4.29	/ISAPI/System/Video/outputs	
	8.4.30	/ISAPI/System/Video/outputs/channels	
	8.4.31	/ISAPI/System/Video/outputs/channels/ <id></id>	
	8.4.32	/ISAPI/System/Video/Menu	107
	8.4.33	/ISAPI/System/Video/Menu/ <id></id>	107
8.5	/ISAPI/S	System/Audio	108
	8.5.1	/ISAPI/System/Audio/capabilities	108
	8.5.2	/ISAPI/System/Audio/channels	108
	8.5.3	/ISAPI/System/Audio/channels/ <id></id>	109
	8.5.4	/ISAPI/System/TwoWayAudio	109
	8.5.5	/ISAPI/System/TwoWayAudio/channels	109
	8.5.6	/ISAPI/System/TwoWayAudio/channels/ <id></id>	110
	8.5.7	/ISAPI/System/TwoWayAudio/channels/ <id>/open</id>	111
	8.5.8	/ISAPI/System/TwoWayAudio/channels/ <id>/close</id>	112
	8.5.9	/ISAPI/System/TwoWayAudio/channels/ <id>/audioData</id>	112
8.6	/ISAPI/S	System/Serial	113
	8.6.1	/ISAPI/SystemSerial/capabilities	113
	8.6.2	/ISAPI/System/Serial/ports	
	8.6.3	/ISAPI/System/Serial/ports/ <id></id>	114
	8.6.4	/ISAPI/System/Serial/ports/ <id>/Transparent</id>	115



	8.6.5	/ISAPI/System/Serial/ports/ <id>/Transparent/channels</id>	115
	8.6.6	/ISAPI/System/Serial/ports/ <id>/Transparent/channels/<id></id></id>	116
	8.6.7	/ISAPI/System/Serial/ports/ <id>/Transparent/channels/<id>/open</id></id>	116
	8.6.8	/ISAPI/System/Serial/ports/ <id>/Transparent/channels/<id>/close</id></id>	117
	8.6.9	/ISAPI/System/Serial/ports/ <id>/Transparent/channels/<id>/transl</id></id>	Data
			117
8.7	/ISAPI/S	System/Hardware/	118
	8.7.1	/ISAPI/System/Hardware/irLightSwitch	118
8.8	/ISAPI/S	Security	119
	8.8.1	/ISAPI/Security/capabilities	119
	8.8.2	/ISAPI/Security/users	119
	8.8.3	/ISAPI/Security/users/ <id></id>	120
	8.8.4	/ISAPI/Security/adminAccesses	121
	8.8.5	/ISAPI/Security/adminAccesses/ <id></id>	122
	8.8.6	/ISAPI/Security/userCheck	123
	8.8.7	/ISAPI/Security/UserPermission	123
	8.8.8	/ISAPI/Security/UserPermission/ <id></id>	124
	8.8.9	/ISAPI/Security/UserPermission/ <id>/localPermission</id>	124
	8.8.10	/ISAPI/Security/UserPermission/ <id>/remotePermission</id>	125
	8.8.11	/ISAPI/Security/UserPermission/anonymouslogin	127
	8.8.12	/ISAPI/Security/UserPermission/operatorCap	127
	8.8.13	/ISAPI/Security/UserPermission/viewerCap	128
	8.8.14	/ISAPI/Security/deviceCertificate	128
8.9	/ISAPI/S	Streaming	129
	8.9.1	/ISAPI/Streaming/status	129
	8.9.2	/ISAPI/Streaming/channels	129
	8.9.3	/ISAPI/Streaming/channels/ <id></id>	130
	8.9.4	/ISAPI/Streaming/channels/ <id>/dynamicCap</id>	137
	8.9.5	/ISAPI/Streaming/channels/ <id>/status</id>	138
	8.9.6	/ISAPI/Streaming/channels/ <id>/picture</id>	139
	8.9.7	/ISAPI/Streaming/channels/ <id>/requestKeyFrame</id>	140
8.10	/ISAPI/S	Snapshot	140
	8.10.1	/ISAPI/Snapshot/channels	140
	8.10.2	/ISAPI/Snapshot/channels/ <id></id>	141
8.11	/ISAPI/E	Event	142
	8.11.1	/ISAPI/Event/capabilities	142
	8.11.2	/ISAPI/Event/triggers	143
	8.11.3	/ISAPI/Event/triggers/ <id></id>	144
	8.11.4	/ISAPI/Event/triggers/ <id>/notifications</id>	146
	8.11.5	/ISAPI/Event/schedules	148
	8.11.6	/ISAPI/Event/schedules/inputs	148
	8.11.7	/ISAPI/Event/schedules/inputs/ <id></id>	148
	8.11.8	/ISAPI/Event/schedules/outputs	149
	8.11.9	/ISAPI/Event/schedules/outputs/ <id></id>	149



	8.11.10	/ISAPI/Event/schedules/motionDetections	150
	8.11.11	/ISAPI/Event/schedules/motionDetections/ <id></id>	150
	8.11.12	/ISAPI/Event/schedules/tamperDetections	151
	8.11.13	/ISAPI/Event/schedules/tamperDetections/ <id></id>	151
	8.11.14	/ISAPI/Event/schedules/videolosses	152
	8.11.15	/ISAPI/Event/schedules/videolosses/ <id></id>	152
	8.11.16	/ISAPI/Event/schedules/PIR	153
	8.11.17	/ISAPI/Event/schedules/fieldDetections	154
	8.11.18	/ISAPI/Event/schedules/fieldDetections/ <id></id>	155
	8.11.19	/ISAPI/Event/schedules/sceneChangeDetections	156
	8.11.20	/ISAPI/Event/schedules/sceneChangeDetections/ <id></id>	156
	8.11.21	/ISAPI/Event/schedules/audioDetections	157
	8.11.22	/ISAPI/Event/schedules/audioDetections/ <id></id>	158
	8.11.23	/ISAPI/Event/notification	159
	8.11.24	/ISAPI/Event/notification/httpHosts	160
	8.11.25	/ISAPI/Event/notification/httpHosts/ <id></id>	161
	8.11.26	/ISAPI/Event/notification/streaming	162
	8.11.27	/ISAPI/Event/notification/streaming/ <id></id>	163
	8.11.28	/ISAPI/Event/notification/alarmCenter	165
	8.11.29	/ISAPI/Event/notification/alarmCenter/ <id></id>	165
	8.11.30	/ISAPI/Event/notification/alertStream	166
	8.11.31	HTTP Notification Alert	168
	8.11.32	Event Triggering Examples	170
8.12	/ISAPI/S	Smart	171
	8.12.1	/ISAPI/Smart/capabilities	171
	8.12.2	/ISAPI/Smart/ROI/channels	172
	8.12.3	/ISAPI/Smart/ROI/channels/ <id></id>	172
	8.12.4	/ISAPI/Smart/ROI/channels/ <id>/regions</id>	173
	8.12.5	/ISAPI/Smart/ROI/channels/ <id>/regions/<id></id></id>	174
	8.12.6	/ISAPI/Smart/ROI/channels/ <id>/facetrace</id>	175
	8.12.7	/ISAPI/Smart/ROI/channels/ <id>/objecttrace</id>	175
	8.12.8	/ISAPI/Smart/FaceDetect/ <id></id>	176
	8.12.9	/ISAPI/Smart/IntelliTrace/ <id></id>	177
	8.12.10	/ISAPI/Smart/IntelliTrace/ <id>/ZoomRatial</id>	177
	8.12.11	/ISAPI/Smart/FieldDetection	178
	8.12.12	/ISAPI/Smart/FieldDetection/ <id></id>	178
	8.12.13	/ISAPI/Smart/FieldDetection/ <id>/regions</id>	179
	8.12.14	/ISAPI/Smart/FieldDetection/ <id>/region/<id></id></id>	180
	8.12.15	/ISAPI/Smart/DefocusDetection	181
	8.12.16	/ISAPI/Smart/DefocusDetection/ <id></id>	182
	8.12.17	/ISAPI/Smart/AudioDetection/channels	182
	8.12.18	/ISAPI/Smart/AudioDetection/channels/ <id></id>	183
	8.12.19	/ISAPI/Smart/AudioDetection/channels/ <id>/status</id>	184
	8 12 20	/ISAPI/Smart/SceneChangeDetection	184



	8.12.21	/ISAPI/Smart/SceneChangeDetection/ <id></id>	.185
8.13	/ISAPI/V	VLAlarm/	.185
	8.13.1	/ISAPI/WLAlarm/capabilities	.185
	8.13.2	/ISAPI/WLAlarm/telecontrol	.186
	8.13.3	/ISAPI/WLAlarm/telecontrol/study	.187
	8.13.4	/ISAPI/WLAlarm/telecontrol/arming	.187
	8.13.5	/ISAPI/WLAlarm/telecontrol/disarming	.187
	8.13.6	/ISAPI/WLAlarm/PIR	.187
	8.13.7	/ISAPI/WLAlarm/WLSensors	.188
	8.13.8	/ISAPI/WLAlarm/WLSensors/ <id></id>	.188
	8.13.9	/ISAPI/WLAlarm/callhelp	.189



# 1 Scope

This specification defines a HTTP-based application programming interface that enables physical security and video management systems to communicate with IP media devices in a particular way.

With regard to Media Streaming, please refer to "develop API of RTSP protocol".

# 2 References

The following documents contain provisions which, through reference in this text, constitute provisions of the present document.

- References are either specific (identified by date of publication, edition number, version number, etc.) or non-specific.
- For a specific reference, subsequent revisions do not apply.
- For a non-specific reference, the latest version applies.
- [1] RFC2616 Hypertext Transfer Protocol-HTTP/1.1
- [2] W3C XML 1.0 specification
- [3] W3C Character encodings
- [4] RFC 2396 Uniform Resource Identifiers (URI): Generic Syntax and Semantics
- [5] RFC 2617 HTTP Authentication: Basic and Digest Access Authentication
- [6] International Electrotechnical Commission "ISO/IEC standard on UPnP device architecture makes networking simple and easy", 2008-12-09. Retrieved on 2009-05-07.
- [7] International Organization for Standardization "ISO/IEC standard on UPnP device architecture makes networking simple and easy", 2008-12-10. Retrieved on 2009-05-07.
- [8] UPnP Forum "UPnP Specifications Named International Standard for Device Interoperability for IP-based Network Devices", 2009-02-05. Retrieved on 2009-05-07.

©2009 – 2014 by HIKVISION. All rights reserved.



# 3 Definitions and abbreviations

### 3.1 Definitions

For the purposes of the present document, the following terms and definitions apply:

**Standard Resources:** "index", "indexr", "description" and "capabilities" resources, that are contained in all Services and General Resources, and provide a special description for these resources.

**Services:** a set of resources consisting of relevant General Resources. **General Resources:** physical resources that supported by the devices.

Node: Services and General Resources.

### 3.2 Abbreviations

For the purposes of the present document, the following abbreviations apply:

FQDN Fully Qualified Domain Name REST REpresentational State Transfer

IO Input/Output

UPnP Universal Plug and Play

# 4 Architecture and Transmission Mechanism

The IP Media Device Management Protocol is based on REST architecture. The management and control interfaces defined in this specification are treated as resources utilizing the REpresentational State Transfer (REST) architecture. This architecture facilitates users by grouping related resources within hierarchical namespaces, and is more flexible for service discovery and future expansion.

REST architecture consists of clients and servers, among which clients initiate request to servers, while servers handle requests and response accordingly. Requests and responses are established via the transmission of "representations" of "resources". REST architecture need to be based on an Application Layer protocol which provides various of standard communication formats for applications based on the transfer of meaningful representational state. HTTP[1] has a very rich vocabulary in terms of verbs(or "methods"),



URIs, request and response headers, Internet media types, HTTP request and response codes etc. In addition, HTTP also has some features particularly suitable for REST architecture. So HTTP is used as external Application Layer protocol in this specification. In the architecture, clients are physical security and video management systems; servers are IP media devices.

This specification also contains full XML schema for the introduced resources.

### 4.1 REST and HTTP Methods

The following table shows how HTTP verbs are typically used to implement a web service based on REST architecture.

Table 1

Resource	GET	PUT	POST	DELETE
Collection URI, such as	List the	Meaning defined	Create a new	Meaning
http://webServer/resour	members of	as "replace the	entry in the	defined
ces	collection,	entire collection	collection where	as " <b>delete</b>
	complete with	with another	the ID is assigned	the entire
	their member	collection".	automatically by	collection"
	URIs for		the collection. The	
	further		ID created is	
	navigation.		usually included	
			as part of the data	
			returned by this	
			operation.	
Member URI, such as	<b>Retrieve</b> a	<b>Update</b> the	Treat the	Delete
http://webServer/resour	representation	addressed member	addressed	the
ces/7416	of the	of the collection or	member as a	addresse
	addressed	create it with the	collection in its	d member
	member of the	specified ID.	own right and	of the
	collection		<b>create</b> a new	collection.
	expressed in		subordinate of it.	
	an appropriate			
	MIME type.			

### 4.2 XML

A device must support the syntax defined by W3C XML 1.0 specification [2] and UTF-8 character set [3]. All XML files must adopt UTF-8 encoding according to RFC3629. Additionally, all resources share a common XML schema as defined in Annex.

Any resources can specify separate input and output XML Documents. If a specific data



structure is defined inside these documents, then they must be specified as XML Schema Documents (xsd) in Annex.

Lists contained in XML blocks will be represented in the format of <ISAPIList>, and each <ISAPIList> tag may contain one or more nodes.

### 4.3 Resources overview

Three kinds of resources are defined in this specification. They are "Standard Resources", "Services" and "General Resources". Related General Resources are grouped by Services. Services and General Resources contain Standard Resources. Figure 1 shows their relationship.




Figure 1

The "index", "indexr", "description" and "capabilities" are defined as Standard Resources in this specification. Both "index" and "description" will be mandatorily included by each node, and both "indexr" and "capabilities" will be optionally included by each node. For more detailed description see Section 6.

Services defined in this specification are divided into different services categories. Each category has its own name spaces (see Section 4.6 for the name space definitions). The following services are defined:

Table 2

Services	Description	Reference
System	Configure and operate the general system functions.	8.1
Network	Configure network interfaces.	8.2
Ю	Configure the Input/Output (IO).	8.3
Video	Handle video-related configuration.	8.4
Audio	Configure the Audio.	8.5
Two way audio	Control two ways audio.	8.6
Serial	Configure and control the Serial ports.	8.7
Security	Provide Security functions.	8.8



Services	Description	Reference
Streaming	8.9	
Motion Detection	Configure and control the motion detection of the device	8.10
Event	Event Provide event notification functions.	
PTZ	Control the device pan tilt and zoom.	8.12

### 4.4 Protocol URL

The URL scheme is used to locate device resources via a specific protocol in the network. This section defines the syntax and semantics for http(s) URLs.

#### cprotocol>://<host>[:port][abs\_path [?query]]

**protocol:** URL scheme for the particular request. The http and https protocols are allowed in this specification.

host: The host field refer to the hostname, IP address, or the FQDN of an IP device.

**port:** The port field refer to the port number of that host on which the identified resource is located at the IP device listening for TCP connections. If the port is empty or not given, the default port is assumed. For HTTP, the default port 80. For HTTPS, the default port 443.

**abs\_path:** The Request-URI [1] for the resources is abs\_path [4]. The abs\_path in this specification is most often of the form "[/Services][/General Resources][/Standard Resources]", which is suitable for resources to update or restore device configurations. "ID" which appears in the abs\_path identifies one resource of a list resource in this specification.

**query:** The query field is a string of information to be interpreted by the resource. It can include some resource-related parameters. It must be listed in name-value pair syntax (p1=v1&p2=v2&...&pn=vn). Each resource can define a set of parameters. Defining input data which is specific to the resource will be prior than query usage.

# 4.5 Messages

HTTP messages are used for communication between physical security and video management systems and IP media devices in this specification. In order to configure and control the device, some provisions are specified for these HTTP message.



### 4.5.1Connection Header Field

Devices that implement HTTP/1.1 should support persistent connections in order to meet video management systems or client applications' requirements that issue multiple HTTP(s) transactions. HTTP/1.1 is implemented and utilized according to RFC 2616 in the IP devices. For a video management system or client application that uses persistent connection for multiple transactions, it is required to implement "Connection: Keep-Alive" HTTP header field, while also adopt the "Connection: close" HTTP header field for the last transaction of the persistent connection. This process will assume that the application can identify the last request in a sequence of multiple requests.

# 4.5.2Authorization and WWW-Authenticate Header Fields

When a video management system or client application sends any request to the device, it must be authenticated by means of Basic Access [5] according to RFC 2617, and thus all the devices are required to support Basic Access. Authorization header field is sent along with each request, and if a user is authenticated, the request will follow the normal execution flow. If client HTTP request is with no authentication credentials, unauthorized HTTP response (401) will be returned with WWW-Authenticate header field.

# 4.5.3Entity Body

The Content-Type entity-header field indicates the media type of the entity body. The Content-Type may be designated as "application/xml; charset='UTF-8'", "application/octet-stream", etc.

For configuration information, the Content-Type is usually "application/xml; charset='UTF-8'". For example,

#### **HTTP Request Message:**

GET /ISAPI/System/status HTTP/1.1 ...

#### **HTTP Response Message:**

```
HTTP/1.1 200 OK
...

Content-Type: application/xml; charset="UTF-8"
...
```



```
<?xml version="1.0" encoding="UTF-8"?>
<DeviceStatus version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
...
</DeviceStatus>
```

For data (i.e. firmware, configuration file, etc.), the Content-Type may be "application/octet-stream". For example,

#### **HTTP Request Message:**

```
PUT /ISAPI/System/configurationData HTTP/1.1
...
Content-Type: application/octet-stream
...
[proprietary configuration file data content]
```

#### **HTTP Response Message:**

```
HTTP/1.1 200 OK
...

Content-Type: application/xml; charset="UTF-8"
...

<?xml version="1.0" encoding="UTF-8"?>
<ResponseStatus version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
...

</ResponseStatus>
```

# 4.5.4Operations

Different resources will specify different operation.

- The "set device configuration" resources use PUT operation. If there is an XML block parameter for the request, the inbound XML format is defined according to a resource-special XML schema. Request status will be returned by the XML response information of the device, and can be used for indicating the PUT operation status. The responded XML format is defined by "XML Response Schema" (please refer to section 4.5.5 for detail description). After the device configuration is updated successfully, it will return an XML response with status code "OK"; while another status code will be used for indicating unsuccessful operations. In either case, the device only responses after it is ready to continue normal operation, i.e. accepting streaming request, receiving configuration commands, etc.
- The "get device configuration" resources use GET operation. After a successful GET operation, the result will be returned in XML format according to the



resource description. For an unsuccessful request (i.e. users is not authenticated), the result will be returned in XML format according to "XML Response Schema".

- Resources to create device configurations information will use the POST operation. If there is an XML block parameter for the request, the inbound XML format is defined according to a resource-special XML schema. The request status will be indicated by the XML response information returned from the device, and can be used to indicate the status of the POST operation. This XML format is defined according to "XML Response Schema" (see section 4.5.5 for details). After successfully creating the data, the device returns an XML response with status code "OK". A separate status code is used for unsuccessful operations.
- Resources to delete device configurations information will use the Delete operation. If successful, the result will be returned an XML response with status code "OK". A separate status code is used for unsuccessful operations. This XML format is defined according to "XML Response Schema" (see section 4.5.5 for details).
- Data uploading resources (i.e. firmware upgrade, import configuration, etc.) will use PUT operation. The content of the data will be stored in the body of the HTTP request. If successful, the result will be returned an XML response with status code "OK". A separate status code is used for unsuccessful operations. This XML format is defined according to "XML Response Schema" (see section 4.5.5 for details).
- Data receiving resources (i.e. export configuration file) use GET operation. If successful, the result will be returned the data according to the resource description. An XML block is used for unsuccessful operations. This XML format is defined according to "XML Response Schema" (see section 4.5.5 for details).
- For Standard Resources, GET operation will be used. For more detailed description see Section 6.

If there is an XML block for the HTTP request or response, the Content-Type and Content-Length will be set in the headers of the HTTP message.

### 4.5.5Error Handling

As with any other protocol, errors may occur during communications, protocol or message processing, and the specification classifies error handling into categories below:

Protocol Errors, which are result of an incorrectly formed protocol message. Protocol Errors may contain header value or be received in an not expected or experience a socket timeout. To indicate and interpret protocol error, HTTP protocol has defined a set of standard status codes [e.g., 1xx, 2xx, 3xx, 4xx, 5xx]. According to this specification, the IP devices will use appropriate HTTP protocol defined status codes for error reporting and when received handle accordingly.



- Application Errors, which are generated as a result of REST operations errors. All such application errors must be reported and handled through HTTP messages. The following table indicates the mapping relationship between HTTP status codes and REST operations, and also the information contained in response header and bodies.

Table 3

LITTO	Table 3				
HTTP Status	REST Meaning	GET	PUT	POST	DELETE
Codes					
200	"OK"-The request has succeeded. Header Notes: None Body Notes: The requested resource will be returned in the	V	V		V
201	body.  "Created"- The request has created a new resource.  Header Notes: The Location header contains the URI of the newly created resource.  Body Notes: The response returns an entity describing the newly created resource.		V	V	
204	"No Content" – The request succeeded, but there is no data to return.  Header Notes: None Body Notes: No body is allowed.		V		V
301	"Moved Permanently" – The requested resource has moved permanently.  Header Notes: The Location Header contains the URI of the new location.  Body Notes: The body may contain the new resource location.	√			
302	"Found" — The requested resource should be accessed through this location, but the resource actually lives at another location. This is typically used to set up an alias.	V			



HTTP Status **REST Meaning GET** PUT **POST** DELETE Codes Header Notes: The Location header contains the URI of the resource. Body Notes: The body may contain the new resource location. "Bad Request" - The request was badly formed. This is commonly used for creating or updating a resource, but the data was incomplete incorrect. The Header Notes: 400 Reason-Phrase sent with the HTTP status header may contain information on the error. Body Notes: The response may contain more information of the underlying error that occurred in addition to the Reason-Phrase. "Unauthorized" - The request requires user authentication to access this resource. If the contains invalid request authentication data, this code is Header Notes: At least one authentication mechanism must 401 specified in WWW-Authenticate header. The Reason-Phrase sent with the HTTP status header may contain information on the error. Body Notes: The response may contain more information of the underlying error that occurred in addition to the Reason-Phrase. "Forbidden" – The request is not 403  $\sqrt{}$  $\sqrt{}$  $\sqrt{}$  $\sqrt{}$ allowed because the server is refusing to fill the request. A



HTTP Status **REST Meaning GET** PUT **POST** DELETE Codes common reason for this is that the device does not support the requested functionality. Header Notes: The Reason-Phrase sent with the HTTP status header may contain information on the error. Body Notes: The response may contain more information of the underlying error that occurred in addition to the Reason-Phrase. "Not Found" - The requested resource does not exist. 404 Header Notes: None Body Notes: None "Method Not Allowed" - The request used an HTTP method that is not supported for the resource because specification does not allow this method. If the device does support the functionality but it is 405  $\sqrt{}$ a valid operation (that has been defined in this specification), then 403 is returned. Header Notes: The Allow header lists the supported **HTTP** methods for this resource. Body Notes: None "Internal Server Error" - An internal server error has  $\sqrt{}$ 500 occurred. Header Notes: None Body Notes: None "Service Unavailable" - The HTTP Server is up, but the REST service is not available. 503 Typically this is caused by too many client requests. Header Notes: The Retry-After



HTTP Status Codes	REST Meaning	GET	PUT	POST	DELETE
	header suggests to the client when to try resubmitting the				
	request. Body Notes: None				

Responses to many resources calls contain data in XML format. XML Response Schema is defined in Annex. XML Response Schema consists of the following sections:

- requestURI the URI of the corresponding HTTP request message
- statusCode indicating the status of the REST operations.

Table 4

statusCode	Description
	"OK" - indicate a successful operation is done (remark: if the request
1	contains some parameters that are not supported, the device will ignore
	those parameters and return OK as statusCode)
2	"Device Busy" - for a command which cannot be processed at that time
2	(i.e. if the device receives a reboot command during upgrading process)
	"Device Error" - if the device can not perform the request for a hardware
3	error. An error message in statusString format to indicate operation
	failure
	"Invalid Operation" - either if the operation is not supported by the device,
4	or if the user has not passed the authentication, or if the user does not
	have enough privilege for this operation
5	"Invalid XML Format" - if the XML format is not recognized by the system.
3	There will be statusString returned to represent different errors
6	"Invalid XML Content" - an incomplete message or a message containing
	an out-of-range parameter. Relative statusString will be return.
7	"Reboot Required" - If a reboot is required before the operation taking
,	effect

- statusString error type for the not completed operation.
- id Return the ID created by the device in POST operation
- subStatusCode detail string indicating the reason the command was not completed. Table 5 contains general subStatusCode, In addition, Each resource may have some special subStatusCode, Each subStatusCode reference resource description.

Table 5

statusCode	subStatusCode	Description
1	ok	indicate a successful operation is done
2	noMemory	Device doesn't have enough memory
2	serviceUnavailable	service unavailable



statusCode subStatusCode **Description** upgrading upgrading deviceBusy Device busy or no response deviceError Device hardware error 3 badFlash Operate flash error notSupport The device does't support this resource IowPrivilege Not have enough privilege for this operation badAuthorization The user has not passed the authentication methodNotAllowed http method is not allowed 4 can't set redundancy attribute for hdd disk(system notSetHdiskRedund exists more than one non-operate hdd disk, and the attribution of a hdd disk is WR) invalidOperation Invalid operation 5 badXmlFormat Wrong XML format badParameters Parameters error badHostAddress Wrong Host Address badXmlContent Wrong XMLcontent badIPv4Address Wrong IPv4 address badIPv6Address Wrong IPv6 address conflictIPv4Address IPV4 address conflict conflictIPv6Address IPV6 address conflict badDomainName Wrong Domain 6 connectSreverFail Failed to connect with Server conflictDomainName Domain conflict badPort Port conflict portError Port error importErrorData Failed to import data badNetMask Wrong subnet mask badVersion Version mismatching badDevType Device type mismatching badLanguage Language mismatching A reboot is required before the operation taking 7 rebootRequired effect

# 4.6 Namespaces

The namespace xmlns="http://www.isapi.org/ver20/XMLSchema" is used in this specification.

The following namespaces are referenced by this specification:

xmlns:xs="http://www.w3.org/2001/XMLSchema"



- xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
- xmlns:xlink="http://www.w3.org/1999/xlink"

### 4.7 Security

User-based access control is adopted in this specification. Security policy configuration in this specification based on three different user levels.

- Administrator the privilege can access all supported resources on IP device.
- Operator the privilege can access some general-level and higher-level resources.
   See the Resource Description of each resource for details.
- Viewer the privilege can only access some general-level resources. See the Resource Description of each resource for details.

In order to access all supported resources, one account with Administrator privilege level must be active at all times. A default user account "admin" is provided by all IP devices. It has an Administrator user level, and must not be deleted. Its default password is "12345".

# 5 Device discovery

The IP devices support Universal Plug and Play (UPnP) technology to discovery/locate themselves. A UPnP compatible device will automatically announce its network address, supported devices and services types when connected to a network, and therefore becoming "plug-and-play" by allowing clients recognize those information and begin using this device immediately.

The UPnP architecture supports zero-configuration networking, and the device can dynamically join a network, obtain IP address, announce its name, convey its capabilities upon request, and gets the on-line status and capabilities of other devices. DHCP and DNS servers are optional and are only used if they are available on the network. Devices can leave the network automatically without leaving any unwanted status information behind. UPnP was published as a 73-part International Standard, ISO/IEC 29341, in December, 2008 [6][7][8].

The foundation for UPnP networking is IP addressing. When a device is connected to the network for the first time, its Dynamic Host Configuration Protocol (DHCP) client will search for a DHCP server. If the device successfully get its domain name via DNS server or DNS forwarding, then it should use this domain name for the following network operations; if the network is unmanaged and no DHCP server is found, the device must assign an address for itself, which is known as "AutoIP" of the UPnP Device Architecture [9][10], and use this IP address for the following network operations.



Once given an IP address, the Discovery process will be executed in UPnP networking. The UPnP discovery protocol is also knows as Simple Service Discovery Protocol (SSDP). When a device is added to the network, SSDP allow that device to announce its services to the control points on the network. Similarly, when a control point is added to the network, SSDP allows that control point to search for relative devices on the network. During the above searching or announcing process, a a discovery message which contains essential device specifics or one of its services will be transfered, for example, device type, identifier, and a pointer to more detailed information.

After a control point has discovered a device, the control point still needs more operations to request more information about the device or to interact with it. An HTTP GET request for mandatory index Standard Resource will return a list of the resources supported by the device.

Remark: the index resource will only return the first level resources of a node, while the indexr Standard Resource will return a complete folder list in tree structure with the current resource as root folder.

# **6 Resource Description**

# **6.1 Resource Description Outline**

Each resource in this specification is defined using the following format.

Resource_URI	Type Ve	ersion
Operation_Name		
Description	Description of the operation.	
Query	Indicates the name/value pairs (p1, p2, p3,,pn) for the resour	rce.
Inbound Data	Indicates inbound data for the resources.	
Success Return	the Type (if present) and the name of XML Data Block	
Error Status Code	Special fault code, optional	
Notes: describes ar	ny special processing rules for the resource.	

Type refers to "Standard Resource", "Service" and "General Resource".

*Version* is used to determine the version of the protocol. The version number shall be set to "1.0" in this specification.

Operation\_Name refers to "GET", "PUT", "POST" and "DELETE".

Inbound Data includes three types as follows:

- NONE -no input data
- DataBlock the name of an XML Data Block. Datablocks used here must be defined according to the specification.



- Mime type – mime type for the input data in the HTTP payload. Remark: "application/ xml" is not a valid mime type.

If a device does not support particular XML tags or blocks, then it may not be supported by the resource operations.

Generally, if a field is not provided in the inbound XML, then its current values shall not be modified in the device's repository.

If a required field did not exist in the device's repository, then it must be provided in the applicable resource operations.

Success Return and Error Return detailed description see Section 4.5.5.

# 6.2 Built-in Types

Table 6

Туре	Description
	A positive numerical value indicating the data transmission rate in symbols
BaudRate	per second.
Dadditate	Value is >=0.
	Example: 9600
Color	RGB triplet in hexadecimal format (3 bytes) without the preceding "0x".
Coloi	Example: "FF00FF"
	A positive numerical value in pixels. A coordinate pair of 0,0 (x,y) indicates
	the
Coordinate	bottom-left corner of the video image.
	Value is >=0.
	Maximum value is dependent on video resolution.
FPS	Frame rate multiplied by 100.
FFS	Example: 2500 [PAL]
IPv4	Notation is ISAPI.ISAPI.ISAPI
Address	Example: 3.137.217.220
MAC	MAC Address
MAC	Notation is aa:bb:cc:dd:ee:ff with 6 hex bytes.

### 6.3 Annotation

The XML Data Blocks described in this document contains annotations for the field's properties. Please refer to the XML schema definitions for detail description.

The following annotation content is inserted into the comments to describe the data carried in the field:

Table 6

Annotation	Description
------------	-------------



req	Required field.
0-4	Optional field. For data uploaded to the device, if the field is present but the
Opt	device does not support it, it should be ignored.
Dep	This field is required depending on the value of another field.
	Read-only. For XML data that is both read and written to the device, this
Ro	field is only present in XML returned from the device. If this field is present
	in XML uploaded to the device, it should be ignored.
	Write-only. This field is only present in XML that can be uploaded to the
Wo	device. This field should never be present in data returned from the device.
	[This is used for uploading passwords].
Xs: <type></type>	A type defined in XML Schema Part 2: Datatypes Second Edition, see
	http://www.w3.org/TR/xmlschema-2

Remark: optional XML structures may contain required fields for the operation, which mean that even if the entire XML block is optional, some of its contained fields may still be necessary if required.

# 7 Standard Resources

This section describes the standard resources.

Standard Resources do not contain themselves.

The requestURIs "/index", "/description" are required.

### 7.1 index

index	Standard Resource v2.0	
GET		
Description	Enumerate child resources of a resource.	
Query	None	
Inbound Data	None	
Success Return	<resourcelist></resourcelist>	
Notes: Returns a non-recursive resource listing of all child resources.		

### 7.2 indexr

indexr	Standard	Resource	v2.0
GET			
Description	Enumerate child resources of a resource.		
Query	None		



Inbound Data	None	
Success Return	<resourcelist></resourcelist>	
Notes: Returns a recursive resource listing of all child resources.		

### 7.3 description

description		Standard	Resource	v2.0
GET				
Description	Describe the corresponding resource			
Query	None			
Inbound Data	None			
Success Return	<resourcedescription></resourcedescription>			
Notes: <version> set the version of resource. In this specification, its value is "2.0".</version>				

A version attribute is included in the description. This means resources with different versions may exist within the same Services. In that case, the version of Services is the version of the contained resource with the lowest version, and all resources in the Services container must be backward compatible. If any resource of a Service container can not maintain backward compatibility with previous versions, a new Services version should be introduced.

# 7.4 capabilities

capabilities	Standard Resource v2.0
GET	
Description	Describe the capabilities of the corresponding resource
Query	None
Inbound Data	None
Success Return	Resource-specified
Notes:	

For the General Resource, which inbound data is specified as an XML payload, the Standard Resource (capabilities) is provided for video management systems or client applications to query an IP device and understand what XML tags are supported.

"Capabilities" is essentially an XML instance of the corresponding General Resource XML Data Block. "Capabilities" must contain the acceptable values for each attribute.

While XML Schema Document are also required of any XML data defined by this specification and xsd documents are capable of defining the acceptable range of values



for any attribute, using a global xsd to define capacities would imply that all devices support the same options for any parameter. By allowing devices to respond to the capabilities request, each device can support different values for any attribute, within the constraints of the schema.

Table 7

Table 7				
Capabilities Attribute	S Description Syntax		Applicable XML Data	
	The minimum character length for a string, or the	Examples: min="0"	Types  All except fixed data types <sup>1)</sup>	
min	minimum numerical value of a number	min="19" min="-74"(numerical only)	data types	
		min="1.6"		
max	The maximum character length for a string, or the maximum numerical value of a number	Examples: max="4" max="37" max="8192" max="14.61"	All except fixed data types <sup>1)</sup>	
range	Indicates the possible range of numerical values within the "min" and "max" attributes of an element. This attribute should only be used if the possible value for an XML element does not include the entire numerical range between "min" and "max" attributes	Ranges are listed in numerical order separated by a "," character. A range has the form "x~y" where x is the range floor and y is the range ceiling. Single numbers may also be used.  Example: if an XML element supports values 0, 456, 1674 to 2009 and 2012, the syntax would be: range="0, 456, 1674~2009, 2012"	All numerical data types	
opt	All except fixed data types	If all options are supported, the syntax is "all". Otherwise, supported options are listed separated by a ", " character.	All except fixed data types	

©2009 – 2014 by HIKVISION. All rights reserved.



**Applicable Capabilities Description Syntax** XML Data **Attribute Types** opt="all" opt="1, 4, 6, 7" Indicates the default value Examples: All data types of the XML element. If the def="7416" element has not default def="ace" def value, this attribute should not be used Indicates if configuration of reqReboot="true" All data types this XML element requires a device reboot before taking reqReboot effect. If an element does not require a boot, this attribute should not be used Indicates if an XML element dynamic="true" All data types has dynamic capabilities dependent on other XML configuration. For example, if an element's data range changes based on another dynamic element's configured value, this attribute must be used. In this case, the element's capability attributes must always reflect the current device configuration Only supported Indicates the maximum Example: If a device number of entries in an XML supports 16 users the for list elements List. This attribute is only example would be Size <UserList size="16"> applicable to **XML** elements. This attribute <User> should not be used for any </UserList> other type of element

©2009 – 2014 by HIKVISION. All rights reserved.

<sup>1)</sup> Fixed, pre-defined data types do not need certain capability attributes because their formats/data ranges are already defined.



# 8 Services and General Resources

# 8.1 /ISAPI/System

/ISAPI/System	Service v2.0
Notes:	

# 8.1.1/ISAPI/System/capabilities

/ISAPI/System/capabilities		General Resource v2.0	
GET			
Description	It is used to get device capability.		
Query	None		
Inbound Data	None		
Success Return	<devicecap></devicecap>		
Notes:			
Some capabilities t	Some capabilities that could not be described by statand capability resource will be listed		
here.			
<issupportdst>: Is this device support daylight saving time.</issupportdst>			

#### DeviceCap XML Block



```
<SmartCap/> <!--- opt -->
    <WLAlarmCap/> <!--- opt-->
    </DeviceCap>
```

# 8.1.2/ISAPI/System/reboot

/ISAPI/System/reboot		General Resource	v2.0	
PUT	PUT			
Description	Reboot the device.			
Query	None			
Inbound Data	None			
Success Return	<responsestatus></responsestatus>			
	statusCode	subStausCod	description	
Error Status Code	Statuscoue	е		
	2 upgrading Device is upgrading			
Notes:				
<responsestatus< th=""><td colspan="3"><responsestatus> is returned before the device proceeds to reboot.</responsestatus></td><td></td></responsestatus<>	<responsestatus> is returned before the device proceeds to reboot.</responsestatus>			

# 8.1.3/ISAPI/System/updateFirmware

/ISAPI/System/updateFirmware General Resourc			General Resource v2.0	
PUT				
Description	Updatethe firn	Updatethe firmware of the device.		
Query	None			
Inbound Data	Opaque Data			
Success Return	<responsestatus></responsestatus>			
Error Status	statusCode	subStatusCod e	description	
	2	upgrading	device upgrading	
Code	3	badFlash	Flash error	
	6 badLanguage Language mismatch			
Notes:				
After successful	completion of th	nis API, the <respo< td=""><td>onseStatus&gt; XML data is returned, and</td></respo<>	onseStatus> XML data is returned, and	

the device proceeds to reboot.



# 8.1.4/ISAPI/System/configurationData

/ISAPI/System/configurationData General R			General Resource	v2.0
GET				
Description	Get device's c	Get device's configuration data.		
Query	None			
Inbound Data	None			
Success Return	Opaque Data			
PUT				
Description	Update device	e's configuration da	ıta.	
Query	None	None		
Inbound Data	Opaque Data			
Success Return	<responsest< td=""><td>tatus&gt;</td><td></td><td></td></responsest<>	tatus>		
	statusCode	subStatusCod e	description	
	2	upgrading	Device upgrading	
Error Status Code	3	badFlash	Flash error	
Code	6	badVersion	Version mismatch	
	6 badDevType Device type mismatch			
	6 badLanguage Language mismatch			
Notes:	is device-dene	ndant – it may he l	oinary or any other format.	
	•	ation file is applied	•	

# 8.1.5/ISAPI/System/factoryReset

/ISAPI/System/factoryReset General Resource v2.0		
PUT		
Description	It is used to reset the configuration for the device to the factory default.	
Query	mode	
Inbound Data	None	
Success Return	<responsestatus></responsestatus>	
Notes:		
Two factory reset i	modes are supported:	
"full" resets all device parameters and settings to their factory values.		
"basic" resets all device parameters and settings except the values in Network Service.		



The default mode is "full".

The device may be rebooted after it is reset.

# 8.1.6/ISAPI/System/deviceInfo

/ISAPI/System/deviceInfo		General Resource	v2.0	
GET				
Description	It is used to get device information.			
Query	None	None		
Inbound Data	None	None		
Success Return	<deviceinfo></deviceinfo>			
PUT				
Description	It is used to update device information.			
Query	None			
Inbound Data	<deviceinfo></deviceinfo>			
Success Return	<responsestatus></responsestatus>			

#### Notes:

Some fields are read-only and may not be set. If these fields are present in the inbound XML block, they are ignored.

For the <DeviceInfo> uploaded to the device during a PUT operation, all fields are considered optional and any fields that are not present in the inbound XML are not changed on the device. This allows setting of the fields individually without having to load the entire XML block to the device.

<deviceDescription> is a description of the device as defined in RFC1213.

For IPC the <deviceDescription> value is IPCamera;

For IP speed Dome the <deviceDescription> value is IPDome;

For DVR or DVS the <deviceDescription> value is DVRDVS;

<deviceLocation> is the location of the device as defined in RFC1213

<systemContact> is the contact information for the device as defined in RFC1213.

#### **DeviceInfo XML Block**

```
<DeviceInfo version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <deviceName>
                      <!-- req, xs:string -->
                                                </deviceName>
  <deviceID>
                    <!-- ro, req, xs:string, uuid-->
                                                       </deviceID>
  <deviceDescription> <!--opt, xs:string--> </deviceDescription>
                       <!--opt, xs:string -->
  <deviceLocation>
                                                </deviceLocation>
  <systemContact>
                       <!-- opt, req, xs:string -->
                                                     </systemContact>
  <model>
                                                 </model>
                     <!-- ro, req, xs:string -->
  <serialNumber>
                       <!-- ro, req, xs:string -->
                                                  </serialNumber>
```



```
<macAddress> <!-- ro, req, xs:string; --> </macAddress>
  <firmwareVersion>
                       <!-- ro, req, xs:string --> </firmwareVersion>
 <firmwareReleasedDate> <!-- ro, opt, xs:string -->
                                                      </firmwareReleasedDate>
 <bootVersion>
                     <!-- ro, opt, xs:string --> </bootVersion>
 <bootReleasedDate> <!-- ro, opt, xs:string -->
                                                    </bootReleasedDate>
 <hardwareVersion> <!-- ro, opt, xs:string --> </hardwareVersion>
 <encoderVersion> <!-- ro, opt, xs:string> </encoderVersion>
 <encoderReleasedDate> <!-- ro, opt, xs:stirng --> </encoderReleasedDate>
 <decoderVersion> <!-- ro, opt, xs:string> </decoderVersion>
 <decoderReleasedDate> <!-- ro, opt, xs:stirng --> </decoderReleasedDate>
 <deviceType>
    <!--ro, reg, xs:string; "IPCamera, IPDome, DVR, HybirdNVR, NVR, DVS, IPZoom"-->
 <deviceType>
 <telecontrolID> <!-- opt, xs:integer; "1-255"> <telecontrolID>
  <supportBeep/> <!--opt, xs:boolean --> </supportBeep>
</DeviceInfo>
```

# 8.1.7/ISAPI/System/status

/ISAPI/System/st	atus General Resource v2.	
GET		
Description	It is used to get the status information of the device.	
Query	None	
Inbound Data	None	
Success Return	DeviceStatus	
Notes:		

#### DeviceStatus XML Block



```
<FanList>
    <!-- opt -->
    <Fan>
      <fanDescription> <!-- req, xs:string --> </fanDescription>
      <speed> <!-- req, xs:integer --> </speed>
    </Fan>
  </FanList>
  <PressureList>
    <!-- opt -->
    <Pressure>
      --></pressureSensorDescription>
                  <!-- req, xs:integer --> </pressure>
      </Pressure>
  </PressureList>
  <TamperList>
    <!-- opt -->
    <Tamper>
      <tamperSensorDescription> <!-- req, xs:string --> </tamperSensorDescription>
      <tamper> <!-- req, xs:boolean --> </tamper>
    </Tamper>
  </TamperList>
  <CPUList>
    <!-- opt -->
    <CPU>
      <cpuDescription> <!-- req, xs:string --> </cpuDescription>
      <cpuUtilization> <!-- req, xs:integer, percentage 0..100 --> </cpuUtilization>
    </CPU>
  </CPUList>
  <MemoryList>
    <!-- opt -->
    <Memory>
      <memoryDescription> <!-- req, xs:string --> </memoryDescription>
      <memoryUsage> <!-- req, xs:float, in MB --> </memoryUsage>
      <memoryAvailable> <!-- req, xs:float, in MB--> </memoryAvailable>
    </Memory>
  </MemoryList>
  <openFileHandles> <!-- opt, xs:integer --> </openFileHandles>
```



</DeviceStatus>

## 8.1.8/ISAPI/System/time

/ISAPI/System/tim	e General Resource v2.0
GET	
Description	Get the device time information.
Query	None
Inbound Data	None
Success Return	Time
PUT	
Description	Udpate the device time information.
Query	None
Inbound Data	Time
Success Return	ResponseStatus
Notes:	
If <timemode> is p</timemode>	resent and set to "local", the <localtime> and <timezone> fields are</timezone></localtime>

required. The <localTime> block sets the device time.

If <timeMode> is present and set to "NTP", only the <timeZone> field is required. The device time is set by synchronizing with NTP.

## **Time XML Block**

## 8.1.9/ISAPI/System/time/localTime

/ISAPI/System/time/localTime		General Resource	v2.0	
GET				
Description	It is used to get the device local time information.			
Query	None	one		
Inbound Data	None			
Success Return	ISO 8601 Date-Time String			
PUT	PUT			
Description	It is used to udpate the device local time in	nformation.		
Query	None			



Inbound Data	ISO 8601 Date-Time String
Success Return	ResponseStatus

### Notes:

An ISO 8601 Date/Time string is accepted and returned. If the date/time value has a time zone, the time is converted into the device's local time zone.

If the device time mode is set to "ntp" setting this value has no effect.

## 8.1.10 /ISAPI/System/time/timeZone

/ISAPI/System/time/timeZone		eral Resource	v2.0	
GET				
Description	It is used to get the device time zone information	ı <b>.</b>		
Query	None			
Inbound Data	None			
Success Return	Time zone string			
PUT				
Description	It is used to udpate the device time zone information	ation.		
Query	None			
Inbound Data	Time zone string			
Success Return	ResponseStatus			

#### Notes:

Time zones are defined by POSIX 1003.1 section 8.3 time zone notations. Note that the value following the +/- is the amount of time that must be added to the local time to result in UTC.

### Example:

EST+5EDT01:00:00,M3.2.0/02:00:00,M11.1.0/02:00:00

Defines eastern standard time as "EST" with a GMT-5 offset. Daylight savings time is called "EDT", is one hour later and begins on the second Sunday of March at 2am and ends on the first Sunday of November at 2am.

CET-1CEST01:00:00,M3.5.0/02:00:00,M10.5.0/03:00:00

Defines central European time as GMT+1 with a one-hour daylight savings time ("CEST") that starts on the last Sunday in March at 2am and ends on the last Sunday in October at 3am.

Check whether the device supports DST capability from 8.1.6 device capabilities



## 8.1.11 /ISAPI/System/time/NtpServers

/ISAPI/System/tim	ne/ntpServers General Resource v2.0
GET	
Description	It is used to get the configuration of NTP servers for the device.
Query	None
Inbound Data	None
Success Return	NTPServerList
PUT	
Description	It is used to update the configuration of NTP servers for the device.
Query	None
Inbound Data	NTPServerList
Success Return	ResponseStatus
POST	
Description	It is used to add the configuration of a NTP server for the device.
Query	None
Inbound Data	NTPServer
Success Return	ResponseStatus
DELETE	
Description	It is used to delete the configuration of NTP servers for the device.
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes:	

- - - -

When the <timeMode> is set to "NTP", the servers in this list are used to synchronize the device's system time.

To determine whether it is possible to dynamically create or delete ntp server, check the defined HTTP methods in /ISAPI/System/time/ntpServers/description.

### NTPServerList XML Block

<NTPServerList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <NTPServer/> <!-- opt --> </ NTPServerList>

## 8.1.12 /ISAPI/System/time/ntpServers/<ID>

/ISAPI/System/time/ntpServers/ID		General Resource va	2.0
GET			
Description	It is used to get the configuration of a	NTP server for the device.	



Query	None
Inbound Data	None
Success Return	NTPServer
PUT	
Description	It is used to update the configuration of a NTP server for the device.
Query	None
Inbound Data	NTPServer
Success Return	ResponseStatus
DELETE	
Description	It is used to delete the configuration of a NTP server for the device.
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes:	

Depending on the value of <addressingFormatType>, either the <hostName> or the IP

#### **NTPServer XML Block**

address fields will be used to locate the NTP server.

## 8.1.13 /ISAPI/System/Holidays

URI	/ISAPI/System/Holidays			Туре	Resource
Function	Access the list of holidays				
Methods	Query String(s)	Inbound Data	Return Result		
GET			<holidaylist></holidaylist>		st >
PUT		<holidaylist></holidaylist>	<responsestatus></responsestatus>		tatus>



Notes		

### holidayList XML Block

```
<HolidayList version="2.0" xmlns="http://urn:selfextension:ISAPlext-ver10-xsd">
    <holiday/> <!-- opt -->
    </HolidayList>
```

## 8.1.14 /ISAPI/System/Holidays/<ID>

URI	/ISAPI/System/Holidays/ID/			Туре	Resource
Function	Access a holiday.				
Methods	Query String(s)	Inbound Data	Ret	urn Res	sult
GET	<holiday></holiday>				>
PUT	<holiday> <responsestatus></responsestatus></holiday>				tatus>
Notes	<holidaymode> decides whether <holidaydate>,<holidayweek>or <holidaymonth> is contained. <holidaymode>:date: example form May 5<sup>th</sup>,1900 to June 8<sup>th</sup>,1900.</holidaymode></holidaymonth></holidayweek></holidaydate></holidaymode>				
	<holidaymode>:week: example form May 1<sup>st</sup> week to May 2<sup>nd</sup> week.</holidaymode>				
	<holidaymode>:month:</holidaymode>	example form May 1 <sup>st</sup> to May 5 <sup>th</sup>			

## holiday XML Block

```
<holiday version="2.0" xmlns="http://urn:selfextension:ISAPlext-ver10-xsd">
  <id>
                                                                    </id>
                       <!-- req, xs:string;id -->
  <enabled>
                        <!-- req, xs:boolean -->
                                                                    </enabled>
  <holidayMode/> <!-- req, xs:string, "date, weeek, month" --> <holidayName>
                                                                                        <!--
  req, xs:string --> </holidayName>
  <holidayDate> <!-- dep -->
   <startDate> <!-- req, xs:date --> </startDate>
   <endDate> <!-- req, xs:date --> </endDate>
  </holidayDate>
  <holidayWeek> <!-- dep -->
   <startWeek> <!-- req -->
     <monthOfYear> <!-- req --> </monthOfYear>
     <sequence> <!-- req, xs:integer, 1...5 --> </sequence>
     <dayOfWeek>
```



```
<!-- req, ISO8601 weekday number, 1=Monday" -->
     </dayOfWeek>
   </startWeek>
   <endWeek> <!-- req -->
     <monthOfYear> <!-- req --> </monthOfYear>
     <sequence> <!-- req, xs:integer, 1...5 --> </sequence>
     <dayOfWeek>
          <!-- req, ISO8601 weekday number, 1=Monday" -->
     </dayOfWeek>
  </endWeek>
  </holidayWeek>
  <holidayMonth> <!-- dep -->
   <startMonth>
                  <!-- req -->
    <monthOfYear> <!-- req, xs:integer, "1...12" --> </monthOfYear>
    <dayOfMonth> <!-- req, xs:integer, "1...31" --> </dayOfMonth>
   </startMonth>
   <endMonth> <!-- req -->
   <monthOfYear> <!-- req, xs:integer, "1...12" --> </monthOfYear>
    <dayOfMonth> <!-- req, xs:integer, "1...31" --> <dayOfMonth>
   </endMonth>
  </holidayMonth>
</holiday>
```

## 8.1.15 /ISAPI/System/upgradeStatus

/ISAPI/System/upgradeStatus		General Resource	v2.0
GET			
Description	It is used to get upgrade status of the de	vice.	
Query	None		
Inbound Data	None		
Success Return	upgradeStatus		
Notes:			

### upgradeStatus XML Block



</upgradeStatus>

## 8.2 /ISAPI/System/Network

/ISAPI/System/Network	Service	v2.0
Notes: Network configuration.		

## 8.2.1/ISAPI/System/Network/capabilities

/ISAPI/System/Network/capabilities		General Resource	v2.0
GET			
Description	It is used to get network capability.		
Query	None		
Inbound Data	None		
Success Return	<networkcap></networkcap>		
Notes:			

## NetworkCap XML Block

```
<NetworkCap version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <isSupportWireless> <!-- req, xs:boolean --> <isSupportWireless>
  <isSupportPPPoE> <!-- req, xs:boolean --> <isSupportPPPoE>
  <isSupportBond> <!-- req, xs:boolean --> <isSupportBond>
  <isSupport802_1x> <!-- req, xs:boolean --> </isSupport802_1x>
  <isSupportNtp> <!-- opt, xs:boolean --> </ isSupportNtp>
  <isSupportFtp> <!-- opt, xs:boolen --> </isSupportFtp>
  < isSupportUpnp> <!-- opt, xs:boolean --> </ isSupportUpnp>
  < isSupportPNP> <!-- opt, xs:boolean --> </isSupportPNP>
  < isSupportDdns> <!-- opt, xs:boolean --> </ isSupportDdns>
  <isSupportHttps> <!-- opt, xs:boolean --> </isSupportHttps>
  <SnmpCap><!-- opt -->
     <isSupport> <!-- req, xs:boolean --> </isSupport>
  </SnmpCap>
  <isSupportExtNetCfg> <!-- opt, xs:boolean --> </isSupportExtNetCfg>
  <isSupportIPFilter> <!-- opt, xs:boolean --> </isSupportIPFilter>
</NetworkCap>
```



## 8.2.2/ISAPI/System/Network/interfaces

/ISAPI/System/Ne	etwork/interfaces	General Resource	v2.0
GET			
Description	It is used to get the device network interfa	aces.	
Query	None	None	
Inbound Data	None		
Success Return	NetworkInterfaceList		
Notes:			
As hardwired system resources, network interfaces cannot be created or destroyed.			

## **NetworkInterfaceList XML Block**

## 8.2.3/ISAPI/System/Network/interfaces/<ID>

/ISAPI/System/N	letwork/interfa	ices/ID	General Resource v2.0
GET			
Description	It is used to ge	et a particular network in	terface.
Query	None		
Inbound Data	None		
Success Return	NetworkInter	face	
PUT			
Description	It is used to up	odate a particular networ	k interface.
Query	None		
Inbound Data	NetworkInter	face	
Success Return	ResponseSta	itus	
	statusCode	subStatusCode	Description
	6	badIPv6Address	error IPv6 address
Error Status	6	conflictIPv6Address	conflictIPv6Address
Code	6	badNetMask	error subnet mask
	6	conflictIPv4Address	conflictIPv4Address
	6	badIPv4Address	error IPv4 address
Notes:			
defaultConnection	n: default netv	vork connection, require	ed when device has more than one



interface.

#### **NetworkInterface XML Block**

# 8.2.4/ISAPI/System/Network/interfaces/<ID>/ipAd dress

/ISAPI/System/N	Network/interfa	aces/ <i>ID</i> /ipAddress	General Resource	v2.0
GET				
Description	It is used to ge	et the ip address of a par	rticular network interface.	
Query	None			
Inbound Data	None			
Success Return	<b>IPAddress</b>			
PUT				
Description	It is used to up	odate the ip address of a	particular network interface.	
Query	None	None		
Inbound Data	<b>IPAddress</b>	IPAddress		
Success Return	ResponseSta	atus		
	statusCode	subStatusCode	Description	
	6	badIPv6Address	error IPv6 address	
Error Status	6	conflictIPv6Address	conflictIPv6Address	
Code	6	badNetMask	error subnet mask	
	6	conflictIPv4Address	conflictIPv4Address	
	6	badIPv4Address	error IPv4 address	

### Notes:

If <addressingType> is dynamic, fields below it need not be provided.

If <addressingType> is dynamic, a DHCP client is used for the device.

If <addressingType> is static the device IP address is configured manually and the gateway and DNS fields are optional.

If <addressingType> refers to APIPA, the device IP address is automatically configured without DHCP. In this case the gateway and DNS fields are optional.



Use of <ipAddress> or <ipv6Address> in fields is dictated by the <ipVersion> field. If <ipVersion> is "v4" the <ipAddress> fields are used; if <ipVersion> is "v6" the <ipv6Address> fields are used. If <ipVersion> is "dual", both <ipAddress> and <ipv6Address> fields may be used.

<subnetMask> notation is "ISAPI.ISAPI.ISAPI.ISAPI".

<IPV6Address> is "ISAPIx:ISAPIx:ISAPIx:ISAPIx:ISAPIx:ISAPIx:ISAPIx:ISAPIx" using CIDR notation.

#### **IPAddress XML Block**

```
<IPAddress version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <ipVersion> <!-- req, xs:string, "v4,v6,dual" --></ipVersion>
 <addressingType> <!-- req, xs:string, "static,dynamic,apipa" --> </addressingType>
 <ipAddress> <!-- dep, xs:string --> </ipAddress>
 <subnetMask> <!-- dep, xs:string, subnet mask for IPv4 address --> </subnetMask>
 <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
 <DefaultGateway> <!-- dep -->
   <ipAddress> <!-- dep, xs:string --> </ipAddress>
   </DefaultGateway>
 <PrimaryDNS> <!-- dep -->
   <ipAddress> <!-- dep, xs:string --> </ipAddress>
   <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
 </PrimaryDNS>
 <SecondaryDNS> <!-- dep -->
   <ipAddress> <!-- dep, xs:string --> </ipAddress>
   <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
 </SecondaryDNS>
 <!-- opt -->
   <ipV6AddressingType>
     <-- dep, xs:string,"ra,manual,dhcp>
   </ipV6AddressingType>
   <ipv6AddressList>
     <v6Address>
       <id><!-- dep, xs:string;id --> </id>
       <type> <-- dep, xs:string, "ra, manual, dhcp> </type>
       <address> <!-- dep, xs:string --> </address>
       </v6Address>
   </ipv6AddressList>
 </lpv6Mode>
</IPAddress>
```



## 8.2.5/ISAPI/System/Network/interfaces/<ID>/wirel

## ess

/ISAPI/System/Ne	twork/interfaces/ <i>ID</i> /wireless	General Resource v2.0
GET		
Description	It is used to get the wireless settings of a p	particular network interface.
Query	None	
Inbound Data	None	
Success Return	Wireless	
PUT		
Description	It is used to update the wireless setting interface.	gs of a particular network
Query	None	
Inbound Data	Wireless	
Success Return	ResponseStatus	
Notes:		

#### **Wireless XML Block**

```
<Wireless version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <enabled> <!-- req, xs:boolean -->
                                         </enabled>
  <wirelessNetworkMode>
    <!-- opt, xs:string, "infrastructure,adhoc" -->
  </wirelessNetworkMode>
  <channel> <!-- opt, xs:string, "1-14,auto" --> </channel>
  <ssid> <!-- opt, xs:string --> </ssid>
  <wmmEnabled> <!-- opt, xs:boolean --> </wmmEnabled>
  <WirelessSecurity> <!-- opt -->
    <securityMode>
      <!-- opt, xs:string,
        "disable, WEP, WPA-personal, WPA2-personal, WPA-RADIUS,
         WPA-enterprise, WPA2-enterprise" -->
    </securityMode>
    <WEP>
      <!-- dep, depends on <securityMode> -->
      <authenticationType>
        <!-- req, xs:string, "open,sharedkey,auto" -->
      </authenticationType>
      <defaultTransmitKeyIndex>
       <!-- req, xs:integer -->
      </defaultTransmitKeyIndex>
      <wepKeyLength> <!-- opt, xs:integer "64,128" --> </wepKeyLength>
```



# 8.2.6/ISAPI/System/Network/interfaces/<ID>/wirel ess/accessPointList

/ISAPI/System/Network/interfaces/ID/wireless/accessPointList		General Resource
		v2.0
GET		
Description	It is used to get the valid acces interface.	s points on the wireless
Query	None	
Inbound Data	None	
Success Return	accessPointList	
Notes:		

### accessPointList XML Block

```
<accessPointList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <accessPoint/> </accessPointList
```

# 8.2.7/ISAPI/System/Network/interfaces/<ID>/wirel ess/accessPointList/<ID>

/ISAPI/System/Network/interfaces/ID/wireless/accessPointList/ID	General
	Resource v2.0



GET	
Description	It is used to get a particular access point.
Query	None
Inbound Data	None
Success Return	accessPoint
Notes:	

### accessPoint XML Block

# 8.2.8/ISAPI/System/Network/interfaces/<ID>/disco very

/ISAPI/System/Net	work/interfaces/ <i>ID</i> /discovery	General Resource v2.0
GET		
Description	It is used to get the discovery setting interface.	gs of a particular network
Query	None	
Inbound Data	None	
Success Return	Discovery	
PUT		
Description	It is used to update the discovery setting interface.	ngs of a particular network
Query	None	
Inbound Data	Discovery	
Success Return	ResponseStatus	



Notes:

## **Discovery XML Block**

## 8.2.9/ISAPI/System/Network/interfaces/<ID>/Link

/ISAPI/System/Network/interfaces/ID/link General Resource v2	
GET	
Description	It is used to get the link layer settings of a particular network interface.
Query	None
Inbound Data	None
Success Return	Link
PUT	
Description	It is used to update the link layer settings of a particular network interface.
Query	None
Inbound Data	Link
Success Return	ResponseStatus
Notes:	

## **Link XML Block**



## 8.2.10 Examples

**Example: Getting the Network Settings** 

```
GET /ISAPI/System/Network/interfaces HTTP/1.1
HTTP/1.1 200 OK
Content-Type: application/xml; charset="UTF-8"
Content-Length: xxx
<?xml version="1.0" encoding="UTF-8"?>
<NetworkInterfaceList version="2.0"
xmlns="http://www.isapi.org/ver20/XMLSchema">
  <NetworkInterface>
    <id>1</id>
    <IPAddress>
      <ipVersion>v4</ipVersion>
      <addressingType>static</addressingType>
      <ipAddress>172.6.64.7</ipAddress>
      <subnetMask>255.255.255.0</subnetMask>
      <DefaultGateway>
        <ipAddress>172.6.64.1</ipAddress>
      </DefaultGateway>
      <PrimaryDNS>
        <ipAddress>192.0.0.200</ipAddress>
      </PrimaryDNS>
    <Discovery>
      <UPnP>
        <enabled>true</enabled>
      </UPnP>
      <Zeroconf>
        <enabled>true</enabled>
      </Zeroconf>
    </Discovery>
    <Link>
      <MACAddress> 00:40:48:4C:7F:F2</MACAddress>
      <autoNegotiation>true</autoNegotiation>
      <speed>1000<speed>
      <duplex>full</duplex>
      <MTU>1500</MTU>
    </Link>
  <NetworkInterface>
```



</NetworkInterfaceList>

### **Example: Setting the IP Address**

```
PUT /ISAPI/System/Network/interfaces/1/ipAddress HTTP/1.1
Content-Type: application/xml; charset="UTF-8"
Content-Length: xxx
<?xml version="1.0" encoding="UTF-8"?>
<IPAddress version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <ipVersion>v4</ipVersion>
  <addressingType>static</addressingType>
  <ipAddress>172.6.64.16</ipAddress>
  <subnetMask>255.255.255.0</subnetMask>
  <DefaultGateway>
    <ipAddress>172.6.64.1</ipAddress>
  </DefaultGateway>
  <PrimaryDNS>
    <ipAddress>192.0.0.200</ipAddress>
  </PrimaryDNS>
HTTP/1.1 200 OK
Content-Type: application/xml; charset="UTF-8"
Content-Length:xxx
<?xml version="1.0" encoding="UTF-8"?>
<ResponseStatus version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <requestURL>/Network/interfaces/1/ipAddress</requestURL>
  <statusCode>1</statusCode>
  <statusString>OK</statusString>
</ResponseStatus>
```

## 8.2.11 /ISAPI/System/Network/interfaces/<ID>/WP

S

/ISAPI/System/Network/interfaces/*ID*/WPS General Resource v2.0 GET



Description	It is used to access WPS configuratioin
Query	None
Inbound Data	None
Success Return	WPS
PUT	
Description	It is used to access WPS configuratioin
Query	None
Inbound Data	WPS
Success Return	ResponseStatus
Notes:	

## **WPSXML Block**

<WPS version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <enable> <!-- req, xs:boolean--> </enable>
</WPS>

# 8.2.12 /ISAPI/System/Network/interfaces/ID/WPS/ AutoConnect

/ISAPI/System/Network/interfaces/ID/WPS/AutoCon		General Resource	v2.0
nect			
PUT			
Description	It is used to WPS auto connection mode		
Query	None		
Inbound Data	WPS		
Success Return	ResponseStatus		
Notes:			

# 8.2.13 /ISAPI/System/Network/interfaces/ID/WPS/d evicePinCode

/ISAPI/System/Network/interfaces/ID/WPS/devicePin Code		General Resource	v2.0
GET			
Description			
Query	None		



Inbound Data	None
Success Return	PIN code string
Notes:	

# 8.2.14 /ISAPI/System/Network/interfaces/ID/WPS/d evicePinCodeUpdate

/ISAPI/System/Ne CodeUpdate	etwork/interfaces/ID/WPS/devicePin	General Resource	v2.0	
GET				
Description	It is used to generate a new device PIN code			
Query	None			
Inbound Data	None			
Success Return	PIN code string			
Notes:				

# 8.2.15 /ISAPI/System/Network/interfaces/ID/WPS/ ApPinCode

/ISAPI/System/Network/interfaces/ID/WPS/ApPinCo		General Resource	v2.0		
	de				
GET					
Description	It is used to access WPS configuration				
Query	None	None			
Inbound Data	None				
Success Return	WpsApPincode				
PUT					
Description	It is used to access WPS configuration				
Query	None				
Inbound Data	WpsApPincode				
Success Return	ResponseStatus				
Notes:					

WpsApPincodeXML Block



```
<WpsApPincode version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
    <ssid> <!-- req, xs:string --> </ssid>
    <pinCode> <!-- req, xs:string --> </pinCode>
    </WpsApPincode>
```

# 8.2.16 /ISAPI/System/Network/interfaces/ID/ieee80 2.1x

/ISAPI/System/Net	General Resource	v2.0		
GET				
Description	It is used to access IEEE 802.1x settings			
Query	None	None		
Inbound Data	None			
Success Return	IEEE802_1x			
PUT				
Description	It is used to configure IEEE 802.1x settings			
Query	None			
Inbound Data	IEEE802_1x			
Success Return	ResponseStatus			

## Notes:

If the <authenticatonProtocolType> tag corresponds to "EAP-TTLS", then the <innerTTLSAuthenticationMethod> tag must be provided.

If the <authenticationProtocolType> corresponds to "EAP-PEAP" or "EAP-FAST", then the <innerEAPProtocolType> tag must be provided.

The <anonymousID> tag is optional. If the <authenticationProtocolType> corresponds to "EAP-FAST", then the <autoPACProvisioningEnabled> tag must be provided. <anonymousID> is the optional anonymous ID to be used in place of the <userName>.

#### IEEE802 1x XML Block



```
<!-- dep, xs:string, "EAP-POTP,MS-CHAPv2" -->
 </innerEAPProtocolType>
  <validateServerEnabled>
                            <!-- dep, xs:boolean --> </validateServerEnabled>
  <userName> <!-- dep, xs:string --> </userName>
  <password> <!-- dep, xs:string --> </password>
                    <!-- opt, xs:string --> </anonymousID>
  <anonymousID>
  <autoPACProvisioningEnabled> <!-- dep, xs:boolean -->
</autoPACProvisioningEnabled>
  <Extensions> <!-- opt -->
   <EAPOLVersion xmlns="http://www.isapi.org/ver20/XMLSchema">
      <!--opt, xs:string, "1, 2"-->
   </EAPOLVersion>
  </Extensions>
</IEEE802_1x>
```

## 8.2.17 /ISAPI/System/Network/PPPoE

/ISAPI/System/Network/PPPoE		General Resource	v2.0	
GET	GET			
Description	It is used to get the configurations of pppo	e.		
Query	None	None		
Inbound Data	None			
Success Return	PPPoEList			
PUT				
Description	It is used to set the configurations of pppc	e.		
Query	None			
Inbound Data	PPPoEList			
Success Return	ResponseStatus			
Notes:				

### **PPPoEList XML Block**

```
<PPPoEList xmlns="http://www.isapi.org/ver20/XMLSchema">
  <PPPoE/> <!--req-->
  </PPPoEList>
```

## 8.2.18 /ISAPI/System/Network/PPPoE/status

/ISAPI/System/Network/PPPoE/status	General Resource	v2.0
GET		



Description	It is used to get the status of pppoe.	
Query	None	
Inbound Data	None	
Success Return	PPPoEStatusList	
Notes:		

### **PPPoEStatusList XML Block**

```
<PPPoEStatusList xmlns="http://www.isapi.org/ver20/XMLSchema">
  <PPPoEStatus/> <!--req-->
  </PPPoEStatusList>
```

## 8.2.19 /ISAPI/System/Network/PPPoE/<ID>

/ISAPI/System/Ne	General Resource v2.0			
GET				
Description	It is used to get the configuration of a	a particular pppoe.		
Query	None			
Inbound Data	None			
Success Return	PPPoE	PPPoE		
PUT				
Description	It is used to set the configurations of	a particular pppoe.		
Query	None			
Inbound Data	PPPoE			
Success Return	ResponseStatus			
Notes:				
<ethernetifid> links the PPPoE to a network interface that the PPPoE dial up used, see</ethernetifid>				
/ISAPI/System/Net	work/interfaces/ <id>.</id>			

### **PPPoE XML Block**



## 8.2.20 /ISAPI/System/Network/PPPoE/<ID>/status

/ISAPI/System/Network/PPPoE/ID/status		General Resource v2.0	
GET			
Description	t is used to get the status of a particular pppoe.		
Query	None		
Inbound Data	None		
Success Return	PPPoEStatus		
Notes:			

### **PPPoEStatus XML Block**

```
<PPPoEStatus xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id><!-- req, xs:string --> </id>
  <enabled> <!-- req, xs:boolean --> </enabled>
  <ethernetIfId> <!-- opt, xs:string; id --> </ethernetIfId>
  <ipAddress> <!-- dep, xs:string --> </ipAddress>
  <subnetMask> <!-- dep, xs:string, subnet mask for IPv4 address --> </subnetMask>
  <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
  <br/><br/>bitMask> <!-- dep, xs:integer, bitmask IPv6 address --> </bitMask>
  <DefaultGateway> <!-- dep -->
    <ipAddress> <!-- dep, xs:string --> </ipAddress>
    <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
  </DefaultGateway>
  <PrimaryDNS> <!-- dep -->
    <ipAddress> <!-- dep, xs:string --> </ipAddress>
    <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
  </PrimaryDNS>
  <SecondaryDNS> <!-- dep -->
    <ipAddress> <!-- dep, xs:string --> </ipAddress>
    <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
  </SecondaryDNS>
</PPPoEStatus>
```

## 8.2.21 /ISAPI/System/Network/Bond

URI	/ISAPI/System/Network/Bond			Туре	Service
Function	Get or set the configuration information of Bond net interfaces.				
Methods	Query String(s) Inbound Data Return Result		Result		



GET		<bondlist></bondlist>
Notes	Bond NIC configuration	

#### **BondList XML Block**

```
<BondList version="2.0" xmlns="urn:selfextension:ISAPlext-ver10-xsd">
  <Bond>
  </BondList>
```

## 8.2.22 /ISAPI/System/Network/Bond/<ID>

URI	/ISAPI/System/Network/Bond/ID			Туре	Resource
Function	Get or set the configuration information of Bond net interface				
Methods	Query String(s)	Inbound Data	Return Result		Result
GET			<e< th=""><th>3ond&gt;</th><th></th></e<>	3ond>	
PUT		<bond></bond>	<responsestatus></responsestatus>		seStatus>
Notes					

### **Bond XML Block**

```
<Bond version="2.0" xmlns="urn:selfextension:ISAPlext-ver10-xsd">
               <!-- req, xs:string --> </id>
  <enabled>
                <!-- req, xs:boolean --> </enabled>
  <workMode> <!-- req, xs:string;"balance-rr, active-backup" --> </workMode>
  <primaryIf> <!-- req, xs:string;id --></primaryIf>
  <slavelfList> <!-- req -->
    <ethernetlfld>
                      <!-- req, xs:string; id -->
                                                  </ethernetIfId>
  </slaveIfList>
  <IPAddress>
    <ipVersion>
                    <!-- req, xs:string, "v4,v6,dual" --></ipVersion>
    <addressingType> <!-- req, xs:string, "static,dynamic,apipa" --> </addressingType>
    <ipAddress>
                       <!-- dep, xs:string -->
                                                      </ipAddress>
    <subnetMask>
                     <!-- dep, xs:string, subnet mask for IPv4 address --> </subnetMask>
    <ipv6Address>
                      <!-- dep, xs:string -->
                                                     </ipv6Address>
    <br/><bitMask>
                       <!-- dep, xs:integer, bitmask IPv6 address --> </bitMask>
    <DefaultGateway> <!-- dep -->
      <ipAddress>
                       <!-- dep, xs:string -->
                                                     </ipAddress>
      <ipv6Address>
                        <!-- dep, xs:string -->
                                                     </ipv6Address>
    </DefaultGateway>
```



```
<PrimaryDNS>
                       <!-- dep -->
      <ipAddress>
                       <!-- dep, xs:string -->
                                                   </ipAddress>
      <ipv6Address>
                        <!-- dep, xs:string -->
                                                   </ipv6Address>
    </PrimaryDNS>
    <SecondaryDNS> <!-- dep -->
      <ipAddress>
                      <!-- dep, xs:string -->
                                                   </ipAddress>
                         <!-- dep, xs:string -->
                                                   </ipv6Address>
      <ipv6Address>
    </SecondaryDNS>
  </IPAddress>
  <Link xmlns="urn:selfextension:ISAPlext-ver10-xsd">
                                                           <!-- opt -->
    <MACAddress> <!-- req, xs:string> </MACAddress>
    <autoNegotiation> <!-- req, xs:boolean> </autoNegotiation>
    <speed> <!-- req, xs:integer, "10, 100, 1000" --><speed>
    <duplex> <!-- req, xs:string, "half, full"> </duplex>
    <MTU> <!-- req, xs:integer --> </MTU>
  </Link>
</Bond>
```

## 8.2.23 /ISAPI/System/Network/extension

URI	/ISAPI/System/Network/extension			Туре	Resource
Function	Get or set the configuration information of network externsion				
Methods	Query String(s) Inbound Data Return Result		Result		
GET			<r< th=""><th>network</th><th>Extension&gt;</th></r<>	network	Extension>
PUT		<networkextension></networkextension>	<f< th=""><th>Respon</th><th>seStatus&gt;</th></f<>	Respon	seStatus>
Notes					

## networkExtension XML Block



## 8.2.24 /ISAPI/System/Network/DDNS

/ISAPI/System/Ne	twork/DDNS	General Resource	v2.0	
GET				
Description	It is used to get the configurations of DDN	NS.		
Query	None			
Inbound Data	None			
Success Return	DDNSList			
PUT				
Description	It is used to set the configurations of pppe	oe.		
Query	None			
Inbound Data	DDNSList			
Success Return	ResponseStatus			
Notes:				

## **DDNSList XML Block**

<DDNSList xmlns="http://www.isapi.org/ver20/XMLSchema">
 <DDNS/> <!--req-->
 </DDNSList>

## 8.2.25 /ISAPI/System/Network/DDNS/<ID>

/ISAPI/System/Network/DDNS/ID General Resource		2.0		
GET				
Description	It is used to get the configuration of a particular DDNS.			
Query	None			
Inbound Data	None			
Success Return	DDNS			
PUT				
Description	It is used to set the configurations of a particular pppoe.			
Query	None			
Inbound Data	DDNS			
Success Return	ResponseStatus			
Notes:	Notes:			
<serveraddress> DDNS server's address.</serveraddress>				
Depending on the	value of <addressingformattype>, either the <hostname> or the <math display="inline"></math></hostname></addressingformattype>	ΙP		



address fields will be used to locate the NTP server.

Use of IPv4 or IPv6 addresses depends on the value of the <ipVersion> field in /ISAPI/System/Network/interfaces/ID/ipAddress.

When rovider> is "IPServer", <serverIPAddress> is required.

When required except the <portNo>.

When voider> is "PeanutHall", all fields are required except the <serverIPAddress> and <portNo>.

<deviceDomainName> the device's domain name.

<password> is a write-only field.

#### **DDNS XML Block**

```
<DDNS version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id><!-- req, xs:string -->
  <enabled>
             <!-- req, xs:boolean --> </enabled>
 cprovider>
    <!-- req, xs:string, "IPServer, DynDNS, PeanutHall, HiDDNS ..." -->
 <serverAddress>
    <addressingFormatType>
      <!-- req, xs:string, "ipaddress,hostname"-->
    </addressingFormatType>
    <hostName> <!-- dep, xs:string -->
                                         </hostName>//不能是中文
    <ipAddress> <!-- dep, xs:string -->
                                         </ipAddress>
   <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
 <serverAddress>
 <portNo> <!-- opt, xs:integer --> </portNo>
  <deviceDomainName> <!-- dep, xs:string --> </deviceDomainName>
  <userName> <!-- dep, xs:string --> </userName>//不能是中文
  <password> <!-- wo, dep, xs:string --></password>
</DDNS>
```

## 8.2.26 /ISAPI/System/Network/SNMP

/ISAPI/System/Network/SNMP		General Resource	v2.0
GET			
Description	Get SNMP Settings.		
Query	None		
Inbound Data	None		
Success Return SNMP			
PUT			
Description	Set SNMP Settings		



Query	None	
Inbound Data	SNMP	
Success Return	ResponseStatus	
Notes:		
At least one of the <snmpv2c> block or <snmpadvanced> block must be provided.</snmpadvanced></snmpv2c>		
<snmpport> snmp a</snmpport>	agent listen port	

## **SNMP XML Block**

## 8.2.27 /ISAPI/System/Network/SNMP/v1c

/ISAPI/System/Network/SNMP/v1c General Resource v2.					
GET					
Description	Get SNMP v1c parameters.				
Query	None				
Inbound Data	None				
Success Return	SNMPv1c				
PUT					
Description	Set SNMP v1c parameters				
Query	None				
Inbound Data	SNMPv1c				
Success Return	ResponseStatus				
Notes:					
SNMP v1c configuration includes SNMP notification parameters and a set of SNMP trap					
receivers.					
SNMP v1c comprises SNMP v1 without the controversial new SNMP v1 security model, using					
instead the simple co	ommunity-based security scheme of SNMP v1				

### **SNMPv1c XML Block**

<SNMPv1c version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">



# 8.2.28 /ISAPI/System/Network/SNMP/v1c/trapRece ivers

/ISAPI/System/Net	work/SNMP/v1c/trapRecevivers	General Resource	v2.0
GET			
Description	Get SNMP trap receiver list.		
Query	None		
Inbound Data	None		
Success Return	SNMPTrapReceiverList		
PUT			
Description	Set SNMP trap receiver list		
Query	None		
Inbound Data	SNMPTrapReceiverList		
Success Return	ResponseStatus		
POST			
Description	create a new SNMP trap receiver		
Query	None		
Inbound Data	SNMPTrapReceiver		
Success Return	ResponseStatus		
DELETE			
Description	Delete SNMP trap receiver list		
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		
Notes:			



# 8.2.29 /ISAPI/System/Network/SNMP/v1c/trapRece iver/<ID>

/ISAPI/System/Network/SNMP/v2c/trapRecevivers/ <id> General Resource v2.</id>				
GET				
Description	Get SNMP trap receiver information.			
Query	None			
Inbound Data	None			
Success Return	SNMPTrapReceiver			
PUT				
Description	Set SNMP trap receiver information			
Query	None			
Inbound Data	SNMPTrapReceiver			
Success Return	ResponseStatus			
DELETE				
Description	Delete SNMP trap receiver			
Query	None			
Inbound Data	None			
Success Return	ResponseStatus			
Notes:				

## 8.2.30 /ISAPI/System/Network/SNMP/v2c

/ISAPI/System/Ne	twork/SNMP/v2c General Resource v2.0		
GET			
Description	Get SNMP v2c parameters.		
Query	None		
Inbound Data	None		
Success Return	SNMPv2c		
PUT			
Description	Set SNMP v2c parameters		
Query	None		
Inbound Data	SNMPv2c		
Success Return	ResponseStatus		
Notes:			
SNMP v2c configuration includes SNMP notification parameters and a set of SNMP trap receivers.			



SNMP v2c comprises SNMP v2 without the controversial new SNMP v2 security model, using instead the simple community-based security scheme of SNMP v1

#### SNMPv2c XML Block

# 8.2.31 /ISAPI/System/Network/SNMP/v2c/trapRece ivers

/ISAPI/System/Net	work/SNMP/v2c/trapRecevivers	General Resource	v2.0
GET			
Description	Get SNMP trap receiver list.		
Query	None		
Inbound Data	None		
Success Return	SNMPTrapReceiverList		
PUT			
Description	Set SNMP trap receiver list		
Query	None		
Inbound Data	SNMPTrapReceiverList		
Success Return	ResponseStatus		
POST			
Description	create a new SNMP trap receiver		
Query	None		
Inbound Data	SNMPTrapReceiver		
Success Return	ResponseStatus		
DELETE			
Description	Delete SNMP trap receiver list		
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		
Notes:			

## **SNMPTrapReceiverList XML Block**



# 8.2.32 /ISAPI/System/Network/SNMP/v2c/trapRece iver/<ID>

/ISAPI/System/Network/SN	General Resource	
	v2.0	
GET		
Description	Get SNMP trap receiver information.	
Query	None	
Inbound Data	None	
Success Return	SNMPTrapReceiver	
PUT		
Description	Set SNMP trap receiver information	
Query	None	
Inbound Data	SNMPTrapReceiver	
Success Return	ResponseStatus	
DELETE		
Description	Delete SNMP trap receiver	
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	
Notes:		

## **SNMPTrapReceiver XML Block**

## 8.2.33 /ISAPI/System/Network/SNMP/advanced

/ISAPI/System/Network/SNMP/advanced General Resource v2	2.0
---	-----



GET	
Description	Get SNMP Advanced parameters.
Query	None
Inbound Data	None
Success Return	SNMPAdvanced
PUT	
Description	Set SNMP Advanced parameters
Query	None
Inbound Data	SNMPAdvanced
Success Return	ResponseStatus
Notes:	
<localengineid> is</localengineid>	a hexadecimal string indicating the local device engine ID.

<authenticationNotificationEnabled> indicates if SNMP authentication failure notification is

<SNMPNotificationFilterList> is a list to filter traps based on OIDs

## **SNMPAdvanced XML Block**

enabled on the device.

# 8.2.34 /ISAPI/System/Network/SNMP/advanced/us

## ers

/ISAPI/System/Ne	twork/SNMP/advanced/users	General Resource	v2.0
GET			
Description	Get SNMP advanced user list.		
Query	None		
Inbound Data	None		
Success Return	SNMPUserList		



PUT		
Description	Set SNMP advanced list	
Query	None	
Inbound Data	SNMPUserList	
Success Return	ResponseStatus	
POST		
Description	create a new SNMP advanced user	
Query	None	
Inbound Data	SNMPUser	
Success Return	ResponseStatus	
DELETE		
Description	Delete SNMP advanced user list	
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	
Notes: Defines the set of SNMP users and their permissions.		

## **SNMPUserList XML Block**

# 8.2.35 /ISAPI/System/Network/SNMP/advanced/us ers/<ID>

/ISAPI/System/Network/SNMP/advanced/users/ID		General Resource v2.0	
GET			
Description	Get SNMP advanced user information.		
Query	None		
Inbound Data	None		
Success Return	SNMPUser		
PUT			
Description	Set SNMP advanced user information		
Query	None		
Inbound Data	SNMPUser		
Success Return	ResponseStatus		
DELETE			



Description	Delete SNMP advanced user
Query	None
Inbound Data	None
Success Return	ResponseStatus

#### Notes:

- <remoteEngineID> indicates the remote SNMP entity to which the user is connected.
- <snmpAuthenticationMethod> indicates the authentication method used.
- <snmpAuthenticationKey> defines the authentication key if encryption is used for <snmpAuthenticationMethod>.
- <snmpAuthenticationPassword> optional password used to calculate the
- <snmpAuthenticationKey> value if encryption is used for <snmpAuthenticationMethod>.
- <snmpPrivacyMethod> indicates if messages are protected from disclosure, and if so, the type of privacy protocol used.
- <snmpPrivacyKey> defines the privacy key if encryption is used for
- <snmpPrivacyMethod>.
- <snmpPrivacyPassword> optional password used to calculate the <snmpPrivacyKey> value if encryptions is used for <snmpPrivacyMethod>

#### **SNMPUser XML Block**

```
<SNMPUser version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
        <!-- req, xs:string;id -->
                                 </id>
                <!-- req, xs:string --> </userName>
 <userName>
 <remoteEngineID> <!-- req, xs:hexBinary --> </remoteEngineID>
 <snmpAuthenticationMethod>
   <!-- req, xs:string, "MD5,SHA,none" -->
 </snmpAuthenticationMethod>
 <snmpAuthenticationKey>
                             <!-- dep, xs:string --> </snmpAuthenticationKey>
 <snmpAuthenticationPassword>
   <!-- dep, xs:string, see RFC3414 -->
 </snmpAuthenticationPassword>
 <snmpPrivacyMethod>
                           <!-- reg, xs:string, "DES,AES,none" -->
    </snmpPrivacyMethod>
 <snmpPrivacyKey> <!-- dep, xs:string --> </snmpPrivacyKey>
 <snmpPrivacyPassword>
                             <!-- dep, xs:string, see RFC3414 -->
</snmpPrivacyPassword>
</SNMPUser>
```

## 8.2.36 /ISAPI/System/Network/mailing

/ISAPI/System/Network/mailing		General Resource	v2.0
GET			
Description	It is used to get the configuration of e-mai	l.	
Query	None		



Inbound Data	None
Success Return	mailingList
PUT	
Description	It is used to set the configuration of e-mail.
Query	None
Inbound Data	mailingList
Success Return	ResponseStatus
Notes:	

## mailingList XML Block

```
<mailingList xmlns="http://www.isapi.org/ver20/XMLSchema">
  <mailing> <!-- opt, xs:string> </mailing>
  </mailingList>
```

## 8.2.37 /ISAPI/System/Network/mailing/<ID>

/ISAPI/System/Network/mailing/ID		General Resource	v2.0
GET			
Description	It is used to get the configuration of a pa	rticular e-mail.	
Query	None		
Inbound Data	None		
Success Return	mailingList		
PUT			
Description	It is used to set the configuration of a part	ticular e-mail.	
Query	None		
Inbound Data	mailingList		
Success Return	ResponseStatus		
Notes:			

## mailing XML Block

```
<mailing xmlns="http://www.isapi.org/ver20/XMLSchema">
    <id/> <!-- req, xs:string, id -->
    <sender> <!--req-->
    <name> <!--req, xs:string> </name>
    <emailAddress> <!--req, xs:string --> </emailAddress>
    <smtp> <!-- req -->
        <enableAuthorization><!--req, xs:boolean--></enableAuthorization>
        <enableSSL><!--opt, xs:boolean--></enableSSL>
        <addressingFormatType>
        <!-- req, xs:string, "ipaddress,hostname" -->
        </addressingFormatType>
```



```
<hostName> <!-- dep, xs:string --> </hostName>
      <ipAddress> <!-- dep, xs:string --> </ipAddress>
      <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
      <portNo> <!-- opt, xs:integer --> </portNo>
      <accountName>
                          <!-- dep, xs:string --> </accountName>
      <password> <!-- dep, xs:string --> </password>
    </smtp>
  </sender>
  <receiverList> <!-- req -->
    <receiver>
      <id><!--req, xs:string; id --> </id>
      <name> <!--req, xs:string --> </name>
      <emailAddress> <!-- req, xs:string --> </emailAddress>
    </receiver>
  </receiverList>
  <attachment><!--opt-->
    <snapshot> <!--opt-->
      <enabled ><!--req, xs:boolean--></ enabled>
      <interval><!--req, xs:integer, seconds></interval>
    </snapshot>
  </attachment>
</mailing>
```

## 8.2.38 /ISAPI/System/Network/UPnP

/ISAPI/System/Ne	twork/UPnP General Resource v2	.0
GET		
Description	Get theUPnP configuration on an IP media device.	
Query	None	
Inbound Data	None	
Success Return	UPnP	
PUT		
Description	Set the UPnP configuration on an IP media device.	
Query	None	
Inbound Data	UPnP	
Success Return	ResponseStatus	
Notes:		

#### **UPnP XML Block**

```
<UPnP version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <enabled/>    <!-- req -->
```



```
<ports/> <!-- opt -->
</UPnP>
```

### 8.2.39 /ISAPI/System/Network/UPnP/ports

/ISAPI/System/Net	work/UPnP/ports	General Resource	v2.0
GET			
Description	Get the Ports configuration on an IP media of	levice.	
Query	None		
Inbound Data	None		
Success Return	ports		
PUT			
Description	Set Ports configuration on an IP media device	ce.	
Query	None		
Inbound Data	ports		
Success Return	ResponseStatus		
Notes:			

#### ports XML Block

## 8.2.40 /ISAPI/System/Network/UPnP/ports/status

/ISAPI/System/Ne	twork/UPnP/ports/status	General Resource	v2.0
GET			
Description	Get NAT ports status on an IP media device	e.	
Query	None		



Inbound Data	None
Success Return	portsStatus
Notes:	
<natrouter> if this</natrouter>	element is provided, the ip media device will use this nat router.

#### portsStatus XML Block

```
<portsStatus version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <enabled/> <!-- req -->
   <natRouterLanAddr> <!-- req -->
     <ipVersion> <!-- req, xs:string, "v4,v6,dual" --> </ipVersion>
    <ipAddress> <!-- dep, xs:string --> </ipAddress>
     <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
   </natRouterLanAddr>
   <natRouterWanAddr> <!-- req -->
     <ipVersion> <!-- req, xs:string, "v4,v6,dual" --> </ipVersion>
    <ipAddress> <!-- dep, xs:string --> </ipAddress>
     <ipv6Address> <!-- dep, xs:string --> </ipv6Address>
   </natRouterWanAddr>
 <portStatusList> <!-- req -->
    <portStatus/> <!-- req -->
  </portStatusList>
</portsStatus>
```

### 8.2.41 /ISAPI/System/Network/UPnP/ports/<ID>

/ISAPI/System/No	etwork/UPnP/ports/ <id> General Resource</id>		v2.0	
GET				
Description	Get a specific I	Get a specific NAT port configuration on an IP media device.		
Query	None			
Inbound Data	None			
Success Return	port			
PUT	PUT			
Description	Set a specific N	Set a specific NAT port configuration on an IP media device.		
Query	None	None		
Inbound Data	None			
Success Return	port			
Error Status Code	statusCode subStausCod description			
	6 badPort Port Conflict			
Notes:				



#### port XML Block

## 8.2.42 /ISAPI/System/Network/UPnP/ports/<ID>/st atus

/ISAPI/System/Network/UPnP/ports/ <id>/status</id>		General Resource	v2.0
GET			
Description	Get NAT port status on an IP media device.		
Query	None		
Inbound Data	None		
Success Return	portStatus		
Notes:			
<natrouter> if this element is provided, the ip media device will use this nat router.</natrouter>			

#### portStatus XML Block

## 8.2.43 /ISAPI/System/Network/ftp

/ISAPI/System/Network/ftp		General Resource	v2.0
GET			
Description	It is used to get the configurations of FTP.		
Query	None		
Inbound Data	None		
Success Return	FTPNotificationList		
PUT			



Description	It is used to set the configurations of FTP.
Query	None
Inbound Data	FTPNotificationList
Success Return	ResponseStatus
Notes:	

#### FTPNotificationList XML Block

### 8.2.44 /ISAPI/System/Network/ftp/<ID>

/ISAPI/System/Ne	twork/ftp/ID	General Resource	v2.0
GET			
Description	It is used to get the configuration of a part	icular FTP.	
Query	None		
Inbound Data	None		
Success Return	FTPNotification		
PUT			
Description	It is used to set the configurations of a pa	rticular FTP.	
Query	None		
Inbound Data	FTPNotification		
Success Return	ResponseStatus		

#### Notes:

Depending on the value of <addressingFormatType>, either the <hostName> or the IP address fields will be used to locate the NTP server.

Note: FTP transfers are always in binary mode.

<pathDepth> the depth of path. For example, / depth is 0, /a depth is 1, /a/b depth is 2

#### **FTPNotification XML Block**



```
<hostName>
                           <!-- dep, xs:string -->
                                                            </hostName>
  <ipAddress>
                           <!-- dep, xs:string -->
                                                            </ipAddress>
                           <!-- dep, xs:string -->
  <ipv6Address>
                                                            </ipv6Address>
  <portNo>
                           <!-- opt, xs:integer -->
                                                            </portNo>
  <userName>
                           <!-- req, xs:string -->
                                                            </userName>
                           <!-- wo, xs:string -->
                                                            </password>
  <password>
  <passiveModeEnabled> <!-- opt, xs:boolean -->
                                                            </passiveModeEnabled>
  <annoyftp> <!--opt, xs:boolean --> </annoyftp>
  <upl>--opt, xs:boolean --> </uploadPicture>
  <uploadVideoClip> <!-- opt, xs:Boolean --> </uploadVideoClip>
  <uploadPath> <!--req -->
    <pathDepth> <!--req, xs:integer, 0...2 --> </pathDepth>
    <topDirNameRule>
      <!-- dep, xs:string, "devName, devId, devIp, customize" -->
    </topDirNameRule>
    <topDirName/> <!-- dep, xs:string-->
    <subDirNameRule>
      <!-- dep, xs:string, "chanName, chanId, customize"
    </subDirNameRule>
    <subDirName/> <!-- dep, xs:string-->
  </uploadPath>
</FTPNotification>
```

## 8.2.45 /ISAPI/System/Network/ipFilter

/ISAPI/System/Ne	twork/ipFilter General Resource v2.0
GET	
Description	Access IP filtering settings.
Query	None
Inbound Data	None
Success Return	IPFilter
PUT	
Description	Access IP filtering settings
Query	None
Inbound Data	IPFilter
Success Return	ResponseStatus
Notes:	
<pre><permissiontype> f</permissiontype></pre>	rield, if provided as a direct child of <ipfilter>, acts as a system</ipfilter>
	and will apply to all of the <ipfilteraddress> entries, overriding the particular <ipfilteraddress> block</ipfilteraddress></ipfilteraddress>



#### **IPFilter XML Block**

```
<IPFilter version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
    <enabled> <!-- req, xs:boolean --> </enabled>
    <permissionType> <!-- opt, xs:string, "deny,allow" --> </permissionType>
    <IPFilterAddressList/> <!-- opt -->
    </IPFilter>
```

## 8.2.46 /ISAPI/System/Network/ipFilter/filterAddres

#### ses

/ISAPI/System/Ne	etwork/ipFilter/filterAddresses	General Resource	v2.0
GET			
Description	Access IP filtering settings.		
Query	None		
Inbound Data	None		
Success Return	IPFilterAddressList		
PUT			
Description	Access IP filtering settings		
Query	None		
Inbound Data	IPFilterAddressList		
Success Return	ResponseStatus		
POST			
Description	Access IP filtering settings		
Query	None		
Inbound Data	IPFilterAddressList		
Success Return	ResponseStatus		
DELETE			
Description	Access IP filtering settings		
Query	None		
Inbound Data	IPFilterAddressList		
Success Return	ResponseStatus		
Notes: The IP filter addres	s list allows addresses to be added and remo	oved from the list, or the	entire

#### **IPFilterAddressList XML Block**

list to be uploaded at once.



## 8.2.47 /ISAPI/System/Network/ipFilter/filterAddres ses/<ID>

/ISAPI/System/No	etwork/ipFilter/filterAddresses/ID	General Resource	v2.0
GET			
Description	Access IP filtering settings.		
Query	None		
Inbound Data	None		
Success Return	IPFilterAddress		
PUT			
Description	Access IP filtering settings		
Query	None		
Inbound Data	IPFilterAddress		
Success Return	ResponseStatus		
DELETE			
Description	Access IP filtering settings		
Query	None		
Inbound Data	IPFilterAddress		
Success Return	ResponseStatus		

#### Notes:

If the <permissionType> tag is not provided as a direct child of <IPFilter>, the <permissionType> tag must be provided for each <IPFilterAddress>.

Since the ordering of the filters can change the behavior, filtering will be applied consecutively starting with the first <IPFilterAddress> in the list.

The <bitMask> field is applied to the corresponding IP address to identify a range of addresses. It indicates the number of '1' bits used to mask the address. For example: '24' would correspond to a subnet mask of 255.255.255.0 and '32' would correspond to a subnet mask of 255.255.255.255 (a single IP address) for IPv4.

If <addressFilterType> refers to "mask", the <AddressMask> block must be provided in place of the <AddressRange> block. If it refers to "range", the <Range> block must be provided in place of the <AddressMask> block.

Use of IPv4 or IPv6 addresses depends on the value of the <ipVersion> field in /ISAPI/System/Network/interfaces/ID/ipAddress.

#### **IPFilterAddress XML Block**

<IPFilterAddress version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <id> <!-- req, xs:string;id --> </id> <permissionType><!-- dep, xs:string, "deny,allow" --></permissionType>



## 8.2.48 /ISAPI/System/Network/qos

/ISAPI/System/Ne	twork/qos	General Resource	v2.0
GET			
Description	This function is used to get QoS Settings.		
Query	None		
Inbound Data	None		
Success Return	QoS		
PUT			
Description	This function is used to set QoS Settings		
Query	None		
Inbound Data	QoS		
Success Return	ResponseStatus		
Notes:			
At least one of <co< td=""><td>SList&gt; or <dscplist> must be provided.</dscplist></td><td></td><td></td></co<>	SList> or <dscplist> must be provided.</dscplist>		

#### **QoS XML Block**

### 8.2.49 /ISAPI/System/Network/qos/cos

/ISAPI/System/Network/qos/cos	<b>General Resource</b>	v2.0
GET		



Description	This function is used to get the QoS cos list setting for the device.
Query	None
Inbound Data	None
Success Return	CoSList
PUT	
Description	This function is used to set the QoS cos list setting for the device
Query	None
Inbound Data	CoSList
Success Return	ResponseStatus
POST	
Description	This function is used to creat the QoS cos setting for the device
Query	None
Inbound Data	CoS
Success Return	ResponseStatus
DELETE	
Description	This function is used to delete the QoS cos list setting for the device
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes:	

#### **CoSList XML Block**

<CoSList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <CoS/> <!-- opt --> </CoSList>

## 8.2.50 /ISAPI/System/Network/qos/cos/<ID>

/ISAPI/System/Networl	k/qos/cos/ID General Resource v2.0
GET	V2.0
Description	This function is used to get the QoS cos setting for the device
Query	None
Inbound Data	None
Success Return	CoS
PUT	
Description	This function is used to set the QoS cos setting for the device
Query	None
Inbound Data	CoS
Success Return	ResponseStatus



DELETE	
Description	This function is used to delete the QoS cos setting for the device
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes:	

#### **CoS XML Block**

### 8.2.51 /ISAPI/System/Network/qos/dscp

/ISAPI/System/Network/qos/dscp General Resource v2		2.0
GET		
Description	This function is used to get the QoS dscp list setting for the device	
Query	None	
Inbound Data	None	
Success Return	DSCPList	
PUT		
Description	This function is used to set the QoS dscp list setting for the device	
Query	None	
Inbound Data	DSCPList	
Success Return	ResponseStatus	
POST		
Description	This function is used to create the QoS dscp setting for the device	
Query	None	
Inbound Data	DSCP	
Success Return	ResponseStatus	
DELETE		
Description	This function is used to delete the QoS cos list setting for the device	
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	



#### Notes:

A list of DSCP parameter blocks is specified for each type of traffic: device management, command and control, video and audio streaming. Devices may extend the set of traffic types.

#### **DSCPList XML Block**

<DSCPList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <DSCP/> <!-- opt -->
 </DSCPList>

## 8.2.52 /ISAPI/System/Network/qos/dscp/<ID>

/ISAPI/System/Network/qos/dscp/ID General Resource v2.0	
GET	V2.0
Description	This function is used to get the QoS dscp setting for the device
Query	None
Inbound Data	None
Success Return	DSCP
PUT	
Description	This function is used to set the QoS dscp setting for the device
Query	None
Inbound Data	DSCP
Success Return	ResponseStatus
DELETE	
Description	This function is used to delete the QoS dscp setting for the device
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes: <traffictype> determines which kind of traffic the settings apply to.</traffictype>	

#### **DSCP XML Block**



</trafficType>

## 8.2.53 /ISAPI/System/Network/telnetd

/ISAPI/System/Network/telnetd General Resource		v2.0	
GET			
Description	It is used to get the configurations of telne	t.	
Query	None		
Inbound Data	None		
Success Return	Telnetd		
PUT			
Description	It is used to set the configurations of telne	t.	
Query	None		
Inbound Data	Telnetd		
Success Return	ResponseStatus		
Notes:			

#### **Telnetd XML Block**

<Telnetd version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <enabled> <!-- req, xs:boolean --> </enabled>
 </Telnetd>

## 8.2.54 /ISAPI/System/Network/SIP

/ISAPI/System/Network/SIP		General Resource	v2.0
GET			
Description			
Query	None		
Inbound Data	None		
Success Return	SIPServerList		
PUT			
Description			
Query	None		
Inbound Data	SIPServerList		
Success Return	ResponseStatus		
Notes:			

#### SIPServerList XML Block



## 8.2.55 /ISAPI/System/Network/SIP/<ID>

/ISAPI/System/Network/SIP/ <id> General Resource v2</id>		v2.0	
GET			
Description			
Query	None		
Inbound Data	None		
Success Return	SIPServer		
PUT			
Description			
Query	None		
Inbound Data	SIPServer		
Success Return	ResponseStatus		
Notes:		_	

**SIPServer XML Block** 



```
<SIPServer version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id> <!—req, xs:string --> </id>
  <localPort> <!-- req, xs:integer, "1-65535"--> </localPort>
  <streamID> <!-- req, xs:interger, "1(main stream),2 (sub stream) "--> </streamID>
  <Standard> <!-- opt -->
   <registerStatus> <!-- ro, req, xs:boolern, "false (unregistered) ,true (registered) "
                                                              --></registerStatus>
   <enabled> <!-- req, xs:string, "true(sign in),false (log out) "--> </enabled>
   <registrar> <!-- req, xs:string--> </registrar>
   <registrarPort> <!-- req, xs:integer--> </registrarPort>
   <displayName> <!-- req, xs:string--> </displayName>
   <userName> <!-- req, xs:string--> </userName>
   <authID> <!-- req, xs:string--> </authID>
   <password> <!-- wo, req, xs:string--> </password>
   <expires> <!-- req, xs:integer--> </expires>
  </Standard>
  <GB28181> <!-- opt -->
   <registerStatus> <!-- req, xs:boolean --></registerStatus>
   <enabled> <!-- req, xs:string, "true,false"--> </enabled>
   <registrar> <!-- req, xs:string--> </registrar>
   <registrarPort> <!-- req, xs:integer--> </registrarPort>
   <serverId> <!-- req, xs:string--> </serverId>
   <serverDomain> <!-- reg, xs:integer--> </serverDomain>
   <userName> <!-- req, xs:string--> </userName>
   <authID> <!-- req, xs:string--> </authID>
   <password> <!-- wo, req, xs:string--> </password>
   <expires> <!-- req, xs:integer--> </expires>
   req, xs:integer--> </liveTime>
   <heartbeatTime> <!-- req, xs:integer--> </heartbeatTime>
   <heartbeatCount> <!-- req, xs:integer--> </heartbeatCount>
  </GB28181>
</SIPServer>
```

### 8.2.56 /ISAPI/System/Network/SIP/<ID>/SIPInfo

/ISAPI/System/Network/SIP/ <id>/SIPInfo</id>		General Resource	v2.0
GET			
Description	Get device ID and alarm ID		
Query	None		
Inbound Data	None		



Success Return	SiPinfo
PUT	
Description	Set device ID and alarm ID
Query	None
Inbound Data	SiPinfo
Success Return	ResponseStatus
Notes:	

#### **SIPInfo XML Block**

## 8.3 /ISAPI/System/IO

/ISAPI/System/IO Service v2	
GET	
Description	It is used to get the I/O ports information.
Query	None
Inbound Data	None
Success Return	IOPortList
Notes:	
The allocation of IDs between input and output ports must be unique.	

#### **IOPortList XML Block**



## 8.3.1/ISAPI/System/IO/capabilities

/ISAPI/System/IO/capabilities		General Resource	v2.0
GET			
Description	It is used to get device capability.		
Query	None		
Inbound Data	None		
Success Return	<iocap></iocap>		
Notes:			

#### **IOCap XML Block**

### 8.3.2/ISAPI/System/IO/status

/ISAPI/System/IO	/status	General Resource	v2.0
GET			
Description	It is used to get the status of the I/O ports		
Query	None		
Inbound Data	None		
Success Return	IOPortStatusList		

#### Notes:

<ioPortID> refers to /IO/inputs/ID or /IO/outputs/ID. The port IDs are guaranteed to be unique across input and output ports.

<ioState> indicates whether the input port is active or inactive. In most applications, a high signal is considered active.

#### IOPortStatusList XML Block



## 8.3.3/ISAPI/system/IO/inputs

/ISAPI/System/IO	/inputs	General Resource v2.0
GET		
Description	It is used to get the Input ports informat	tion.
Query	None	
Inbound Data	None	
Success Return	IOInputPortList	
Notes:		
IO inputs are hardwired, meaning that the inputs are statically allocated by the device and		
cannot be created	or deleted.	

#### IOInputPortList XML Block

## 8.3.4/ISAPI/System/IO/inputs/<ID>

/ISAPI/System/IO/	/inputs/ID General Resource v2.0	
GET		
Description	It is used to get particular input port information.	
Query	None	
Inbound Data	None	
Success Return	IOInputPort	
PUT		
Description	It is used to update particular input port information.	
Query	None	
Inbound Data	IOInputPort	
Success Return	ResponseStatus	
Notes:		
<triggering> indicates the signal conditions to trigger the input port. High/Low will</triggering>		
continuously trigger for the duration of high/low input signal.		
<name> IO input p</name>	<name> IO input port name.</name>	

#### IOInputPort XML Block



<name> <!--opt,xs:string--></name> </lOInputPort>

## 8.3.5/ISAPI/System/IO/inputs/<ID>/status

/ISAPI/System/IO	/inputs/ <i>ID</i> /status	General Resource v2.0
GET		
Description	It is used to get the status of a particular	r input port.
Query	None	
Inbound Data	None	
Success Return	IOPortStatus	
Notes:		
See /IO/status for an explanation of the fields.		

## 8.3.6/ISAPI/System/IO/outputs

/ISAPI/System/IO	outputs	General Resource v2.0
GET		
Description	It is used to get the output ports information	ation.
Query	None	
Inbound Data	None	
Success Return	IOOutputPortList	
Notes:		
IO outputs are hardwired, meaning that the outputs are statically allocated by the device		
and cannot be crea	ated or deleted.	

#### IOOutputPortList XML Block

<IOOutputPortList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <IOOutputPort/> <!-- opt --> </IOOutputPort>

## 8.3.7/ISAPI/System/IO/outputs/<ID>

/ISAPI/System/IO/outputs/ID		General Resource	v2.0
GET			
Description	It is used to get particular output port info	rmation.	
Query	None		



Inbound Data	None
Success Return	IOOutputPort
PUT	
Description	It is used to update particular output port information.
Query	None
Inbound Data	IOOutputPort
Success Return	ResponseStatus

#### Notes:

- <PowerOnState> defines the output port configuration when the device is powered on.
- <defaultState> is the default output port signal when it is not being triggered.
- <outputState> is the output port signal when it is being triggered. Pulse will cause the output port to send a signal (opposite of the <defaultState>) for a duration specified by the <pulseDuration> tag.
- <pulseDuration> is the duration of a output port signal when it is being triggered. It must be provided if the <outputState> is "pulse".

#### IOOutputPort XML Block

## 8.3.8/ISAPI/System/IO/outputs/<ID>/status

/ISAPI/System/IC	/outputs/ <i>ID</i> /status	General Resource v2.0
GET		
Description	It is used to get the status of a pa	rticular output port.
Query	None	
Inbound Data	None	
Success Return	IOPortStatus	
Notes:		
See /IO/status for an explanation of the fields.		



## 8.3.9/ISAPI/System/IO/outputs/<ID>/trigger

/ISAPI/System/IO/outputs/ID/trigger		General Resource	v2.0
PUT			
Description	It is used to manually trigger a particular of	output port.	
Query	None		
Inbound Data	IOPortData		
Success Return	ResponseStatus		
Notes:			
Note that the ID used here MUST correspond to the ID in /IO/outputs/ID.			
The IO output port	s toggled to a high or low signal accordingl	y.	

#### **IOPortData XML Block**

## 8.4 /ISAPI/System/Video

/ISAPI/System/Video	Service v2.0
Notes:	

## 8.4.1/ISAPI/System/Video/capabilities

/ISAPI/System/Vi	deo/capabilities	General Resource	v2.0
GET			
Description	It is used to get device capability.		
Query	None		
Inbound Data	None		
Success Return	<videocap></videocap>		
Notes:			

#### VideoCap XML Block

<VideoCap version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <videoInputPortNums> <!-- opt, xs:integer--> <videoInputPortNums>
 <videoOutputPortNums> <!-- opt, xs:integer--> <videoOutputPortNums>
 </VideoCap>



## 8.4.2/ISAPI/System/Video/inputs

/ISAPI/System/Video/inputs General Resou		General Resource v2.0
GET		
Description	It is used to get the video inputs of	configuration on an IP media device.
Query	None	
Inbound Data	None	
Success Return	VideoInput	
Notes:		
An IP media device may contain a set of video inputs. These inputs are hardwired by the		

#### **VideoInput XML Block**

device, meaning that the IDs can be discovered but not created or deleted.

## 8.4.3/ISAPI/System/Video/inputs/channels

ISAPI/System/Video/inputs/channels General Resource		General Resource v2.0
GET		
Description	It is used to get the video input of media device.	channels configuration on an IP
Query	None	
Inbound Data	None	
Success Return	VideoInputChannelList	
Notes:		
Since video input channels are resources that are defined by the hardware configuration		
of the device, they cannot be created or deleted.		

#### VideoInputChannelList XML Block



## 8.4.4/ISAPI/System/Video/inputs/channels/<ID>

ISAPI/System/Video/inputs/channels/ID General Resource v2.			2.0
GET			
Description	It is used to get a particular video input of IP media device.	channel configuration on	an
Query	None		
Inbound Data	None		
Success Return	VideoInputChannel		
PUT			
Description	It is used to update a particular video inp an IP media device.	ut channel configuration	on
Query	None		
Inbound Data	VideoInputChannel		
Success Return	ResponseStatus		
Notes:			

#### VideoInputChannel XML Block

## 8.4.5/ISAPI/System/Video/inputs/channels/<ID>/fo cus

/ISAPI/System/Video/inputs/channels/ID/focus		General Resource v2.0
PUT		
Description	Manually focus a video input channel.	
Query	None	
Inbound Data	FocusData	
Success Return	ResponseStatus	
Notes:		



<focus>: focus vector data. Negative numbers focus near, positive numbers focus far.Numerical value is a percentage of the maximum focus speed of the lens module.

#### FocusData XML Block

### 8.4.6/ISAPI/System/Video/inputs/channels/<ID>/iri

S

/ISAPI/System/Video	/inputs/channels/ <i>ID</i> /iris	General Resource	
		v2.0	
PUT			
Description	Manually adjust iris for a video	Manually adjust iris for a video input channel.	
Query	None	None	
Inbound Data	IrisData		
Success Return	ResponseStatus		
Notes:	·		
<iris> negative numbers close iris, positive numbers open iris. Numerical value is a percentage</iris>			
of the maximum iris speed of the lens module.			

#### IrisData XML Block

## 8.4.7/ISAPI/System/Video/inputs/channels/<ID>/pr ivacyMask

/ISAPI/System/Video/inputs/channels/ID/privacyMask		General Resource v2.0
GET		
Description It is used to get the privacy maskin video input channel.		sking configuration for a
Query	None	



Inbound Data	None	
Success Return	PrivacyMask	
PUT		
Description	It is used to update the privacy masking configuration for a video input channel.	
Query	None	
Inbound Data	PrivacyMask	
Success Return	ResponseStatus	
Notes:		
Privacy masking can be enabled and the region list configured per channel.		

#### PrivacyMask XML Block

# 8.4.8/ISAPI/System/Video/inputs/channels/<ID>/pr ivacyMask/regions

/ISAPI/System/Video/inputs/channels/ <i>ID</i> /privacyMask/regions General Resource		
v2.0		
GET		
Description	It is used to get the privacy mask regions configuration	
Description	for a video input channel.	
Query	None	
Inbound Data	None	
Success Return	PrivacyMaskRegionList	
PUT		
Description	It is used to update the privacy mask regions	
Description configuration for a video input channel.		
Query	None	
Inbound Data	PrivacyMaskRegionList	
Success Return	ResponseStatus	
POST		



Description	It is used to add a privacy mask region for a video input channel.	
Query	None	
Inbound Data	PrivacyMaskRegion	
Success Return	ResponseStatus	
DELETE		
Description	It is used to delete the privacy mask regions configuration for a video input channel.	
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	
Notes:		
Privacy masking consists of a set of regions that are combined to grey or black out areas of a video input.		

#### PrivacyMaskRegionList XML Block

<PrivacyMaskRegionList version="2.0"
xmIns="http://www.isapi.org/ver20/XMLSchema">
 <PrivacyMaskRegion/> <!-- opt -->
</PrivacyMaskRegionList>

# 8.4.9/ISAPI/System/Video/inputs/channels/<ID>/pr ivacyMask/regions/<ID>

/ISAPI/System/Video/inputs/channels/ID/privacyMask/regions/I General		
D	Resource v2.0	
GET		
Description	It is used to get a particular privacy mask region configuration for a video input channel.	
Query	None	
Inbound Data	None	
Success Return PrivacyMaskRegion		
PUT		
Description	It is used to update a particular privacy mask region configuration for a video input channel.	
Query	None	
Inbound Data	PrivacyMaskRegion	
Success Return	ResponseStatus	
DELETE		
Description	It is used to delete a particular privacy mask region	



	configuration for a video input channel.	
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	

#### Notes:

Region coordinates are dependent on normalized screen size.

The computer screen coordinate system is used, which the origin coordinate is on top-left corner, the Y axis is vertical downwards, the X axis is horizontal rightwards.

Only support the rectangular region which will be "drawn" from four coordinates. The four points is counterclockwise direction, and the beginning point is the top-left point.


Ordering of <PrivacyMaskRegion> blocks is insignificant.

#### PrivacyMaskRegion XML Block

```
<PrivacyMaskRegion version="2.0"
xmIns="http://www.isapi.org/ver20/XMLSchema">
 <id><!-- req, xs:integer --> </id>
 <enabled> <!-- req,xs:boolean --> </enabled>
 <RegionCoordinatesList> <!-- req -->
    <RegionCoordinates> <!-- req -->
      <positionX> <!-- req, xs:integer;coordinate -->
                                                          </positionX>
      <positionY>
                       <!-- req, xs:integer;coordinate -->
                                                            </positionY>
    </RegionCoordinates>
 </RegionCoordinatesList>
 <privacymaskName><!-- opt, xs:string--></privacymaskName>
 <maskType>
    <!--opt, xs:string "gray,red,yellow,blue,orange,green,
       transparent, half-transparent, mosaic"-->
 </maskType>
  <zoomdoorlimit> <!-- opt, xs:integer "10-1000"--> </zoomdoorlimit>
</PrivacyMaskRegion>
```

#### **Example for priavacyMask Region:**





# 8.4.10 /ISAPI/System/Video/inputs/channels/<ID>/t amperDetection

/ISAPI/System/Video/inputs/channels/ <i>ID</i> /tamperDetection General Resource v2.0			
GET			
Description	It is used to get the shelter alarm of input channel.	It is used to get the shelter alarm configuration for a video input channel.	
Query	None	None	
Inbound Data	None	None	
Success Return	TamperDetection	TamperDetection	
PUT			
Description	It is used to update the shelter all video input channel.	arm configuration for a	
Query	None		
Inbound Data	TmaperDetection		
Success Return	ResponseStatus		
Notes:	·		

#### **TameprDectection XML Block**



# 8.4.11 /ISAPI/System/Video/inputs/channels/<ID>/t amperDetection/regions

/ISAPI/System/Video/inputs/channels/ID/tamperDetection/region General		
s	Resource v2.0	
GET		
Description	It is used to get the shelter alarm regions configuration	
Description	for a video input channel.	
Query	None	
Inbound Data	None	
Success Return	TamperDetectionRegionList	
PUT		
Description	It is used to update the shelter alarm regions	
Description	configuration for a video input channel.	
Query	None	
Inbound Data	TamperDetectionRegionList	
	ResponseStatus	
Success Return	ResponseStatus	
Success Return POST	ResponseStatus	
POST	ResponseStatus  It is used to add a shelter alarm region for a video input	
POST	It is used to add a shelter alarm region for a video input	
POST  Description	It is used to add a shelter alarm region for a video input channel.	
POST  Description  Query	It is used to add a shelter alarm region for a video input channel.  None	
POST  Description  Query Inbound Data	It is used to add a shelter alarm region for a video input channel.  None  TamperDetectionRegion	
POST  Description  Query Inbound Data Success Return  DELETE	It is used to add a shelter alarm region for a video input channel.  None  TamperDetectionRegion	
POST  Description  Query Inbound Data Success Return	It is used to add a shelter alarm region for a video input channel.  None  TamperDetectionRegion  ResponseStatus	
POST  Description  Query Inbound Data Success Return  DELETE	It is used to add a shelter alarm region for a video input channel.  None  TamperDetectionRegion  ResponseStatus  It is used to delete the shelter alarm regions	
POST  Description  Query Inbound Data Success Return  DELETE  Description	It is used to add a shelter alarm region for a video input channel.  None  TamperDetectionRegion  ResponseStatus  It is used to delete the shelter alarm regions configuration for a video input channel.	



Notes:

#### TamperDetectionRegionList XML Block

<TamperDetectionRegionList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <TamperDetectionRegion/> <!-- opt --> </ TamperDetectionRegionList >

# 8.4.12 /ISAPI/System/Video/inputs/channels/<ID>/t amperDetection/regions/<ID>

/ISAPI/System/Video/inputs/channels/ID/tamperDetection/regions/ID General	
	Resource
	v2.0
GET	
Description	It is used to get a particular shelter alarm region configuration for a video input channel.
Query	None
Inbound Data	None
Success Return	TamperDetectionRegion
PUT	
Description	It is used to update a particular shelter alarm region configuration for a video input channel.
Query	None
Inbound Data	TamperDetectionRegion
Success Return	ResponseStatus
DELETE	
Description	It is used to delete a particular shelter alarm region configuration for a video input channel.
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes:	
Region coordinates are de	ependent on video resolution. Only support the rectangular region
which will be "drawn" from	n four coordinates. The four points is clockwise direction, and the
beginning point is the low	-left point.

#### TamperDetectionRegion XML Block

Ordering of <TamperDetectionRegion> blocks is insignificant.



```
<TamperDetectionRegion version="2.0"</p>
xmIns="http://www.isapi.org/ver20/XMLSchema">
  <id>
                   <!-- req, xs:string, id -->
                                                     </id>
  <sensitivityLevel>
    <!--req, xs:integer, 0..100, 0 is the least sensitive -->
  </sensitivityLevel>
  <RegionCoordinatesList> <!-- req -->
    <RegionCoordinates> <!-- req -->
                        <!-- req, xs:integer;coordinate -->
                                                             </positionX>
      <positionX>
      <positionY>
                        <!-- req, xs:integer;coordinate --> </positionY>
    </RegionCoordinates>
  </RegionCoordinatesList>
</TamperDetectionRegion>
```

## 8.4.13 /ISAPI/System/Video/inputs/channels/<ID>/ motionDetection

/ISAPI/System/Vio	deo/inputs/channels/ID Service v2.0
/MotionDetection	
GET	
Decerinties	It is used to get the motion detection configuration for all video input
Description	channels.
Query	None
Inbound Data	None
Success Return	MotionDetection
PUT	
Description	It is used to udpate the motion detection configuration for a video
	input channel.
Query	None
Inbound Data	MotionDetection
Success Return	ResponseStatus
Notes:	
If motion detection	is supported by the device, a motion detection ID will be allocated for

#### **MotionDetection XML Block**

channel ID.

<motiondetection version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"></motiondetection>		
<enabled></enabled>	req, xs:boolean	
<enablehighlight></enablehighlight>	opt, xs:boolean	

each video input channel ID. The motion detection ID must correspond to the video input



```
<samplingInterval> <!-- opt, xs:integer, number of frames --> </samplingInterval>
  <startTriggerTime> <!-- opt, xs:integer, milliseconds --> </startTriggerTime>
  <endTriggerTime> <!-- opt, xs:integer, milliseconds --> </endTriggerTime>
 <regionType>
                    <!-- ro, req, xs:string, "grid, roi, none" -->
                                                                   </regionType>
 <Grid>
                 <!-- dep -->
    <rowGranularity>
                        <!-- ro, req, xs:integer --> </rowGranularity>
    <columnGranularity> <!-- ro, req, xs:integer --> </columnGranularity>
 </Grid>
 <ROI> <!-- dep -->
    <normalizedScreenWidth> <!-- ro, req, xs:integer --></normalizedScreenWidth>
    <normalizedScreenHeight> <!-- ro, req, xs:integer --></normalizedScreenHeight>
 </ROI>
  <MotionDetectionLayout/> <!-- req -->
</MotionDetection>
```

## 8.4.14 /ISAPI/System/Video/inputs/channels/<ID>/ motionDetection/layout

/ISAPI/System/Video/inputs/channels/ID General Resource v2.0
/MotionDetection/layout

Notes:

#### MotionDetectionLayout XML Block



# 8.4.15 /ISAPI/System/Video/inputs/channels/<ID>/ motionDetection/layout/gridLayout

/ISAPI/System/Video/inputs/channels/ID General Resource v2.0 /MotionDetection/layout/gridLayout		
GET		
Description	It is used to get the motion detection regions configuration for a video input channel.	
Query	None	
Inbound Data	None	
Success Return	MotionDetectionGridLayout	
PUT		
Description	It is used to update the motion detection regions configuration for a video input channel.	
Query	None	
Inbound Data	MotionDetectionGridLayout	
Success Return	ResponseStatus	
Notes:		

All motion detection regions share a sensitivity level.

It is possible to define mask regions that are subtracted from other regions.

<gridMap> required when region type is grid.

A "1" denotes an grid to detect and a "0" no to detect.

The first cell is in the upper left corner. Then the cell order goes first from left to right and then from up to down (see flowing example).

If the number of cells is not a multiple of 8 the last byte is filled with zeros.

#### MotionDetectionGridLayout XML Block


## 8.4.16 Motion Detection Example

#### **Set up Motion Detection**



The following command configures two rectangular detection regions, with one "masked" region on video input channel ID 1. Example assumes a resolution of 1600x1200 and a grid motion detection algorithm:

Motion detection is enabled with a granularity of a 22x18 grid (each row will reserve 2 grids, the actual region is 24x18; but generally the last two rows are ignored.) – this means the detection region coordinates will ultimately be defined by a grid of 432 regions. For a resolution of 1600x1200, this means that each "granule" will be 1600/22 x 1200/18 pixels. (If a coordinate doesn't exactly match the configured granularity, it should be mapped internally to the nearest possible point).



PUT /MotionDetection/1 HTTP/1.1

Content-Type: application/xml; charset="UTF-8"

Content-Length: ISAPI

<?xml version="2.0" encoding="UTF-8"?>

<MotionDetection version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">

<id>1</id>

<enabled>true</enabled>

<MotionDetectionLayout>

<sensitivityLevel>20</sensitivityLevel>

<gridMap>

00000000000000f00000f00000f00000f00000

</gridMap>

</MotionDetectionLayout>

</MotionDetection>



## 8.4.17 /ISAPI/System/Video/inputs/channels/<ID>/ motionDetectionExt

/ISAPI/System/Video/inputs/channels/ <i>ID</i> Service v2./motionDetectionExt		
GET		
Description	It is used to get the motion detection configuration for all video input channels.	
Query	None	
Inbound Data	None	
Success Return	MotionDetectionExt	
PUT		
Description	It is used to udpate the motion detection configuration for a video input channel.	
Query	None	
Inbound Data	MotionDetectionExt	
Success Return	ResponseStatus	
Notes:		

If motion detection is supported by the device, a motion detection ID will be allocated for each video input channel ID. The motion detection ID must correspond to the video input channel ID.

The devices supports two kinds of motion detection, <activeMode> is used to check current motion detection mode, if the value is normal, please refer to /motionDetection branch; if the value is expert, please refer to /motionDetectionExt branch.

#### MotionDetectionExt XML Block



<MotionDetectionSwitch/> <!--opt -->
 <activeMode> <!-- ro, xs:string, "normal,expert"> <activeMode>
 <MotionDetectionRegionList/> <!-- req -->
 </MotionDetectionExt>

## 8.4.18 /ISAPI/System/Video/inputs/channels/<ID>/ motionDetectionExt/regions

/ISAPI/System/Video/inputs/channels/ID	General Resource v2.0
/motionDetectionExt/regions	
GET	

#### MotionDetectionRegionList XML Block

<MotionDetectionRegionList version="2.0"
xmIns="http://www.isapi.org/ver20/XMLSchema">
<MotionDetectionRegion/> <!-- opt -->
</MotionDetectionRegionList>

# 8.4.19 /ISAPI/System/Video/inputs/channels/<ID>/ motionDetectionExt/regions/<ID>

•	eo/inputs/channels/ID General Resource v2.0
/motionDetection	Ext/ID/regions/ID
GET	
Description	It is used to get the motion detection configuration for all video input
Description	channels.
Query	None
Inbound Data	None
Success Return	MotionDetectionRegion
PUT	
Description	It is used to udpate the motion detection configuration for a video
	input channel.
Query	None
Inbound Data	MotionDetectionRegion
Success Return	ResponseStatus
Notes:	
If motion detectio	n is supported by the device, a motion detection ID will be allocated for



each video input channel ID. The motion detection ID must correspond to the video input channel ID.

#### MotionDetectionRegion XML Block

```
<MotionDetectionRegion version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
        <!-- req, xs:string;id --></id>
 <enabled> <!-- req, xs:boolean --> </enabled>
 <sensitivityLevel> <!-- req -->
   <!-- req, xs:integer, 0..100, 0 is least sensitive -->
 </sensitivityLevel>
 <daySensitivityLevel>
                          <!-- dep -->
   <!-- req, xs:integer, 0..100, 0 is least sensitive-->
 </daySensitivityLevel>
 <nightSensitivityLevel> <!-- dep -->
   <!-- req, xs:integer, 0..100, 0 is least sensitive-->
 </nightSensitivityLevel>
 <objectSize>
                 <!-- dep -->
    <!-- req, xs:integer, 0..100, 0 is least sensitive -->
 </objectSize>
 <dayObjectSize> <!-- dep -->
    <!-- req, xs:integer, 0..100, 0 is least sensitive -->
 </dayObjectSize>
 <nightObjectSize> <!-- dep -->
    <!-- req, xs:integer, 0..100, 0 is least sensitive -->
 </nightObjectSize>
 <RegionCoordinatesList> <!-- req -->
   <RegionCoordinates> <!-- Note: at least two coordinates are required -->
     <positionX> <!-- req, xs:integer --> </positionX>
     <positionY> <!-- req, xs:integer --> </positionY>
   </RegionCoordinates>
 </RegionCoordinatesList>
</MotionDetectionRegion>
```

## 8.4.20 /ISAPI/System/Video/inputs/channels/<ID>/ motionDetectionExt/switch

/ISAPI/System/\ ectionExt/switc	/ideo/inputs/channels/ID/motionDet h	General Resource v2.0	D
GET			
Description	It is used to get the motion detection	switch day and night settings.	
Query	None		



Inbound Data	None
Success Return	MotionDetectionSwitch
PUT	
Description	It is used to udpate the motion detection switch day and night settings.
Query	None
Inbound Data	MotionDetectionSwitch
Success Return	ResponseStatus
Notes:	

If motion detection is supported by the device, a motion detection ID will be allocated for each video input channel ID. The motion detection ID must correspond to the video input channel ID.

### MotionDetectionSwitch XML Block

# 8.4.21 /ISAPI/System/Video/inputs/channels/<ID>/ overlays

/ISAPI/System/Video/inputs/channels/ID/overlays		General Resource	v2.0
GET			
Description	It is used to get the overlays configur	ation for a video input chann	nel.
Query	None		
Inbound Data	None		
Success Return	VideoOverlay		
PUT			



Description	It is used to update the overlays configuration for a video input channel.	
Query	None	
Inbound Data	VideoOverlay	
Success Return	ResponseStatus	

### VideoOverlay XML Block

# 8.4.22 /ISAPI/System/Video/inputs/channels/<ID>/ overlays/text

/ISAPI/System/Video/inputs/channels/ID/overlays/text General Resou		General Resource
		v2.0
GET		
Description	It is used to get the text overlays of input channel.	configuration for a video
Query	None	
Inbound Data	None	
Success Return	TextOverlayList	
PUT		
Description It is used to update the text overlays configuration for a video input channel.		lays configuration for a
Query	None	
Inbound Data	TextOverlayList	
Success Return	ResponseStatus	
POST		



Description	It is used to add a text overlay for a video input channel.	
Query	None	
Inbound Data	TextOverlay	
Success Return	ResponseStatus	
DELETE		
Description	It is used to delete the text overlays configuration for a video	
Description	input channel.	
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	
Notes:		

A set of text overlays is managed. They are composited over the video signal in increasing

### TextOverlayList XML Block

ID-order.

# 8.4.23 /ISAPI/System/Video/inputs/channels/<ID>/ overlays/text/<ID>

/ISAPI/System/Video/inputs/channels/ID/overlays/text/ID General Resource			
		v2.0	
GET	GET		
Description	It is used to get a particular text over	erlay configuration for a	
Description	video input channel.		
Query	None		
Inbound Data	None		
Success Return	TextOverlay		
PUT			
Deceriation	It is used to update a particular tex	xt overlay configuration	
Description	for a video input channel.		
Query	None		
Inbound Data	TextOverlay		
Success Return	ResponseStatus		
DELETE			
Description	It is used to delete a particular text of	overlay configuration for	
Description	a video input channel.		



Query	None
Inbound Data	None
Success Return	ResponseStatus

### Notes:

Position coordinates are dependent on normalized screen size.

The computer screen coordinate system is used, which the origin coordinate is on top-left corner, the Y axis is vertical downwards, the X axis is horizontal rightwards.

### **TextOverlay XML Block**

```
<TextOverlay version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id>
                  <!-- req, xs:string;id -->
                                               </id>
  <enabled>
                 <!-- req, xs:boolean -->
                                               </enabled>
  <positionX>
                 <!-- req, xs:float -->
                                           </positionX>
  <positionY>
                 <!-- req, xs:float -->
                                           </positionY>
  <displayText>
                   <!-- req, xs:string -->
                                            </displayText>
</TextOverlay>
```

# 8.4.24 /ISAPI/System/Video/inputs/channels/<ID>/ overlays/channelNameOverlay

/ISAPI/System/Video/inputs/channels/ID/overlays/ General Resource v2.0 channelNameOverlay		
GET		
Description	It is used to get a particular channel name configuration for a video input channel.	
Query	None	
Inbound Data	None	
Success Return	channelNameOverlay	
PUT		
Description	It is used to update a particular channel name configuration for a video input channel.	
Query	None	
Inbound Data	channelNameOverlay	
Success Return	ResponseStatus	
Notes:		

#### Notes:

Position coordinates are dependent on normalized screen size.

The computer screen coordinate system is used, which the origin coordinate is on top-left corner, the Y axis is vertical downwards, the X axis is horizontal rightwards.

## channelNameOverlay XML Block



```
<channelNameOverlay version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <enabled> <!-- req, xs:boolean --> </enabled> //Show channel name
  <positionX> <!-- req, xs:integer;coordinate --> </positionX>
  <positionY> <!-- req, xs:integer;coordinate --> </positionY>
</channelNameOverlay>
```

# 8.4.25 /ISAPI/System/Video/inputs/channels/<ID>/ overlays/dateTimeOverlay

/ISAPI/System/Video/inputs/channels/ID/overlays/dateTime General Resource		
	v2.0	
GET		
Description	It is used to get the OSD configuration for a video input channel.	
Query	None	
Inbound Data	None	
Success Return	DatetimeOverlay	
PUT		
Description It is used to update the OSD configuration for a video input channel.		
Query	None	
Inbound Data	DatetimeOverlay	
Success Return	ResponseStatus	
Notes:		

Position coordinates are dependent on normalized screen size.

The computer screen coordinate system is used, which the origin coordinate is on top-left corner, the Y axis is vertical downwards, the X axis is horizontal rightwards.

### DateTimeOverlay XML Block

```
<DateTimeOverlay version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <enabled> <!-- req, xs:boolean --> </enabled>//check whether to display date
  <positionX> <!-- req, xs:integer;coordinate --> </positionX>
  <positionY> <!-- req, xs:integer;coordinate --> </positionY>
  <dateStyle>
    <!--
            opt,
                   xs:string,
                                 "YYYY-MM-DD,
                                                    MM-DD-YYYY,
                                                                      DD-MM-YYYY,
CHR-YYYY-MM-DD, CHR-MM-DD-YYYY, CHR-DD-MM-YYYY" -->
  </dateStyle>
  <timeStyle> <!--opt, xs:string, "12hour, 24hour" --> </timeStyle>
  <displayWeek> <!-- opt, xs:boolean --> </displayWeek>//check whether to display week
</DateTimeOverlay>
```



# 8.4.26 /ISAPI/System/Video/inputs/channels/<ID>/i mage

/ISAPI/System/Video/inputs/channels/ID/image General Resource		v2.0
GET		
Description	Access on-screen Image for a special channel.	
Query	None	
Inbound Data	None	
Success Return	ImageOverlayList	
PUT		
Description	Configure the on-screen Image for a special channel.	
Query	None	
Inbound Data	ImageOverlayList	
Success Return	ResponseStatus	
Notes:		

## ImageOverlayList XML Block

<lmageOverlayList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <ImageOverlay/> <!-- opt -->
 </ImageOverlayList>

# 8.4.27 /ISAPI/System/Video/inputs/channels/<ID>/i mage/<ID>

/ISAPI/System/Video/inputs/channels/ID/image/ID General Resource		v2.0	
GET			
Description	Access on-screen Image for a special char	nnel.	
Query	None		
Inbound Data	None		
Success Return	ImageOverlay		
PUT			
Description	Configure the on-screen Image for a special	l channel.	
Query	None		
Inbound Data	ImageOverlay		
Success Return	ResponseStatus		
Notes:			



### ImageOverlay XML Block

# 8.4.28 /ISAPI/System/Video/inputs/channels/<ID>/i mage/picture

/ISAPI/System/Video/inputs/channels/ID/image/pict		
ure		
POST		
Description	Configure the on-screen Image for a special channel.	
Query	None	
Inbound Data	Picture over HTTP	
Success Return	ResponseStatus	
Notes:		

## 8.4.29 /ISAPI/System/Video/outputs

/ISAPI/System/Vi	General Resource v2.0	
GET		
Description	It is used to get the video outputs device.	configuration on an IP media
Query	None	
Inbound Data	None	
Success Return	VideoOutput	
Notes:		
An IP media device may contain a set of video outputs. These outputs are hardwired by the device, meaning that the IDs can be discovered but not created or deleted.		



### VideoOutput XML Block

## 8.4.30 /ISAPI/System/Video/outputs/channels

ISAPI/System/Video/outputs/channels Ge		General Resource v2.0
GET		
Description	It is used to get the video output channels configuration on an IP media device.	
Query	None	
Inbound Data	None	
Success Return	VideoOutputChannelList	
Notes:		
Since video output channels are resources that are defined by the hardware configuration		
of the device, they cannot be created or deleted.		

### VideoOutputChannelList XML Block

## 8.4.31 /ISAPI/System/Video/outputs/channels/<ID

>

ISAPI/System/Video/outputs/channels/ <id> General Resource v2.0</id>		
GET		
Description	It is used to get a particular video input channel configuration on an IP media device.	
Query	None	
Inbound Data	None	
Success Return	VideoOutputChannel	
Notes:		
<menu> required if the port support display menu. <mirrormenu> check whether to support to display menu of another port simultaneously</mirrormenu></menu>		



### VideoOutputChannel XML Block

## 8.4.32 /ISAPI/System/Video/Menu

URI	/ISAPI/System/Video/Menu		Туре	Resource
Function	Access the local menu configuration on an IP media device.			
Methods	Query String(s)	Inbound Data	Return Result	
GET			<me< th=""><th>nuList&gt;</th></me<>	nuList>
Notes	An IP media device may contain a set of local menus. These menus are hardwired by the device, meaning that the IDs can be discovered but not created or deleted. ID numbering or values should be considered arbitrary and			

#### MenuList XML Block

```
<MenuList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <Menu/>  <!-- opt  -->
  </MenuList>
```

## 8.4.33 /ISAPI/System/Video/Menu/<ID>

URI	/ISAPI/System/Video/Menu/ <id></id>		Туре	Resource
Function	Access menu configuration.			
Methods	Query String(s) Inbound Data Return Result		esult	
GET		None	<menu></menu>	
PUT		<menu></menu>	<responsesta< th=""><th>tus&gt;</th></responsesta<>	tus>
Notes	lf(mode == auto) Vide	oOutputPortList is ro		

### Menu XML Block



```
<Menu version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <mode> <!--req, xs:string, "auto, manual" --> </mode>
  <VideoOutputPortList> <!-- req -->
    <videoOutputPortID> <!-- opt, xs:string, id--> </videoOutputPortID>
  </VideoOutputPortList>
  </Menu>
```

## 8.5 /ISAPI/System/Audio

/ISAPI/System/Audio Service	
Notes:	

## 8.5.1/ISAPI/System/Audio/capabilities

/ISAPI/System/Audio/capabilities		General Resource	v2.0
GET			
Description	It is used to get audio capability.		
Query	None		
Inbound Data	None		
Success Return	<audiocap></audiocap>		
Notes:			

### AudioCap XML Block

```
<AudioCap version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
    <audioInputNums> <!-- req, xs:integer> </audioInputNums>
    <audioOutputNums> <!-- req, xs:integer> </audioOutputNums>
    </AudioCap>
```

## 8.5.2/ISAPI/System/Audio/channels

/ISAPI/System//Audio/channels		General Resource v2.0
GET		
Description	It is used to get the audio channels of device.	configuration on an IP media
Query	None	
Inbound Data	None	
Success Return	AudioChannelList	
Notes:		



Since inputs are resources that are defined by the hardware configuration of the device, audio channels cannot be created or deleted.

#### AudioChannelList XML Block

# 8.5.3/ISAPI/System/Audio/channels/<ID>

/ISAPI/System/Audio/channels/ID		General Resource v2.0
GET		
Description	It is used to get a particular audio charmedia device.	nnel configuration on an IP
Query	None	
Inbound Data	None	
Success Return	AudioChannel	
Notes: <audiomode> is the duplex mode for audio transmission between the client and media device.</audiomode>		

#### AudioChannel XML Block

# 8.5.4/ISAPI/System/TwoWayAudio

/ISAPI/System/TwoWayAudio	General Resource	v2.0
Notes: two way audio Service.		

## 8.5.5/ISAPI/System/TwoWayAudio/channels

/ISAPI/System/TwoWayAudio/channels	General Resource	v2.0



GET	
Description	It is used to get the two way audio channels list
Query	None
Inbound Data	None
Success Return	TwoWayAudioChannelList
Notes:	

### TwoWayAudioChannelList XML Block

```
<TwoWayAudioChannelList version="2.0"

xmIns="http://www.isapi.org/ver20/XMLSchema">
    <TwoWayAudioChannel/> <!-- opt -->
    </TwoWayAudioChannelList>
```

## 8.5.6/ISAPI/System/TwoWayAudio/channels/<ID>

/ISAPI/System/TwoWayAudio/channels/ID General Resource v2.0			v2.0
GET			
Description	It is used to get a particular two way audio channel		
Query	None		
Inbound Data	None		
Success Return	TwoWayAudioChannel		
PUT			
Description	It is used to get a particular transparent of	channel	
Query	None		
Inbound Data	TwoWayAudioChannel		
Success Return	ResponseStatus		
Notes:			
When <enabled>is true, two way audio is open; otherwise two way audio is closed.</enabled>			
When <audiocompressiontype> is MP212, <audiobitrate> supports to set bit rate.</audiobitrate></audiocompressiontype>			

### TwoWayAudioChannel XML Block



```
-->
  </audioCompressionType>
  <audioInboundCompressionType>
      <!-- opt, xs:string,
      "G.711alaw,G.711ulaw,G.726,G.729,G.729a,G.729b,PCM,MP3,AC3,AAC,ADPCM
  </audioInboundCompressionType>
  <speakerVolume> <!-- opt, xs:int--> </speakerVolume>
  <microphoneVolume> <!-- opt, xs:int--> </microphoneVolume>
  <noisereduce> <!-- opt, xs: Boolean, "true, false" --> </noisereduce>
  <audioBitRate> <!-- opt, xs:integer;kbs--> </audioBitRate>
  <audioInputType > <!-- opt, xs:string, "MicIn, LineIn"--> </audioInputType>
  <associateVideoInputs> <!-- opt -->
    <enabled> <!-- req, xs:Boolean --> </enabled>
    <videoInputChannelList>
                               <!-- req -->
      <videoInputChannelID> <!-- opt, xs:string; id --> </videoInputChannelID>
    </videoInputChannelList>
  </associateVideoInputs>
</TwoWayAudioChannel>
```

# 8.5.7/ISAPI/System/TwoWayAudio/channels/<ID>/ open

/ISAPI/System/TwoW	/ayAudio/channels/ID/open	General Resource	
		v2.0	
PUT			
Description	It is used to open the two wa	ay audio channel.	
Query	None	None	
Inbound Data	None		
Success Return	TwoWayAudioSession		
Notes:			
In sessionId 8.6.5, if se	nd Voice data, need to use this field to	represent the communication on	
which session.			

#### TwoWayAudioSession XML Block

<TwoWayAudioSession version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <sessionId> <!-- req, xs:string --> </sessionId>



</TwoWayAudioSession>

# 8.5.8/ISAPI/System/TwoWayAudio/channels/<ID>/

/ISAPI/System/TwoWayAudio/channels/ID/close		General Resource v2.0
PUT		
Description	It is used to close the two way audio	channel.
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	
Notes:		

# 8.5.9/ISAPI/System/TwoWayAudio/channels/<ID>/ audioData

/ISAPI/System/TwoWayAudio/channels/ID/audioData		General Resource v2.0
GET		
Description	It is used to get data on the tra	nsparent channel.
Query	sessionId	
Inbound Data	Raw Data	
Success Return	ResponseStatus	
PUT		
Description	It is used to send data on the tr	ransparent channel.
Query	None	
Inbound Data	Raw Data	
Success Return	ResponseStatus	
Notes:		

## Example: Client sends audio data to server

PUT /ISAPI/System/TwoWayAudio/channels/ID/transData HTTP 1.1
...
Content-Type: application/binary; charset="UTF-8"\r\n
\r\n
TwowayAudio Data...



...

### Example: Client receives audio data from server

GET /ISAPI/System/TwoWayAudio/channels/ID/transData HTTP/1.1

HTTP/1.1 200 OK

. . .

Content-Type: application/binary; charset="UTF-8"\r\n

 $r\n$ 

TwoWayAudio Data.....

## 8.6 /ISAPI/System/Serial

/ISAPI/System/Serial	Service v2.0
Notes: Serial port service.	

## 8.6.1/ISAPI/SystemSerial/capabilities

/ISAPI/System/Serial/capabilities		<b>General Resource</b>	v2.0
GET			
Description	It is used to get device capability.		
Query	None		
Inbound Data	None		
Success Return	<serialcap></serialcap>		
Notes:			

### SerialCap XML Block

```
<SerialCap version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <rs485PortNums> <!-- opt, xs:integer --> </rs485PortNums>
  <supportRS232Config> <!-- opt, xs:Boolean --> </supportRS232Config>
  <rs422PortNums> <!-- opt, xs:integer--> </rs422PortNums>
  <rs232PortNums> <!-- opt, xs:integer--> </rs232PortNums>
  </SerialCap>
```

## 8.6.2/ISAPI/System/Serial/ports

/ISAPI/System/Serial/ports General Resource vi	2.0
--	-----



GET	
Description	It is used to get the list of serial ports supported by the device.
Query	None
Inbound Data	None
Success Return	SerialPorList
Neter	

#### Notes:

Since serial ports are resources that are defined by the hardware configuration of the device, they cannot be created or deleted.

#### SerialPortList XML Block

## 8.6.3/ISAPI/System/Serial/ports/<ID>

/Serial/ports/ID	General Resource v2.0
GET	
Description	It is used to get the configuration of a serial port supported by the device.
Query	None
Inbound Data	None
Success Return	SerialPort
PUT	
Description	It is used to update the configuration of a serial port supported by the device.
Query	None
Inbound Data	SerialPort
Success Return	ResponseStatus

## Notes:

Access to the serial port parameters.

- <serialPortType> set the type of port; RS232, RS485, etc.
- <direction> indicates whether the port is bidirectional.
- <duplexMode> indicates whether the serial port runs in full or half duplex mode.
- <workMode> is required only when serial port type is RS232

#### **SerialPort XML Block**

<SerialPort version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">



## 8.6.4/ISAPI/System/Serial/ports/<ID>/Transparent

/ISAPI/System/Serial/ports/ID/Transparent	General Resource v2.0
Notes: Transparent Service.	

# 8.6.5/ISAPI/System/Serial/ports/<ID>/Transparent/

/ISAPI/System/Serial/ports/ID/Transparent/channels		General Resource	v2.0
GET			
Description	It is used to get the transparen	nt channels list	
Query	None		
Inbound Data	None		
Success Return	TransparentChannelList		
Notes:	·		

### TransparentChannelList XML Block

```
<TransparentChannelList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
<TransparentChannel/> <!-- opt -->
</TransparentChannelList>
```



# 8.6.6/ISAPI/System/Serial/ports/<ID>/Transparent/channels/<ID>

/ISAPI/System/Serial/ports	s/ID/Transparent/channels/ID	General Resource v2.0
GET		
Description	It is used to get a particular transpa	rent channel
Query	None	
Inbound Data	None	
Success Return	TransparentChannel	
PUT		
Description	It is used to get a particular transpa	rent channel
Query	None	
Inbound Data	TransparentChannel	
Success Return	ResponseStatus	_
Notes:		

## **TransparentChannel XML Block**

```
<TransparentChannel version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
        <id><!-- req, xs:string;id --> </id>
        <enabled> <!-- req, xs:boolean --> </enabled>
        <serialPortID> <!--req,ro, xs:string; id --> </serialPortID>
        </transparentChannel>
```

# 8.6.7/ISAPI/System/Serial/ports/<ID>/Transparent/ channels/<ID>/open

/ISAPI/System/Serial/ports/ <i>ID</i> /Trar	nsparent/channels/ID/open	General Resource v2.0
PUT		
Description	It is used to open the transpa	rent channel.
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	
Notes:		



Only support RS485 transparent channel.

# 8.6.8/ISAPI/System/Serial/ports/<ID>/Transparent/channels/<ID>/close

/ISAPI/System/Serial/ports/ID/Transparent/channels/ID/close General Resource		General Resource
		v2.0
PUT		
Description It is used to close the transparent channel.		channel.
Query None		
Inbound Data None		
Success Return ResponseStatus		
Notes:		

# 8.6.9/ISAPI/System/Serial/ports/<ID>/Transparent/channels/<ID>/transData

/ISAPI/System/Serial/ports/ID/Transparent/channels/ID/transData General		
	Resource	
	v2.0	
GET		
Description	It is used to get data on the transparent channel.	
Query	None	
Inbound Data	Raw Data	
Success Return	n ResponseStatus	
PUT		
Description	It is used to send data on the transparent	
Description	channel.	
Query	None	
Inbound Data	Raw Data	
Success Return ResponseStatus		
Notes:		

#### Example:

GET /ISAPI/System/Serial/ports/ID/Transparent/channels/ID/transData HTTP/1.1



HTTP/1.1 200 OK

. . .

Content-Type: application/binary; charset="UTF-8"

Content-Length: ISAPI

 $r\n$ 

Raw data...

### Example:

PUT /ISAPI/System/Serial/ports/ID/Transparent/channels/ID/transData HTTP/1.1

. . .

Content-Type: application/binary; charset="UTF-8"

 $\r\n$ 

Raw data...

## 8.7 /ISAPI/System/Hardware/

/ISAPI/System/Hardware/ Service	
Notes:	

## 8.7.1/ISAPI/System/Hardware/irLightSwitch

/ISAPI/System/Hardware/irLightSwitch General Resource		v2.0	
GET			
Description			
Query	None		
Inbound Data	None		
Success Return	IrLightSwitch		
PUT			
Description			
Query	None		
Inbound Data	IrLightSwitch		
Success Return	ResponseStatus		
Notes:			

### IrLightSwitch XML Block



## 8.8 /ISAPI/Security

/ISAPI/Security	Service	v2.0
Notes:		

## 8.8.1/ISAPI/Security/capabilities

/ISAPI/Security/capabilities General Resource		v2.0	
GET	GET		
Description	It is used to get security capability.		
Query	None		
Inbound Data	None		
Success Return	<securitycap></securitycap>		
Notes:			

### SecurityCap XML Block

# 8.8.2/ISAPI/Security/users

/ISAPI/Security/users General Resource		
GET		
Description	It is used to get the user list for the device.	
Query	None	
Inbound Data	None	
Success Return	UserList	
PUT	PUT	
Description	It is used to update the user list for the device.	
Query	None	
Inbound Data	UserList	
Success Return	ResponseStatus	



POST	
Description	It is used to add a user for the device.
Query	None
Inbound Data	User
Success Return	ResponseStatus
DELETE	Administrator
Description	It is used to delete the user list for the device.
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes:	

A default user account, "admin", must be provided. Its default password is "12345". It has an Administrator user level, and must not be deleted.

Passwords can only be uploaded - they are never revealed during GET operations.

### **UserList XML Block**

# 8.8.3/ISAPI/Security/users/<ID>

/ISAPI/Security/users/ID General Resource v2.0		v2.0	
GET		Vie	ewer
Description	It is used to get a particular user configurat	ion for the device.	
Query	None		
Inbound Data	None		
Success Return	User		
PUT		Administra	ator
Description	It is used to update a particular user config	uration for the device.	
Query	None		
Inbound Data	User		
Success Return	ResponseStatus		
DELETE		Administra	ator
Description	It is used to delete a particular user for the	device.	
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		
Notes:			
<id> of "admin" acc</id>	count is 1. "admin" account must not be delet	ed.	



<password> is a write-only field.

#### **User XML Block**

```
<User version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
                  <!-- req, xs:integer, "1-16" -->
                                                        </id>
  <id>
  <userName>
                        <!-- req, xs:string --> </userName>
  <password>
                       <!-- wo, req, xs:string --> </password>
  <br/>
<br/>
ddressList>
      <body><br/><br/>bondlpAddress/></br/></br/>
  </bondlpAddressList>
  <br/>
<br/>
dondMacAddressList>
       <br/>
<br/>
dondMacAddress/>
  </br></ bondMacAddressList>
  <userLevel> <!-- opt, xs:string, "Administrator, Operator, Viewer" --> </userLevel>
  <attribute> <!-- opt -->
    <inherent> <!--xs:boolean --> </inherent>
  </attribute>
</User>
```

### bondlpAddress XML Block

#### bondMacAddress XML Block

## 8.8.4/ISAPI/Security/adminAccesses

/ISAPI/Security/adminAccesses General Resource	
GET	Viewer
Description	It is used to get administrative access protocol for the device.
Query	None
Inbound Data	None
Success Return	AdminAccessProtocolList
PUT	Administrator



Description	It is used to update administrative access protocol for the device.
Query	None
Inbound Data	AdminAccessProtocolList
Success Return	ResponseStatus
Notes:	
<pre><pre>cprotocol&gt; is the protocol name for admin access, i.e. "HTTP", "HTTPS", etc.</pre></pre>	

### AdminAccessProtocolList XML Block

## 8.8.5/ISAPI/Security/adminAccesses/<ID>

/ISAPI/Security/adminAccesses/ID		General Resource	v2.0
GET		Vi	ewer
Description	It is used to get administrative access p	rotocol for the device.	
Query	None		
Inbound Data	None		
Success Return	AdminAccessProtocol		
PUT		Administr	ator
Description	It is used to update administrative acce	ss protocol for the device	э.
Query	None		
Inbound Data	AdminAccessProtocol		
Success Return	ResponseStatus		
Notes:			
<pre><pre><pre>cprotocol&gt; is the p</pre></pre></pre>	rotocol name for admin access, i.e. "HTT	P", "HTTPS", etc.	

### AdminAccessProtocol XML Block



## 8.8.6/ISAPI/Security/userCheck

/ISAPI/Security/userCheck		General Resource	v2.0
GET			
Description	It is used to check is password matche up	ser name.	
Query	None		
Inbound Data	None		
Success Return	userCheck		

### Notes:

The device always returns HTTP 200/OK no matter whether userCheck is successful, or not.

The client software checks user name/password via <statusValue>. If the value is 200, it means match, otherwise, if the value is 401, it means mismatch.

#### userCheck XML Block

## 8.8.7/ISAPI/Security/UserPermission

/ISAPI/Security/UserPermission Gen		General Resource	v2.0
GET			
Description	It is used to get user permission of the de	vice.	
Query	None		
Inbound Data	None		
Success Return	UserPermissionList		
PUT			
Description	It is used to set user permission of the de	vice.	
Query	None		
Inbound Data	UserPermissionList		
Success Return	ResponseStatus		
Notes:			
only the user "admin" has the right to review or edit user's permission.			

### UserPermissionList XML Block

<UserPermissionList version="2.0" xmlns=" http://www.isapi.org/ver20/XMLSchema">
 <UserPermission/> <!-- opt -->

</UserPermissionList>

## 8.8.8/ISAPI/Security/UserPermission/<ID>

/ISAPI/Security/Us	serPermission/ID	General Resource	v2.0
GET			
Description	It is used to get a particular user's permiss	sion	
Query	None		
Inbound Data	None		
Success Return	UserPermission		
PUT			
Description	It is used to set a particular user's permiss	sion	
Query	None		
Inbound Data	UserPermission		
Success Return	ResponseStatus		
Notes:			
<userid> links the</userid>	user permission to a user, see /ISAPI/Securit	ty/AAA/users/ID.	
<usertype> The type value of the user, which can be 'admin', 'operator' or 'viewer'. 'admin'</usertype>			
is the administrator	ne administrator of the IPMD, it have all permissions. 'operator' and 'viewer' have default		
permission policy.	The default permission policy can	be edited by prov	/iding
<localpermission>,</localpermission>	<remotepermission>.</remotepermission>		

### **UserPermission XML Block**

# 8.8.9/ISAPI/Security/UserPermission/<ID>/localPermission

/ISAPI/Security/UserPermission/ID/localPermission General Resource		v2.0
GET		
Description It is used to get a particular user's local permission		



Query	None
Inbound Data	None
Success Return	localPermission
PUT	
Description	It is used to set a particular user's local permission
Query	None
Inbound Data	localPermission
Success Return	ResponseStatus
Notes:	

#### **localPermission XML Block**

```
<localPermission version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <backup> <!-- opt, xs:boolean --> </backup>
  <record> <!-- opt, xs:boolean --> </record>
  <playBack> <!-- opt, xs:boolean --> </playBack>
  <videoChannelPermissionList> <!-- opt -->
    <videoChannelPermission> <!-- opt -->
      <id><!-- req, must correspond to the video input channel id --> </id>
      <playBack> <!-- opt, xs:boolean --> </playBack>
      <record> <!-- opt, xs:boolean --> </record>
      <backup> <!-- opt, xs:boolean --> </backup>
    </videoChannelPermission>
  </videoChannelPermissionList>
  <ptzControl> <!-- req, xs:boolean --> </ptzControl>
  <ptzChannelPermissionList> <!-- opt -->
    <ptzChannelPermission> <!-- req -->
      <id><!--req, must correspond to ptz id, see /ISAPI/PTZCtrl/channels/ID--> </id>
      <ptzControl> <!-- opt, xs:boolean --> </ptzControl>
    </ptzChannelPermission>
  </ptzChannelPermissionList>
  <logOrStateCheck> <!-- opt, xs:boolean --> </logOrStateCheck>
  <parameterConfig> <!--opt, xs:boolean --> </parameterConfig>
  <restartOrShutdown> <!--opt, xs:boolean --> </restartOrShutdown>
  <upgrade> <!--opt, xs:boolean --> </upgrade>
</localPermission>
```

# 8.8.10 /ISAPI/Security/UserPermission/<ID>/remot ePermission

/ISAPI/Security/UserPermission/ID/remotePermission

**General Resource** 



		v2.0
GET		
Description	It is used to get a particular user's remote permission	
Query	None	
Inbound Data	None	
Success Return	remotePermission	
PUT		
Description	It is used to set a particular user's remote permission	
Query	None	
Inbound Data	remotePermission	
Success Return	ResponseStatus	
Notes:		

#### remotePermission XML Block

```
<remotePermission version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <record> <!-- opt, xs:boolean --> </record>
 <playBack> <!-- opt, xs:boolean --> </playBack>
 <videoChannelPermissionList> <!-- opt -->
    <videoChannelPermission> <!-- opt -->
     <id><!-- req, must correspond to the video input channel id --> </id>
     <palyBack> <!-- opt, xs:boolean --> </palyBack>
     <record> <!--opt, xs:Boolean --> </record>
    </videoChannelPermission>
  </videoChannelPermissionList>
  <ptzControl> <!-- opt, xs:boolean --> </ptzControl>
 <ptzChannelPermissionList> <!-- opt -->
    <ptzChannelPermission> <!-- opt -->
     <id><!--req, must correspond to ptz id, see /ISAPI/PTZCtrl/channels/ID--> </id>
     <ptzControl> <!-- opt, xs:boolean --> </ptzControl>
    </ptzChannelPermission>
 </ptzChannelPermissionList>
 <logOrStateCheck> <!-- opt, xs:boolean --> </logOrStateCheck>
 <parameterConfig> <!--opt, xs:boolean --> </parameterConfig>
 <restartOrShutdown> <!--opt, xs:boolean --> </restartOrShutdown>
 <upgrade> <!--opt, xs:boolean --> </upgrade>
 <voiceTalk> <!--opt, xs:boolean --> </voiceTalk>
 <transParentChannel> <!--opt, xs:boolean --> <transParentChannel>
 <contorlLocalOut> <!-- opt, xs:boolean --> </contorlLocalOut>
  <alarmOutOrUpload> <!-- opt, xs:boolean --> </alarmOutOrUpload>
</remotePermission>
```



# 8.8.11 /ISAPI/Security/UserPermission/anonymou slogin

/ISAPI/Security/UserPermission/anonymouslogin		General Resource	
GET		v2.0	
Description	Access and configure the user's pe	ermission	
Query	None		
Inbound Data	None		
Success Return	anonymouslogin		
PUT			
Description	Access and configure the user's permission.		
Query	None		
Inbound Data	anonymouslogin		
Success Return	ResponseStatus		
Notes:			
Anonymouslogin owns corre	Anonymouslogin owns corresponding privilege of interfaces below:		
/ISAPI/Streaming/channels is used to get the resolution			
/ISAPI/Security/userCheck			
/ISAPI/System/Network/interfaces and /ISAPI/System/Network/UPnP/ports/status			
/ISAPI/Security/adminAcces	/ISAPI/Security/adminAccesses		

## anonymouslogin XML Block

# 8.8.12 /ISAPI/Security/UserPermission/operatorCa

p

/ISAPI/Security/UserPermission/operatorCap		General Resource	v2.0
GET			
Description	It is used to get default capabilities of	of operator.	
Query	None		
Inbound Data	None		
Success Return	UserPermissionCap		
Notes:			



### **UserPermissionCap XML Block**

## 8.8.13 /ISAPI/Security/UserPermission/viewerCap

/ISAPI/Security/UserPermission/viewerCap		General Resource	v2.0
GET			
Description	It is used to get default capabilities of vie	ewer.	
Query	None		
Inbound Data	None		
Success Return	UserPermissionCap		
Notes:			

# 8.8.14 /ISAPI/Security/deviceCertificate

/ISAPI/Security/de	eviceCertificate Ge	neral Resource	v2.0
GET			
Description	This function is used to upload a user certificate to the device. The user certificate is used for 802.1x (radius) with various authentication mechanisms.		e user
Query	None		
Inbound Data	None		
Success Return	Data		
PUT			
Description	This function is used to upload a user certificate certificate is used for 802.1x (radius) with various authentication me		e user
Query	None		
Inbound Data	Data		
Success Return	ResponseStatus		
Notes:			



The format of the certificate is device-dependent.

Distinguish different certificate by Content-type:

CA- certificate (root certificate): application/x-x509-ca-cert

Clent certificate: application/x-x509-client-cert Clent password : application/x-x509-client-key

## 8.9 /ISAPI/Streaming

/ISAPI/Streaming	Service v2.0
Notes:	

# 8.9.1/ISAPI/Streaming/status

/ISAPI/Streaming/status		General Resource	v2.0
GET			
Description	It is used to get a device streaming status	S.	
Query	None		
Inbound Data	None		
Success Return	StreamingStatus		
Notes:			
This command accesses the status of all device streaming sessions.			

### StreamingStatus XML Block

## 8.9.2/ISAPI/Streaming/channels

/ISAPI/Streaming	channels General Resource v2.0
GET	
Description	It is used to get the properties of streaming channels for the device.
Query	None
Inbound Data	None
Success Return	StreamingChannelList
PUT	



Description	It is used to update the properties of streaming channels for the	
	device.	
Query	None	
Inbound Data	StreamingChannelList	
Success Return	ResponseStatus	
POST		
Description	It is used to add a streaming channel for the device.	
Query	None	
Inbound Data	StreamingChannel	
Success Return	ResponseStatus	
DELETE		
Description	It is used to delete the list of streaming channels for the device.	
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	
Notes:		

Notes:

Streaming channels may be hardwired, or it may be possible to create multiple streaming channels per input if the device supports it. To determine whether it is possible to dynamically create streaming channels, check the defined HTTP methods in /ISAPI/Streaming/channels/description.

### StreamingChannelList XML Block

# 8.9.3/ISAPI/Streaming/channels/<ID>

/ISAPI/Streaming	/channels/ID General Resource v2.0	
GET		
Description	It is used to get the properties of a particular streaming channel for the device.	
Query	None	
Inbound Data	None	
Success Return	StreamingChannel	
PUT		
Description	It is used to update the properties of a particular streaming channel for the device.	



Query	None	
Inbound Data	StreamingChannel	
Success Return	ResponseStatus	
DELETE		
Description	It is used to delete a particular streaming channel for the device.	
Query	None	
Inbound Data	None	
Success Return	ResponseStatus	

#### Notes:

To support multi video input devices , the streaming ID in URL should be indicate video input channel number , so it is defined as : straming-ld + video-input-ld \*100, for example : /Streaming/channels/101 indicates the first streaming from the first video input /Streaming/channels/202 indicates the second streaming from the second video input

For IPC, becourse of only one video input, case is simeple, it can accecpt 1 as the main stream id, 2 as the sub-stream.

- <ControlProtocolList> identifies the control protocols that are valid for this type of streaming.
- <Unicast> is for direct unicast streaming.
- <Multicast> is for direct multicast streaming.
- <videoSourcePortNo> and <audioSourcePortNo> are the source port numbers for the outbound video or audio streams.
- <videoInputChanneIID> refers to /ISAPI/System/Video/inputs/channel/ID.
- <audioInputChannelID> refers to /ISAPI/System/Audio/channels/ID. It must be configured as an input channel.

Use of IPv4 or IPv6 addresses depends on the value of the <ipVersion> field in /ISAPI/System/Network/interfaces/ID/ipAddress.

- <Security> determines whether SRTP is used for stream encryption.
- <audioResolution> is the resolution for the outbound audio stream in bits.

### StreamingChannel XML Block



```
<audioSourcePortNo><!-- opt, xs:integer --> </audioSourcePortNo>
  <ControlProtocolList> <!-- req -->
    <ControlProtocol>
      <!-- req -->
      <streamingTransport>
        <!-- req, xs:string, "HTTP,RTSP,SHTTP" -->
      </streamingTransport>
    </ControlProtocol>
  </ControlProtocolList>
  <Unicast><!-- opt -->
    <enabled> <!-- req, xs:boolean --> </enabled>
    <interfaceID> <!-- opt, xs:string --> </interfaceID>
    <rtpTransportType>
      <!-- opt, xs:string, "RTP/UDP,RTP/TCP" -->
    </rtpTransportType>
  </Unicast>
  <Multicast> <!-- opt -->
    <enabled> <!-- req, xs:boolean -->
                                         </enabled>
    <userTriggerThreshold> <!-- opt, xs:integer --> </userTriggerThreshold>
    <destlPAddress> <!-- dep, xs:string --> </destlPAddress>
    <videoDestPortNo><!-- opt, xs:integer --></videoDestPortNo>
    <audioDestPortNo><!-- opt, xs:integer --></audioDestPortNo>
    <destlPv6Address><!-- dep, xs:string --></destlPv6Address>
    <ttl><!-- opt, xs:integer --></ttl>
  </Multicast>
  <Security>
    <!-- opt -->
    <enabled><!-- req, xs:boolean --></enabled>
  </Security>
</Transport>
<Video>
  <!-- opt -->
  <enabled><!-- req, xs:boolean --></enabled>
  <videoInputChannelID> <!-- req, xs:string;id --> </videoInputChannelID>
  <videoCodecType>
    <!-- req, xs:string, "MPEG4,MJPEG,3GP,H.264,HK.264,MPNG" -->
  </videoCodecType>
  <videoScanType>
    <!-- opt, xs:string, "progressive,interlaced" -->
  </videoScanType>
  <videoResolutionWidth> <!-- req, xs:integer --> </videoResolutionWidth>
  <videoResolutionHeight> <!-- req, xs:integer --> </videoResolutionHeight>
  <videoPositionX> <!-- opt, xs:integer --> </videoPositionX>
```



```
<videoPositionY> <!-- opt, xs:integer --> </videoPositionY>
    <videoQualityControlType>
      <!-- opt, xs:string, "CBR,VBR" -->
    </videoQualityControlType>
    <constantBitRate> <!-- dep, xs:integer, in kbps -->
                                                      </constantBitRate>
    <fixedQuality> <!-- opt, xs:integer, percentage, 0..100 -->
                                                               </fixedQuality>
    <vbrUpperCap> <!-- dep, xs:integer, in kbps --> </vbrUpperCap>
    <vbrLowerCap> <!-- dep, xs:integer, in kbps --> </vbrLowerCap>
    <maxFrameRate>
                        <!-- req, xs:integer, maximum frame rate x100 -->
    </maxFrameRate>
    <keyFrameInterval> <!-- opt, xs:integer, milliseconds --> </keyFrameInterval>
    <rotationDegree> <!-- opt, xs:integer, degrees, 0..360 --></rotationDegree>
    <mirrorEnabled> <!-- opt, xs:boolean --> </mirrorEnabled>
    <snapShotImageType>
      <!-- opt, xs:string, "JPEG,GIF,PNG" -->
    </snapShotImageType>
    <Mpeg4Profile> <!--dep, xs:string, "SP,ASP"--> </Mpeg4Profile>
    <H264Profile>
      <!-- dep, xs:string, "Baseline, Main, High, Extended" -->
    </H264Profile>
    <GovLength> <!--opt, xs:integer --> </GovLength>
    <SVC>
     <enabled> <!-- req, xs:boolean --> </enabled>
    <SVC>
  </Video>
  <Audio>
    <!-- opt -->
    <enabled> <!-- req, xs:boolean -->
                                          </enabled>
    <audioInputChannelID> <!-- req, xs:string;id --> </audioInputChannelID>
    <audioCompressionType>
      <!-- req, xs:string,
       " G.711alaw,G.711ulaw,G.726,G.729,G.729a,G.729b,PCM,MP3,AC3,AAC,ADPC
M, MP2L2"
      -->
    </audioCompressionType>
    <audioInboundCompressionType>
      <!-- opt, xs:string,
      "G.711alaw,G.711ulaw,G.726,G.729,G.729a,G.729b,PCM,MP3,AC3,AAC,ADPCM,
MP2L2"
      -->
    </audioInboundCompressionType>
    <audioBitRate> <!-- opt, xs:integer, in kbps --> </audioBitRate>
    <audioSamplingRate><!-- opt, xs:float, in kHz --> </audioSamplingRate>
```



```
<audioResolution> <!-- opt, xs:integer, in bits --> </audioResolution>
</Audio>
<enableCABAC> <!-- opt, xs: boolean --> <enableCABAC>
<subStreamRecStatus> <!-- opt, xs: boolean --> </subStreamRecStatus>
</streamingChannel>
```

### **Example: Getting Streaming Channel Properties**

The following is an example of a GET on the streaming parameters of a particular channel that has been preconfigured by the IP media device. Depending on the device, some streaming channels may be already preconfigured or the device while other may require that channels be manually configured before use.

```
GET /ISAPI/Streaming/channels/444 HTTP/1.1
HTTP/1.1 200 OK
Content-Type: application/xml; charset="UTF-8"
Content-Length: ISAPI
<?xml version="1.0" encoding="UTF-8"?>
<StreamingChannel version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id>444</id>
  <channelName>Input 1 MPEG-4 ASP</channelName>
  <enabled>true</enabled>
  <Transport>
    <rtspPortNo>554</rtspPortNo>
    <maxPacketSize>1446</maxPacketSize>
    <ControlProtocolList>
    <ControlProtocol>
      <streamingTransport>RTSP</streamingTransport>
    </ControlProtocol>
    <ControlProtocol>
      <streamingTransport>HTTP</streamingTransport>
    </ControlProtocol>
  </Transport>
  <Video>
    <enabled>true</enabled>
    <videoInputChannelID>2</videoInputChannelID>
    <videoCodecType>MPEG4</videoCodecType>
    <videoScanType>progressive</videoScanType>
    <videoResolutionWidth> 640</videoResolutionWidth>
    <videoResolutionHeight>480</videoResolutionHeight>
    <videoPositionX>0</videoPositionX>
    <videoPositionY>0</videoPositionY>
```



```
<videoQualityControlType>CBR</videoQualityControlType>
   <constantBitRate>2000</constantBitRate>
    <maxFrameRate>2500</maxFrameRate>
   <keyFrameInterval>1000</keyFrameInterval>
   <rotationDegree>0</rotationDegree>
   <mirrorEnabled>false</mirrorEnabled>
   <snapShotImageType>JPEG</snapShotImageType>
 </Video>
 <Audio>
   <enabled>false</enabled>
   <audioInputChannelID>2</audioInputChannelID>
   <audioCompressionType> G.726</audioCompressionType>
   <audioBitRate>24</audioBitRate>
   <audioSamplingRate>8</audioSamplingRate>
 </Audio>
</StreamingChannel>
```

#### **Example: Getting Streaming Capabilities**

```
GET /ISAPI/Streaming/channels/444/capabilities HTTP/1.1
HTTP/1.1 200 OK
Content-Type: application/xml; charset="UTF-8"
Content-Length: ISAPI
<?xml version="1.0" encoding="UTF-8"?>
<StreamingChannel version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id opt="111,222,333,444">444</id>
  <channelName min="0" max="64">Input 1 MPEG-4 ASP</channelName>
  <enabled opt="true,false" def="true">true</enabled>
  <Transport>
    <rtspPortNo min="0" max="65535" def="554">554</rtspPortNo>
    <maxPacketSize min="0" max="1500">1446</maxPacketSize>
    <audioPacketLength min="0" max="5000"/>
    <audioInboundPacketLength min="0" max="5000"/>
    <audioInboundPortNo min="0" max="65535"/>
    <videoSourcePortNo min="0" max="65535"/>
    <audioSourcePortNo min="0" max="65535"/>
    <ControlProtocolList>
      <ControlProtocol>
        <streamingTransport opt="RTSP/RTP,HTTP">RTSP</streamingTransport>
      </ControlProtocol>
      <ControlProtocol>
```



```
<streamingTransport opt="RTSP/RTP,HTTP">HTTP</streamingTransport>
      </ControlProtocol>
    </ControlProtocolList>
    <Unicast>
      <enabled opt="true,false" def="false"/>
      <rtpTransportType opt="RTP/UDP,RTP/TCP"/>
    </Unicast>
    <Multicast>
      <enabled opt="true,false" def="false"/>
      <userTriggerThreshold/>
      <videoDestPortNo min="0" max="65535"/>
      <audioDestPortNo min="0" max="65535"/>
      <destIPAddress min="8" max="16"/>
      <destIPv6Address min="15" max="39"/>
      <ttl min="0" max="127" def="1"/>
    </Multicast>
    <Security>
      <enabled opt="true,false" def="false"/>
    </Security>
  </Transport>
  <Video>
    <enabled opt="true,false">true</enabled>
    <videoInputChannelID opt="1,2,3,4">2</videoInputChannelID>
    <videoCodecType opt="MJPEG,MPEG4">MPEG4</videoCodecType>
    <videoScanType opt="interlaced,progressive">progressive</videoScanType>
    <videoResolutionWidth min="0" max="640">640</videoResolutionWidth>
    <videoResolutionHeight min="0" max="480">480</videoResolutionHeight>
    <videoPositionX min="0" max="640">0</videoPositionX>
    <videoPositionY min="0" max="480">0</videoPositionY>
    <videoQualityControlType opt="CBR,VBR">CBR</videoQualityControlType>
    <constantBitRate min="50" max="4000" dynamic="true">2000</constantBitRate>
    <maxFrameRate
                                                    opt="2500,1250,625,312,156,78"
dynamic="true">2500</maxFrameRate>
    <keyFrameInterval min="0", max="10000">1000</keyFrameInterval>
    <rotationDegree opt="0,90,180,270" def="0">0</rotationDegree>
    <mirrorEnabled opt="true,false" def="false">false
    <snapShotImageType opt="JPEG" def="JPEG">JPEG</snapShotImageType>
  </Video>
  <Audio>
    <enabled opt="true,false" def="false">false</enabled>
    <audioInputChannelID opt="1,2,3,4">2</audioInputChannelID>
    <audioCompressionType
                                                             opt="G.726,G.711ulaw"
def="G.726">G.726</audioCompressionType>
```



```
<audioBitRate opt="16,24,32,40" def="32" dynamic="true">24</audioBitRate>
<audioSamplingRate opt="8" dynamic="true">8</audioSamplingRate>
<audioResolution opt="3,4,5,6" dynamic="true"/>
</Audio>
</StreamingChannel>
```

## 8.9.4/ISAPI/Streaming/channels/<ID>/dynamicCap

/ISAPI/Streaming	/channels/ <i>ID</i> /dynamicCap	General Resource v2.0
GET		
Description	Get dynamic capabilities, different rates; different audio compression	
Query	None	
Inbound Data	None	
Success Return	DynamicCap	
Notes:		

### DynamicCap XML Block

```
<DynamicCap version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <ResolutionAvailableDscriptorList>
    <ResolutionAvailableDscriptor>
      <videoResolutionWidth> <!-- req, xs:integer --> </videoResolutionWidth>
      <videoResolutionHeight> <!-- req, xs:integer --> </videoResolutionHeight>
      <supportedFrameRate> <!-- req, xs:string --> </supportedFrameRate>
    </ResolutionAvailableDscriptor>
  </ResolutionAvailableDscriptorList>
  <AudioDscriptorList>
      <audioCompressionType>
        <!-- req, xs:string,
         " G.711alaw,G.711ulaw,G.726,G.729,G.729a,G.729b,PCM,MP3,AC3,AAC,ADP
CM, MP2L2"-->
      </audioCompressionType>
  </AudioDscriptorList>
</DynamicCap>
```

## **Example: Getting the Dynamic Capabilities**

```
GET /ISAPI/Streaming/Channels/101/dynamicCap HTTP/1.1
...
HTTP/1.1 200 OK
Content-Type: application/xml; charset="UTF-8"
```



```
Content-Length: xxx
<?xml version="1.0" encoding="UTF-8"?>
<DynamicCap version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <ResolutionAvailableDscriptorList>
    <ResolutionAvailableDscriptor>
      <videoResolutionWidth>176</videoResolutionWidth>
      <videoResolutionHeight>144</videoResolutionHeight>
      <supportedFrameRate>2500,6,12,25,50,100,200,400,600,800,1000,1200,1500,16
00,1800,2000,2200</supportedFrameRate>
    </ResolutionAvailableDscriptor>
    <ResolutionAvailableDscriptor>
      <videoResolutionWidth>352</videoResolutionWidth>
      <videoResolutionHeight>288</videoResolutionHeight>
      <supportedFrameRate>2500,6,12,25,50,100,200,400,600,800,1000,1200,1500,16
00,1800,2000,2200</supportedFrameRate>
    </ResolutionAvailableDscriptor>
    <ResolutionAvailableDscriptor>
      <videoResolutionWidth>704</videoResolutionWidth>
      <videoResolutionHeight>576</videoResolutionHeight>
      <supportedFrameRate>2500,6,12,25,50,100,200,400,600,800,1000,1200,1500,16
00,1800,2000,2200</supportedFrameRate>
    </ResolutionAvailableDscriptor>
  </ResolutionAvailableDscriptorList>
  <AudioDscriptorList>
    <audioCompressionType
SupportedAudioBitRate="32,64,128">MP2L2</audioCompressionType>
  </AudioDscriptorList>
</DynamicCap>
```

## 8.9.5/ISAPI/Streaming/channels/<ID>/status

/ISAPI/Streaming/channels/ID/status		General Resource v2.0
GET		
Description	It is used to get the list of streaming particular channel.	sessions associated with a
Query	None	
Inbound Data	None	
Success Return	StreamingSessionStatusList	
Notes:		



### StreamingSessionStatusList XML Block

```
<StreamingSessionStatusList version="2.0"

xmIns="http://www.isapi.org/ver20/XMLSchema">

<StreamingSessionStatus>

<clientAddress> <!-- req -->

<ipAddress> <!-- req, xs:string --> </ipAddress>

</clientAddress>

</StreamingSessionStatus>
</StreamingSessionStatusList>
```

## 8.9.6/ISAPI/Streaming/channels/<ID>/picture

/ISAPI/Streaming/channels/ID/picture		General Resource	v2.0
GET			
Description	It is used to get a snapshot of the current	image.	
	videoResolutionWidth		
Query	videoResolutionHeight		
	snapShotImageType		
Inbound Data	None		
Success Return	Picture over HTTP		

#### Notes:

All devices must support <snapShotImageType> of "JPEG".

Only support the main stream channel snapshot.

To determine the format of the picture returned either the parameters in <Video> or the query string values are used, or, if the Accept: header field is present in the request and the server supports it, the picture is returned in that format.

For supported values, query /Streaming/channels/ID/picture/capabilities.

### Examples:

GET /ISAPI/Streaming/channels/101/picture?snapShotImageType=JPEG

. . .

GET /ISAPI/Streaming/channels/101/picture

Accept: image/jpeg

. . .



# 8.9.7/ISAPI/Streaming/channels/<ID>/requestKeyF rame

/ISAPI/Streaming/channels/ID/requestKeyFrame General Resource v2		2.0	
PUT		Operat	or
Description	It is used to request that the device issue	a key frame on a particu	ılar
Description	channel.		
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		
Notes:			
The key frame that is issued should include everything necessary to initialize a video		leo	
decoder, i.e. parameter sets for H.264 or VOS for MPEG-4.			

## 8.10 /ISAPI/Snapshot

/ISAPI/Snapshot	Service v2.0
Notes: snapshot service	

## 8.10.1 /ISAPI/Snapshot/channels

/ISAPI/Snapshot/channels General Resource v2	
GET	
Description	It is used to get the properties of snapshot channels for the device.
Query	None
Inbound Data	None
Success Return	SnapshotChannelList
PUT	
Description	It is used to update the properties of snapshot channels for the
Description	device.
Query	None
Inbound Data	SnapshotChannelList
Success Return	ResponseStatus
Notes:	

## SnapshotChannelList XML Block

<SnapshotChannelList version="2.0"



## 8.10.2 /ISAPI/Snapshot/channels/<ID>

/ISAPI/Snapshot/channel/ID General Resource v2		
GET		
Description	It is used to get the properties of a particular snapshot channel.	
Query	None	
Inbound Data	None	
Success Return	SnapshotChannel	
PUT		
Description	It is used to update the properties of a particular snapshot channel.	
Query	None	
Inbound Data	SnapshotChannel	
Success Return	ResponseStatus	
Notes:		

### **SnapshotChannel XML Block**

```
<SnapshotChannel version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id><!-- req, xs:string;id --> </id>
  <videoInputChannelID> <!-- req, xs:string;id --> </videoInputChannelID>
  <timingCapture> <!-- opt -->
    <enabled> <!-- req, xs:boolean --> </enabled>
    <supportSchedule> <!-- opt, ro, xs:boolean> </supportSchedule>
    <compress>
      <pictureCodecType>
         <!-- req, xs:string, "JPEG,BMP,GIF,PNG" -->
      </pictureCodecType>
      <pictureWidth> <!-- req, xs:integer --> </pictureWidth>
      <pictureHeight> <!-- req, xs:integer --> </pictureHeight>
      <quality> <!-- opt, xs:integer, percentage, 0..100 --> </quality>
      <captureInterval> <!-- opt, xs:integer, milliseconds --> </captureInterval>
    <compress>
  </timingCapture>
  <eventCapture> <!-- opt -->
                   <!-- reg, xs:boolean --> </enabled>
    <supportSchedule> <!-- opt, ro, xs:boolean> </supportSchedule>
    <compress>
      <pictureCodecType>
```



## 8.11 /ISAPI/Event

/ISAPI/Event	Service v2.0
GET	Viewer
Description	It is used to get the configuration of the device event behavior, scheduling and notifications.
Query	None
Inbound Data	None
Success Return	EventNotification
PUT	Operator
Description	It is used to udpate the configuration of the device event behavior, scheduling and notifications.
Query	None
Inbound Data	EventNotification
Success Return	ResponseStatus
Notes:	

#### **EventNotification XML Block**

The event notification methods define what types of notification (e-mail) are supported.

The event trigger list defines the set of device behaviors that trigger events.

The event schedule defines when event notifications are active.

## 8.11.1 /ISAPI/Event/capabilities

/ISAPI/Event/capabilities	General Resource	v2.0



GET	
Description	It is used to get network capability.
Query	None
Inbound Data	None
Success Return	< EventCap>
Notes:	

## **EventCap XML Block**

## 8.11.2 /ISAPI/Event/triggers

/ISAPI/Event/triggers General Resource vi		v2.0	
GET			
Description	It is used to get the list of event triggers.		
Query	None		
Inbound Data	None		
Success Return	EventTriggerList		
PUT			
Description	It is used to update the list of event trigger	S.	
Query	None		
Inbound Data	EventTriggerList		
Success Return	ResponseStatus		
POST			
Description	It is used to add an event trigger.		
Query	None		
Inbound Data	EventTrigger		
Success Return	ResponseStatus		



DELETE	
Description	It is used to delete the list of event triggers.
Query	None
Inbound Data	None
Success Return	ResponseStatus
Matan	

Notes:

Event triggering defines how the device reacts to particular events, such as video loss or motion detection.

## **EventTriggerList XML Block**

## 8.11.3 /ISAPI/Event/triggers/<ID>

/ISAPI/Event/trigg	ers/ <i>ID</i>	General Resource	v2.0
GET			
Description	It is used to get a particular event trigger	configuration.	
Query	None		
Inbound Data	None		
Success Return	EventTrigger		
PUT			
Description	It is used to update a particular event trigg	ger configuration.	
Query	None		
Inbound Data	EventTrigger		
Success Return	ResponseStatus		
DELETE			
Description	It is used to delete a particular event trigg	er.	
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		
Notes:			

An event trigger determines how the device reacts when a particular event is detected. The following types are supported:

IO: trigger when an input IO port changes state.

VMD: trigger on video motion detection.

Video loss: trigger when the input video signal cannot be detected.



Disk failure: trigger when a disk fails.

Recording failure: trigger when recording fails: either there is a problem with the disk, or

the storage volume is full, or the volume is corrupt.

Bad video: trigger when the input video is bad.

POS: trigger when a point-of-sale event is detected.

Analytics: trigger on a general analytics event. Currently analytics events apart from VMD, which has its own event trigger, are not supported. Fan failure: trigger when a fan

fails.

Nicbroken: trigger when net interface is broken.

Resolution mismatch: trigger when video input port resolution is not matched up to compress resolution.

The ID in "/Event/triggers/ID" is defined as following declaration:

If the event type is IO, the ID is IO-InputPortNumber.

Examples:

IO-1 :the first IO input port

If the event type is VMD, videoloss or tamperdetection, the ID style is VMD/videoloss/tamper-InputChanneIID.

Examples:

If video input channel id is "video1", the id is as follows:

VMD-1: Video Motion Detection of video input channel "video1".

videoloss-1: Video Loss Detection of video input channel "video1".

tamper-1: Tamper Detection of video input channel "video1".

### **EventTrigger XML Block**



```
<EventTrigger version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id> <!-- req, xs:string;id --> </id>
  <eventType>
     <!-- req, xs:string,
        "IO,VMD,videoloss,raidfailure,recordingfailure,
        badvideo, POS, analytics, fanfailure, overheat, tamperdetection, diskfull, diskerror,
                       ipconflict,
        nicbroken,
                                                 videomismatch,
                                                                    resolutionmismatch,
                                    illaccess.
        radifailure, PIR, WLSensor"
   </eventType>
   <eventDescription><!-- opt, xs:string --></eventDescription>
   <inputIOPortID> <!-- dep, xs:string; id --> </inputIOPortID>
   <dynInputIOPortID> <!-- dep, xs:string; id --> </dynInputPortID>
   <videoInputChannelID> <!-- dep, xs:string; id --> </videoInputChannelID>
   <dynVideoInputChannelID> <!-- dep, xs:string; id --> </dynVideoInputChannelID>
   <intervalBetweenEvents> <!-- opt, xs:integer, seconds --></intervalBetweenEvents>
   <WLSensorID> <!-- dep, xs:string; id --> </WLSensorID>
   <EventTriggerNotificationList/> <!-- opt -->
</EventTrigger>
```

## 8.11.4 /ISAPI/Event/triggers/<ID>/notifications

/ISAPI/Event/trigg	ers/ <i>ID</i> /notifications	General Resource	v2.0
GET			
Description	It is used to get the list of notification me event trigger.	ethods and behaviors for	or an
Query	None		
Inbound Data	None		
Success Return	EventTriggerNotificationList		
PUT			
Description	It is used to update the list of notification an event trigger.	n methods and behavio	rs for
Query	None		
Inbound Data	EventTriggerNotificationList		
Success Return	ResponseStatus		
DELETE			
Description	It is used to delete the list of notification event trigger.	method and behavior for	or an
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		



```
Notes:

ptz: PTZ action

record: recording

monitorAlarm: monitor alarm

center:send alarm to center

LightAudioAlarm: light blink and sound the alarm

<outputIOPortID> or <dynOutputIOPortID> is only required if the <notificationMethod> is

"IO".

<videoInputID> or <dynVideoInputID> is only required if the <notificationMethod> is

"record"。

<ptzAction> is only required if the <notificationMethod> is "ptz";
```

#### **EventTriggerNotificationList XML Block**

## **EventTriggerNotification XML Block**

```
<EventTriggerNotification> <!-- opt -->
  <id> <!-- req, xs:string;id --> </id>
  <notificationMethod>
    <!-- req, xs:string, "email,IM,IO,syslog,HTTP,FTP,beep, ptz, record
    monitorAlarm, center, LightAudioAlarm ..." -->
  </notificationMethod>
  <notificationRecurrence>
    <!-- opt, xs:string, "beginning,beginningandend,recurring" -->
  </notificationRecurrence>
  <notificationInterval> <!-- dep, xs:integer, milliseconds --> </notificationInterval>
  <outputIOPortID> <!-- dep, xs:string;id --> </outputIOPortID>
  <dynOutputIOPortID> <!-- dep, xs:string;id --> </dynOutputIOPortID>
  <videoInputID> <!-- dep, xs:string;id --> </videoInputID>
  <dynVideoInputID> <!-- dep, xs:string;id --> </dynVideoInputID>
  <ptzAction> <!-- dep -->
    <ptzChannelID> <!--req, xs:string; id --> </ptzChannelID>
    <actionName> <!-- req, xs:string, "preset, pattern, patrol" --> </actionName>
    <actionNum> <!-- dep, xs:integer> </actionNum>
  </ptzAction>
</EventTriggerNotification>
```



## 8.11.5 /ISAPI/Event/schedules

/ISAPI/Event/schedules	General Resource v2.0	
Notes:		

## 8.11.6 /ISAPI/Event/schedules/inputs

/ISAPI/Event/schedules/inputs		General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	InputScheduleList		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	InputScheduleList		
Success Return	ResponseStatus		
Notes:			

## InputScheduleList XML Block

# 8.11.7 /ISAPI/Event/schedules/inputs/<ID>

/ISAPI/Event/sche	dules/inputs/ID	General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	Schedule		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	Schedule		
Success Return	ResponseStatus		

©2009 – 2014 by HIKVISION. All rights reserved.



Notes:

## 8.11.8 /ISAPI/Event/schedules/outputs

/ISAPI/Event/sch	edules/outputs	General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	OutputScheduleList		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	OutputScheduleList		
Success Return	ResponseStatus		
Notes:			

## OutputScheduleList XML Block

< OutputScheduleList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> < Schedule/> <!-- opt -->

</OutputScheduleList>

# 8.11.9 /ISAPI/Event/schedules/outputs/<ID>

/ISAPI/Event/sche	dules/outputs/ID	General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	Schedule		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	Schedule		
Success Return	ResponseStatus		
Notes:			



## 8.11.10 /ISAPI/Event/schedules/motionDetection

S

/ISAPI/Event/schedules/motionDetections		General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	MotionDetectionScheduleList		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	MotionDetectionScheduleList		
Success Return	ResponseStatus		
Notes:			

#### MotionDetectionScheduleList XML Block

# 8.11.11 /ISAPI/Event/schedules/motionDetection s/<ID>

/ISAPI/Event/sche	dule/motionDetections/ID	General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	Schedule		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	Schedule		
Success Return	ResponseStatus		
Notes:			



# 8.11.12 /ISAPI/Event/schedules/tamperDetection

S

/ISAPI/Event/sche	dules/tamperDetections	General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	TamperDetectionScheduleList		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	TamperDetectionScheduleList		
Success Return	ResponseStatus		
Notes:			

## TamperDetectionScheduleList XML Block

<TamperDetectionScheduleList version="2.0"
xmIns="http://www.isapi.org/ver20/XMLSchema">
< Schedule/> <!-- opt -->
</ TamperDetectionScheduleList>

# 8.11.13 /ISAPI/Event/schedules/tamperDetection s/<ID>

/ISAPI/Event/sche	dule/tamperDetections/ID	General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	Schedule		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	Schedule		
Success Return	ResponseStatus		
Notes:			



## 8.11.14 /ISAPI/Event/schedules/videolosses

/ISAPI/Event/sche	dules/videolosses	General Resource	v2.0
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	videolossScheduleList		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	videolossScheduleList		
Success Return	ResponseStatus		
Notes:			

## videolossScheduleList XML Block

## 8.11.15 /ISAPI/Event/schedules/videolosses/<ID

>

/ISAPI/Event/schedule/videolosses/ID General Resource v		v2.0	
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	Schedule		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	Schedule		
Success Return	ResponseStatus		
Notes:			

#### **Schedule XML Block**

<Schedule version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <id> <!-- req, xs:string; id --> </id>



```
<inputIOPortID>
                       <!-- ro, dep, xs:string; id -->
                                                         </inputIOPortID>
 <outputIOPortID>
                        <!-- ro, dep, xs:string; id -->
                                                           </inputIOPortID>
 <videoInputChannelID><!-- ro, dep, xs:string; id --></videoInputChannelID>
 <TimeBlockList> <!-- req -->
    <TimeBlock>
      <dayOfWeek>
        <!-- opt, xs:integer, ISO8601 weekday number, 1=Monday, ... -->
      </dayOfWeek>
      <TimeRange>
                         <!-- req -->
        <br/><beginTime> <!-- req, xs:time, ISO8601 time --> </beginTime>
        <endTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
      </TimeRange>
   </TimeBlock>
 </TimeBlockList>
 <HolidayBlockList> <!-- opt -->
    <TimeBlock>
      <TimeRange>
                         <!-- req -->
        <beginTime> <!-- req, xs:time, ISO8601 time --> </beginTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
        <endTime>
      </TimeRange>
   </TimeBlock>
 </HolidayBlockList>
</Schedule>
```

## 8.11.16 /ISAPI/Event/schedules/PIR

/ISAPI/Event/schedule/PIRs/ID General Resource v		v2.0	
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	Schedule		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	Schedule		
Success Return	ResponseStatus		
Notes:			

#### **Schedule XML Block**



```
<Schedule version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id> <!-- req, xs:string; id --> </id>
                      <!-- ro, dep, xs:string; id -->
 <inputIOPortID>
                                                        </inputIOPortID>
                       <!-- ro, dep, xs:string; id -->
 <outputIOPortID>
                                                          </inputIOPortID>
 <videoInputChannelID><!-- ro, dep, xs:string; id --></videoInputChannelID>
 <TimeBlockList> <!-- req -->
    <TimeBlock>
      <dayOfWeek>
        <!-- opt, xs:integer, ISO8601 weekday number, 1=Monday, ... -->
      </dayOfWeek>
      <TimeRange>
                       <!-- req -->
        <beginTime> <!-- req, xs:time, ISO8601 time --> </beginTime>
        <endTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
      </TimeRange>
  </TimeBlock>
 </TimeBlockList>
 <HolidayBlockList> <!-- opt -->
    <TimeBlock>
      <TimeRange>
                       <!-- req -->
        <br/><beginTime> <!-- req, xs:time, ISO8601 time --> </beginTime>
        <endTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
      </TimeRange>
  </TimeBlock>
 </HolidayBlockList>
</Schedule>
```

## 8.11.17 /ISAPI/Event/schedules/fieldDetections

/ISAPI/Event/schedules/fieldDetections General Resource		v2.0	
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	FieldDetectionScheduleList		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	FieldDetectionScheduleList		
Success Return	ResponseStatus		
Notes:			



#### FieldDetectionScheduleList XML Block

## 8.11.18 /ISAPI/Event/schedules/fieldDetections/<

## ID>

/ISAPI/Event/schedule/fieldDetections/ID General Resource		v2.0	
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	Schedule		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	Schedule		
Success Return	ResponseStatus		
Notes:			

#### **Schedule XML Block**

```
<Schedule version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id> <!-- req, xs:string; id --> </id>
  <inputlOPortID>
                      <!-- ro, dep, xs:string; id -->
                                                         </inputIOPortID>
  <outputIOPortID> <!-- ro, dep, xs:string; id -->
                                                           </inputIOPortID>
 <videoInputChannelID><!-- ro, dep, xs:string; id --></videoInputChannelID>
 <TimeBlockList> <!-- req -->
    <TimeBlock>
      <dayOfWeek>
        <!-- opt, xs:integer, ISO8601 weekday number, 1=Monday, ... -->
      </dayOfWeek>
      <TimeRange>
                         <!-- req -->
        <br/>beginTime>
                       <!-- req, xs:time, ISO8601 time --> </beginTime>
        <endTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
      </TimeRange>
   </TimeBlock>
 </TimeBlockList>
```



# 8.11.19 /ISAPI/Event/schedules/sceneChangeDe tections

/ISAPI/Event/schedules/sceneChangeDetections General Resource		v2.0	
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	SceneChangeDetectionScheduleList		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	SceneChangeDetectionScheduleList		
Success Return	ResponseStatus		
Notes:			

### SceneChangeDetectionScheduleList XML Block

# 8.11.20 /ISAPI/Event/schedules/sceneChangeDe tections/<ID>

/ISAPI/Event/schedule/sceneChangeDetections/ID General Resource		v2.0	
GET			
Description	It is used to get trigger schedule.		



Query	None
Inbound Data	None
Success Return	Schedule
PUT	
Description	It is used to update trigger schedule.
Query	None
Inbound Data	Schedule
Success Return	ResponseStatus
Notes:	

### **Schedule XML Block**

```
<Schedule version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id> <!-- req, xs:string; id --> </id>
 <inputIOPortID>
                       <!-- ro, dep, xs:string; id --> </inputIOPortID>
                       <!-- ro, dep, xs:string; id -->
 <outputIOPortID>
                                                           </inputIOPortID>
 <videoInputChannelID><!-- ro, dep, xs:string; id --></videoInputChannelID>
 <TimeBlockList> <!-- req -->
    <TimeBlock>
      <dayOfWeek>
        <!-- opt, xs:integer, ISO8601 weekday number, 1=Monday, ... -->
      </dayOfWeek>
      <TimeRange>
                       <!-- req -->
        <br/>beginTime>
                      <!-- reg, xs:time, ISO8601 time --> </beginTime>
        <endTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
      </TimeRange>
  </TimeBlock>
 </TimeBlockList>
 <HolidayBlockList> <!-- opt -->
    <TimeBlock>
      <TimeRange>
                       <!-- req -->
        <beginTime> <!-- req, xs:time, ISO8601 time --> </beginTime>
        <endTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
      </TimeRange>
  </TimeBlock>
 </HolidayBlockList>
</Schedule>
```

## 8.11.21 /ISAPI/Event/schedules/audioDetections

/ISAPI/Event/schedules/audioDetections

General Resource v2.0



GET		
Description	It is used to get trigger schedule.	
Query	None	
Inbound Data	None	
Success Return	AudioDetectionScheduleList	
PUT	PUT	
Description	It is used to update trigger schedule.	
Query	None	
Inbound Data	AudioDetectionScheduleList	
Success Return	ResponseStatus	
Notes:		

### AudioDetectionScheduleList XML Block

# 8.11.22 /ISAPI/Event/schedules/audioDetections /<ID>

/ISAPI/Event/schedule/audioDetections/ID General Resource		v2.0	
GET			
Description	It is used to get trigger schedule.		
Query	None		
Inbound Data	None		
Success Return	Schedule		
PUT			
Description	It is used to update trigger schedule.		
Query	None		
Inbound Data	Schedule		
Success Return	ResponseStatus		
Notes:	Notes:		

## Schedule XML Block

<Schedule version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <id><!-- req, xs:string; id --> </id>
 <inputIOPortID> <!-- ro, dep, xs:string; id --> </inputIOPortID>
 <outputIOPortID> <!-- ro, dep, xs:string; id --> </inputIOPortID>



```
<videoInputChannelID><!-- ro, dep, xs:string; id --></videoInputChannelID>
<TimeBlockList> <!-- req -->
   <TimeBlock>
     <dayOfWeek>
        <!-- opt, xs:integer, ISO8601 weekday number, 1=Monday, ... -->
     </dayOfWeek>
     <TimeRange>
                        <!-- req -->
        <br/><beginTime> <!-- req, xs:time, ISO8601 time --> </beginTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
        <endTime>
     </TimeRange>
  </TimeBlock>
</TimeBlockList>
<HolidayBlockList> <!-- opt -->
   <TimeBlock>
     <TimeRange>
                        <!-- req -->
        <beginTime> <!-- req, xs:time, ISO8601 time --> </beginTime>
        <endTime>
                      <!-- req, xs:time, ISO8601 time --> </endTime>
     </TimeRange>
  </TimeBlock>
</HolidayBlockList>
</Schedule>
```

## 8.11.23 /ISAPI/Event/notification

/ISAPI/Event/notification General Resource vi		v2.0	
GET			
Description	It is used to get the configuration of not	ifications.	
Query	None		
Inbound Data	None		
Success Return	EventNotificationMethods		
PUT			
Description	It is used to set the configuration of not	ifications.	
Query	None		
Inbound Data	EventNotificationMethods		
Success Return	ResponseStatus		
Notes:			
The following notification types are supported:			
HTTP: the device connects to a given address and port and issues an HTTP GET/POST with the given parameters.			
FTP: a video clip or snapshot is uploaded to an FTP server.			



E-mail: a mail with the video clip or snapshot is sent in an e-mail to a list of servers. <MediaFormat> determines the type of snapshot, video clip and the video clip pre and post recording times.

### **EventNotificationMethods XML Block**

```
<EventNotificationMethods version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <MailingNotificationList/><!-- opt -->
  <FTPNotificationList/><!-- opt -->
  <HttpHostNotificationList/><!-- opt -->
  <FTPFormat><!-- opt -->
    <uploadSnapShotEnabled><!-- req, xs:boolean --></uploadSnapShotEnabled>
    <uploadVideoClipEnabled><!-- req, xs:boolean --></uploadVideoClipEnabled>
  </FTPFormat>
  <EmailFormat><!-- opt -->
    <senderEmailAddress><!-- req, xs:string --></senderEmailAddress>
    <receiverEmailAddress><!-- req, xs:string --></receiverEmailAddress>
    <subject><!-- req, xs:string --></subject>
    <BodySetting><!-- opt -->
      <attachedVideoURLEnabled>
                                         <!--
                                                    req.
                                                               xs:boolean
</attachedVideoURLEnabled>
      <attachedSnapShotEnabled>
                                         <!--
                                                               xs:boolean
                                                    req,
</attachedSnapShotEnabled>
      <attachedVideoClipEnabled><!--
                                               req,
                                                            xs:boolean
</attachedVideoClipEnabled>
    </BodySetting>
  </EmailFormat>
  <MediaFormat>
                     <!-- opt -->
    <snapShotImageType>
                                              xs:string,
                                                            "JPEG,GIF,PNG"
                                      opt,
</snapShotImageType>
    <videoClipFormatType>
                                <!--
                                         opt,
                                                   xs:string,
                                                                 "ASF,MP4,3GP,264"
--></videoClipFormatType>
    <preCaptureLength> <!-- opt, xs:integer, milliseconds --> </preCaptureLength>
    <postCaptureLength> <!-- opt, xs:integer, milliseconds --> </postCaptureLength>
  </MediaFormat>
<EventNotificationMethods>
```

## 8.11.24 /ISAPI/Event/notification/httpHosts

/ISAPI/Event/notification/httpHosts General Resource		v2.0
GET		
Description It is used to get the configuration of e-mail.		



Query	None
Inbound Data	None
Success Return	HttpHostNotificationList
PUT	
Description	It is used to set the configuration of e-mail.
Query	None
Inbound Data	HttpHostNotificationList
Success Return	ResponseStatus
Notes:	

## HttpHostNotificationList XML Block

```
<HttpHostNotificationList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
    <HttpHostNotification/> <!-- opt -->
    </HttpHostNotificationList>
```

## 8.11.25 /ISAPI/Event/notification/httpHosts/<ID>

/ISAPI/Event/notification/httpHosts/ID		General Resource	v2.0
GET			
Description	It is used to get the configuration of a pa	articular e-mail.	
Query	None		
Inbound Data	None		
Success Return	HttpHostNotification		
PUT			
Description	It is used to set the configuration of a particular e-mail.		
Query	None		
Inbound Data	HttpHostNotification		
Success Return	ResponseStatus		
Notes:			

## HttpHostNotification XML Block



```
<hostName> <!-- dep, xs:string --> </hostName>
<ipAddress> <!-- dep, xs:string --> </ipAddress>
<ipv6Address> <!-- dep, xs:string --> </ipv6Address>
<portNo> <!-- opt, xs:integer --> </portNo>
<userName> <!-- dep, xs:string --> </userName>
<password> <!-- dep, xs:string --> </password>
<httpAuthenticationMethod>
<!-- req, xs:string, "MD5digest,none" -->
</httpAuthenticationMethod>
<!-- teq, xs:string --> </httpAuthenticationMethod>
</httpAuthenticationMethod>
</httpAuthenticationMethod>
</httpHostNotification>
```

## 8.11.26 /ISAPI/Event/notification/streaming

/ISAPI/Event/notification/streaming General Resource v2.			v2.0
GET			
Description	It is used to get the list of recording notification	ations.	
Query	None		
Inbound Data	None		
Success Return	StreamingNotificationList		
PUT			
Description	It is used to update the list of E-mail notific	ations.	
Query	None		
Inbound Data	StreamingNotificationList		
Success Return	ResponseStatus		
POST			
Description	It is used to add an E-mail notification.		
Query	None		
Inbound Data	StreamingNotification		
Success Return	ResponseStatus		
DELETE			
Description	It is used to delete the list of E-mail notification	ations.	
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		
Notes:			
When an event occ	urs, modifying the compression parameters	of a video stream	

### StreamingNotificationList XML Block



```
<StreamingNotificationList version="2.0"
xmlns="http://www.isapi.org/ver20/XMLSchema">
<StreamingNotification/> <!-- opt -->
</StreamingNotificationList>
```

## 8.11.27 /ISAPI/Event/notification/streaming/<ID>

/ISAPI/Event/notification/Streaming/ID General Resource			v2.0	
GET				
Description	It is used to get a particular E-mail notification configuration.			
Query	None			
Inbound Data	None			
Success Return	StreamingNotification			
PUT				
Description	It is used to update a particular E-mail notification configuration.			
Query	None			
Inbound Data	StreamingNotification			
Success Return	ResponseStatus			
DELETE				
Description	It is used to delete a particular E-mail notification.			
Query	None			
Inbound Data	None			
Success Return	ResponseStatus			
Notes:				

#### StreamingNotification XML Block

```
<StreamingNotification version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id> <!-- req, xs:string;id -->
                                  </id>//101 201 301
  <streamingId> <!-- req, xs:string;id --> <streamingId>
  <Video>
    <!-- opt -->
    <enabled><!-- req, xs:boolean --></enabled>
    <videoInputChannelID> <!-- req, xs:string;id --> </videoInputChannelID>
    <videoCodecType>
      <!-- req, xs:string, "MPEG4,MJPEG,3GP,H.264,MPNG" -->
    </videoCodecType>
    <videoScanType>
      <!-- opt, xs:string, "progressive,interlaced" -->
    </videoScanType>
    <videoResolutionWidth> <!-- req, xs:integer --> </videoResolutionWidth>
    <videoResolutionHeight> <!-- req, xs:integer --> </videoResolutionHeight>
```



```
<videoPositionX> <!-- opt, xs:integer --> </videoPositionX>
    <videoPositionY> <!-- opt, xs:integer --> </videoPositionY>
    <videoQualityControlType>
      <!-- opt, xs:string, "CBR, VBR" -->
    </videoQualityControlType>
    <constantBitRate> <!-- dep, xs:integer, in kbps --> </constantBitRate>
    <fixedQuality> <!-- opt, xs:integer, percentage, 0..100 -->
                                                               </fixedQuality>
    <vbrUpperCap> <!-- dep, xs:integer, in kbps --> </vbrUpperCap>
    <vbrLowerCap> <!-- dep, xs:integer, in kbps --> </vbrLowerCap>
    <maxFrameRate>
                         <!-- req, xs:integer, maximum frame rate x100
    </maxFrameRate>
    <keyFrameInterval> <!-- opt, xs:integer, milliseconds --> </keyFrameInterval>
    <rotationDegree> <!-- opt, xs:integer, degrees, 0..360 --></rotationDegree>
    <mirrorEnabled> <!-- opt, xs:boolean --> </mirrorEnabled>
    <snapShotImageType>
      <!-- opt, xs:string, "JPEG,GIF,PNG" -->
    </snapShotImageType>
    <Mpeg4Profile> <!--dep, xs:string, "SP,ASP"--> </Mpeg4Profile>
    <H264Profile>
      <!-- dep, xs:string, "Baseline, Main, High, Extended" -->
    </H264Profile>
    <GovLength> <!--opt, xs:integer --> </GovLength>
  </Video>
  <Audio>
    <!-- opt -->
    <enabled> <!-- req, xs:boolean -->
                                          </enabled>
    <audioInputChannelID> <!-- req, xs:string;id --> </audioInputChannelID>
    <audioCompressionType>
      <!-- req, xs:string,
       " G.711alaw,G.711ulaw,G.726,G.729,G.729a,G.729b,PCM,MP3,AC3,AAC,ADPC
M"
    </audioCompressionType>
    <audioInboundCompressionType>
      <!-- opt, xs:string,
      "G.711alaw,G.711ulaw,G.726,G.729,G.729a,G.729b,PCM,MP3,AC3,AAC,ADPCM
    </audioInboundCompressionType>
    <audioBitRate> <!-- opt, xs:integer, in kbps --> </audioBitRate>
    <audioSamplingRate><!-- opt, xs:float, in kHz --> </audioSamplingRate>
    <audioResolution> <!-- opt, xs:integer, in bits --> </audioResolution>
  </Audio>
```

</StreamingNotification>

## 8.11.28 /ISAPI/Event/notification/alarmCenter

URI	/ISAPI/Event/notif	ication/alarmCenter	•	Туре	Resource
Function	Access the list of ala	arm center notification hosts.			
Methods	Query String(s)	Inbound Data		Returr	Result
GET			<alarmce< th=""><th>enterN</th><th>otificationList</th></alarmce<>	enterN	otificationList
PUT		<alarmcenternotificationlist></alarmcenternotificationlist>	<f< th=""><th>Respor</th><th>seStatus&gt;</th></f<>	Respor	seStatus>
POST		<alarmcenternotification></alarmcenternotification>	<f< th=""><th>Respor</th><th>seStatus&gt;</th></f<>	Respor	seStatus>
DELETE			<f< th=""><th>Respor</th><th>seStatus&gt;</th></f<>	Respor	seStatus>
Notes	Alarm center notification involves the device connecting to a particular alarm center delivering an privacy envent message whenever the event triggers.				

### alarmCenterNotificationList XML Block

## 8.11.29 /ISAPI/Event/notification/alarmCenter/<I

## D>

URI	/ISAPI/Event/notif	ication/alarmCenter/ID		Туре	Resource
Function	Access a particular	HTTP notification host.			
Methods	Query String(s)	Inbound Data	Return Result		
GET			<alarmcenternotification></alarmcenternotification>		
PUT		<alarmcenternotification></alarmcenternotification>	<responsestatus></responsestatus>		
DELETE			<responsestatus></responsestatus>		
Notes	Notes  Depending on the value of <addressingformattype>, either the <hostname> or the IP address fields will be used to locate the alarm center</hostname></addressingformattype>			ostName>	

## alarmCenterNotification XML Block



```
<alarmCenterNotification version="2.0"
xmlns="http://www.isapi.org/ver20/XMLSchema">
                        <!-- req, xs:string;id -->
                                                                  </id>
  <addressingFormatType>
    <!-- req, xs:string, "ipaddress,hostname" -->
  </addressingFormatType>
  <hostName>
                        <!-- dep, xs:string -->
                                                                  </hostName>
  <ipAddress>
                        <!-- dep, xs:string -->
                                                                  </ipAddress>
  <ipv6Address>
                        <!-- dep, xs:string -->
                                                                  </ipv6Address>
  <portNo>
                        <!-- req, xs:integer -->
                                                                  </portNo>
</alarmCenterNotification>
```

## 8.11.30 /ISAPI/Event/notification/alertStream

/ISAPI/Event/notification/alertStream General Res		General Resource	v2.0
GET		Vi€	ewer
Description	It is used to get the event notification server push.	data stream through h	HTTP
Query	None		
Inbound Data	None		
Success Return Stream of <eventnotificationalert></eventnotificationalert>			

#### Notes:

This function is used to get an event notification alert stream from the media device via HTTP or HTTPS. This function does not require that a client/VMS system be added as an HTTP(S) destination on the media device. Instead, the client/VMS system can call this API to initialize a stream of event information from the device. In other words, a connection is established with the device when this function is called, and stays open to constantly receive event notifications.

This API uses HTTP server-push with the MIME type multipart/mixed defined in RFC 2046.

or "HTTPS".

<channelID> is present for video and analytics events.

<activePostCount> is the sequence number of current notification for this particular event. It starts at 1. Useful for recurring notifications of an event. Each event maintains a separate post count.

#### **EventNotificationAlert XML Block**



```
<ipv6Address><!-- dep, xs:string --></ipv6Address>
                <!-- opt, xs:integer -->
  <portNo>
                                         </portNo>
 col>
                <!-- opt, xs:string -->
                                       </protocol>
 <macAddress> <!-- opt, xs:string;MAC --> </macAddress>
                 <!-- dep, xs:string --> </channelID>
  <channelID>
 <dateTime> <!-- req, xs:datetime --> </dateTime>
  <activePostCount> <!-- req, xs:integer -->
                                              </activePostCount>
 <eventType> <!-- req, xs:string, "IO,VMD,videoloss, shelteralarm" --> </eventType>
                  <!-- req, xs:string, "active,inactive" --> </eventState>
 <eventState>
 <eventDescription> <!-- req, xs:string -->
                                                      </eventDescription>
 <inputIOPortID> <!-- dep, xs:integer, if <eventType> is "IO" -->
                                                               </inputIOPortID>
                             <!-- dep, if <eventType> is "VMD" -->
 <DetectionRegionList>
    <DetectionRegionEntry> <!-- req -->
      <regionID>
                        <!-- req, xs:string -->
                                                 </regionID>
      <sensitivityLevel>
                        <!-- req, xs:integer, 0..100 --> </sensitivityLevel>
    </DetectionRegionEntry>
  </DetectionRegionList>
</EventNotificationAlert>
```

### **Example**

The following is an example of an HTTP event stream that pushes a VMD event from video channel 1.

```
GET /Event/notification/alertStream HTTP/1.1
HTTP/1.1 200 OK
MIME-Version: 1.0
Content-Type: multipart/mixed; boundary="<boundary>"
--<boundary>
Content-Type: application/xml; charset="UTF-8"
Content-Length: ISAPI
<?xml version="1.0" encoding="UTF-8"?>
<EventNotificationAlert version="2.0"
 xmlns="http://www.isapi.org/ver20/XMLSchema">
  <ipAddress>172.6.64.7</ipAddress>
  <portNo>80</portNo>
  cprotocol>HTTP
  <macAddress>01:17:24:45:D9:F4</macAddress>
  <channelID>1</channelID>
  <dateTime>2009-11-14T15:27Z</dateTime>
  <activePostCount>1</activePostCount>
  <eventType>VMD</eventType>
```



## 8.11.31 HTTP Notification Alert

http:// <ipaddress>:<portno>/<url></url></portno></ipaddress>		
POST		
Description	Send alert info to alarm center by HTTP POST method.	
Query	None	
Inbound Data	None	
Success Return	eturn Notification Alert	

#### Notes:

Either GET or POST can be used. If GET is used, the corresponding query string parameters are provided in place of the inbound XML. If Post is used, the inbound XML is provided in place of the corresponding query string parameters.

The "DeviceID=" and "DeviceName=" fields are taken from the <DeviceInfo> settings for the device.

The <parameterFormatType> tag indicates whether XML or query string parameters should be used for this API.

The coolType> tag under <HttpHostList> determines whether HTTP or HTTPS is used for this API.

The <portNo> tag under <HttpHostList> determines the port number to be used for the notification alert.

The <portNo> and tags in the alert are provided for a client application to connect/manage the device after it sends out this notification.

The <addressingFormatType> tag under <HttpHostList> determines whether <ipAddress>/IPAddress or <ipv6Address>/IPv6Address is used.

The <url> tag under <HttpHostList> indicates the URL base to be used for the alert.

If <eventType>/EventType refers to an input-port-related event, the <inputIOPortID> tag or InputIOPortID parameter must be provided.

If <eventType>/EventType refers to a motion-related event, the <DetectionRegionList> block



or RegionIndexX parameter(s) must be provided if detection regions have been defined. If the motion event is for a full-screen configuration, these region indexes should not be provided.

The <sensitivityLevel>/SensitivityLevelX and <detectionThreshold>/DetectionThresholdX parameters are used to indicate the current values of the activity detection at the time that the notification is sent out.

If the alert is for a motion-related event, multiple region indexes may be provided per single API. If query string parameters are used, the format "RegionIndexX" is used where "X" is a number starting with "1" and incrementing by one for every subsequent region index provided. If the <a href="httpAuthenticationMethod">httpAuthenticationMethod</a> tag under <a href="httpHostList">httpHostList</a> is configured for "MD5 Digest Authentication", the corresponding security values must be stored in the header fields of the HTTP(S) request.

The <activePostCount>/ActivePostCount parameter is a sequence number starting at 1 and incrementing by one for every event notification sent.

#### **Notification Alert**





DetectionThreshold2=

## 8.11.32 Event Triggering Examples

#### **Example: Trigger Events on IO Port**

The command below enables detection for input port 1. When the input signal is detected according to <inputIOPortID>, two event notification responses are used – output port 1 will be triggered for the duration of the input signal detection, and an SMTP server will be notified with the "E-mail Event Notification Alert". The behavior of this notification is as follows:

- A SMTP notification is sent at detection time, and every some seconds after while the signal is present. This is denoted by the <notificationRecurrence> tags. These APIs will have an <eventState> of "active".
- When the input port 1 signal detection stops, one last E-mail notification is sent to the server with an <eventState> of "active".
- After the signal detection stops for input port 1, the device will wait some seconds before starting to detect the signal again for this port.

```
PUT /ISAPI/Event/triggers/IO-1 HTTP/1.1
Content-Type: application/xml; charset="UTF-8"
Content-Length: xxx
<?xml version="1.0" encoding="UTF-8"?>
<EventTrigger version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id>IO-1</id> <!-- "eventType: IO" -->
  <EventTriggerNotificationList>
    <EventTriggerNotification>
    <id>1</id>
    <notificationMethod>email</notificationMethod>
    </EventTriggerNotification>
    <EventTriggerNotification>
      <id>2</id>
      <notificationMethod> IO</notificationMethod>
      <outputIOPortID>1
    </EventTriggerNotification>
  </EventTriggerNotificationList>
</EventTrigger>
```

#### **Example: Schedule event detection and triggering**

The command below schedules event detection and triggering from 7:00 am to 5:00 pm. every Tuesday.



```
PUT /ISAPI/Event/schedule/IO-IN-1 HTTP/1.1
Content-Type: application/xml; charset="UTF-8"
Content-Length: xxx
<?xml version="1.0" encoding="UTF-8"?>
<EventSchedule version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id>IO-IN-1</id>
  <eventType>IO</eventType>
 <inputIOPortID>1</inputIOPortID>
 <TimeBlockList>
   <TimeBlock>
      <dayOfWeek>2</dayOfWeek>
      <TimeRange>
        <br/><beginTime>07:00:00</beginTime>
        <endTime>17:00:00</endTime>
      </TimeRange>
   </TimeBlock>
 </TimeBlockList>
</EventSchedule>
```

#### 8.12 /ISAPI/Smart

/ISAPI/Smart	Service v2.0
Notes: Smart service	

# 8.12.1 /ISAPI/Smart/capabilities

/ISAPI/Smart/capa	abilities General Resource	v2.0
GET		
Description	It is used to get Smart capability.	
Query	None	
Inbound Data	None	
Success Return	< SmartCap>	
Notes:		

#### SmartCap XML Block

```
<SmartCap version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
    <isSupportROI> <!-- opt, xs:boolen --> </isSupportROI>
    <isSupportFaceDetect> <!-- opt, xs:boolen --> </isSupportFaceDetect>
```



- <isSupportIntelliTrace> <!-- opt, xs:boolen --> </isSupportIntelliTrace>
- <isSupportFieldDetection> <!-- opt, xs:boolen --> </isSupportFieldDetection>
- <isSupportDefocusDetection> <!-- opt, xs:boolen --> </isSupportDefocusDetection>
- <isSupportAudioDetection> <!-- opt, xs:boolen --> </isSupportAudioDetection>
- <isSupportSceneChangeDetection> <!-- opt, xs:boolen -->
- </isSupportSceneChangeDetection>
- </SmartCap>

## 8.12.2 /ISAPI/Smart/ROI/channels

/ISAPI/Smart/ROI/channels		General Resource	v2.0
GET			
Description	Access and configure the ROI.		
Query	None		
Inbound Data	None		
Success Return	ROIList		
PUT			
Description	Access and configure the ROI.		
Query	None		
Inbound Data	ROIList		
Success Return	ResponseStatus		
Notes:			

#### **ROIList XML Block**

<ROIList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <ROI/> <!-- opt --> </ROIList>

## 8.12.3 /ISAPI/Smart/ROI/channels/<ID>

/ISAPI/Smart/ROI/channels/ID		General Resource	v2.0
GET			
Description	Access and configure the ROI for a special channel.		
Query	None		
Inbound Data	None		
Success Return	ROI		
PUT			



Description	Access and configure the ROI for a special channel.
Query	None
Inbound Data	ROI
Success Return	ResponseStatus
DELETE	
Description	Access and configure the ROI for a special channel.
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes:	
normalizedScreen	Size: the size of normalized screen
ROIRegionList:the	list of ROI region
<id> should be cor</id>	nsistent with <id> of streaming.</id>
<enabled></enabled> re</th <td>eq, xs:string&gt; if the value of this tag is "disable", all of regions are</td>	eq, xs:string> if the value of this tag is "disable", all of regions are
invalid.	

#### **ROI XML Block**

# 8.12.4 /ISAPI/Smart/ROI/channels/<ID>/regions

/ISAPI/Smart/ROI/channels/ID/regions		General Resource v2.0
GET		
Description	Access and configure the ROI regions for a special channel.	
Query	None	
Inbound Data	None	
Success Return	ROIRegionsList	
PUT		



Description	Access and configure the ROI regions for a special channel	
Query	None	
Inbound Data	ROIRegionsList	
Success Return	ResponseStatus	
Notes:		

#### **ROIRegionsList XML Block**

<ROIRegionsList version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema" size=> <ROIRegion/> <!-- opt --> </ROIRegionsList>

# 8.12.5 /ISAPI/Smart/ROI/channels/<ID>/regions/<I

# D>

/ISAPI/Smart/ROI/	channels/ID/regions/ID	General Resource	v2.0
GET			
Description	Access and configure one ROI region for	a special channel.	
Query	None		
Inbound Data	None		
Success Return	ROIRegion		
PUT			
Description	Access and configure one ROI region for	a special channel	
Query	None		
Inbound Data	ROIRegion		
Success Return	ResponseStatus		
DELETE			
Description	Access and configure one ROI region for	a special channel	
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		
Notes:			
qualityLevel:quality level of a region			
RegionCoordinates	sList:coordinate of ROI		

#### **ROIRegion XML Block**

<ROIRegion version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema"> <id> <!-- req, xs:integer--> </id>



```
<enabled> <!-- req, xs:boolean --> </enabled>
  <name> <!-- opt, xs:string --> </name>
  <qualityLevelOfROI> <!-- req, xs:integer "1-6"--> </qualityLevelOfROI>
  <RegionCoordinatesList/>
</ROIRegion>
```

## 8.12.6 /ISAPI/Smart/ROI/channels/<ID>/facetrace

/ISAPI/Smart/ROI/channels/ID/facetrace General Resource		General Resource	v2.0
GET			
Description	Access and configure the ROI regions for	a special channel.	
Query	None		
Inbound Data	None		
Success Return	FaceTrace		
PUT			
Description	Access and configure the ROI regions for	a special channel	
Query	None		
Inbound Data	FaceTrace		
Success Return	ResponseStatus		
Notes:			

#### FaceTrace XML Block

## 8.12.7 /ISAPI/Smart/ROI/channels/<ID>/objecttrac

e

/ISAPI/Smart/ROI/channels/ID/objecttrace		General Resource	v2.0
GET			
Description	Access and configure the ROI regions for a special channel.		
Query	None		
Inbound Data	None		
Success Return	ObjectTrace		



PUT		
Description	Access and configure the ROI regions for a special channel	
Query	None	
Inbound Data	ObjectTrace	
Success Return	ResponseStatus	
Notes:		

#### ObjectTrace XML Block

#### 8.12.8 /ISAPI/Smart/FaceDetect/<ID>

/ISAPI/Smart/FaceDetect/ID		General Resource	v2.0
GET			
Description	Access and configure the FaceDetect.		
Query	None		
Inbound Data	None		
Success Return	FaceDetect		
PUT			
Description	Access and configure the FaceDetect.		
Query	None		
Inbound Data	FaceDetect		
Success Return	ResponseStatus		
Notes:			
<id> stands for channel number</id>			

#### FaceDetect XML Block



## 8.12.9 /ISAPI/Smart/IntelliTrace/<ID>

/ISAPI/Smart/Intel	liTrace/ <id></id>	General Resource	v2.0
GET			
Description			
Query	None		
Inbound Data	None		
Success Return	IntelliTrace		
PUT			
Description			
Query	None		
Inbound Data	IntelliTrace		
Success Return	ResponseStatus		
Notes:			

#### IntelliTrace XML Block

## 8.12.10 /ISAPI/Smart/IntelliTrace/<ID>/ZoomRati

al

/ISAPI/Smart/IntelliTrace/ID/ZoomRatial General Resource v2.	.0
--	----



PUT	
Description	
Query	None
Inbound Data	None
Success Return	ResponseStatus
Notes:	

## 8.12.11 /ISAPI/Smart/FieldDetection

/ISAPI/Smart/FieldDetection		General Resource	v2.0
GET			
Description	Field detection configuration for all video	input channels.	
Query	None		
Inbound Data	None		
Success Return	FieldDetectionList		
PUT			
Description	Field detection configuration for all video	input channels.	
Query	None		
Inbound Data	FieldDetectionList		
Success Return	ResponseStatus		
Notes:			

#### FieldDetectionList XML Block

## 8.12.12 /ISAPI/Smart/FieldDetection/<ID>

/ISAPI/Smart/FieldDetection/ID		General Resource v2.0	
GET			
Description	Field detection configuration for a video in	Field detection configuration for a video input channels.	
Query	None		
Inbound Data	None		
Success Return	FieldDetection		
PUT			
Description	Field detection configuration for a video in	nput channels.	
Query	None		



Inbound Data	FieldDetection
Success Return	ResponseStatus
Notes:	

#### FieldDetection XML Block

```
<FieldDetection version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id> <!-- req, xs:string --> </id>
  <enabled> <!-- req, xs:boolean -->
                                       </enabled>
<startTriggerTime> <!-- req, xs:integer, milliseconds --> </startTriggerTime>
  <endTriggerTime> <!-- req, xs:integer, milliseconds --> </endTriggerTime>
<normalizedScreenSize>
 <normalizedScreenWidth> <!-- req, xs:integer --> </normalizedScreenWidth>
 <normalizedScreenHeight> <!-- req, xs:integer --> </normalizedScreenHeight>
 </normalizedScreenSize>
 <minObjectSize>
  <!-- opt, xs:integer, min number of pixels per object -->
</minObjectSize>
  <maxObjectSize>
  <!-- opt, xs:integer, max number of pixels per object -->
 </maxObjectSize>
<FieldDetectionRegionList size="4"/>
</FieldDetection>
```

# 8.12.13 /ISAPI/Smart/FieldDetection/<ID>/region

S

/ISAPI/Smart/Field	Detection/ID/regions	General Resource	v2.0
GET			
Description	Access the list of regions for Field dete input channel.	ction on a particular	video
Query	None		
Inbound Data	None		
Success Return	FieldDetectionRegionList		
PUT			
Description	Access the list of regions for Field dete input channel.	ction on a particular	video
Query	None		
Inbound Data	FieldDetectionRegionList		
Success Return	ResponseStatus		
POST			



Description	Access the list of regions for Field detection on a particular video input channel.
Query	None
Inbound Data	None
Success Return	FieldDetectionRegion
DETELE	
Description	Access the list of regions for Field detection on a particular video input channel.
Query	None
Inbound Data	None
Ilibouliu Data	None
Success Return	ResponseStatus

## FieldDetectionRegionsList XML Block

<FieldDetectionRegionList version="2.0"
xmIns="http://www.isapi.org/ver20/XMLSchema">
 <FieldDetectionRegion/>
 </FieldDetectionRegionList>

# 8.12.14 /ISAPI/Smart/FieldDetection/<ID>/region/ <ID>

/ISAPI/Smart/Field	Detection/ID/regions/ID	General Resource	v2.0
GET			
Description	Access the list of regions for Field detection	on.	
Query	None		
Inbound Data	None		
Success Return	FieldDetectionRegion		
PUT			
Description	Access the list of regions for Field detection	on.	
Query	None		
Inbound Data	FieldDetectionRegion		
Success Return	ResponseStatus		
DELETE			
Description	Access the list of regions for Field detection	on.	
Query	None		
Inbound Data	None		
Success Return	ResponseStatus		



Notes:

#### FieldDetectionRegion XML Block

```
<FieldDetectionRegion version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
                   <!-- req, xs:string -->
                                                  </id>
  <id>
   <enabled>
                 <!-- req, xs:boolean -->
                                           </enabled>
  <sensitivityLevel>
    <!--req, xs:integer-->
  </sensitivityLevel>
  <timeThreshold>
    <!--req, xs:integer -->
  </timeThreshold>
  <objectOccupation>
     <!--req, xs:integer-->
  </objectOccupation>
  <RegionCoordinatesList>
    <RegionCoordinates> <!-- req, -->
                        <!-- req, xs:integer;coordinate -->
                                                             </positionX>
      <positionX>
      <positionY>
                        <!-- req, xs:integer;coordinate -->
                                                             </positionY>
    </RegionCoordinates>
  </RegionCoordinatesList>
</FieldDetectionRegion>
```

## 8.12.15 /ISAPI/Smart/DefocusDetection

/ISAPI/Smart/DefocusDetection General R		General Resource	v2.0
GET			
Description	Defocus detection configuration for all au	dio input channels.	
Query	None		
Inbound Data	None		
Success Return	DefocusDetectionList		
PUT			
Description	Defocus detection configuration for all au	dio input channels.	
Query	None		
Inbound Data	DefocusDetectionList		
Success Return	ResponseStatus		
Notes:			

#### **DefocusDetectionList XML Block**



## 8.12.16 /ISAPI/Smart/DefocusDetection/<ID>

/ISAPI/Smart/ DefocusDetection/ID		General Resource	v2.0
GET			
Description	Defocus detection configuration for a a	audio input channel.	
Query	None		
Inbound Data	None		
Success Return	DefocusDetection		
PUT			
Description	Defocus detection configuration for a a	audio input channel.	
Query	None		
Inbound Data	DefocusDetection		
Success Return	ResponseStatus		
Notes:			

#### **DefocusDetection XML Block**

<DefocusDetection version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <id> <!-- req, xs:string --> </id>
 <enabled> <!-- req, xs:boolean --> </enabled>
</DefocusDetection>

## 8.12.17 /ISAPI/Smart/AudioDetection/channels

/ISAPI/Smart/AudioDetection/channels		eral Resource	v2.0
GET			
Description	Audio detection configuration for all audio input	channels.	
Query	None		
Inbound Data	None	None	
Success Return	AudioDetectionList		
PUT			
Description	Audio detection configuration for all audio input	channels.	
Query	None		
Inbound Data	AudioDetectionList		
Success Return	ResponseStatus		



Notes:

#### AudioDetectionList XML Block

### 8.12.18 /ISAPI/Smart/AudioDetection/channels/<

#### ID>

/ISAPI/Smart/Aud	ioDetection/channels/ID	General Resource	v2.0
GET			
Description	Audio detection configuration for a audio	input channel.	
Query	None		
Inbound Data	None		
Success Return	AudioDetection		
PUT			
Description	Audio detection configuration for a audio	input channel.	
Query	None		
Inbound Data	AudioDetection		
Success Return	ResponseStatus		
Notes:			

#### **AudioDetection XML Block**

```
<AudioDetection version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <id> <!-- req, xs:string;id -->
  <audioInputException>
   <enabled>
                  <!-- req, xs:boolean --> </enabled>
  </audioInputException>
  <soundIntensityMutation>
   <enabled>
                 <!-- req, xs:boolean -->
                                           </enabled>
   <sensitivityLevel>
     <!--req, xs:integer-->
   </sensitivityLevel>
  <mutationThreshold>
    <!--req, xs:integer -->
  </mutationThreshold>
  </soundIntensityMutation>
  </AudioDetection>
```



# 8.12.19 /ISAPI/Smart/AudioDetection/channels/< ID>/status

/ISAPI/Smart/AudioDetection/channels/ID/status		General Resource	v2.0
GET			
Description	It is used to get audio strength.		
Query	None		
Inbound Data	None		
Success Return	AudioStrengthStatus		
Notes:			

#### AudioStrengthStatus XML Block

## 8.12.20 /ISAPI/Smart/SceneChangeDetection

/ISAPI/Smart/SceneChangeDetection General Resource		v2.0	
GET			
Description	Scene change detection configuration for al	l video input channels.	
Query	None		
Inbound Data	None		
Success Return	SceneChangeDetectionList		
PUT			
Description	Scene change detection configuration for al	l video input channels.	
Query	None		
Inbound Data	SceneChangeDetectionList		
Success Return	ResponseStatus		
Notes:			

#### SceneChangeDetectionList XML Block

<SceneChangeDetectionList version="2.0"

xmIns="http://www.isapi.org/ver20/XMLSchema">

<SceneChangeDetection/> <!-- opt -->



</SceneChangeDetectionList>

## 8.12.21 /ISAPI/Smart/SceneChangeDetection/<ID

>

/ISAPI/Smart/SceneChangeDetection/ID General Resource		v2.0	
GET			
Description	Scene change detection configuration for a vide	eo input channels.	
Query	None		
Inbound Data	None		
Success Return	SceneChangeDetection		
PUT			
Description	Scene change detection configuration for a video in	nput channels.	
Query	None		
Inbound Data	SceneChangeDetection		
Success Return	ResponseStatus		
Notes:			

#### SceneChangeDetection XML Block

## 8.13 /ISAPI/WLAlarm/

/ISAPI/WLAIarm	Service v2.0
Notes: wireless alarm service	

## 8.13.1 /ISAPI/WLAlarm/capabilities

/ISAPI/WLAlarm/capabilities		General Resource	v2.0
GET			
Description	It is used to get wireless alarm capability.		



Query	None
Inbound Data	None
Success Return	<wlalarmcap></wlalarmcap>
Notes:	

#### WLAIarmCap XML Block

## 8.13.2 /ISAPI/WLAlarm/telecontrol

/ISAPI/WLAIarm/tel	econtrol General Resource v2.0
GET	
Description	It is used to get the properties of snapshot channels for the device.
Query	None
Inbound Data	None
Success Return	telecontrol
PUT	
Description	It is used to config the properties of snapshot channels for the device.
Query	None
Inbound Data	telecontrol
Success Return	ResponseStatus
Notes:	

#### telecontrol XML Block

```
<telecontrol version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
    <enabled> <!-- req, xs:boolean --> </enabled>
    <delay> <!--opt, xs:integer, seconds -->
        <armingdelay><!--opt, xs:integer, seconds --> </armingdelay>
        <disarmingdelay><!--opt, xs:integer, seconds --> </disarmingdelay>
        </delay>
        </delay>
        </telecontrol>
```



# 8.13.3 /ISAPI/WLAlarm/telecontrol/study

/ISAPI/WLAlarm/telecontrol/study		General Resource	v2.0
PUT			
Description	It is used to update the properties of a pa	rticular snapshot chan	nel.
Query	None		
Inbound Data			
Success Return	ResponseStatus		
Notes: the device enters arming status			

# 8.13.4 /ISAPI/WLAlarm/telecontrol/arming

/ISAPI/WLAlarm/telecontrol/arming		General Resource v2.0
PUT		
Description	It is used to update the properties of a	particular snapshot channel.
Query	None	
Inbound Data		
Success Return	ResponseStatus	
Notes:		
The device enters arming status		

# 8.13.5 /ISAPI/WLAlarm/telecontrol/disarming

/ISAPI/WLAlarm/telecontrol/disarming		General Resource v2.0
PUT		
Description	It is used to update the properties of a pa	rticular snapshot channel.
Query	None	
Inbound Data		
Success Return	ResponseStatus	
Notes:		

## 8.13.6 /ISAPI/WLAIarm/PIR

/ISAPI/WLAIarm/P	IR General Resource v2.0
GET	
Description	It is used to get the properties of snapshot channels for the device.



Query	None		
Inbound Data	None		
Success Return	PIRAlarm		
PUT			
Description	It is used to config the properties of snapshot channels for the device.		
Query	None		
Inbound Data	PIRAlarm		
Success Return	ResponseStatus		
Notes:			

#### **PIRAlarm XML Block**

```
<PIRAlarm version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <enabled> <!--req, xs:boolean --></enable>
  <name> <!--opt, xs:string --></name>
  </PIRAlarm>
```

## 8.13.7 /ISAPI/WLAlarm/WLSensors

/ISAPI/WLAIarm/	WLSensors General Resource v2.0			
GET				
Description	It is used to get the properties of snapshot channels for the device.			
Query	None			
Inbound Data	None			
Success Return	WLSensorlist			
PUT				
Description	It is used to config the properties of snapshot channels for the device.			
Query	None			
Inbound Data	WLSensorlist			
Success Return	ResponseStatus			
Notes:				

#### **WLSensorlist XML Block**

<WLSensorlist version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
 <WLSensor/>
 </WLSensorlist>

## 8.13.8 /ISAPI/WLAlarm/WLSensors/<ID>

/ISAPI/WLAlarm/WLSensors/ID General Resource	v2.0
--	------



GET			
Description	It is used to get the properties of snapshot channels for the device.		
Query	None		
Inbound Data	None		
Success Return	WLSensor		
PUT			
Description	It is used to config the properties of snapshot channels for the device.		
Query	None		
Inbound Data	WLSensor		
Success Return	ResponseStatus		
Notes:			

#### **WLSensorlist XML Block**

```
<WLSensor version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <enabled> <!--req, xs:boolean --></enable>
  <name> <!--opt, xs:string --></name>
  </WLSensor>
```

# 8.13.9 /ISAPI/WLAlarm/callhelp

/ISAPI/WLAlarm/callhelp		General Resource	v2.0	
GET				
Description				
Query	None			
Inbound Data	None			
Success Return	Callhelp			
PUT				
Description				
Query	None			
Inbound Data	Callhelp			
Success Return	ResponseStatus			
Notes:				

#### Callhelp XML Block

```
<Callhelp version="2.0" xmlns="http://www.isapi.org/ver20/XMLSchema">
  <enabled> <!--req, xs:boolean --></enable>
  <name> <!--opt, xs:string --></name>
  </Callhelp>
```