

The Intel x64

It was simple at first...

2

#### The Intel x64

- The Intel x64 is the main processor used by servers, laptops, and desktops
- It has evolved continuously over a 40+ year period



Sacramento State - Cook - CSc 3

ou \_\_\_\_\_

The Original x86

- First "x86" was the 8086
- Released in 1978
- Attributes:
  - 16-bit registers
  - 16 registers
  - could access of 1MB of RAM (in 64KB blocks using a special "segment" register)

Sacramento State - Cook - CSc 35

3

# What to call the processor

- The classic term "x86" refers to the 32-bit and 16-bit processor family
- With move to 64-bit, the term "x64" is used to differentiate the newest design from the previous

all 2020 Sacramento State - Cook - CS

(mede)

It was simple at first...

Original x86

Registers

6





#### Original x86 Registers

- The original x86 contained 16 registers
- 8 can be used by your programs
- The other 8 are used for memory management



7

#### Original x86 Registers

- 8 Registers can be used by your programs
  - · Four General Purpose: AX, BX, CX, DX
  - · Four pointer index: SI, DI, BP, SP
- The remaining 8 are restricted
  - Six segment: CS, DS, ES, FS, GS, SS
  - · One instruction pointer: IP
  - One status register used in computations

9

# Original General Purpose Registers

However, back then (and now too) it is very useful to store 8-bit values

Original x86 Registers

strange names

The x86 processor has evolved

continuously over the last 4 decades

The result is many of the registers have


• It first jumped to 32-bit, and then, again, to

- So, Intel chopped 4 of the registers in half
- These registers have generic names of A, B, C, D

10

## Original General Purpose Registers


- The first and second byte can be used separately or used together
- Naming convention
  - · high byte has the suffix "H"
  - · low byte has the suffix "L"
  - · for both bytes, the suffix is "X"






## Original General Purpose Registers


- This essentially doubled the number of registers
- So, there are:
  - four 16-bit registers or
  - · eight 8-bit registers
  - · ...and any combination you can think off



<u>11</u>

<u>12</u>







<u>14</u>




When the x86 moved to 32-bit era, Intel expanded the registers to 32-bit
the 16-bit ones still exist
they have the prefix "e" for extended
New instructions were added to use them


<u>16</u>







<u>18</u>






20







<u>21</u>



<u>24</u>







<u> 26</u>

Register	32-bit	16-bit	8-bit High	8-bit Low
rax	eax	ax	ah	al
rbx	ebx	bx	bh	bl
rcx	ecx	СX	ch	cl
rdx	edx	dж	dh	dl
rsi	esi	si		sil
rdi	edi	di		dil
rbp	ebp	bp		bpl
rsp	esp	sp		spl

4-Bit Register Table						
Register	32-bit	16-bit	8-bit High	8-bit Low		
r8	r8d	r8w		r8b		
r9	r9d	r9w		r9b		
r10	r10d	r10w		r10b		
r11	r11d	r11w		r11b		
r12	r12d	r12w		r12b		
r13	r13d	r13w		r13b		
r14	r14d	r14w		r14b		
r15	r15d	r15w		r15b		

28





<u>30</u>

#### Types of Operands

- Registers
- Address in memory
- Register pointing to a memory address
- Immediate

31

#### Intel x86 Instruction Limits

- There are some limitations...
- Some instructions must use an immediate
- Some instructions require a specific register to perform calculations



32

#### Intel x86 Instruction Limits

- A register must always be involved
  - · processors use registers for all activity
  - · both operands cannot access memory at the same time
  - the processor has to have it at some point!
- Also, obviously, the receiving field cannot be an immediate value

33

Instruction: Move

- The Intel *Move Instruction* combines transfer, load and store instructions under one name
- well, that's something the assembler does for us – but, we'll cover that soon
- "Move" is a tad confusing it copies data


34


# Instruction: Move Immediate, Register, MOV destination, source Register, Memory

Example: Move immediate Source is a immediate constant MOV rax, Same as Java **Destination** is rax


36


<u>35</u>





38








40


Instruction: Add & Subtract
 The Add and Subtract instructions take two operands and store the result in the second operand
 This is the same as the += and -= operators used in Visual Basic .NET, C, C++, Java, etc...


<u>41</u>
















Call Instruction CALL address Usually a label – a constant that holds an address

<u>48</u>





<u>49</u>