Solar Design Algorithm

The document below defines the calculations used to design and evaluate a PV system in preparation for creating electrical drawings.

The secondary documents are automatically created from this source:

- A printable PDF document describing the algorithm, with no computer code (SDA_standard.pdf).
- Key computer code used in FSEC's online express drawing creation application (SDA.js).
- A printable PDF document describing the algorithm and it's related computer code (SDA.pdf).

Note: For each section, the symbols are pre-pended by a section name to assist with their use in the computer code, in the form of "section.symbol".

String Inverter System Calculations

Modules, source circuits, and array

Calculation summary:

Description	Symbol	Calculation
Maximum Power (W)	source.max_power	module.pmp * array.largest_string
Open-Circuit Voltage (V)	source.voc	module.voc * array.largest_string
Short-Circuit Current (A)	source.isc	module.isc
Maximum Power Voltage (V)	source.vmp	module.vmp * array.largest_string
Maximum Power Current (A)	source.imp	module.imp
Source Circuit Maximum Current (A), Isc x 1.25	source.lsc_adjusted	module.isc * 1.25
Maximum system voltage Option 1 (module temp. correction factor)	array.max_sys_voltage_2	source.voc * (1 + module.tc_voc_percent / 100 * (array.min_temp - 25)
Maximum system voltage Option 1 (general temp. correction factor)	array.max_sys_voltage_1	source.voc * array.voltage_correction_factor
Maximum system voltage	array.max_sys_voltage	sf.max(array.max_sys_voltage_1, array.max_sys_voltage_2)
Minimum array voltage (module temp. correction factor)	array.min_voltage	array.smallest_string * module.vmp * (1 + module.tc_vpmax_percent /
Maximum Power (W)	array.pmp	array.num_of_modules * module.pmp
Open-Circuit Voltage (V)	array.voc	source.voc
Short-Circuit Current (A)	array.isc	module.isc * array.num_of_strings
Maximum Power Voltage (V)	array.vmp	module.vmp * array.largest_string
Maximum Power Current (A)	array.imp	module.imp * array.num_of_strings
PV Power Source Maximum Current (A)	array.isc_adjusted	array.isc * 1.25
PV Power Source Maximum Voltage (V)	array.vmp_adjusted	array.max_sys_voltage_2
PV Power Source Minimum Voltage (V)	array.vmp_adjusted_min	???
Enter Maximum Number of Parallel Source Circuits per Output Circuit (1-2)	array.circuits_per_MPPT	Math.ceil(array.num_of_strings / inverter.mppt_channels)
PV Output Circuit Maximum Current (A)	array.combined_isc	source.isc * array.circuits_per_MPPT
PV Output Circuit Maximum Current (A), Isc x 1.25	array.combined_isc_adjusted	module.isc * 1.25 * array.circuits_per_MPPT
Maximum PV Output Circuit Voltage at Lowest Temperature	array.max_sys_voltage_2	array.max_sys_voltage_2

```
source.max_power = module.pmp * array.largest_string;
source.voc = module.voc * array.largest_string;
source.isc = module.isc;
source.vmp = module.vmp * array.largest string;
source.imp = module.imp;
source.Isc_adjusted = module.isc * 1.25;
array.max_sys_voltage_1 = source.voc * array.voltage_correction_factor;
array.max_sys_voltage_2 = source.voc * ( 1 + module.tc_voc_percent / 100 * ( array.min_temp - 25));
array.max_sys_voltage = sf.max( array.max_sys_voltage_1, array.max_sys_voltage_2 );
array.min_voltage = array.smallest_string * module.vmp * ( 1 + module.tc_vpmax_percent / 100 * ( array.max_temp - 25 ) );
array.pmp = array.num_of_modules * module.pmp;
array.voc = source.voc;
array.isc = module.isc * array.num_of_strings;
array.vmp = module.vmp * array.largest_string;
array.imp = module.imp * array.num_of_strings;
array.max sys current = array.isc;
array.isc_adjusted = array.isc * 1.25;
array.vmp_adjusted = array.max_sys_voltage_2;
array.circuits_per_MPPT = Math.ceil( array.num_of_strings / inverter.mppt channels );
array.combined_isc = source.isc * array.circuits_per_MPPT;
array.combined_isc_adjusted = module.isc * 1.25 * array.circuits_per_MPPT;
array.max_sys_voltage_2 = array.max_sys_voltage_2;
```

The maximum array voltage is must not exceed the maximum system voltage allowed by the module.

```
error_check.array_test_1 = array.max_sys_voltage > module.max_system_v;
// If error check is true, flag system design failure, and report notice to user.
if(error_check.array_test_1 ){ report_error( 'Maximum system voltage exceeds the modules max system voltage.' );}
```

The maximum array voltage is must not exceed the maximum system voltage allowed by the building code.

```
error_check.array_test_2 = array.max_sys_voltage > array.code_limit_max_voltage;
// If error check is true, flag system design failure, and report notice to user.
if(error_check.array_test_2){ report_error( 'Maximum system voltage exceeds the maximum voltage allows by code.' );}
```

The maximum array voltage must not exceed the maximum system voltage allowed by the inverter.

```
error_check.array_test_3 = array.max_sys_voltage > inverter.vmax;
// If error check is true, flag system design failure, and report notice to user.
if(error_check.array_test_3){ report_error( 'Maximum system voltage exceeds the inverter maximum voltage rating' );}
```

The minimum array voltage must be greater than the inverter minimum operating voltage.

```
error_check.array_test_4 = array.min_voltage < inverter.voltage_range_min;
// If error check is true, flag system design failure, and report notice to user.
if(error_check.array_test_4){ report_error( 'Minimum Array Vmp is less than the inverter minimum operating voltage.' );}</pre>
```

The total array power must be less than 10,000W.

```
error_check.power_check_array = array.pmp > 10000;
// If error check is true, flag system design failure, and report notice to user.
if( error_check.power_check_array ){    report_error( 'Array total power exceeds 10kW' );}
```

The combined DC short circuit current from the array must be less than the maximum allowed per inverter MPPT channel.

The combined current is the total current per MPP tracker input.

A correction factor of 1.25 is applied to the STC module lsc to account for high irradiance conditions.

```
error_check.current_check_inverter = ( array.combined_isc * 1.25 ) > inverter.isc_channel;
// If error check is true, flag system design failure, and report notice to user.
if( error_check.current_check_inverter ){ report_error( 'PV output circuit maximum current exceeds the inverter maximum dc
current per MPPT input.' );}
```

Inverter

If max_ac_ocpd is not provided by the manufacturer, it is calculated as follows:

```
AC_OCPD_max = max_ac_output_current * 1.25
```

```
inverter.AC_OCPD_max = sf.if( sf.not( inverter.max_ac_ocpd ), inverter.max_ac_output_current * 1.25, inverter.max_ac_ocpd );
```

The nominal ac output power is selected from fields based on the user selected grid voltage. As an example, if the user selects 240 VAC, then:

```
nominal_ac_output_power = nominal_ac_output_power_240 max_ac_output_current = max_ac_output_current_240
```

```
inverter.nominal_ac_output_power = inverter['nominal_ac_output_power_'+inverter.grid_voltage];
inverter.max_ac_output_current = inverter['max_ac_output_current_'+inverter.grid_voltage];
```

Conductor and conduit schedule

For string inverters, these are the circuit names:

- · Exposed source circuit wiring: DC wires exposed on the roof.
- PV DC source circuits: DC wires in conduit.
- Inverter AC output circuit: AC circuits between the inverter and panel OCPD.

```
var circuit_names = [
  'exposed source circuit wiring',
  'pv dc source circuits',
  'inverter ac output circuit',
];
circuit_names.forEach(function(circuit_name){
  circuits[circuit_name] = {};
});
```

The array temperature adder is found in NEC table 310.15(B)(3)(c), or Table 1 in appendix, with module.array_offset_from_roof as "Distance Above Roof to Bottom of Conduit (in)".

```
// Use Table 1, lookup: module.array_offset_from_roof, return the first column.
circuits['exposed source circuit wiring'].temp_adder = sf.lookup( module.array_offset_from_roof, tables[1] );
```

The maximum current and voltage for the array DC circuits are equal to source.isc and source.voc.

```
circuits['exposed source circuit wiring'].max_current = array.combined_isc;
circuits['exposed source circuit wiring'].max_voltage = source.voc;
circuits['pv dc source circuits'].max_current = array.combined_isc;
circuits['pv dc source circuits'].max_voltage = source.voc;
```

The number of DC current carrying conductors is equal to twice the number of strings in the array ($array.num_of_strings*2$). Total conductors adds one more for the ground.

```
circuits['exposed source circuit wiring'].total_cc_conductors = ( array.num_of_strings * 2 );
circuits['exposed source circuit wiring'].total_conductors = ( array.num_of_strings * 2 ) + 1;
circuits['pv dc source circuits'].total_cc_conductors = ( array.num_of_strings * 2 );
circuits['pv dc source circuits'].total_conductors = ( array.num_of_strings * 2 ) + 1;
```

The AC grid voltage is defined by system specifications (user input).

```
circuits['inverter ac output circuit'].max voltage = inverter.grid voltage;
```

The maximum AC output is defined by the inverter manufacturer specifications.

```
circuits['inverter ac output circuit'].max_current = inverter.max_ac_output_current;
```

AC conductors numbers are defined by the grid voltage.

```
var conductors_options = {
    '120V': ['ground', 'neutral', 'L1'],
    '240V': ['ground', 'neutral', 'L1', 'L2'],
    '208V': ['ground', 'neutral', 'L1', 'L2'],
    '277V': ['ground', 'neutral', 'L1'],
    '480V Wye': ['ground', 'neutral', 'L1', 'L2', 'L3'],
    '480V Delta': ['ground', 'L1', 'L2', 'L3'],
};
inverter.conductors = conductors_options[inverter.grid_voltage+'V'];
inverter.num_conductors = inverter.conductors.length;

circuits['inverter ac output circuit'].total_cc_conductors = inverter.num_conductors;
```

For each circuit, calculate the following.

```
circuit_names.forEach(function(circuit_name, i){
  var circuit = circuits[circuit_name];
  circuit.id = i;

circuit.power_type = sf.index( ['DC', 'DC', 'AC'], circuit.id );
  // If temperature adder is not defined, set it to 0 for use in further calculations.
  circuit.temp_adder = sf.if( circuit.temp_adder, circuit.temp_adder, 0 );
```

The array maximum temperature of the array is equal to the 2% maximum temperature at the install location, or nearest weather station. For a state wide design, the largest maximum temperature for the state is used. Rooftop array circuits also have a temperature adjustment defined above.

```
circuit.max_conductor_temp = array.max_temp + circuit.temp_adder;
// Use Table 2, lookup: circuit.max_conductor_temp, return the first column.
circuit.temp_correction_factor = sf.lookup( circuit.max_conductor_temp, tables[2] );
// Use Table 3, lookup: circuit.total_cc_conductors, return the first column.
circuit.conductors adj factor = sf.lookup( circuit.total cc conductors , tables[3] );
```

There are three options to calculate the minimum required current:

- circuit.max_current * 1.25;
- circuit.max_current / (circuit.temp_correction_factor * circuit.conductors_adj_factor);
- 3. circuit.max current * 1.25 * 1.25;

```
circuit.min_req_cond_current_1 = circuit.max_current * 1.25;
circuit.min_req_cond_current_2 = circuit.max_current / ( circuit.temp_correction_factor * circuit.conductors_adj_factor );
circuit.min_req_cond_current_3 = circuit.max_current * 1.25 * 1.25;
```

For AC circuits, the maximum of #1 and #2 is used. For DC circuits, the maximum of #2 and #3 is used.

```
circuit.min_req_cond_current = sf.max( circuit.min_req_cond_current_1, circuit.min_req_cond_current_2 );
```

For OCPD calculations, DC uses #3, and SC uses #1.

```
circuit.min_req_OCPD_current = sf.if( circuit.power_type === 'DC', circuit.min_req_cond_current_3,
circuit.min_req_cond_current_1);
```

For strings per MPP tracker of 2 or less, or for inverters with built in OCPD, additional DC OCPD is not required. The AC circuits do require OCPD at the panel.

```
circuit.OCPD_required = sf.index( [false, false, true ], circuit.id );
circuit.ocpd_type = sf.index( ['NA', 'PV Fuse', 'Circuit Breaker'], circuit.id );
```

Choose the OCPD that is greater or equal to the minimum required current.

```
// Use Table 9, lookup: circuit.min_req_OCPD_current, find the next highest or matching value, return the index column.
circuit.OCPD = sf.lookup( circuit.min_req_OCPD_current, tables[9], 0, true, true);
if( circuit_name === 'inverter ac output circuit' ){ inverter.OCPD = circuit.OCPD; }
```

Choose the conductor with a current rating that is greater than the OCPD rating from NEC table 310.15(B)(16). NEC chapter 9 table 8 provides more details on the conductor. For DC circuits, 10 AWG wire is used as a best practice.

```
circuit.min req cond current = sf.if( circuit.OCPD required, circuit.OCPD, circuit.min req OCPD current );
// Use Table 4, lookup: circuit.min req cond current, find the next highest value, return the index column.
circuit.conductor current = sf.lookup( circuit.min req cond current, tables[4], 0, true);
// Use Table 4, lookup: circuit.conductor current, return the first column.
circuit.conductor_size_min = sf.lookup( circuit.conductor_current, tables[4] );
if( circuit_name === 'exposed source circuit wiring' ){
  circuit.conductor size min = '10';
if( circuit name === 'pv dc source circuits' ){
  circuit.conductor_size_min = '10';
if( circuit name === 'inverter ac output circuit' ){
  if( circuit.OCPD === 15){
    circuit.conductor size min = '14';
  } else if( circuit.OCPD === 20){
    circuit.conductor size min = '12';
  } else if( circuit.OCPD === 25){
    circuit.conductor_size_min = '10';
  } else if( circuit.OCPD === 30){
    circuit.conductor_size_min = '10';
// Use Table 5, lookup: circuit.conductor_size_min, return the first column.
circuit.conductor current = sf.lookup( circuit.conductor size min, tables[5], 1);
// Correct conductor current for temperature and conduit fill.
circuit.conductor_current_cor = circuit.conductor_current * circuit.temp_correction_factor * circuit.conductors_adj_factor; // Use Table 6, lookup: circuit.conductor_size_min, return the first column.
circuit.conductor_strands = sf.lookup( circuit.conductor_size_min, tables[6], 1 );
// Use Table 6, lookup: circuit.conductor_size_min, return the second column.
circuit.conductor_diameter = sf.lookup( circuit.conductor_size_min, tables[6], 2 );
circuit.min_req_conduit_area_40 = circuit.total_conductors * ( 0.25 * PI() * math.pow(circuit.conductor_diameter, 2) );
```

The NEC article 352 and 358 tables are used to find a conduit with a sufficent 40% fill rate to hold the total conductor size for all the conductors.

```
// Use Table 7, lookup: circuit.min_req_conduit_area_40, find the next highest value, return the first column.
circuit.min_conduit_size_PVC_80 = sf.lookup( circuit.min_req_conduit_area_40, tables[7], 1, true );
// Use Table 8, lookup: circuit.min_req_conduit_area_40, find the next highest value, return the first column.
circuit.min_conduit_size_EMT = sf.lookup( circuit.min_req_conduit_area_40, tables[8], 1, true );
circuit.min_conduit_size = circuit.min_conduit_size_EMT;
```

Select further wire details based on code requirements and best practices.

Exposed source circuit wiring:

- Conductor: 'DC+/DC-, EGC'
- · Location: 'Free air'
- Material: 'CU'
- Type: 'PV Wire, bare'
- Volt rating: 600
- Wet temp rating: 90
- Conduit type: 'NA'

PV DC source circuits:

- Conductor: 'DC+/DC-, EGC'
- Location: 'Conduit/Exterior'
- Material: 'CU'
- Type: 'THWN-2'
- Volt rating: 600
- Wet temp rating: 90
- Conduit type: 'Metallic'

Inverter ac output circuit:

- Conductor: 'L1/L2, N, EGC'
- Location: 'Conduit/Interior'
- Material: 'CU'
- Type: 'THWN-2'
- Volt rating: 600
- Wet temp rating: 90
- Conduit type: 'Metallic'

```
circuit.conductor = sf.index( ['DC+/DC-, EGC', 'DC+/DC-, EGC', 'L1/L2, N, EGC'], circuit.id );
circuit.location = sf.index( ['Free air', 'Conduit/Exterior', 'Conduit/Interior'], circuit.id );
circuit.material = 'CU';
circuit.type = sf.index( ['PV Wire, bare', 'THWN-2'], circuit.id );
circuit.volt_rating = 600;
circuit.wet_temp_rating = 90;
circuit.conduit_type = sf.index( ['NA', 'Metallic', 'Metallic'], circuit.id );

//////
// cleanup for display
if( ! circuit.0CPD_required ){
    circuit.ocpd_type = '-';
    circuit.ocpd_type = '-';
    circuit.conductor_size_min = circuit.conductor_size_min + ', ' + circuit.conductor_size_min + ', ' +
circuit.conductor_size_min;
//////
});
```

Interconnection

At least one of the following checks must not fail:

- The sum of 125 percent of the inverter(s) output circuit current and the rating of the overcurrent device protecting the busbar exceeded the ampacity of the busbar.
- The sum of 125 percent of the inverter(s) output circuit current and the rating of the overcurrent device protecting the busbar exceeded 120 percent of the ampacity of the busbar.
- The sum of the ampere ratings of all overcurrent devices on panelboards exceeded the ampacity of the busbar.

```
interconnection.inverter_output_cur_sum = interconnection.inverter_output_cur_sum || inverter.max_ac_output_current;
interconnection.inverter_ocpd_dev_sum = interconnection.inverter_ocpd_dev_sum || inverter.0CPD;
interconnection.max_ac_current = inverter.max_ac_output_current;
interconnection.max_ac_current_125 = interconnection.max_ac_current * 1.25;

interconnection.check_1 = ( ( interconnection.inverter_output_cur_sum * 1.25 ) + interconnection.supply_ocpd_rating ) >
interconnection.bussbar_rating;
interconnection.check_2 = ( interconnection.inverter_output_cur_sum * 1.25 ) + interconnection.supply_ocpd_rating >
interconnection.bussbar_rating * 1.2;
interconnection.check_3 = ( interconnection.inverter_ocpd_dev_sum + interconnection.load_breaker_total ) >
interconnection.bussbar_rating;
error_check.interconnection_bus_pass = sf.and( interconnection.check_1, interconnection.check_2, interconnection.check_3 );
// If error check is true, flag system design failure, and report notice to user.
if( error_check.interconnection_bus_pass ) { report_error( 'The busbar is not compliant.' );}
```

The panel's main OCPD must not exceed the bussbar rating.

```
error_check.interconnection_check_4 = interconnection.supply_ocpd_rating > interconnection.bussbar_rating;
// If error check is true, flag system design failure, and report notice to user.
if( error_check.interconnection_check_4 ){ report_error( 'The rating of the overcurrent device protecting the busbar exceeds the rating of the busbar. ' );}
```