# The Memory Hierarchy

15-213: Introduction to Computer Systems 11<sup>th</sup> Lecture, October 4, 2016

#### **Instructor:**

Phil Gibbons

# **Today**

- Storage technologies and trends
- Locality of reference
- Caching in the memory hierarchy

# Random-Access Memory (RAM)

#### Key features

- RAM is traditionally packaged as a chip.
- Basic storage unit is normally a cell (one bit per cell).
- Multiple RAM chips form a memory.

#### RAM comes in two varieties:

- SRAM (Static RAM)
- DRAM (Dynamic RAM)

# **SRAM vs DRAM Summary**

	Trans. per bit	Access time	Needs refresh?	Needs EDC?	Cost	Applications
SRAM	4 or 6	1X	No	Maybe	100x	Cache memories
DRAM	1	10X	Yes	Yes	1X	Main memories, frame buffers

## **Enhanced DRAMs**

- Basic DRAM cell has not changed since its invention in 1966.
  - Commercialized by Intel in 1970.
- DRAM cores with better interface logic and faster I/O:
  - Synchronous DRAM (SDRAM)
    - Uses a conventional clock signal instead of asynchronous control
    - Allows reuse of the row addresses (e.g., RAS, CAS, CAS, CAS)
  - Double data-rate synchronous DRAM (DDR SDRAM)
    - Double edge clocking sends two bits per cycle per pin
    - Different types distinguished by size of small prefetch buffer:
      - DDR (2 bits), DDR2 (4 bits), DDR3 (8 bits)
    - By 2010, standard for most server and desktop systems
    - Intel Core i7 supports DDR3 and DDR4 SDRAM

## **Nonvolatile Memories**

#### DRAM and SRAM are volatile memories

Lose information if powered off.

## Nonvolatile memories retain value even if powered off


- Read-only memory (ROM): programmed during production
- Programmable ROM (PROM): can be programmed once
- Eraseable PROM (EPROM): can be bulk erased (UV, X-Ray)
- Electrically eraseable PROM (EEPROM): electronic erase capability
- Flash memory: EEPROMs. with partial (block-level) erase capability
  - Wears out after about 100,000 erasings

#### Uses for Nonvolatile Memories

- Firmware programs stored in a ROM (BIOS, controllers for disks, network cards, graphics accelerators, security subsystems,...)
- Solid state disks (replace rotating disks in thumb drives, smart phones, mp3 players, tablets, laptops,...)
- Disk caches


# **Traditional Bus Structure Connecting CPU and Memory**

- A bus is a collection of parallel wires that carry address, data, and control signals.
- Buses are typically shared by multiple devices.




# **Memory Read Transaction (1)**

CPU places address A on the memory bus.




# **Memory Read Transaction (2)**

Main memory reads A from the memory bus, retrieves word x, and places it on the bus.




# **Memory Read Transaction (3)**

CPU read word x from the bus and copies it into register %rax.




# **Memory Write Transaction (1)**

CPU places address A on bus. Main memory reads it and waits for the corresponding data word to arrive.




# **Memory Write Transaction (2)**

CPU places data word y on the bus.



# **Memory Write Transaction (3)**

Main memory reads data word y from the bus and stores it at address A.



## What's Inside A Disk Drive?





Image courtesy of Seagate Technology


# **Disk Geometry**

- Disks consist of platters, each with two surfaces.
- Each surface consists of concentric rings called tracks.
- Each track consists of sectors separated by gaps.



# Disk Geometry (Multiple-Platter View)

Aligned tracks form a cylinder.




# **Disk Capacity**

- Capacity: maximum number of bits that can be stored.
  - Vendors express capacity in units of gigabytes (GB), where
     1 GB = 10<sup>9</sup> Bytes.
- Capacity is determined by these technology factors:
  - Recording density (bits/in): number of bits that can be squeezed into a 1 inch segment of a track.
  - Track density (tracks/in): number of tracks that can be squeezed into a 1 inch radial segment.
  - Areal density (bits/in²): product of recording and track density.

# **Recording zones**

- Modern disks partition tracks into disjoint subsets called recording zones
  - Each track in a zone has the same number of sectors, determined by the circumference of innermost track.
  - Each zone has a different number of sectors/track, outer zones have more sectors/track than inner zones.
  - So we use average number of sectors/track when computing capacity.



# **Computing Disk Capacity**

```
Capacity = (# bytes/sector) x (avg. # sectors/track) x (# tracks/surface) x (# surfaces/platter) x (# platters/disk)
```

#### **Example:**


- 512 bytes/sector
- 300 sectors/track (on average)
- 20,000 tracks/surface
- 2 surfaces/platter
- 5 platters/disk

```
Capacity = 512 x 300 x 20,000 x 2 x 5
= 30,720,000,000
= 30.72 GB
```


# **Disk Operation (Single-Platter View)**

The disk surface The read/write *head* spins at a fixed is attached to the end rotational rate of the arm and flies over the disk surface on a thin cushion of air. spindle By moving radially, the arm can position the read/write head over any track.

# **Disk Operation (Multi-Platter View)**




# Disk Structure - top view of single platter



Surface organized into tracks


**Tracks divided into sectors** 

## **Disk Access**




## Head in position above a track

## **Disk Access**




## **Rotation is counter-clockwise**

## **Disk Access – Read**



## About to read blue sector


## **Disk Access – Read**



After **BLUE** read

## After reading blue sector


## **Disk Access - Read**



After **BLUE** read


## Red request scheduled next

## Disk Access – Seek




Seek to red's track

# **Disk Access – Rotational Latency**




Wait for red sector to rotate around

## Disk Access – Read



## **Complete read of red**

# **Disk Access – Service Time Components**



## **Disk Access Time**

## Average time to access some target sector approximated by:

- $T_{access} = T_{avg seek} + T_{avg rotation} + T_{avg transfer}$
- Seek time (T<sub>avg seek</sub>)
  - Time to position heads over cylinder containing target sector.
  - Typical T<sub>avg seek</sub> is 3—9 ms
- Rotational latency (T<sub>avg rotation</sub>)
  - Time waiting for first bit of target sector to pass under r/w head.
  - $T_{avg\ rotation} = 1/2 \times 1/RPMs \times 60 \sec/1 min$
  - Typical T<sub>avg rotation</sub> = 7,200 RPMs
- Transfer time (T<sub>avg transfer</sub>)
  - Time to read the bits in the target sector.
  - T<sub>avg transfer</sub> = 1/RPM x 1/(avg # sectors/track) x 60 secs/1 min.

# **Disk Access Time Example**

#### Given:

- Rotational rate = 7,200 RPM
- Average seek time = 9 ms.
- Avg # sectors/track = 400.

#### Derived:

- $\blacksquare$   $\mathsf{T}_{\mathsf{avg\ rotation}} =$
- $T_{avg transfer} =$
- $T_{access} =$

#### Average time to access some target sector approximated by:

- Seek time (T<sub>avg seek</sub>)
  - Time to position heads over cylinder containing target sector.
  - Typical T<sub>avg seek</sub> is 3—9 ms

#### ■ Rotational latency (T<sub>avg rotation</sub>)

- Time waiting for first bit of target sector to pass under r/w head.
- $T_{avg rotation} = 1/2 \times 1/RPMs \times 60 sec/1 min$
- Typical T<sub>avg rotation</sub> = 7,200 RPMs

#### **■ Transfer time (T**<sub>avg transfer</sub>)

- Time to read the bits in the target sector.
- T<sub>avg transfer</sub> = 1/RPM x 1/(avg # sectors/track) x 60 secs/1 min.

# **Disk Access Time Example**

#### Given:

- Rotational rate = 7,200 RPM
- Average seek time = 9 ms.
- Avg # sectors/track = 400.

#### Derived:

- $T_{avg\ rotation} = 1/2\ x\ (60\ secs/7200\ RPM)\ x\ 1000\ ms/sec = 4\ ms$ .
- $T_{avg\ transfer} = 60/7200\ RPM\ x\ 1/400\ secs/track\ x\ 1000\ ms/sec = 0.02\ ms$
- $T_{access} = 9 \text{ ms} + 4 \text{ ms} + 0.02 \text{ ms}$


## Important points:

- Access time dominated by seek time and rotational latency.
- First bit in a sector is the most expensive, the rest are free.
- SRAM access time is about 4 ns/doubleword, DRAM about 60 ns
  - Disk is about 40,000 times slower than SRAM,
  - 2,500 times slower then DRAM.


# **Logical Disk Blocks**

- Modern disks present a simpler abstract view of the complex sector geometry:
  - The set of available sectors is modeled as a sequence of b-sized logical blocks (0, 1, 2, ...)
- Mapping between logical blocks and actual (physical) sectors
  - Maintained by hardware/firmware device called disk controller.
  - Converts requests for logical blocks into (surface,track,sector) triples.
- Allows controller to set aside spare cylinders for each zone.
  - Accounts for the difference in "formatted capacity" and "maximum capacity".


# I/O Bus




# Reading a Disk Sector (1)




# Reading a Disk Sector (2)



# Reading a Disk Sector (3)



# Solid State Disks (SSDs)



- Pages: 512KB to 4KB, Blocks: 32 to 128 pages
- Data read/written in units of pages.
- Page can be written only after its block has been erased
- A block wears out after about 100,000 repeated writes.

## **SSD Performance Characteristics**

Sequential read tput 550 MB/s Sequential write tput 470 MB/s Random read tput 365 MB/s Random write tput 303 MB/s Avg seq read time 50 us Avg seq write time 60 us

#### Sequential access faster than random access

Common theme in the memory hierarchy

#### Random writes are somewhat slower

- Erasing a block takes a long time (~1 ms)
- Modifying a block page requires all other pages to be copied to new block
- In earlier SSDs, the read/write gap was much larger.

Source: Intel SSD 730 product specification.

# **SSD Tradeoffs vs Rotating Disks**

#### Advantages

■ No moving parts → faster, less power, more rugged

## Disadvantages

- Have the potential to wear out
  - Mitigated by "wear leveling logic" in flash translation layer
  - E.g. Intel SSD 730 guarantees 128 petabyte (128 x 10<sup>15</sup> bytes) of writes before they wear out
- In 2015, about 30 times more expensive per byte

## Applications

- MP3 players, smart phones, laptops
- Beginning to appear in desktops and servers

# The CPU-Memory Gap

The gap widens between DRAM, disk, and CPU speeds.

