Interfacing a Hard Disk Drive to an AT91RM9200 Microcontroller

1. Scope

This Application Note describes the AT91RM9200 hardware and software interface for a hard disk drive. The AT91RM9200 embeds a CompactFlash® Glue Logic that can be adapted to support such a peripheral.

1.1 Reference Documents

The following table gives the references of the documents and their denominations in this Application Note.

 Table 1-1.
 Reference Document Table

Owner - Reference	Denomination
Atmel Literature Number 1768	AT91RM9200 Datasheet
	AT Attachment Interface Document, American National Standards Institute, X3.221-1994



AT91 ARM[®]
Thumb[®]
Microcontrollers

Application Note

6023B-ATARM-06-Jan-06





2. Hardware Interface

2.1 External Bus Interface Signals

The External Bus Interface integrates circuitry to interface with CompactFlash devices using Attribute, Memory and I/O modes. Most of these signals can be used to connect a hard disk drive to the AT91RM9200.

Note: For a full description of external bus interface signals, refer to the EBI Programmer Datasheet.

This document only contains information relevant to accessing a hard disk drive.

Note: The External Bus Interface does not allow DMA accesses.

Table 2-1. EBI Signals for HDD Support

EBI Name	HDD Name	Function	Туре	Active Level
CFIOR	_IOR	HDD I/O Read Signal	Output	Low
CFIOW	_IOW	HDD I/O Write Signal	Output	Low
CFRNW		HDD Read Not Write	Output	
CFCS		HDD Chip select	Output	Low
A0-A2	A0-A2	Address Bus	Output	
D0-D15	D0-D15	Data Bus	Input/Output	
NWAIT	IORDY	HDD Ready Signal	Input	High

2.2 Other AT91RM9200 Signals

In addition to the External Bus interface signal, the hard disk drive requires the signals shown in Table 2-2.

 Table 2-2.
 Other AT91RM9200 Signals for HDD Support


AT91RM9200 Name	HDD Name	Function	Туре	Active Level
PC11-PC12	_CS0CS1	HDD Chip Select	Output	Low
PC5 ⁽¹⁾	_RESET	HDD Reset	Output	Low

Note: 1. Or any free PIO.

Other HDD signals are not handled by the AT91RM9200 microcontroller.

2.3 HDD Application Example

Figure 2-1. HDD Application Example







3. Software Interface

3.1 External Bus Interface Signal Handling

The EBI CompactFlash Glue Logic integrates a fourth memory space that can be accessed through NCS4 (i.e., between 0x5000 0000 and 0x5FFF FFFF).

This memory space, True IDE Mode Space, is intended to access CompactFlash in True IDE Mode (Hard Disk Drive, so).

Table 3-1. Address Map

	True IDE Mode Space
Offset 0x00C0 0000	
	I/O Mode Space
Offset 0x0080 0000	
	Common Memory Mode Space
Offset 0x0040 0000	
	Attribute Memory Mode Space
Offset 0x0000 0000	

To use the CompactFlash Glue Logic feature, the following PIOs must be set as peripherals:

- PC6 that enables NWAIT
- PC7 that enables A23
- PC9 that enables A25 CFRNW
- PC10 that enables NCS4 CFCS

Moreover, the CompactFlash Glue Logic must be activated via the Chip Select 4 Assignment Field in the EBI User Interface.

3.2 Handling Other AT91RM9200 Signals

In Attribute, Memory and I/O modes, PC11 - PC12 signals that are connected to CS0 - CS1 HDD signals are used by the EBI to manage CFCE1 - CFCE2 to enable upper-byte and lower-byte access on the data bus of the CompactFlash.

As this behavior is not compatible with IDE accesses, these signals must be configured as PIOs, i.e., PC11 and PC12.

PC11 and PC12 levels must be set by software before the access to the HDD.

Application Note

Data Bus Width must be set depending on the access needed. See Table 3-2.

Table 3-2. Signals Depending on Access Type

Access	PC11	PC12	Offset	D[15:8]	D[7:0]	SMC_CSR4 (DBW)
Byte R/W Task File Register Access	0	1	1 - 7h	Don't Care/High Z	Odd/Even Byte	8-bit
Half-word R/W Task File Data Register Access	0	1	0h	Odd Byte	Even Byte	16-bit
Byte W Control Register Byte R Alt Status Register Byte R/W Drive Access Register	1	0	6 - 7h	Don't Care/High Z	Odd/Even Byte	8-bit

3.3 Timings

The SMC2_CSR4 Chip Select is to be programmed depending on the HDD timing accesses. Typical values are listed in Table 3-3.

Table 3-3. Timing Parameter Values

Parameter	Value
NWS	10
TDF	0
RWS	5
RWH	3

3.4 Software Example

An example HDD driver describing signal management with the AT91 software package can be downloaded from the Atmel web site http://www.atmel.com.

4. Warranty

All delivered sources are free of charge and can be copied or modified without authorization.

The software is delivered "AS IS" without warranty or condition of any kind, either express, implied or statutory. This includes without limitation any warranty or condition with respect to merchantability or fitness for any particular purpose, or against the infringements of intellectual property rights of others.



5. Revision History

Table 5-1.Revision History

Document Ref.	Comments	Change Request
6023A	First issue.	
6023B	Updated referenced documents in Table 1-1, "Reference Document Table," on page 1.	04-312



Atmel Corporation

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311

Fax: 1(408) 487-2600

Regional Headquarters

Europe

Atmel Sarl Route des Arsenaux 41 Case Postale 80 CH-1705 Fribourg Switzerland

Tel: (41) 26-426-5555 Fax: (41) 26-426-5500

Asia

Room 1219 Chinachem Golden Plaza 77 Mody Road Tsimshatsui East Kowloon Hong Kong

Tel: (852) 2721-9778 Fax: (852) 2722-1369

Japan

9F, Tonetsu Shinkawa Bldg. 1-24-8 Shinkawa Chuo-ku, Tokyo 104-0033 Japan

Tel: (81) 3-3523-3551 Fax: (81) 3-3523-7581

Atmel Operations

Memory

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311 Fax: 1(408) 436-4314

Microcontrollers

2325 Orchard Parkway San Jose, CA 95131, USA Tel: 1(408) 441-0311 Fax: 1(408) 436-4314

La Chantrerie BP 70602 44306 Nantes Cedex 3, France

Tel: (33) 2-40-18-18-18 Fax: (33) 2-40-18-19-60

ASIC/ASSP/Smart Cards

Zone Industrielle 13106 Rousset Cedex, France Tel: (33) 4-42-53-60-00

Fax: (33) 4-42-53-60-01

1150 East Cheyenne Mtn. Blvd. Colorado Springs, CO 80906, USA

Tel: 1(719) 576-3300 Fax: 1(719) 540-1759

Scottish Enterprise Technology Park Maxwell Building East Kilbride G75 0QR, Scotland

Tel: (44) 1355-803-000 Fax: (44) 1355-242-743

RF/Automotive

Theresienstrasse 2 Postfach 3535 74025 Heilbronn, Germany

Tel: (49) 71-31-67-0 Fax: (49) 71-31-67-2340

1150 East Cheyenne Mtn. Blvd. Colorado Springs, CO 80906, USA

Tel: 1(719) 576-3300 Fax: 1(719) 540-1759

Biometrics/Imaging/Hi-Rel MPU/ High Speed Converters/RF Datacom

Avenue de Rochepleine

BP 123

38521 Saint-Egreve Cedex, France

Tel: (33) 4-76-58-30-00 Fax: (33) 4-76-58-34-80



Literature Requests www.atmel.com/literature

Disclaimer: The information in this document is provided in connection with Atmel products. No license, express or implied, by estoppel or otherwise, to any intellectual property right is granted by this document or in connection with the sale of Atmel products. EXCEPT AS SET FORTH IN ATMEL'S TERMS AND CONDITIONS OF SALE LOCATED ON ATMEL'S WEB SITE, ATMEL ASSUMES NO LIABILITY WHATSOEVER AND DISCLAIMS ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY RELATING TO ITS PRODUCTS INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT. IN NO EVENT SHALL ATMEL BE LIABLE FOR ANY DIRECT, INDIRECT, CONSEQUENTIAL, PUNITIVE, SPECIAL OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, OR LOSS OF INFORMATION) ARISING OUT OF THE USE OR INABILITY TO USE THIS DOCUMENT, EVEN IF ATMEL HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Atmel makes no representations or warranties with respect to the accuracy or completeness of the contents of this document and reserves the right to make changes to specifications and product descriptions at any time without notice. Atmel does not make any commitment to update the information contained herein. Unless specifically provided otherwise, Atmel products are not suitable for, and shall not be used in, automotive applications. Atmel's products are not intended, authorized, or warranted for use as components in applications intended to support or sustain life.

© Atmel Corporation 2006. All rights reserved. Atmel[®], logo and combinations thereof, Everywhere You Are[®] and others are registered trademarks or trademarks of Atmel Corporation or its subsidiaries. ARM[®], the ARMPowered logo[®] and others are the registered trademarks of ARM Ltd. Other terms and product names may be trademarks of others.

