# RML approach to design


### **Common Library**

The main idea of RMl is reuse common components in different projects:

The Common Library consists common interfaces and implementation for:

- CortexM4 Hardware modules
- Registers wrapper
- Diagnostic
- Nv parameters
- Simple Tasker (Rtos)
- Rtos wrapper for third part RTOS
- Some other specific things like Filter, Duration calculation and so on

It allows RML to use components in their applications without any modification. The application just configure the components and uses it.



Example of configuring the Hardware

Example of configure the Rtos Timers:

```
// rtostimersconfig.hpp
#pragma once
#include "rtostimer.hpp" // For RtosTimer
#include "rtostimerservice.hpp" // For RtosTimerService
#include "tasksconfig.hpp" // For led1Task
//Timer for Led1 task
using tLed1Timer = RtosTimer<</pre>
  led1Task,
  1000U, //time in ms
  static_cast<tTaskEvents>(Led1TaskEvents::togglePin)> ;
//Timer for MeasurementDirector task
using tMeasTimer = RtosTimer<</pre>
  measTask,
  100U, //time in ms
  static_cast<tTaskEvents>(MeasurementDirectorTaskEvents::calculate)> ;
//Timer for Frequency Transmition task
using tFrequencyTransmissionTimer = RtosTimer<</pre>
  frequencyTransmissionTask,
  1000U, //time in ms
  static_cast<tTaskEvents>(FrequencyTransmissionEvents::transmitFrequency)> ;
using tRtosTimerService =
  RtosTimerService<tLed1Timer, tMeasTimer, tFrequencyTransmissionTimer>;
```

Example of tasks configuration:

```
//Filename : tasksconfig.hpp
#pragma once
#include "itask.hpp"
                                                // For ITask
#include "rtos.hpp"
                                                // For Rtos
#include "testtasks.hpp"
                                                // For Led1Task, Led2Task
#include "measurementdirector.hpp"
                                                // For MeasurementDirector
#include "measurementdirectorconfig.hpp"
                                                // For SensorBoardFrequencyProcessing
#include "frequencytransmissiondirector.hpp"
                                                // For FrequencyTransmissionDirector
//Tasks: global objects
inline Led1Task led1Task ;
inline MeasurementDirector<SensorBoardFrequencyProcessing> measTask ;
inline FrequencyTransmissionDirector frequencyTransmissionTask ;
enum class TaskPriorities : tTaskPriority
  lowest = 1U,
  low = 2U,
  medium = 3U,
  high = 4U,
 highest = 5U
} ;
//Configuration of Tcb block of task Led1
inline constexpr TaskControlBlock tcb1
{
  &led1Task,
  static_cast<tTaskPriority>(TaskPriorities::low)
};
//Configuration of Tcb block of MeasurementDirector task
inline constexpr TaskControlBlock tcb2
{
  &measTask,
  static_cast<tTaskPriority>(TaskPriorities::low)
} ;
//Configuration of Tcb block of Frequency Transmission task
inline constexpr TaskControlBlock tcb3
{
  &frequencyTransmissionTask,
  static_cast<tTaskPriority>(TaskPriorities::low)
} ;
using tRtos = Rtos<&tcb1, &tcb2, &tcb3> ;
```

And use this:

```
int main()
{
   tUart::Enable();
   tUart::SetBaudRate(tU32{9600U});
   tUart::SetParity(UartParity::none);
   tUart::SetWordLength(UartWordLength::eightDataBits);
   tUart::SetStopBitsNumber(UartStopBits::oneBit);
   tUart::EnableTransmitter();

//Start three tasks: frequencyTransmissionTask, measTask, led1Task
   tRtos::Start();

return 0;
}
```

All design used static polymorphism, but it is possible to use the traditional approach with objects

### **Common Library advantages**

- Save a lot of efforts.
- Reduce risk of mistakes and bug
- · Less manual work

Example

#### Статическая подписка

Позволяет на этапе компиляции подписать необходимые объекты или классы на события без лишнего кода и гемора.


```
template<tU8 size>
class cRtosHwTimer
{
   public:
      virtual void isrHandler(void);
      void subscribe(cHwTimerSubscriber* pSubscriber);
   private:
      cRtosHwTimer(const cRtosHwTimer& other);
      const cRtosHwTimer& operator=(const cRtosHwTimer& other);
      static const tU8 maxSubscribersNumber;
      cHwTimerSubscriber* subscribers[size];
      tU8 subscribersNumber;
};
// ненужный метод вообще
template<tU8 size>
void cRtosHwTimer<size>::subscribe(cHwTimerSubscriber* pSubscriber)
{
   ASSERT(subscribersNumber < maxSubscribersNumber); // проверка на длину массива
   subscribers[subscribersNumber] = pSubscriber; //дурацкая подписка
   subscribersNumber++; //лишний счетчик
}
template<tU8 size>
void cRtosHwTimer<size>::isrHandler(void)
{
   for(tU8 index = (tU8)0; index < subscribersNumber; index++)</pre>
      subscribers[index]->timerExpiredNotify();
   }
}
//затем для каждого таймера нужно вызвать метод для подписки. Лишний код и работа
// Мозг можно сломать....
cRtosTimerService::cRtosTimerService(void) : ...
{
   cRtosHwTimer<TIMER MULTIPLE SUBSCRIBERS>& oHalfSecondTimer = oRtosHwTimerService
.getTimerHalfSecond();
   oHalfSecondTimer.subscribe(&timerSensorTemperature);
   oHalfSecondTimer.subscribe(&timerTaskExecutionMonitor);
   oHalfSecondTimer.subscribe(&timerLoiDirector);
   oHalfSecondTimer.subscribe(&timerLoiDirectorMenuMode);
   oHalfSecondTimer.subscribe(&timerLoiDirectorMenuModeExitTimeout);
   oHalfSecondTimer.subscribe(&oTestFixedCurrent);
}
```

```
template <auto8 ...Timers> //если типы то template <typename ...Timers>
struct TaskerTimerService {
    static void OnSystemTick() //Timer interrupt handler
    {
        (Timers.timerExpiredNotify(), ...); //notify all subsribers
    }
};

//Subscribe timers of tasks on service of SystemTimer.
using tRtosTimerService = TaskerTimerService<timerSensorTemperature,
timerTaskExecutionMonitor, timerLoiDirector, timerLoiDirectorMenuMode,
timerLoiDirectorMenuModeExitTimeout>;
```

## Register approach

RML does not used the CMSIS at all. Instead of that is used registers which are generated from \*.svd files, base on the article https://habr.com/ru/post/459642/. It allows to have safe access to the registers.



And example of usage

```
Register wrappers are static classes that provide methods to read/write values to/from
specified memory address.
Do not use these classes directly - use special generator tool to convert SVD file to set of
registers descriptions of device.
Example of generated description of peripheral TIM2:
struct Tim2
struct Cr1: public ReadWriteRegister<32, 0x40000000>
 using Ckd = ReadWriteRegisterField<Tim2::Cr1, 8, 2>;
 using Arpe = ReadWriteRegisterField<Tim2::Cr1, 7, 1>;
 using Cms = ReadWriteRegisterField<Tim2::Cr1, 5, 2>;
 using Dir = ReadWriteRegisterField<Tim2::Cr1, 4, 1>;
 using Opm = ReadWriteRegisterField<Tim2::Cr1, 3, 1>;
 using Urs = ReadWriteRegisterField<Tim2::Cr1, 2, 1>;
 using Udis = ReadWriteRegisterField<Tim2::Cr1, 1, 1>;
 using Cen = ReadWriteRegisterField<Tim2::Cr1, 0, 1>;
};
};
Example of usage:
int main()
using tCr1 = Tim2::Cr1::Type;
 auto cr1Value = Tim2::Cr1::Read();
Tim2::Cr1::Cen::Write(tCr1(0));
Tim2::Cr1::Ckd::Write(tCr1(3));
Tim2::Cr1::Cen::Write(tCr1(1));
 auto currentCms = Tim2::Cr1::Cms::Read();
```

In the begginig RML uses CMSIS and this how they works with registers:

And then RML decided to use autogenerated registers from svd file:

```
Gpioa::Afrh::Afrh11::Write(11U) ;

Rcc::Apb1Enr::Tim2En::Write(RccApb1EnrTim2EnValues::clockEnabled) ;
Rcc::Apb1Enr::Tim5En::Write(RccApb1EnrTim5EnValues::clockEnabled) ;
Rcc::Apb1Enr::Uart4En::Write(RccApb1EnrUart4EnValues::clockEnabled) ;
NvicManager::EnableIrq<Irqn::tim2>() ;
```

It is possible to use another approach for safety access to the registers: