
Chapter 5 Link Layer and LANs



5: DataLink Layer

Chapter 5: The Data Link Layer

Our goals:

- □ understand principles behind data link layer services: 재전송 없이 고치는 것
 - o error detection, correction
 - o sharing a broadcast channel multiple access
 - link layer addressing
- o reliable data transfer, flow control: done!
- □ instantiation and implementation of various link layer technologies

Link Layer

- 5.1 Introduction and services
- 5.2 Error detection and correction
- 5.3 Multiple access protocols
- □ 5.4 Link-layer Addressing
- □ 5.5 Fthernet

- □ 5.6 Link-layer switches
- □ 5.7 PPP
- 5.8 Link virtualization: ATM, MPLS

텍스트

5: DataLink Layer

5-3

인접한 노드늘을 연결하기 위한 모든 것 ▼ > 무선, 유선 둘 다 가능.

Link Layer: Introduction Some terminology: hosts and routers are nodes communication channels that connect adjacent nodes along communication path are links wired links wireless links LANs layer-2 packet is a frame, encapsulates datagram data-link layer has responsibility of transferring datagram from one node to adjacent node over a link 5: DataLink Layer 5-4

Tip 각각의 layer 마다 책임지는 부분이 다름 트랜스포트, 네트워크, 링크 계층의 책임차이를 알아 볼 것.

Link layer: context

- datagram transferred by different link protocols over different links:
 - e.g., Ethernet on first link, frame relay on intermediate links, 802.11 on last link
- each link protocol provides different services
 - e.g., may or may not provide rdt over link

transportation analogy

- trip from Princeton to Lausanne
 - limo: Princeton to JFK
 - o plane: JFK to Geneva
 - o train: Geneva to Lausanne
- □ tourist = datagram
- transport segment = communication link
- transportation mode = link layer protocol
- travel agent = routing
 algorithm

5: DataLink Layer

5-5

MAC주소(물리적 주소): 하나의 링크 내에서 식별하기 위한 주소 ex) 80 e6 50 0f 3c a0 IP주소: 네트워크 계층에서 식별하기 위해(호스트를 구별할때) 사용하는 주소 ex) 203,253,22,72

Link Layer Services

- framing, link access:
 - o encapsulate datagram into frame, adding header, trailer
 - channel access if shared medium
 - "MAC" addresses used in frame headers to identify source, dest
 - · different from IP address!
- □ reliable delivery between adjacent nodes
 - we learned how to do this already (chapter 3)!
 - seldom used or low bit-error link (fiber, some twisted pair)
 - o wireless links: high error rates
 - · Q: why both link-level and end-end reliability?

이건 소재를 어떻게 쓰느냐의 문제이므로

보통 에러발생비율이 작음

>즉 , 링크 자체로 보면 에러확률이 적기 때문에

굳이 쓰지 않음.

Link Layer Services (more)

- □ flow control:
 - o pacing between adjacent sending and receiving nodes
- error detection
 - o errors caused by signal attenuation, maise

FDM을 사용하는데 주파수가 겹처서 혼선, 잡음 발생.

- receiver detects presence of errors:
 - · signals sender for retransmission or drops frame
- error correction:
 - receiver identifies and corrects bit error(s) without resorting to retransmission
- half-duplex and full-duplex
 - with half duplex, nodes at both ends of link can transmit, but not at same time

5: DataLink Layer 5-

5-7

잘못되었다는 것을 아니까 >그냥 고치고 끝냄 재전송 X

수신자가 받을 수 있도록


송신자가 적당히 보내는 것.

목적은 같지만 부분이 다름.


앞쪽에서 배웠던 flow control과는

Where is the link layer implemented?

- in each and every host
- link layer implemented in "adaptor" (aka network interface card NIC)
 - Ethernet card, PCMCI card, 802.11 card
 - implements link, physical layer
- attaches into host's system buses
- combination of hardware, software, firmware



Adaptors Communicating



- sending side:
 - encapsulates datagram in frame
 - adds error checking bits, rdt, flow control, etc.
- receiving side
 - looks for errors, rdt, flow control, etc
 - extracts datagram, passes to upper layer at receiving side

5: DataLink Layer


5-9

Link Layer

- □ 5.1 Introduction and services
- 5.2 Error detection and correction
- □ 5.3Multiple access protocols
- □ 5.4 Link-layer Addressing
- □ 5.5 Ethernet

- □ 5.6 Link-layer switches
- □ 5.7 PPP
- 5.8 Link Virtualization: ATM. MPLS

Error Detection EDC= Error Detection and Correction bits (redundancy) D = Data protected by error checking, may include header fields · Error detection not 100% reliable! protocol may miss some errors, but rarely · larger EDC field yields better detection and correction datagram datagram otherwise all bits in D OK detected ←d data bits-D EDC EDC' bit-error prone link () 5: DataLink Layer 5-11 checksum과 비슷한 역할.



Internet checksum (review)

<u>Goal:</u> detect "errors" (e.g., flipped bits) in transmitted packet (note: used at transport layer *only*)

Sender:

- treat segment contents as sequence of 16-bit integers
- checksum: addition (1's complement sum) of segment contents
- sender puts checksum value into UDP checksum field

Receiver:

- compute checksum of received segment
- check if computed checksum equals checksum field value:
 - NO error detected
 - YES no error detected.
 But maybe errors
 nonetheless?

5: DataLink Laver 5-13

방법: 내가 보낸 것을 G로 나눌경우

> 상대방도 받고나서 G로 나눔

%G ==0 > 에러없음


아니면 에러 있음.

나머지가 0임

CRC

Checksumming: Cyclic Redundancy Check

- view data bits, D, as a binary number
- choose r+1 bit pattern (generator), G
- goal: choose r CRC bits, R, such that
 - <D,R> exactly divisible by G (modulo 2)
 - receiver knows G, divides <D,R> by G. If non-zero remainder: error detected!
 - o can detect all burst errors less than r+1 bits
- widely used in practice (Ethernet, 802.11 WiFi, ATM)





CRC Example

Want:

D.2r XOR R = nG


equivalently:

 $D \cdot 2^r = nG \times R$

equivalently:

if we divide $D \cdot 2^r$ by G, want remainder R

R = remainder $\left[\frac{D \cdot 2^r}{6}\right]$



5: DataLink Layer 5-15

Link Layer

- 5.1 Introduction and services
- 5.2 Error detection and correction
- 5.3Multiple access protocols
- 5.4 Link-layer Addressing
- □ 5.5 Ethernet

- □ 5.6 Link-layer switches
- □ 5.7 PPP
- 5.8 Link Virtualization: ATM, MPLS





multi point links

텍스트

Multiple Access Links and Protocols

Two types of "links":

- point-to-point
 - o PPP for dial-up access
 - o point-to-point link between Ethernet switch and host
- broadcast (shared wire or medium)
 - o old-fashioned Ethernet
 - o upstream HFC
 - 802.11 wireless LAN







shared RF (e.g., 802.11 WiFi)



shared RF (satellite)



humans at a cocktail party (shared air, acoustical)

5: DataLink Layer 5-17

control 이니까 다 합쳐서 읽으면 > multiple access control(mac)

Multiple Access protocols

- □ single shared broadcast channel
- two or more simultaneous transmissions by nodes: interference
- collision if node receives two or more signals at the same time multiple access protocol
- distributed algorithm that determines how nodes share channel, i.e., determine when node can transmit
- communication about channel sharing must use channel itself!
 - o no out-of-band channel for coordination

Ideal Multiple Access Protocol

Broadcast channel of rate R bps

- 1. when one node wants to transmit, it can send at rate R.
- 2. when M nodes want to transmit, each can send at average rate R/M
- 3. fully decentralized:
 - o no special node to coordinate transmissions
 - o no synchronization of clocks, slots
- 4. simple


5: DataLink Layer 5-19

MAC Protocols: a taxonomy

Three broad classes:

- Channel Partitioning
 - divide channel into smaller "pieces" (time slots, frequency, code)
 - o allocate piece to node for exclusive use
- □ Random Access
 - o channel not divided, allow collisions
 - o "recover" from collisions
- "Taking turns"
 - nodes take turns, but nodes with more to send can take longer turns

Channel Partitioning MAC protocols: TDMA TDMA: time division multiple access access to channel in "rounds" each station gets fixed length slot (length = pkt trans time) in each round unused slots go idle example: 6-station LAN, 1,3,4 have pkt, slots 2,5,6 idle



Random Access Protocols

- When node has packet to send
 - o transmit at full channel data rate R.
 - o no a priori coordination among nodes
- two or more transmitting nodes → "collision",
- □ random access MAC protocol specifies:
 - how to detect collisions
 - o how to recover from collisions (e.g., via delayed retransmissions)
- Examples of random access MAC protocols:
 - slotted ALOHA
 - ALOHA
 - O CSMA, CSMA/CD, CSMA/CA

5: DataLink Layer 5-23

1. 충돌을 어떻게 감지?

2. 발생한 충동을 어떻게 복구.


Slotted ALOHA

Assumptions:

- □ all frames same size
- time divided into equal size slots (time to transmit 1 frame)
- nodes start to transmit only slot beginning
- nodes are synchronized
- □ if 2 or more nodes transmit in slot, all nodes detect collision

Operation:

- when node obtains fresh frame, transmits in next
 - o if no collision: node can send new frame in next slot
 - o if collision: node retransmits frame in each subsequent slot with prob. p until success



Slotted Aloha efficiency

Efficiency: long-run fraction of successful slots (many nodes, all with many frames to send)

- suppose: N nodes with many frames to send, each transmits in slot with probability p
- prob that given node has success in a slot = p(1-p)^{N-1}
- □ prob that any node has a success = Np(1-p)^{N-1}


- max efficiency: find p* that maximizes Np(1-p)^{N-1}
- for many nodes, take limit of Np*(1-p*)^{N-1} as N goes to infinity, gives:

Max efficiency = 1/e = .37

At best: channel used for useful transmissions 37% of time!



- □ unslotted Aloha: simpler, no synchronization
- when frame first arrives
 - o transmit immediately
- collision probability increases:
 - \circ frame sent at t_0 collides with other frames sent in $[t_0$ -1, t_0 +1]



간단하지만 slotted ALOHA보다 훨씬 중놀확률이 높음 효율은 아래에도 나오지만 약 0.18로 절반정도에 그침.

Pure Aloha efficiency

P(success by given node) = P(node transmits) ·

P(no other node transmits in $[p_0-1,p_0]$

P(no other node transmits in $[p_0-1,p_0]$

= $p \cdot (1-p)^{N-1} \cdot (1-p)^{N-1}$

 $= p \cdot (1-p)^{2(N-1)}$

... choosing optimum p and then letting n -> infty ...

= 1/(2e) = .18

even worse than slotted Aloha!

CSMA (Carrier Sense Multiple Access)

바쁠때 전송을 미룸.

CSMA: listen before transmit:

If channel sensed idle: transmit entire frame

- □ If channel sensed busy, defer transmission
- □ human analogy: don't interrupt others!

5: DataLink Layer 5-29

CSMA collisions spatial layout of nodes - space collisions can still occur: propagation delay means two nodes may not hear each other's transmission time collision: entire packet transmission time wasted note: role of distance & propagation delay in determining collision probability 5: DataLink Layer 5-30

CSMA/CD (Collision Detection)

CSMA/CD: carrier sensing, deferral as in CSMA

- o collisions detected within short time
- colliding transmissions aborted, reducing channel wastage
- collision detection:
 - easy in wired LANs: measure signal strengths, compare transmitted, received signals
 - difficult in wireless LANs: received signal strength overwhelmed by local transmission strength
- human analogy: the polite conversationalist

5: DataLink Layer 5-31

CSMA/CD collision detection Space Collision detection 5: DataLink Layer 5-32

"Taking Turns" MAC protocols

channel partitioning MAC protocols:

- o share channel efficiently and fairly at high load
- inefficient at low load: delay in channel access,
 1/N bandwidth allocated even if only 1 active node!

Random access MAC protocols

- efficient at low load: single node can fully utilize channel
- o high load: collision overhead


"taking turns" protocols

look for best of both worlds!

5: DataLink Layer 5-33

"Taking Turns" MAC protocols Polling: master node "invites" slave nodes to transmit in turn typically used with master "dumb" slave devices concerns: o polling overhead latency slave 마스터가 죽는 순간 링크가 죽어버림. ◆ o single point of failure (master) 5: DataLink Layer 5-34 station 이라 부른다.

17



Summary of MAC protocols

- channel partitioning, by time, frequency or code
 - Time Division, Frequency Division
- random access (dynamic),
 - o ALOHA, S-ALOHA, CSMA, CSMA/CD
 - carrier sensing: easy in some technologies (wire), hard in others (wireless)
 - o CSMA/CD used in Ethernet
 - o CSMA/CA used in 802.11
- taking turns

_ Avoidance

- o polling from central site, token passing
- Bluetooth, FDDI, IBM Token Ring

Link Layer

- 5.1 Introduction and services
- 5.2 Error detection and correction
- □ 5.3Multiple access protocols
- 5.4 Link-Layer Addressing
- □ 5.5 Fthernet

- □ 5.6 Link-layer switches
- □ 5.7 PPP
- 5.8 Link Virtualization: ATM, MPLS


5: DataLink Layer 5-37

MAC Addresses and ARP

IP주소는 레이어 3 (트랜스포트)에서 사용

- □32-bit IP address:
- mac 주소는 레이어 2(링크)에서 사용
- o network-layer address

- So, mac은 device를 식별하고 ip는 그 위치를 식별함
- o used to get datagram to destination IP subnet >mac 주△ = lan address
- ■MAC (or LAN or physical or Ethernet) address:
 - function: get frame from one interface to another physically-connected interface (same network)
 - 48 bit MAC address (for most LANs)
 - burned in NIC ROM, also sometimes software settable




LAN Address (more)

- MAC address allocation administered by <u>IEEE</u>
- manufacturer buys portion of <u>MAC address</u> space (to assure uniqueness)
- analogy:
 - (a) MAC address: like Social Security Number
 - (b) IP address: like postal address
- MAC flat address → portability
 - o can move LAN card from one LAN to another
- □ IP hierarchical address NOT portable
 - o address depends on IP subnet to which node is attached

ARP: Address Resolution Protocol

Question: how to determine MAC address of B knowing B's IP address?



- Each IP node (host, router) on LAN has ARP table
- ARP table: IP/MAC address mappings for some LAN nodes

< IP address: MAC address: TTL>

 TTL (Time To Live): time after which address mapping will be forgotten (typically 20 min)

5: DataLink Layer 5-41

ARP protocol: Same LAN (network)


- A wants to send datagram to B and B's MAC address not in A's ARP table.
- A broadcasts ARP query packet, containing B's IP address
 - dest MAC address = FF-FF-FF-FF-FF
 - all machines on LAN receive ARP query
- B receives ARP packet, replies to A with its (B's) MAC address
 - frame sent to A's MAC address (unicast)

- A caches (saves) IP-to-MAC address pair in its ARP table until information becomes old (times out)
 - soft state: information that times out (goes away) unless refreshed
- □ ARP is "plug-and-play": 꽂아놓으면 나머지는 알아서.
 - nodes create their ARP tables without intervention from net administrator

5: DataLink Layer 5-42

21

Addressing: routing to another LAN walkthrough: send datagram from A to B via R assume A knows B's IP address 88-B2-2F-54-1A-0F 74-29-9C-E8-FF-55 E6-E9-00-17-BB-4B 222.222.222.221 1A-23-F9-CD-06-9I 111.111.111.111 222.222.22 222.222.222.22 111.111.111.110 111.111.111.112 49-BD-D2-C7-56-2A CC-49-DE-D0-AB-7D ■ two ARP tables in router R, one for each IP network (LAN) 5: DataLink Layer 5-43



Link Layer

- 5.1 Introduction and services
- 5.2 Error detection and correction
- 5.3Multiple access protocols
- □ 5.4 Link-Layer Addressing
- □ 5.5 Ethernet


- □ 5.6 Link-layer switches
- □ 5.7 PPP
- 5.8 Link Virtualization: ATM and MPLS

5: DataLink Layer 5-45


Ethernet


"dominant" wired LAN technology:

- cheap \$20 for NIC
- first widely used LAN technology
- □ simpler, cheaper than token LANs and ATM
- □ kept up with speed race: 10 Mbps 10 Gbps



Metcalfe's Ethernet sketch





Ethernet Frame Structure (more) Addresses: 6 bytes if adapter receives frame with matching destination address, or with broadcast address (eg ARP packet), it passes data in frame to network layer protocol otherwise, adapter discards frame Type: indicates higher layer protocol (mostly IP but others possible, e.g., Novell IPX, AppleTalk) CRC: checked at receiver, if error is detected, frame is dropped Dest. Address Address Data CRC

Type

H렸을때, 신뢰적 데이터 전송 처리는 레이어 4에서 책임.

Ethernet: Unreliable, connectionless

- connectionless: No handshaking between sending and receiving NICs
- □ unreliable: receiving NIC doesn't send acks or nacks to sending NIC
 - stream of datagrams passed to network layer can have gaps (missing datagrams)
 - o gaps will be filled if app is using TCP
 - o otherwise, app will see gaps
- Ethernet's MAC protocol: unslotted CSMA/CD

5: DataLink Layer 5-50

J. DalaLIIIK Laver 5-49

Ethernet CSMA/CD algorithm

- NIC receives datagram from network layer, creates frame
- 2. If NIC senses channel idle, starts frame transmission If NIC senses channel busy, waits until channel idle, then transmits
- 3. If NIC transmits entire frame without detecting another transmission, NIC is done with frame!
- 4. If NIC detects another transmission while transmitting, aborts and sends jam signal
- 5. After aborting, NIC enters exponential backoff: after mth collision, NIC chooses Kat random from {0,1,2,...,2^m-1}. NIC waits K·512 bit times, returns to Step 2

한번 쫑날때마다 0~2의 m승 -1 의 수 중 하나를 선택 쫑나는 횟수가 m이다.

so 쫑이 많이 나면 날 수록 높은 수를 뽑을 확률이 높아진다

5: DataLink Layer 5-51

Ethernet's CSMA/CD (more)

Jam Signal: make sure all other transmitters are aware of collision: 48 bits

Bit time: .1 microsec for 10 Mbps Ethernet; for K=1023, wait time is about 50 msec

See/interact with Java applet on AWL Web site: highly recommended!

Exponential Backoff:

- Goal: adapt retransmission attempts to estimated current load
 - heavy load: random wait will be longer
- ☐ first collision: choose K from {0,1}; delay is K· 512 bit transmission times
- after second collision: choose K from {0,1,2,3}...
- after ten collisions, choose K from {0,1,2,3,4,...,1023}

CSMA/CD efficiency

- Tprop = max prop delay between 2 nodes in LAN
- □ t_{trans} = time to transmit max-size frame

$$efficiency = \frac{1}{1 + 5t_{prop}/t_{trans}}$$


- efficiency goes to 1
 - o as t_{prop} goes to 0
 - o as t_{trans} goes to infinity
- better performance than ALOHA: and simple, cheap, decentralized!

5: DataLink Layer 5-53


802.11 > 무선인터넷

802.3 Ethernet Standards: Link & Physical Layers

- many different Ethernet standards
 - o common MAC protocol and frame format
 - o different speeds: 2 Mbps, 10 Mbps, 100 Mbps, 16bps, 106 bps
 - o different physical layer media: fiber, cable








- □ used in 10BaseT
- each bit has a transition
- allows clocks in sending and receiving nodes to synchronize to each other
 - o no need for a centralized, global clock among nodes!
- ☐ Hey, this is physical-layer stuff!

5: DataLink Layer 5-55

Link Layer

- □ 5.1 Introduction and services
- □ 5.2 Error detection and correction
- □ 5.3 Multiple access protocols
- 5.4 Link-layer Addressing
- □ 5.5 Ethernet

- 5.6 Link-layer switches
- □ 5.7 PPP
- 5.8 Link Virtualization: ATM, MPLS




허브와는 달리 들어오는 녀석을 원하는 위치로 보내줌. 허브보다 똑똑한놈 적극적이라는 말은 판단을 한다는 소리임. 선택적으로 포워드해준다 > 목적지 맥주소를 조사할 수 있음.

Switch

- □ link-layer device: smarter than hubs, take active role
 - o store, forward Ethernet frames
 - examine incoming frame's MAC address, selectively forward frame to one-or-more outgoing links when frame is to be forwarded on segment, uses CSMA/CD to access segment
- □ transparent 호스트는 데이터를 보낼때 스위치가 있는지도 모름
 - o hosts are unaware of presence of switches
- □ plug-and-play, self-learning
 - o switches do not need to be configured

Switch: allows *multiple* simultaneous transmissions

- hosts have dedicated, direct connection to switch
- switches buffer packets
- Ethernet protocol used on each incoming link, but no collisions; full duplex
 - each link is its own collision domain
- switching: A-to-A' and Bto-B' simultaneously, without collisions
 - o not possible with dumb hub




switch with six interfaces (1,2,3,4,5,6)

5: DataLink Layer 5-59

Switch Table

- \(\overline{Q}\): how does switch know that A' reachable via interface 4, B' reachable via interface 5?
- <u>A:</u> each switch has a switch table, each entry:
 - (MAC address of host, interface to reach host, time stamp)
- □ looks like a routing table!
- Q: how are entries created,maintained in switch table?
 - something like a routing protocol?




switch with six interfaces (1,2,3,4,5,6)

5: DataLink Layer 5-60

 $\nearrow 1$

각 스위치들은 스위치 테이블이 있다. 이를 통해 스위치가 알 수 있음.



처음에 보낸놈 A의 주소와 인터페이스 넘버를 기억한다. 이후 받은 것을 어디로 보낼 지 모르니까 다 보낸다 이럼 다시 응답하는 놈이 있을테니까 그 응답을 통해 다시 A'의 인터페이스 넘버를 기억한다. 반복을 통해 테이블을 채운다! >plug & play가능!

Switch: frame filtering/forwarding

When frame received:

- 1. record link associated with sending host
- 2. index switch table using MAC dest address
- 3. if entry found for destination
 then {


if dest on segment from which frame arrived then drop the frame


else forward the frame on interface indicated

}

else flood


forward on all but the interface on which the frame arrived





Self-learning multi-switch example

Suppose C sends frame to I, I responds to C



 \square Q: show switch tables and packet forwarding in S_1 ,


 S_2, S_3, S_4

테이블에는 맥주소 인터페이스넘버 티티엘 세가지가 들어간다!

테이블에 없으면 뿌려서 보내고 테이블에 있으면 그 부분만 보낸다

5: DataLink Layer 5-65


DMZ



33

Switches vs. Routers

- both store-and-forward devices
 - routers: network layer devices (examine network layer headers)
 - o switches are link layer devices
- routers maintain routing tables, implement routing algorithms
- switches maintain switch tables, implement filtering, learning algorithms



스위치

5: DataLink Layer 5-67

스위치와 라우터의 차이

허브는 레이어 1임
스위치는 레이어 2임
라우터는 레이어 3임
라우터는 ip주소를 보고
스위치는 맥주소
허브는 비트만 보냄(해석x)
+알파
L4스위치:
>보통 스위치는 레이어 2다
하지만 가끔
레이어 4(트랜스포트)
의 기능까지 구현한 스위치
존재!

Link Layer

- □ 5.1 Introduction and services
- □ 5.2 Error detection and correction
- □ 5.3Multiple access protocols
- 5.4 Link-Layer Addressing
- □ 5.5 Ethernet

- □ 5.6 Hubs and switches
- □ 5.7 PPP
- 5.8 Link Virtualization: ATM

Point to Point Data Link Control

- one sender, one receiver, one link: easier than broadcast link:
 - o no Media Access Control
 - o no need for explicit MAC addressing
 - e.g., dialup link, ISDN line
- popular point-to-point DLC protocols:
 - PPP (point-to-point protocol)
 - HDLC: High level data link control (Data link used to be considered "high layer" in protocol stack!

5: DataLink Layer 5-69

PPP Design Requirements [RFC 1557]

- packet framing: encapsulation of network-layer datagram in data link frame
 - carry network layer data of any network layer protocol (not just IP) at same time
 - o ability to demultiplex upwards
- bit transparency: must carry any bit pattern in the data field
- error detection (no correction)
- connection liveness: detect, signal link failure to network layer
- network layer address negotiation: endpoint can learn/configure each other's network address

PPP non-requirements


- □ no error correction/recovery
- □ no flow control
- out of order delivery OK
- □ no need to support multipoint links (e.g., polling)

Error recovery, flow control, data re-ordering all relegated to higher layers!

5: DataLink Layer 5-71

PPP Data Frame


- □ Flag: delimiter (framing)
- □ Address: does nothing (only one option)
- □ Control: does nothing; in the future possible multiple control fields
- □ Protocol: upper layer protocol to which frame delivered (eg, PPP-LCP, IP, IPCP, etc)




PPP Data Frame □ info: upper layer data being carried □ check: cyclic redundancy check for error detection variable 2 or 4 1 or 2 1 length 01111110 11111111 00000011 protocol 01111110 info check flag control flag address 5: DataLink Layer 5-73

Byte Stuffing

- □ "data transparency" requirement: data field must be allowed to include flag pattern <01111110>
 - Q: is received <01111110> data or flag?
- □ Sender: adds ("stuffs") extra < 01111110> byte after each < 01111110> data byte
- □ Receiver:
 - two 01111110 bytes in a row: discard first byte, continue data reception
 - o single 01111110: flag byte





Link Layer

- 5.1 Introduction and services
- 5.2 Error detection and correction
- 5.3Multiple access protocols
- □ 5.4 Link-Layer Addressing
- □ 5.5 Ethernet

- □ 5.6 Hubs and switches
- □ 5.7 PPP
- 5.8 Link Virtualization: ATM and MPLS

5: DataLink Layer 5-77

Virtualization of networks

Virtualization of resources: powerful abstraction in systems engineering:


- computing examples: virtual memory, virtual devices
 - Virtual machines: e.g., java
 - IBM VM os from 1960's/70's
- layering of abstractions: don't sweat the details of the lower layer, only deal with lower layers abstractly

The Internet: virtualizing networks

1974: multiple unconnected nets

- ARPAnet
- odata-over-cable networks
- o packet satellite network (Aloha)
- o packet radio network

- ... differing in:
- addressing conventions
- opacket formats
- o error recovery
- routing




ARPAnet

"A Protocol for Packet Network Intercommunication", V. Cerf, R. Kahn, IEEE Transactions on Communications, May, 1974, pp. 637-648.



satellite net



Cerf & Kahn's Internetwork Architecture

What is virtualized?

- two layers of addressing: internetwork and local network
- new layer (IP) makes everything homogeneous at internetwork layer
- underlying local network technology
 - o cable
 - o satellite
 - 56K telephone modem
 - o today: ATM, MPLS

... "invisible" at internetwork layer. Looks like a link layer technology to IP!

5: DataLink Layer 5-81

ATM and MPLS


- □ ATM, MPLS separate networks in their own right
 - different service models, addressing, routing from Internet
- □ viewed by Internet as logical link connecting IP routers
 - just like dialup link is really part of separate network (telephone network)
- ☐ ATM, MPLS: of technical interest in their own right

Asynchronous Transfer Mode: ATM

- 1990's/00 standard for high-speed (155Mbps to 622 Mbps and higher) Broadband Integrated Service Digital Network architecture
- Goal: integrated, end-end transport of carry voice, video, data
 - meeting timing/QoS requirements of voice, video (versus Internet best-effort model)
 - "next generation" telephony: technical roots in telephone world
 - packet-switching (fixed length packets, called "cells") using virtual circuits

5: DataLink Layer 5-83

ATM architecture



- adaptation layer: only at edge of ATM network
 - o data segmentation/reassembly
 - roughly analogous to Internet transport layer
- □ ATM layer: "network" layer
 - o cell switching, routing
- physical layer


ATM: network or link layer?

Vision: end-to-end transport: "ATM from desktop to desktop"

> ATM is a network technology

Reality: used to connect IP backbone routers


- o "IP over ATM"
- ATM as switched link layer, connecting IP routers



5: DataLink Layer 5-85

ATM Adaptation Layer (AAL)

- ATM Adaptation Layer (AAL): "adapts" upper layers (IP or native ATM applications) to ATM layer below
- □ AAL present only in end systems, not in switches
- AAL layer segment (header/trailer fields, data) fragmented across multiple ATM cells
 - o analogy: TCP segment in many IP packets



ATM Adaptation Layer (AAL) [more] Different versions of AAL layers, depending on ATM service class: □ AAL1: for CBR (Constant Bit Rate) services, e.g. circuit emulation □ AAL2: for VBR (Variable Bit Rate) services, e.g., MPEG video □ AAL5: for data (eg, IP datagrams) User data User Data Convergence sublayer CPCS Header CPCS AAL PDU SAR sublayer AAL Payload Data AAL ATM cell Header <=48 bytes Trailer Header ATM Cell o: DataLink Layer o-87

	<u> ayer</u>					
Service:	transport	cells acro	ss A	TM net	twork	
🗖 analogo	ous to IP i	network la	yer			
very d	ifferent s	ervices th	an IP	netwo	ork lay	er
Network Architecture	Service Model		Guarantees ?			Congestion
		Bandwidth	Loss	Order	Timing	feedback
Internet	best effort	none	no	no	no	no (inferred via loss)
ATM	CBR	constant rate	yes	yes	yes	no congestion
ATM	VBR	guaranteed rate	yes	yes	yes	no congestion
ATM	ABR	guaranteed minimum	no	yes	no	yes
ATM	UBR	none	no	ves	no	no


ATM Layer: Virtual Circuits


- □ VC transport: cells carried on VC from source to dest
 - o call setup, teardown for each call before data can flow
 - each packet carries VC identifier (not destination ID)
 - every switch on source-dest path maintain "state" for each passing connection
 - link,switch resources (bandwidth, buffers) may be allocated to VC: to get circuit-like perf.
- Permanent VCs (PVCs)
 - long lasting connections
 - o typically: "permanent" route between to IP routers
- □ Switched VCs (SVC):
 - o dynamically set up on per-call basis

5: DataLink Layer 5-89

ATM VCs

- □ Advantages of ATM VC approach:
 - QoS performance guarantee for connection mapped to VC (bandwidth, delay, delay jitter)
- □ Drawbacks of ATM VC approach:
 - Inefficient support of datagram traffic
 - one PVC between each source/dest pair) does not scale (N*2 connections needed)
 - SVC introduces call setup latency, processing overhead for short lived connections





ATM Physical Layer (more)

Two pieces (sublayers) of physical layer:

- Transmission Convergence Sublayer (TCS): adapts ATM layer above to PMD sublayer below
- Physical Medium Dependent: depends on physical medium being used

TCS Functions:


- O Header checksum generation: 8 bits CRC
- Cell delineation
- With "unstructured" PMD sublayer, transmission of idle cells when no data cells to send


5: DataLink Layer 5-93

ATM Physical Layer

Physical Medium Dependent (PMD) sublayer

- □ SONET/SDH: transmission frame structure (like a container carrying bits);
 - bit synchronization;
 - o bandwidth partitions (TDM);
 - several speeds: OC3 = 155.52 Mbps; OC12 = 622.08 Mbps; OC48 = 2.45 Gbps, OC192 = 9.6 Gbps
- TI/T3: transmission frame structure (old telephone hierarchy): 1.5 Mbps/ 45 Mbps
- unstructured: just cells (busy/idle)





Datagram Journey in IP-over-ATM Network


- □ at Source Host:
 - IP layer maps between IP, ATM dest address (using ARP)
 - o passes datagram to AAL5
 - o AAL5 encapsulates data, segments cells, passes to ATM layer
- □ ATM network: moves cell along VC to destination
- □ at Destination Host:
 - AAL5 reassembles cells into original datagram
 - o if CRC OK, datagram is passed to IP

5: DataLink Layer 5-97

IP-Over-ATM

Issues:

- ☐ IP datagrams into ATM AAL5 PDUs
- □ from IP addresses to ATM addresses
 - just like IP addresses to 802.3 MAC addresses!




Multiprotocol label switching (MPLS) initial goal: speed up IP forwarding by using fixed length label (instead of IP address) to do forwarding borrowing ideas from Virtual Circuit (VC) approach but IP datagram still keeps IP address! PPP or Ethernet header MPLS header IP header remainder of link-layer frame

MPLS capable routers

- a.k.a. label-switched router
- ☐ forwards packets to outgoing interface based only on label value (don't inspect IP address)
 - MPLS forwarding table distinct from IP forwarding tables
- □ signaling protocol needed to set up forwarding
 - O RSVP-TE
 - forwarding possible along paths that IP alone would not allow (e.g., source-specific routing)!!
 - o use MPLS for traffic engineering
- must co-exist with IP-only routers

5: DataLink Layer 5-100



Chapter 5: Summary

- principles behind data link layer services:
 - o error detection, correction
 - o sharing a broadcast channel: multiple access
 - link layer addressing
- instantiation and implementation of various link layer technologies
 - Ethernet
 - o switched LANS
 - PPP
 - o virtualized networks as a link layer: ATM, MPLS

Chapter 5: let's take a breath

- □ journey down protocol stack *complete* (except PHY)
- □ solid understanding of networking principles, practice
- could stop here but lots of interesting topics!
 - wireless
 - o multimedia
 - security
 - o network management