Lecture 23 Multilevel Caches

School of Computer Science and Engineering Soongsil University

5. Large and Fast: Exploiting Memory Hierarchy

- **5.1** Introduction
- **5.2 Memory Technologies**
- **5.3** The Basics of Caches
- **5.4 Measuring and Improving Cache Performance**
- **5.5** Dependable Memory Hierarchy
- **5.6 Virtual Machines**
- **5.7 Virtual Memory**
- **5.8** A Common Framework for Memory Hierarchies
- 5.9 Using a Finite-State Machine to Control a Simple Cache
- **5.10** Parallelism and Memory Hierarchies: Cache Coherence
- **5.11 Parallelism and Memory Hierarchy: RAID**
- **5.12 Advanced Material: Implementing Cache Controllers**
- **5.13** Real Stuff: The ARM Cortex-A8 and Intel Core i7 Memory Hierarchies

Choosing Which Block to Replace

Replacement algorithms

- Direct-mapped cache ... uniquely specified
- Set-associative cache ... choice among the blocks in the set
- Fully associative cache ... choice among all the blocks

LRU (least recently used)

- Victim ... the block that has been unused for the longest time
- Implementation
 by keeping track of when each element was used
- For 2-way set-associative cache1 reference bit
- Higher degree of associativity
 Harder to implement

Example: Tag size vs. Associativity (1)

- 32-bit address, cache of 4096 (=2¹²) bytes with block size = 1 byte
- Direct, 2-way, 4-way, fully associative

[Answer]

```
    Direct mapped
    4K blocks -> 12-bit index
    tag = (32 - 12) x 4K = 80K bits
```

- 2-way set associative
 2K sets -> 11-bit index
 tag = (32 11) x 2 x 2K = 84K bits
- 4 -way set associative
 1K sets -> 10-bit index
 tag = (32 10) x 4 x 1K = 88K bits
- Fully associative
 1 set, tag = 32 x 4K x 1 = 128K bits

Example: Tag size vs. Associativity (2)

• Cache of 4096 (= 2^{12}) bytes with block size = 4 words

[Answer]

- Number of blocks = $4KB/16B = 2^8 = 256$
- ❖ 16 bytes per block -> 4-bit block offset
- Direct mapped
 256 blocks -> 8-bit index
 tag = (28 8) x 256 = 5K bits
- 2-way set associative
 128 sets -> 7-bit index
 tag = (28 7) x 2 x 128 = 5.25K bits
- 4 -way set associative
 64 sets -> 6-bit index
 tag = (28 6) x 4 x 64 = 5.5K bits
- Fully associative
 1 set, tag = 28 x 256 x 1 = 7K bits

Example: Tag size vs. Associativity (3)

• Cache of 4096 (= 2^{12}) blocks with block size = 4 words [Answer]

- Cache size = 4K x 16 bytes = 64K bytes
- 16 bytes per block -> 4-bit offset
- Direct mapped
 4K sets -> 12-bit index
 tag = (28 12) x 4K = 64K bits
- 2-way set associative
 2K sets -> 11-bit index
 tag = (28 11) x 2 x 2K = 68K bits
- 4 -way set associative
 1K sets -> 10-bit index
 tag = (28 10) x 4 x 1K = 72K bits
- Fully associative
 1 set, tag = 28 x 4K x 1 = 112K bits

Reducing the Miss Penalty Using Multilevel Caches

Primary cache

On-chip

Secondary cache

- Off-chip SRAMs
- Reduce primary cache's miss penalty

Example : Performance of Multilevel Caches

- ❖ Clock rate = 4 GHz
- CPI = 1.0 with a primary cache of 100% hit rate
- Main memory access time = 100 ns (including miss handling)
- Miss rate/instruction at the primary cache = 2%
- With a secondary cache below, how will it be faster? global miss rate = 0.5%, access time = 5 ns

[Answer]

With 1 level of cache

Miss penalty to main memory

= 100ns/0.25ns = 400 clock cycles

Total CPI

= base CPI + memory-stall cycles per instruction

$$= 1.0 + 2\% \times 400 = 9.0$$

With 2 levels of caches

Miss penalty to secondary cache

= 5ns/0.25ns = 20 clock cycles

Total CPI = 1 + primary stalls + secondary stalls

$$= 1 + 2\% \times 20 + 0.5\% \times 400 = 3.4$$

 \star Thus, speedup = 9.0/3.4 = 2.6

Design Considerations for a Primary and Secondary Cache

Primary caches

- Focus on minimizing hit time
 - to yield a shorter clock cycle or fewer pipeline stages
- Smaller cache
- Smaller block size → reduced miss penalty

Secondary caches

- Focus on reducing miss rate
 - to reduce the penalty of long memory access times
- Larger
 - since access time is less critical
- Larger block size and higher associativity
 - to reduce miss rates

Caches of Real Machines

	Intel Nehalem	AMD Barcelona
L1 cache organization & size	Split I\$ and D\$; 32KB for each per core; 64B blocks	Split I\$ and D\$; 64KB for each per core; 64B blocks
L1 associativity	4-way (I), 8-way (D) set assoc.; ~LRU replacement	2-way set assoc.; LRU replacement
L1 write policy	write-back, write-allocate	write-back, write-allocate
L2 cache organization & size	Unified; 256KB (0.25MB) per core; 64B blocks	Unified; 512KB (0.5MB) per core; 64B blocks
L2 associativity	8-way set assoc.; ~LRU	16-way set assoc.; ~LRU
L2 write policy	write-back, write-allocate	write-back, write-allocate
L3 cache organization & size	Unified; 8192KB (8MB) shared by cores; 64B blocks	Unified; 2048KB (2MB) shared by cores; 64B blocks
L3 associativity	16-way set assoc.	32-way set assoc.; evict block shared by fewest cores
L3 write policy	write-back, write-allocate	write-back; write-allocate

Summary: Improving Cache Performance

1. Reduce the time to hit in the cache

- smaller cache
- direct mapped cache
- smaller blocks
- for writes
 - no write allocate no "halt" on cache, just write to write buffer
 - write allocate to avoid two cycles (first check for hit, then write) pipeline writes via a delayed write buffer to cache

2. Reduce the miss rate

- bigger cache
- more flexible placement (increase associativity)
- larger blocks (16 to 64 bytes typical)
- victim cache small buffer holding most recently discarded blocks

Summary: Improving Cache Performance

3. Reduce the miss penalty

- smaller blocks
- use a write buffer to hold dirty blocks being replaced so don't have to wait for the write to complete before reading
- check write buffer (and/or victim cache) on read miss may get lucky
- for large blocks fetch critical word first
- use multiple cache levels L2 cache not tied to CPU clock rate
- faster backing store/improved memory bandwidth
 - wider buses
 - memory interleaving, DDR SDRAMs

Summary: The Cache Design Space


Several interacting dimensions


- cache size
- block size
- associativity
- replacement policy
- write-through vs write-back
- write allocation

The optimal choice is a compromise

- depends on access characteristics
 - workload
 - use (I-cache, D-cache, TLB)
- depends on technology / cost

Simplicity often wins





5.5 Dependable Memory Hierarchy

- RAS (Reliability, Availability, Serviceability)
- Dependability
 - "a measure of a system's availability, reliability, and its maintainability" from Wikipedia

Defining Failure

- Two states of delivered service with respect to the service specification
 - 1. Service accomplishment
 - 2. Service interruption

State transition

- Failure: state 1 -> state 2
- Restoration: state 2 -> state 1

Reliability

- Reliability
 - Measure of the continuous service accomplishment
- MTTF (Mean Time To Failure)
- Annual failure rate (AFR)
 - Percentage of devices that would be expected to fail in a year for a given MTTF
- MTBF (Mean Time Between Failure)
 - = MTTF + MTTR (Mean Time To Repair)

Availability

Availability

Measure of the service accomplishment with respect to the alteration between the two states

Availability =
$$\frac{MTTF}{MTTF + MTTR}$$

How to reduce MTTR

Improved tools and processes for diagnosis and repair

How to improve MTTF

- 1. Fault avoidance: Preventing fault occurrence by construction.
- 2. Fault tolerance: Using redundancy to allow the service to comply with the service specification despite faults occurring.
- Fault forecasting: Predicting the presence and creation of faults, allowing the component to be replaced before it fails.

The Hamming SEC/DED Code

Richard Hamming

Invented a popular redundancy scheme for memory, for which he received the Turing Award in 1968

Hamming distance

- Minimum number of bits that are different between any two correct bit patterns
- ❖ Hamming distance = 2 provides single bit error detection
 - E.g. parity code
- Hamming distance = 3 provides single error correction/double error detection

Parity code

- Single error detection
- Even/Odd parity ... The number of 1s in a word is even/odd
- 1-bit parity code cannot detect 2 bits of error
- 1-bit parity code cannot correct errors

Hamming Error Correction Code (ECC)

Bit position		1	2	3	4	5	6	7	8	9	10	11	12
Encoded date bits		p1	p2	d1	р4	d2	d3	d4	p8	d5	d6	d7	d8
Parity bit coverate	p1	Χ		Χ		Х		Χ		Χ		Χ	
	p2		Χ	Χ			Χ	Χ			Χ	Χ	
	р4				Χ	Χ	Χ	Χ					Χ
	р8								Χ	Χ	Χ	Χ	Χ

Figure 5.24

Encoding SEC

- All bit positions that are a power 2 are parity bits
- Even parity

Decoding SEC

- Value of parity bits indicates which bits are in error
 - Parity bits = 0000 indicates no error
 - Parity bits = 1001 indicates error in bit 9

Example: Hamming Error Correction Code

- Data = $9A_{hex} = 10011010_{two}$
 - Show Hamming ECC.
 - Invert bit 10 and show that the ECC corrects the single bit error.

[Answer]

Bit position	1	2	3	4	5	6	7	8	9	10	11	12
	p1	p2	d1	p4	d2	d3	d4	p8	d5	d6	d7	d8
	0	1	1	1	0	0	1	0	1	0	1	0
p1 (xxx1)	0		1		0		1		1		1	
p2 (xx1x)		1	1			0	1			0	1	
p4 (x1xx)				1	0	0	1					0
p8 (1xxx)								0	1	0	1	0

- Invert bit 10: 011100101010 -> 011100101110
- * p1=E, p2=O, p4=E, p8=O -> 1010_{two} = 10_{ten} -> error in bit 10_{ten}

Hamming SEC/DED Code

Single Error Correcting, Double Error Detecting Code

- ❖ With one more parity bit, the minimum Hamming distance in a code = 4
- Add a parity bit that is calculated over the whole word

• Example: data=1001

Bit position	1	2	3	4	5	6	7	8	
	p ₁	p ₂	d1	p ₃	d2	d3	d4	p ₄	
encoding	0	0	1	1	0	0	1	1	
case 1	0	0	1	1	0	0	1	1	no error
case 2	0	0	1	1	0	0	0	1	single error (d4)
case 3	0	0	1	1	0	0	1	0	p ₄ error
case 4	0	0	1	1	1	1	1	1	double error (d2,d3)

72-bit DIMM


8-byte data block + 1-byte parity block

Supplement

Fully Associative Cache

[ref] Mano, Computer System Architecture


- Associative Memory = Content Addressable Memory (CAM)
 - Accessed by the content of the data rather than by an address




Operation of Associative Memory

- Compare each word in CAM in parallel with the contents of A (Argument Register)
- If CAM Word[i] = A, M(i) = 1
- Read sequentially accessing CAM for M(i) = 1
- K (Key Register) provides a mask for choosing a particular field or key in the argument in A
 - only those bits in the argument that have 1's in their corresponding position of K are compared


Internal Organization of CAM



Typical Cell C_{ij} of CAM



Match Logic




•
$$M_i = \Pi\{(F_{ij}'A_j) + (F_{ij}'A_j') + K_j'\}$$

Understanding Program Performance

Impact of the memory hierarchy on performance

Computer Architecture

LaMarca, A. and R. E. Ladner [1996]. "The influence of caches on the performance of heaps," ACM J. of Experimental Algorithmics, Vol. 1.



Designing the Memory System to Support Caches

Increased bandwidth from memory to cache

- Reduced miss penalty
- Larger block size with low miss penalty

Bus


- Connecting memory to processor
- Much slower than the processor, by as much as a factor of 10

Assumptions

- 1 memory bus clock cycle to send address
- 15 clock cycles for each DRAM access initiated
- 1 clock cycle to send a word of data
- Cache block of 4 words

One-word-wide Memory

- A one-word-wide bank of DRAMs
- All accesses are made sequentially.
- Miss penalty
 - \star 1 + 4 x 15 + 4 x 1 = 65 (clock cycles)
- The number of bytes transferred per clock cycle for a single miss
 - $4 \times (4 \times 4) / 65 = 0.25 \text{ (bytes/cycle)}$
- Timing






Figure 5.11a

Wide Memory (1/2)

- Increase the bandwidth to memory by widening the memory and the bus
 - Parallel access to all the words of the block

Major costs

- Wider bus
- Potential increase in cache access time due to the multiplexor and control logic between processor and cache




Figure 5.11b


Wide Memory (2/2)


If a main memory width= 2 words

- Miss penalty = $1 + 2 \times 15 + 2 \times 1 = 33$ (clock cycles)
- * Bandwidth for a single miss = $4 \times 4 / 33 = 0.48$ (bytes/cycle)

If a main memory width= 4 words

- * Miss penalty = $1 + 1 \times 15 + 1 \times 1 = 17$ (clock cycles)
- * Bandwidth for a single miss = $4 \times 4 / 17 = 0.94$ (bytes/cycle)





Interleaved Memory (2/1)

- Widening the memory but not the bus and cache
- Organize the memory chips in banks to read or write multiple words in one access time
- Advantage of incurring the full memory latency only once
- Each bank can be written independently
 - 4 times write bandwidth
 - Less stall occurs in write-through cache




Figure 5.11c

Interleaved Memory (2/2)

With 4 banks

- 4-way interleaved memory
- \bullet Miss penalty = 1 + 1x15 + 4x1 = 20 (clock cycles)
- * Bandwidth for a single miss = $4 \times 4 / 20 = 0.80$

