DEVICE JSON SETTING MANUAL

DEVICE JSON 補充配置的 Data Field

目的: 標識離線使用和鏡頭加載 models

版本演變: DOC FROM: X:\MediaGuardAppV31\MediaGuard_DOC 幫助說明

FROM X:\MediaGuardAppV31\MediaGuard DOC

業務 API

什麼是設備序列號:

下文中 "device_serial_no": "lbOEHIOZQz" 就是設備序列號, 指的是程序唯一標識符,是任意一串字符串或 CPU 序列號 等為規則的字符串,與雲端配置的設備序列號一致,以實現 API 訪問的 KEY(當然也要附加 API TOKEN),每個程序安裝在 Windows 或 Linux 上的一個整體視為一個設備.

和實體的設備序列號不同:海康的設備序列號是通過 HIKSDK 提供的函數獲得,其他的實體設備有自己的方式獲得真實 的硬件設備序列號.

1、啟動 MediaGuard 配置

配置設備有三種方式:

- 1、雲端系統進行配置設備,程式自動下載配置到本地.
- 2、直接通過設備的 JSON 文件配置設備
- 3、通過設備 API 上存配置 JSON 文件到設備.

序~ ≡ 檢視~ ···· 用於離線 此json	脫機使用此鏡頭列	長,聯網配置好後	,自動本地保存-	一個列表,當脫機時候,僅讀明
名稱	修改日期	類型	大小	
camera_list.json	13/3/2024 14:56	JSON 源文件	2 KB	
in config.json 作廢. 改用device.json	3/3/2024 14:56	JSON 源文件	2 KB	
device.json 設備配置json,需要手	動網寫。具體設置參考	多	4 KB	
deviceUtf8.json	6/3/2024 17:31	JSON 源文件	3 KB	

第一種方式請參考: DVR_AI_MEDIAGUARD 系統操作說明 - HK.pdf

2、device.json 配置說明

增加一個關鍵字段標識設備是否脫機還是聯機(device_is_online_always = true | false)

脫機聯機之間如果出現不同步,可以嘗試把 "device_is_online_always": true false 改變後重新運行

Device.Json 配置說明:

```
"device_config": {
   "maincom_id": "6000014",
   "device_ip": "192.168.0.177",
   "device_port": 8080,
   "device_serial_no": "IbOEHlOZQz",
   "device serial no hmac": "5834f9a3218e1a895002414dd966bdedd8a13261",
   "device_is_online_always": true,//<mark>[標識設備是否 online]</mark>
   "language code" :"zh-HK",
   "user": "admin2",
   "password": "admin123",
   "password_format": "plain text",
   "local_login": "admin",
   "local password": "admin888",
   "local_authorization": "7ad166bdb8395514bb54cc0ac21db289",
   "reamrks": "serial no is hamc by toll from STAR-LangMXcore password format is md5_32_upcase, admin required
lower.",
   "language code": "zh-HK"
```

```
"http_server_cloud": {
    "scheme": "http",
   "host": "81.71.74.135",
   "port": 5002,
    "remarks": "cloud for api"
 },
 "http_server": {
   "scheme": "http",
   "host": "81.71.74.135",
   "port": 5002,
    "remarks": "device web server AIG WEB SITE"
 },
 "storage server": {
   "scheme": "http",
    "host": "81.71.74.135",
   "port": "5002",
   "remarks": "The node and cloud are the same, if they are separated, you need to set another one here"
 },
 "global setting": {
    "recordTimeMinutes": 300000,
    "picRemainMinutes": 15,
   "videoRemainMinutes": 15,
    "storageLimitedbytes": 502400001,
    "ffmpegOpenInfo": false,
    "nHDType": "kHWDeviceTypeCUDA",
    "nHDTypeRemark": {
      "remarks": "nHDType 硬件解碼類型 storageLimitedbytes=502400001 字節即 500Mb",
      "hdtype": [
        "kHWDeviceTypeNone 無硬件解碼",
       "kHWDeviceTypeVDPAU",
       "kHWDeviceTypeCUDA",
       "kHWDeviceTypeVAAPI",
       "kHWDeviceTypeDXVA2 英德爾集成顯卡解碼",
       "kHWDeviceTypeQSV",
       "kHWDeviceTypeVIDEOTOOLBOX",
       "kHWDeviceTypeD3D11VA",
       "kHWDeviceTypeDRM",
       "kHWDeviceTypeOPENCL",
       "kHWDeviceTypeMEDIACODEC"
   },
    "remarks": "The node is used to configure the recording system and hardware environment; Storage Limited bytes 502400000
 502M ; media file record Timespan Minutes 5minutes = 60 * 1000 * 5; videoRemainMinutes:: The rule keeps video files for at
least 15 minutes"
```

```
"database": {
   "ip": "81.71.74.135",
   "port": 3306,
   "base_frontend": "camera_guard_business",
   "base_history": "camera_guard_history",
   "user": "root",
   "password": "root"
 "pool": { "database_pool": 30 },
 "carPlateRecogBusiness": {
   "enable": false,
   "permited_cameraId": [
       "cameraId": 12,
       "name": "大華 SRV2_IP91",
       "rtspIp": "192.168.0.91"
     },
       "cameraId": 18,
       "name": "海康 SRV2_IP91",
       "rtspIp": "192.168.0.90"
   ],
   "permited camerald remark": "permited_camerald 是允许具体哪个镜头启动车牌监测",
   "http_server_api": "http://81.71.74.135:5005/PlateReturn",
   "http_detect_server_api": "http://localhost:5600/detect",
   "threshold": 0.6,
   "user": "admin",
   "password": "123456",
   "reamrks": "for card plate recognition, post to detct server and return the result and then post back to
http server^{\,,} Post time out 200millseconds - 500millseconds,timeout will be exited!"
 "doc_encoding": "the current document endoding is requied utf-8.本文档必须是非bom非签名的UTF,否则读取出错 *****"
```

3、設備配置與播放列表 Camera_List Json(來自 API)

鏡頭的 json 列表

是由 API 通過 bool CameraMpeg::camera_list 這個函數通過雲獲取,如果如何設置離線(脫機 Offline)則從本機獲取文件。

增加鏡頭指定的 models 對象數組, Models 數組包含的字段:

"model id":1,

- model name :"yolovx.pt"
- alert trigger conditions:true //true:當預設條件符合則警報,false:不符合則警報
- precision rate:75 //程式判斷預設: >大於
- alert voice:"請使用指定袋" // 空白="" 則 alert voice file
- alert voice file: "aaa.mp3" //如果 alert voice=empty 則使用語音文件播放警報

```
"meta": {
"success": true,
"message": "OK",
"errorCode": -1
"data": [{
      "rtspIp": "192.168.0.92",
      "rtspUsername": "admin",
      "rtspPassword": "hik12345",
      "maincomId": "6000014",
      "cameraId": 8,
      "name": "海康攝像 IP92:",
      "cameraIp": null,
      "siteId": 10,
      "siteName": "6 樓",
      "rtsp": "rtsp://admin:hik12345@192.168.0.92:554/h264/ch1/main/av_stream",
      "type": 0,
      "online": "使用中",
      "remark": "Floor3 3006",
      "createTime": "2023-01-20 00:00:00",
      "deviceId": 3007,
      "deviceName": "HUA SERVER1",
      "recordStatus": 0,
      "deviceType": 1006, //從雲端邏輯獲得的鏡頭類型
      "onlive": true, //指鏡頭是否可連線的狀態
      "modelListSetting": [{
           "modelId": "M00123",
           "modelName": "yolovx.pt",
            "alertTriggerConditions": false,
            "precisionRate": 90,
            "alertVoice": "請使用指定袋",
            "alertVoiceFile": "aaa.mp3"
            "modelId": "1M00122",
            "modelName": "yolovx2.pt",
```

```
"alertTriggerConditions": false,
              "precisionRate": 90,
              "alertVoice": "請使用指定袋",
              "alertVoiceFile": "aaa.mp3"
        }], //model 數組
         "rtspIp": "192.168.0.91",
         "rtspUsername": "admin",
         "rtspPassword": "admin888888",
         "maincomId": "6000014",
         "cameraId": 12,
         "name": "大華 IP91",
         "cameraIp": null,
         "siteId": 12,
         "siteName": "7樓A座",
         "rtsp":
rtsp://admin:admin888888@192.168.0.91:554/cam/realmonitor?channel=1&subtype=0",
         "type": 0,
         "online": "使用中",
         "remark": "大華鏡頭 IP91",
         "createTime": "2023-01-20 00:00:00",
         "deviceId": 3007,
         "deviceName": "HUA_SERVER1",
         "recordStatus": 1,
         "deviceType": 1006,
         "onlive": true, //指鏡頭是否可連線的狀態
        "modelListSetting": [{
              "modelId": "1M00122",
              "modelName": "yolovx2.pt",
              "alertTriggerConditions": false,
              "precisionRate": 90,
              "alertVoice": "請使用指定袋",
              "alertVoiceFile": "aaa.mp3"
           }] //單個數組
     }]
```

函數 bool CameraMpeg::get_task_list_by_camera_id 需要加上 model 對象 FOR Yolov8:

```
"model_name": "yolovx.pt",

"alert_trigger_conditions": false, //不是垃圾袋的情况

"precision_rate": 90,

"alert_voice": "請使用指定袋",

"alert_voice_file": "aaa.mp3"

`}] //單個數組
```

4、鏡頭配置和錄像時段

```
"meta": {
 "message": "OK",
 "errorCode": -1
"data": {
 "cameraId": 8,
 "cameraName": "海康攝像 IP92:",
 "cameraIp": "192.168.0.92",
 "deviceId": 3007, //定義設備的編號 ID 由雲端對盒子定義 ID
 "deviceName": "HUA_SERVER1",
 "siteId": "10", //位置編號 ID,由雲端定義
 "maincomId": "6000014",
 "policyIsStart": true, //是否啟動策略
 "saveVideo": true, //是否保存錄像
 "saveMpeg4": true, //是否以 mp4 格式保存,否則 flv 保存
 "hlsOutput": true, //是否保存 hls 輸出
 "rtmpOutput": false, //未作測試,需要配合 Nginx 才能被用戶以 url 形式請求
 "savePic": true,
 "savePictRate": 60, // 公式: 60%25 = 2 次(保存次數)也就是兩秒 10 幀保存兩次 或者說 每 1 秒假設 25 幀 60 產生 2 次的圖片保存
 "sundayStart": "00:00:00", //星期天保存的時段開始 功能未實現
 "sundayEnd": "00:00:00", //星期天保存的時段結束 功能未實現
 "mondayStart": "00:00:00",
 "mondayEnd": "00:00:00",
 "tuesdayStart": "00:00:00",
 "tuesdayEnd": "00:00:00",
 "wednesdayStart": "00:00:00",
 "wednesdayEnd": "00:00:00",
 "thursdayStart": "00:00:00",
 "thursdayEnd": "00:00:00",
 "fridayStart": "00:00:00",
```

```
"fridayEnd": "00:00:00",

"saturdayStart": "00:00:00",

"saturdayEnd": "00:00:00"

}
```

5、通過設備序列號獲取設備相關的主公司資料配置

文件名稱: main_company_detais_by_serialno.json

存儲路徑: "./conf/main_company_detais_by_serialno.json"

規則:如果在線,則雲端獲取,否則通過本地 json 獲取

6、鏡頭的任務列表 JSON

通過脫機或者聯機獲取鏡頭的任務列表 包含 Al Model 數組,保存在 ./conf

camera_tasks_list_{camerald}.json

如果 API,則請求: /Task/GetTaskListByCamerald/{camerald}

例如: camerald = 1003

camera_tasks_list_1003.json
/Task/GetTaskListByCamerald/1003

7、獲取鏡頭詳細 get camera details

如果 API,則請求: /zh-CN/Cam/CameraDetails?CameraId={Camerald}

例如: camerald = 12366

camera_details__12366.json
/zh-CN/Cam/CameraDetails?CameraId=12

8、車牌檢測 API http_detect_server_api

來自 device.json 局部:

```
9 · "carPlateRecogBusiness": {
10 · "enable": false,
11 · "permited_cameraId": [
```

```
12、
13、
           "cameraId": 12,
14、
           "name": "大華 SRV2_IP91",
15、
           "rtspIp": "192.168.0.91"
16、
         },
17、
18、
           "cameraId": 18,
19、
           "name": "海康 SRV2_IP91",
20、
           "rtspIp": "192.168.0.90"
21、
22、
       ],
23、
       "permited_cameraId_remark": "permited_cameraId 是允许具体哪个镜头启动车牌监测",
24、
       "http_server_api": "http://81.71.74.135:5005/PlateReturn",
25、
       "http_detect_server_api": "http://localhost:5600/detect",
26、
       "threshold": 0.6,
27、
       "user": "admin",
28、
       "password": "123456",
29、
       "reamrks": "for card plate recognition, post to detct server and return the result and
then post back to http server,Post time out 200millseconds - 500millseconds,timeout will be
exited!"
30 \ },
```