

### **COMPUTER ORGANIZATION AND DESIGN**

(1) R/L

The Hardware/Software Interface

## **Chapter 5**

**Cache Memory** 

# **Example: Larger Block Size**

- 64 blocks, 16 bytes/block (for a cache)
  - To what block number does address 1200 map?
- Block address = [1200/16] = 75
- Block number = 75 modulo 64 = 11

31		10	9	۷	1	3	0
	Tag			ndex		Off	set
	22 bits			6 bits		4 b	oits



### **Block Size Considerations**

- Larger blocks should reduce miss rate
  - Due to spatial locality
- But in a fixed-sized cache
  - Larger blocks ⇒ fewer of them
    - More competition ⇒ increased miss rate
  - Larger blocks ⇒ pollution
- Larger miss penalty
  - Can override benefit of reduced miss rate
  - Early restart and critical-word-first can help



### **Cache Misses**

- On cache hit, CPU proceeds normally
- On cache miss
  - Stall the CPU pipeline
  - Fetch block from next level of hierarchy
  - Instruction cache miss
    - Restart instruction fetch
  - Data cache miss
    - Complete data access



# Write-Through

- On data-write hit, could just update the block in cache
  - But then cache and memory would be inconsistent
- Write through: also update memory
- But makes writes take longer
  - e.g., if base CPI = 1, 10% of instructions are stores, write to memory takes 100 cycles
    - Effective  $CPI = 1 + 0.1 \times 100 = 11$
- Solution: write buffer
  - Holds data waiting to be written to memory
  - CPU continues immediately
    - Only stalls on write if write buffer is already full



### Write-Back

- Alternative: On data-write hit, just update the block in cache
  - Keep track of whether each block is dirty
- When a dirty block is replaced
  - Write it back to memory
  - Can use a write buffer to allow replacing block to be read first



### **Write Allocation**

- What should happen on a write miss?
- Alternatives for write-through
  - Allocate on miss: fetch the block
  - Write around: don't fetch the block
    - Since programs often write a whole block before reading it (e.g., initialization)
- For write-back
  - Usually fetch the block




## **Main Memory Supporting Caches**

- Use DRAMs for main memory
  - Fixed width (e.g., 1 word)
  - Connected by fixed-width clocked bus
    - Bus clock is typically slower than CPU clock
- Example cache block read
  - 1 bus cycle for address transfer
  - 15 bus cycles per DRAM access
  - 1 bus cycle per data transfer
- For 4-word block, 1-word-wide DRAM
  - Miss penalty =  $1 + 4 \times 15 + 4 \times 1 = 65$  bus cycles
  - Bandwidth = 16 bytes / 65 cycles = 0.25 B/cycle



## **Increasing Memory Bandwidth**



- 4-word wide memory
  - Miss penalty = 1 + 15 + 1 = 17 bus cycles
  - Bandwidth = 16 bytes / 17 cycles = 0.94 B/cycle
- 4-bank interleaved memory
  - Miss penalty =  $1 + 15 + 4 \times 1 = 20$  bus cycles
  - Bandwidth = 16 bytes / 20 cycles = 0.8 B/cycle



Memory

a. One-word-wide

memory organization


# **Advanced DRAM Organization**

- Bits in a DRAM are organized as a rectangular array
  - DRAM accesses an entire row
  - Burst mode: supply successive words from a row with reduced latency
- Double data rate (DDR) DRAM
  - Transfer on rising and falling clock edges
- Quad data rate (QDR) DRAM
  - Separate DDR inputs and outputs



### **DRAM Generations**

Year	Capacity	\$/GB
1980	64Kbit	\$1500000
1983	256Kbit	\$500000
1985	1Mbit	\$200000
1989	4Mbit	\$50000
1992	16Mbit	\$15000
1996	64Mbit	\$10000
1998	128Mbit	\$4000
2000	256Mbit	\$1000
2004	512Mbit	\$250
2007	1Gbit	\$50





## **Measuring Cache Performance**

- Components of CPU time
  - Program execution cycles
    - Includes cache hit time
  - Memory stall cycles
    - Mainly from cache misses
- With simplifying assumptions:

Memory stall cycles

$$= \frac{\text{Memory accesses}}{\text{Program}} \times \text{Miss rate} \times \text{Miss penalty}$$

$$= \frac{\text{Instructions}}{\text{Program}} \times \frac{\text{Misses}}{\text{Instruction}} \times \text{Miss penalty}$$



# Cache Performance Example

### Given

- I-cache miss rate = 2%
- D-cache miss rate = 4%
- Miss penalty = 100 cycles
- Base CPI (ideal cache) = 2
- Load & stores are 36% of instructions
- Miss cycles per instruction
  - I-cache:  $0.02 \times 100 = 2$
  - D-cache:  $0.36 \times 0.04 \times 100 = 1.44$
- Actual CPI = 2 + 2 + 1.44 = 5.44
  - Ideal CPU is 5.44/2 =2.72 times faster



## **Average Access Time**

- Hit time is also important for performance
- Average memory access time (AMAT)
  - AMAT = Hit time + Miss rate × Miss penalty
- Example
  - CPU with 1ns clock, hit time = 1 cycle, miss penalty = 20 cycles, I-cache miss rate = 5%
  - $\blacksquare$  AMAT = 1 + 0.05 × 20 = 2ns
    - 2 cycles per instruction



# **Performance Summary**

- When CPU performance increased
  - Miss penalty becomes more significant
- Decreasing base CPI
  - Greater proportion of time spent on memory stalls
- Increasing clock rate
  - Memory stalls account for more CPU cycles
- Can't neglect cache behavior when evaluating system performance




### **Associative Caches**

- Fully associative
  - Allow a given block to go in any cache entry
  - Requires all entries to be searched at once
  - Comparator per entry (expensive)
- n-way set associative
  - Each set contains n entries
  - Block number determines which set
    - (Block number) modulo (#Sets in cache)
  - Search all entries in a given set at once
  - n comparators (less expensive)



# **Associative Cache Example**





# **Spectrum of Associativity**

### For a cache with 8 entries

### One-way set associative (direct mapped)

Tag	Data
	Tag

#### Two-way set associative

Set	Tag	Data	Tag	Data
0				
1				
2				
3				

#### Four-way set associative

Set	Tag	Data	Tag	Data	Tag	Data	Tag	Data
0								
1								

#### Eight-way set associative (fully associative)

Tag	Data														



# **Associativity Example**

- Compare 4-block caches
  - Direct mapped, 2-way set associative, fully associative
  - Block access sequence: 0, 8, 0, 6, 8
- Direct mapped

Block	Cache	Hit/miss	Cache content after access				
address	index		0	1	2	3	
0	0	miss	Mem[0]				
8	0	miss	Mem[8]				
0	0	miss	Mem[0]				
6	2	miss	Mem[0]		Mem[6]		
8	0	miss	Mem[8]		Mem[6]		



# **Associativity Example**

### 2-way set associative

Block	Cache	Hit/miss	Cache content after access			
address	index		Se	et O	Set 1	
0	0	miss	Mem[0]			
8	0	miss	Mem[0]	Mem[8]		
0	0	hit	Mem[0]	Mem[8]		
6	0	miss	Mem[0]	Mem[6]		
8	0	miss	<b>Mem[8]</b>	Mem[6]		

### Fully associative

Block address	Hit/miss	Cache content after access				
0	miss	Mem[0]				
8	miss	Mem[0]	Mem[8]			
0	hit	Mem[0]	Mem[8]			
6	miss	Mem[0]	Mem[8]	Mem[6]		
8	hit	Mem[0]	Mem[8]	Mem[6]		




# **How Much Associativity**

- Increased associativity decreases miss rate
  - But with diminishing returns
- Simulation of a system with 64KB
  D-cache, 16-word blocks, SPEC2000
  - 1-way: 10.3%
  - 2-way: 8.6%
  - 4-way: 8.3%
  - 8-way: 8.1%



### **Set Associative Cache Organization**





# Replacement Policy

- Direct mapped: no choice
- Set associative
  - Prefer non-valid entry, if there is one
  - Otherwise, choose among entries in the set
- Least-recently used (LRU)
  - Choose the one unused for the longest time
    - Simple for 2-way, manageable for 4-way, too hard beyond that
- Random
  - Gives approximately the same performance as LRU for high associativity



### **Multilevel Caches**

- Primary cache attached to CPU
  - Small, but fast
- Level-2 cache services misses from primary cache
  - Larger, slower, but still faster than main memory
- Main memory services L-2 cache misses
- Some high-end systems include L-3 cache



# Multilevel Cache Example

- Given
  - CPU base CPI = 1, clock rate = 4GHz
  - Miss rate/instruction = 2%
  - Main memory access time = 100ns
- With just primary cache
  - Miss penalty = 100ns/0.25ns = 400 cycles
  - Effective CPI =  $1 + 0.02 \times 400 = 9$



# Example (cont.)

- Now add L-2 cache
  - Access time = 5ns
  - Global miss rate to main memory = 0.5%
- Primary miss with L-2 hit
  - Penalty = 5ns/0.25ns = 20 cycles
- Primary miss with L-2 miss
  - Extra penalty = 500 cycles
- $\blacksquare$  CPI = 1 + 0.02 × 20 + 0.005 × 400 = 3.4
- Performance ratio = 9/3.4 = 2.6



### **Multilevel Cache Considerations**

- Primary cache
  - Focus on minimal hit time
- L-2 cache
  - Focus on low miss rate to avoid main memory access
  - Hit time has less overall impact
- Results
  - L-1 cache usually smaller than a single cache
  - L-1 block size smaller than L-2 block size



### **Sources of Misses**

- Compulsory misses (aka cold start misses)
  - First access to a block
- Capacity misses
  - Due to finite cache size
  - A replaced block is later accessed again
- Conflict misses (aka collision misses)
  - In a non-fully associative cache
  - Due to competition for entries in a set
  - Would not occur in a fully associative cache of the same total size



# Cache Design Trade-offs

Design change	Effect on miss rate	Negative performance effect
Increase cache size	Decrease capacity misses	May increase access time
Increase associativity	Decrease conflict misses	May increase access time
Increase block size	Decrease compulsory misses	Increases miss penalty. For very large block size, may increase miss rate due to pollution.



# Specialized caches

- Victim cache
  - hold blocks evicted from a CPU cache upon replacement
  - usually fully associative, and is intended to reduce the number of conflict misses
- Trace cache
  - a mechanism for increasing the instruction fetch bandwidth and decreasing power consumption
  - stores traces of instructions that have already been fetched and decoded
  - used in the Pentium 4





### **Cache Coherence Problem**

- Suppose two CPU cores share a physical address space
  - Write-through caches

Time step	Event	CPU A's cache	CPU B's cache	Memory
0				0
1	CPU A reads X	0		0
2	CPU B reads X	0	0	0
3	CPU A writes 1 to X	1	0	1



### **Coherence Defined**

- Informally: Reads return most recently written value
- Formally:
  - P writes X; P reads X (no intervening writes)
    - ⇒ read returns written value
  - P<sub>1</sub> writes X; P<sub>2</sub> reads X (sufficiently later)
    - ⇒ read returns written value
      - c.f. CPU B reading X after step 3 in example
  - P<sub>1</sub> writes X, P<sub>2</sub> writes X
    - ⇒ all processors see writes in the same order
      - End up with the same final value for X



### **Cache Coherence Protocols**

- Operations performed by caches in multiprocessors to ensure coherence
  - Migration of data to local caches
    - Reduces bandwidth for shared memory
  - Replication of read-shared data
    - Reduces contention for access
- Snooping protocols
  - Each cache monitors bus reads/writes
- Directory-based protocols
  - Caches and memory record sharing status of blocks in a directory



## **Invalidating Snooping Protocols**

- Cache gets exclusive access to a block when it is to be written
  - Broadcasts an invalidate message on the bus
  - Subsequent read in another cache misses
    - Owning cache supplies updated value

CPU activity	Bus activity	CPU A's cache	CPU B's cache	Memory
				0
CPU A reads X	Cache miss for X	0		0
CPU B reads X	Cache miss for X	0	0	0
CPU A writes 1 to X	Invalidate for X	1		0
CPU B read X	Cache miss for X	1	1	1



# **Memory Consistency**

- When are writes seen by other processors
  - "Seen" means a read returns the written value
  - Can't be instantaneously
- Assumptions
  - A write completes only when all processors have seen it
  - A processor does not reorder writes with other accesses
- Consequence
  - P writes X then writes Y⇒ all processors that see new Y also see new X
  - Processors can reorder reads, but not writes

