What you will learn in this lesson



- In the previous lesson, you learned how to write equations for simulation of a battery pack comprising multiple PCMs
- In this lesson, you will see some Octave/MATLAB code that simulating PCMs, and will see how it works step-by-step
- This code (optionally) allows every cell to have different parameter values, and allows for an arbitrary number of cells in parallel and in series
- It even (optionally) allows simulation of packs containing cell(s) having open-circuit or short-circuit faults

Dr. Gregory L. Plett University of Colorado Colorado Springs

Equivalent Circuit Cell Model Simulation | Simulating battery packs in different configurations | 1 of 11

2.4.4: Introducing Octave code to simulate PCMs

Initialization code



The following code loads model, begins configuration

```
% simPCM: Simulate parallel-cell-module packs (cells are connected in parallel
% to make modules; these modules are connected in series to make packs)
% The parameter values for each cell may be different
clear; close all; clc;
% Initialize some pack configuration parameters...
Ns = 3; % Number of modules connected in series to make a pack
Np = 3; % Number of cells connected in parallel in each module
% Initialize some simulation configuration parameters...
maxtime = 3600; % Simulation run time in simulated seconds
               % Pack rests after time t0
storez = zeros([maxtime Ns Np]); % create storage for SOC
storei = zeros([maxtime Ns Np]);  % create storage for current
```

Dr. Gregory L. Plett | University of Colorado Colorado Spring

Equivalent Circuit Cell Model Simulation | Simulating battery packs in different configurations | 2 of 11

2.4.4: Introducing Octave code to simulate PCMs

Code for default initialization



The following code initializes all states and parameters

```
% Initialize states for ESC cell model
  = 0.25*ones(Ns,Np); % SOC for each cell
= zeros(Ns,Np);
% Default initialization for cells within the pack
   = 25; % Default temperature
T
    = getParamESC('QParam',T,model)*ones(Ns,Np);
rc = exp(-1./abs(getParamESC('RCParam',T,model)))'*ones(Ns,Np);
   = (getParamESC('RParam',T,model))';
   = getParamESC('MParam',T,model)*ones(Ns,Np);
m0 = getParamESC('MOParam',T,model)*ones(Ns,Np);
    = getParamESC('GParam',T,model)*ones(Ns,Np);
   = getParamESC('ROParam',T,model)*ones(Ns,Np);
r0
rt = 0.000125; % 125 microOhm resistance for each tab
```

Code to modify cell parameter values



The following code (optionally) modifies some parameters

```
% Modified initialization for cell variability
% e.g., set individual random "initial SOC" values
if 1, % set to "if 1," to execute, or "if 0," to skip this code
 z=0.30+0.40*rand([Ns Np]); % rand. init. SOC for ea. cell
% e.g., set individual random cell-capacity values
if 1, % set to "if 1," to execute, or "if 0," to skip this code
 q=4.5+rand([Ns Np]);
                            % random capacity for ea. cell
end
\% e.g., set individual random cell-resistance relationships
if 1, % set to "if 1," to execute, or "if 0," to skip this code
 r0 = 0.005 + 0.020 * rand(Ns, Np);
end
r0 = r0 + 2*rt; % add tab resistance to cell resistance
```

Dr. Gregory L. Plett University of Colorado Colorado Springs

Equivalent Circuit Cell Model Simulation | Simulating battery packs in different configurations | 4 of 11

2.4.4: Introducing Octave code to simulate PCMs

Code to add faults, set up simulation



■ The following code (optionally) adds faults, then sets up sim

```
% Add faults to pack: cells faulted open- and short-circuit
% To delete a PCM (open-circuit fault), set a resistance to Inf
%r0(1,1) = Inf; % for example...
\% To delete a cell from a PCM (short-circuit fault), set its SOC to NaN
%z(1,2) = NaN; % for example, delete cell 2 in PCM 1
Rsc = 0.0025; % Resistance value to use for cell whose SOC < 0%
\% Get ready to simulate... first compute pack capacity in Ah
totalCap = min(sum(q,2)); % pack capacity = minimum module capacity
I = 10*totalCap; % cycle at 10C... not realistic, faster simulation
% Okay... now to simulate pack performance using ESC cell model...
```

Dr. Gregory L. Plett | University of Colorado Colorado Springs

Equivalent Circuit Cell Model Simulation | Simulating battery packs in different configurations | 5 of 11

2.4.4: Introducing Octave code to simulate PCMs

Main code loop to simulate PCMs



```
for k = 1:maxtime,
 v = OCVfromSOCtemp(z,T,model); % get OCV for Ns * Np cells
 v = v + m.*h + m0.*s - r.*irc; % add in capacitor voltages and hysteresis
 r0(isnan(z)) = Rsc; % short-circuit fault has "short-circuit" resistance
 V = (sum(v./r0,2) - I)./sum(1./r0,2);
 ik = (v-repmat(V,1,Np))./r0;
 z = z - (1/3600)*ik./q; % Update each cell SOC
 z(z<0) = NaN; % set over-discharged cells to short-circuit fault
  irc = rc.*irc + (1-rc).*ik; % Update R-C currents
 fac = \exp(-abs(g.*ik)./(3600*q));
 h = fac.*h + (fac-1).*sign(ik); % Update hysteresis voltages
 s(abs(ik)>1e-3) = sign(ik(abs(ik)>1e-3)); % Update current sign
 minz = min(z(:)); maxz = max(z(:)); % Check to see if SOC limit hit
 if minz < 0.05, I = -abs(I); end % stop discharging</pre>
 if maxz > 0.95, I = abs(I); end % stop charging
 if k>t0, I = 0; end % rest
 storez(k,:,:) = z; storei(k,:,:) = ik; % Store SOC, current for later plotting
end % for k
```



Example of how to plot results

```
% Plot individual cell SOC vs. time for all cells
% in all series PCMs. There is one subplot for each PCM.
figure; clf; t = (0:(length(storez(:,:,1))-1))/60;
xplots = round(ceil(sqrt(Ns))); yplots = ceil(Ns/xplots);
for k = 1:Ns,
  zr=squeeze(100*storez(:,k,:)); subplot(yplots,xplots,k); plot(t,zr);
 axis([0 ceil(maxtime/60) 0 100]); title(sprintf('Cells in PCM %d',k));
ylabel('SOC (%)'); xlabel('Time (min)');
end
% Plot individual cell current vs. time for all cells in all series PCMs
figure; clf; t = (0:(length(storei(:,:,1))-1))/60;
for k = 1:Ns,
 zr=squeeze(storei(:,k,:)); subplot(yplots,xplots,k); plot(t,zr);
  axis([0 ceil(maxtime/60) -101 101]); title(sprintf('Cells in PCM %d',k));
 ylabel('Current (A)'); xlabel('Time (min)');
```

Equivalent Circuit Cell Model Simulation | Simulating battery packs in different configurations

2.4.4: Introducing Octave code to simulate PCMs

Example simulation scenario




- We look at an example simulation with $N_s = 3$ and $N_p = 3$
- lacktriangle Cell SOCs are randomly initialized between 30 % and 70 %
- Cell R_0 values are randomly initialized between 5 m Ω and 25 m Ω
- Cell capacities are randomly initialized between 4.5 Ah and 5.5 Ah
- The pack is repeatedly
 - \Box Discharged at 10C rate until lowest cell hits 5 %
 - \Box Charged at 10C rate until highest cell hits 95 %
- After 45 min, the pack rests

Equivalent Circuit Cell Model Simulation | Simulating battery packs in different configurations | 8 of 11

2.4.4: Introducing Octave code to simulate PCMs

Results for cell SOCs






 Representative results for individual cell SOCs and PCM-average SOCs are shown

Dr. Gregory L. Plett | University of Colorado Colorado Spri

50



2.4.4: Introducing Octave code to simulate PCMs

Summary



- In this lesson, you have learned how to write Octave/MATLAB code to simulate battery packs built from PCMs
- This code allows for arbitrarily sized packs, and (optionally) allows for every cell to have different parameter values, and even to be faulted open- or short-circuit
- The code agrees with the math presented in the prior lesson
- Results show interesting and valuable insight into the individual cell responses in a battery pack comprising PCMs that would be difficult to measure in an actual pack

Dr. Gregory L. Plett | University of Colorado Colorado Spri

Equivalent Circuit Cell Model Simulation | Simulating battery packs in different configurations