Contents

| S485 Interface Commands and Documentation |
|---|
| Context |
| Board |
| Parameters |
| Command Structure |
| Limitations |
| Command List |
| Duty Cycle Control |
| Encoder |
| Temperature |
| Duty Cycle Thread Logic |

RS485 Interface Commands and Documentation

Context

Board

This interface is intended, and only compatible with, the custom 410_LACEP revision of the VESC Controller.

Parameters

The interface consists of an RS485 physical layer, using one differential pair. The data is transferred on a half-duplex serial UART running at **115200 baud**.

Command Structure

Each command consists of the *controller_id* a *command_name* and an optional sequence of *args* separated by *whitespace* and terminated with newline (\n).

```
<controller id> <command name> <args>\n
```

All directed commands return a *response* terminated by a single newline (\n).

```
<controller id> <response>\n
```

Some *command names* are available in short form (the first letter).

There is a *broadcast id* * that sends a command to all motors, but doesn't return any response.

In case a command does not match any on the list a error $\it response \it error \it response \it or \it command \it common \it commo$

Checkout the test.py file to see a Class that implements the communication and runs a battery of tests.

```
usage: python3 test.py
[-h] [--duty] [--encoder] [--temperature] [--all]
[--show] [--plot] [--forever] [--count COUNT]
port
```

Example:

```
python3 test.py --plot --all --count 1
```

Will run the following sequence:


- **Ramp** to the maximum duty cycle actuating both motors sequentially
- ullet Ramp to the maximum inverted duty cycle (runs in reverse) actuating both motors sequentially
- Ramp to stop both motors using the *broadcast id*.

- Run the motors in 0.3 duty cycle, while polling the encoder
- Read motor and MOSFET temperatures individually and with the combined temp command
- Plot the captured encoder data using matplotlib

The script also depends on numpy

Limitations

Preliminary tests have encountered problems running the board on the extremes of the possible range of control. The following figure is the plot of a "VESC Motor Experiment" sweeping the duty cycle from 0% to 100%.



The x-axis is correlated with the duty cycle. The duty cycle is incremented by 2% every 3 seconds. So the start of the usable band is at around 24s, divide by 3, so 8 steps totalling 16%. The upper limit is also identified at 84%. **So the usable duty cycle range is from 16%-84%**. The interface limits the actual duty cycle applied to the motor to the interval 10%-85% (in forward and reverse).

Command List

Duty Cycle Control

Set Duty Cycle Target

- Usage: <id> duty <setpoint>
- Short form: d
- Sets the target duty cycle to *setpoint*. The controller will then close the distance by adding the value of *delta* every *interval*.
- Response: Expected time to *setpoint* in seconds
- Example: 0 duty 0.3

Set Ramp Step

- Usage: <id> delta <value>
- Sets delta (in %) that the duty cycle will jump every interval
- Note: Setting the delta to >0.10 will cause oscillations when passing through the duty cycle deadzone (+/- 10%). Ideally the delta should be small to keep the ramp smooth. The default delta is 0.5%.
- Example: 0 delta 0.0025

Set Ramp Interval

• Usage: <id> interval <value>

• Short form: i

• Sets time interval between updates to the duty cycle in seconds.

• The default interval is 10ms.

• Example: 0 delta 0.005

Encoder

Read Encoder Count

• Usage: <id> encoder

• Short form: e

• Gets current encoder position in degrees

• Response: 216.40

Reset Encoder Count

• Usage: <id> reset encoder

• Short form: r

• Rests current encoder count.

• Response: 0

Temperature

Read Temperature Sensors

• Usage: <id> temp

• Short form: t

 Returns current temperature of motor and MOSFET in degree Celsius, separated by a comma.

Read Motor Temperature Sensor

• Usage: <id> temp motor

• Returns only the motor temperature in degree Celsius.

Read MOSFET Temperature Sensor

• Usage: <id> temp_mosfet

• Returns only the MOSFET temperature in degree Celsius.

Duty Cycle Thread Logic

The interface architecture is divided in two threads. One responsible to ingest, parse and respond to commands (*Commands Thread*) and another to update the motor duty cycle (*Duty Cycle Thread*).