
BODY LOWER BACK PANEL (CUT)

REPLACEMENT

With the back door opening side frame removed.




REMOVAL




F24065


175 mm (6.89 in.)



INSTALLATION

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the
 finish
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.





F24067

POINT

1 Inspect the fitting of the back door and rear combination light, etc., before welding, since this affects the appearance of the finish.

