

## LVDS (Tx/Rx) Design With 5V Devices in Sky130nm Process Transceiver Netlist

Nov 2023 Revision 0.1

Copyright © 2023 LeWiz Communications, Inc. All rights reserved

> PO Box 9276 San Jose, CA 95157

www.lewiz.com

Email: <a href="mailto:support@lewiz.com">support@lewiz.com</a>

## **Transceiver Netlist**

```
** sch path: /home/saumeek/xschem test/Transciever Netlist.sch
**.subckt Transciever Netlist Vinp Vinn Vout VCC INN INP BGR Vref Vss
VCC 1v8 Vinp1v8 Vinn1v8
*.ipin Vinp
*.ipin Vinn
*.opin Vout
*.iopin VCC
*.opin INN
*.opin INP
*.ipin BGR
*.ipin Vref
*.iopin Vss
*.iopin VCC 1v8
*.ipin Vinp1v8
*.ipin Vinn1v8
XM1 OP B Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=30 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM2 B B Vss Vss sky130 fd pr _{\rm nfet} g5v0d10v5 L=0.5 W=30 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM3 ON B Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=30 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM9 OP A VCC VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
```

```
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM10 A A VCC VCC sky130 fd pr pfet q5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM11 ON A VCC VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
IO ref VCC net1 500u
I1 ref VCC net2 500u
R3 C B 0.5k m=1
R4 A C 0.5k m=1
R5 OP INP 0.5k m=1
R6 ON INN 0.5k m=1
XM7 C C Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=2.5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM4 Vss OP net1 VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM5 C net3 net1 VCC sky130_fd_pr__pfet_g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
```

```
XM6 C net3 net2 VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM8 Vss ON net2 VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
V1 net3 Vss 2.5
 .save i(v1)
XM12 BGR BGR Vss Vss sky130 fd pr nfet q5v0d10v5 L=0.5 W=5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM13 net4 BGR Vss Vss sky130 fd pr fd nfet 
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM14 F F Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM15 net7 F Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM16 N1 net8 Vss Vss sky130 fd pr _{\rm nfet} g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
```

```
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' nrd='0.29 / W' nrs='0.29 / W'
```

+ sa=0 sb=0 sd=0 mult=1 m=1

XM17 net8 net8 Vss Vss sky130\_fd\_pr\_\_nfet\_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) \* W/nf \* 0.29'

+ as='int((nf+2)/2) \* W/nf \* 0.29' pd='2\*int((nf+1)/2) \* (W/nf + 0.29)' ps='2\*int((nf+2)/2) \* (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM18 net4 net4 VCC VCC sky130\_fd\_pr\_\_pfet\_g5v0d10v5 L=0.5 W=40 nf=1 ad='int((nf+1)/2) \* W/nf \* 0.29'

+ as='int((nf+2)/2) \* W/nf \* 0.29' pd='2\*int((nf+1)/2) \* (W/nf + 0.29)' ps='2\*int((nf+2)/2) \* (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM19 net6 net4 VCC VCC sky130\_fd\_pr\_\_pfet\_g5v0d10v5 L=0.5 W=50 nf=2 ad='int((nf+1)/2) \* W/nf \* 0.29'

+ as='int((nf+2)/2) \* W/nf \* 0.29' pd='2\*int((nf+1)/2) \* (W/nf + 0.29)' ps='2\*int((nf+2)/2) \* (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM20 net7 net7 VCC VCC sky130\_fd\_pr\_\_pfet\_g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) \* W/nf \* 0.29'

+ as='int((nf+2)/2) \* W/nf \* 0.29' pd='2\*int((nf+1)/2) \* (W/nf + 0.29)' ps='2\*int((nf+2)/2) \* (W/nf + 0.29)'

+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1

XM21 N1 net7 VCC VCC sky130\_fd\_pr\_\_pfet\_g5v0d10v5 L=0.5 W=67 nf=1 ad='int((nf+1)/2) \* W/nf \* 0.29' as='int((nf+2)/2) \* W/nf \* 0.29'

+ pd='2\*int((nf+1)/2) \* (W/nf + 0.29)' ps='2\*int((nf+2)/2) \* (W/nf + 0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM22 H net5 VCC VCC sky130\_fd\_pr\_\_pfet\_g5v0d10v5 L=0.5 W=67 nf=2 ad='int((nf+1)/2) \* W/nf \* 0.29' as='int((nf+2)/2) \* W/nf \* 0.29'

+ pd='2\*int((nf+1)/2) \* (W/nf + 0.29)' ps='2\*int((nf+2)/2) \* (W/nf + 0.29)' nrd='0.29 / W' nrs='0.29 / W'

+ sa=0 sb=0 sd=0 mult=1 m=1

XM23 net5 net5 VCC VCC sky130\_fd\_pr\_\_pfet\_g5v0d10v5 L=0.5 W=67 nf=2 ad='int((nf+1)/2) \* W/nf \* 0.29'

```
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29) ' ps='2*int((nf+2)/2) * (W/nf + 0.29)'
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM24 E E VCC VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM25 N1 E VCC VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=67 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM26 net8 OP net6 VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=50 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM27 F ON net6 VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=50 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM28 net5 ON D Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM29 E OP D Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM30 Vinv N1 VCC VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=30 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
```

```
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM31 Vinv N1 Vss Vss sky130 fd pr nfet q5v0d10v5 L=0.5 W=35 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM32 Vout Vinv VCC VCC sky130 fd pr pfet g5v0d10v5 L=0.5 W=50 nf=2
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29) ' ps='2*int((nf+2)/2) * (W/nf + 0.29) '
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM33 Vout Vinv Vss Vss sky130 fd pr _{\rm nfet} g5v0d10v5 L=0.5 W=67 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29) ' ps='2*int((nf+2)/2) * (W/nf + 0.29)'
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM34 D BGR Vss Vss sky130 fd pr nfet q5v0d10v5 L=0.5 W=83 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM35 H H Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=83 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM36 N1 H Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=83 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
```

+ sa=0 sb=0 sd=0 mult=1 m=1

x1 VCC\_1v8 Vss VCC Vinn1v8 Vinp1v8 Vref BGR Vinp Vinn INP INN OutputDriverNetlist\_5v

```
**.ends
```

```
* expanding
                                                           symbol: OutputDriverNetlist 5v.sym # of pins=11
** sym path: /home/saumeek/xschem test/OutputDriverNetlist_5v.sym
** sch path: /home/saumeek/xschem test/OutputDriverNetlist 5v.sch
 .subckt OutputDriverNetlist 5v VCC 1v8 Vss VCC5 Vinn1v8 Vinp1v8 Vref
BGR Vinp Vinn Vop Von
*.ipin Vinp
*.ipin Vinn
*.opin Vop
*.opin Von
*.iopin VCC5
*.iopin Vss
*.iopin VCC 1v8
*.ipin BGR
*.ipin Vref
*.ipin Vinp1v8
*.ipin Vinn1v8
R1 Vcm Vop 1.5k m=1
R2 Von Vcm 1.5k m=1
C5 C Vss 1p m=1
C6 net5 Vss 1p m=1
R11 Vcm net5 100 m=1
XM27 net6 H Vss Vss sky130_fd_pr__nfet_g5v0d10v5 L=0.5 W=25 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM8 net1 H Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=25 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
```

```
+ sa=0 sb=0 sd=0 mult=1 m=1
XM25 Vop pu net6 Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM7 Von pd net1 Vss sky130_fd_pr__nfet_g5v0d10v5 L=0.5 W=15 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM6 B C Vss Vss sky130 fd pr nfet q5v0d10v5 L=0.5 W=80 nf=6
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM11 H H Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=88 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM13 C C Vss Vss sky130 fd pr _{\rm nfet} g5v0d10v5 L=0.5 W=68 _{\rm nf}=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM15 K Vcm F Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=50 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM19 F BGR Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=55 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
```

```
+ sa=0 sb=0 sd=0 mult=1 m=1
XM16 E Vref F Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=50 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM23 net3 BGR Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM24 D BGR Vss Vss sky130 fd pr nfet q5v0d10v5 L=0.5 W=20 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM26 BGR Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=5.88 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29) ' ps='2*int((nf+2)/2) * (W/nf + 0.29) '
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM21 D net3 net4 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM20 net4 D VCC5 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=30 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM22 net3 vCC5 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
```

0.29) 'ps='2\*int((nf+2)/2) \* (W/nf + 0.29)'

```
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM17 E E VCC5 VCC5 sky130_fd_pr__pfet_g5v0d10v5 L=0.5 W=50 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM18 K K VCC5 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=50 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM14 C K VCC5 VCC5 sky130 fd pr pfet q5v0d10v5 L=0.5 W=68 nf=3
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM12 H D VCC5 VCC5 sky130_fd_pr__pfet_g5v0d10v5 L=0.5 W=85 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM1 Vop Vinn5 A VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=50 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM4 Von Vinp5 A VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=50 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf +
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM3 B Vinn5 Von VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=40 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
```

```
+ sa=0 sb=0 sd=0 mult=1 m=1
XM2 B Vinp5 Vop VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=40 nf=2
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM5 A E VCC5 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=80 nf=6
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM10 net2 D VCC5 VCC5 sky130 fd pr pfet q5v0d10v5 L=0.5 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM9 Vop pu net2 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=30 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM28 Von pd net7 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=30 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM29 net7 D VCC5 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
x2 pd pu dnl dpl Vinp1v8 Vinn1v8 VCC 1v8 Vss VCC5
LevelShifterNetlist 5v
x3 Vinp5 Vss VCC5 Vinn1 5Netlist
x1 Vinn5 Vss VCC5 Vinp 5Netlist
```

.ends

```
* expanding symbol: LevelShifterNetlist 5v.sym # of pins=9
** sym path: /home/saumeek/xschem test/LevelShifterNetlist 5v.sym
** sch path: /home/saumeek/xschem test/LevelShifterNetlist 5v.sch
 .subckt LevelShifterNetlist_5v Dn_H Dp_H Dn_L Dp_L vinp vinn VCC 1v8
VSS VCC5
*.opin Dp H
*.opin Dn H
*.ipin vinp
*.ipin vinn
*.opin Dp L
*.opin Dn L
*.iopin VCC5
*.iopin VSS
*.iopin VCC 1v8
XM1 Dn H Dp H VCC5 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=15 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29) 'ps='2*int((nf+2)/2) * (W/nf + 0.29)'
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM2 Dp H Dn H VCC5 VCC5 sky130 fd pr pfet g5v0d10v5 L=0.5 W=15 nf=1
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29) ' ps='2*int((nf+2)/2) * (W/nf + 0.29) '
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
XM5 Dn H Dp L VSS VSS sky130 fd pr nfet g5v0d10v5 L=0.5 W=50 nf=10
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29) ' ps='2*int((nf+2)/2) * (W/nf + 0.29) '
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
```

```
XM3 Dp H Dn L VSS VSS sky130 fd pr nfet g5v0d10v5 L=0.5 W=50 nf=10
ad='int((nf+1)/2) * W/nf * 0.29'
+ as='int((nf+2)/2) * W/nf * 0.29' pd='2*int((nf+1)/2) * (W/nf + 0.29' pd='2*int((nf+1)/2) * (W/nf +
0.29) ' ps='2*int((nf+2)/2) * (W/nf + 0.29) '
+ nrd='0.29 / W' nrs='0.29 / W' sa=0 sb=0 sd=0 mult=1 m=1
x2 Dp L VSS VCC 1v8 VCC5 vinp PreEmphasisDriverNetlist 1v8 3v3
x3 Dn L VSS VCC 1v8 VCC5 vinn PreEmphasisDriverNetlist 1v8 3v3
.ends
* expanding symbol: Vinn1 5Netlist.sym # of pins=3
** sym path: /home/saumeek/xschem test/Vinn1 5Netlist.sym
** sch path: /home/saumeek/xschem test/Vinn1 5Netlist.sch
.subckt Vinn1 5Netlist Vinn VSS VCC5
*.opin Vinn
*.iopin VCC5
*.iopin VSS
x3 net2 net3 VCC5 VSS inv 0 5 3v3
x1 Vinn net1 VCC5 VSS inv 0 5 3v3
x5 net5 net4 VCC5 VSS inv 0 5 3v3
x8 net1 net2 VCC5 VSS inv 1 5 3v3
x2 net3 net5 VCC5 VSS inv 1 5 3v3
x7 net4 Vinn VCC5 VSS inv 0 5 3v3
.ends
```

```
* expanding symbol: Vinp_5Netlist.sym # of pins=3

** sym_path: /home/saumeek/xschem_test/Vinp_5Netlist.sym

** sch_path: /home/saumeek/xschem_test/Vinp_5Netlist.sch
.subckt Vinp_5Netlist Vinp VSS VCC5

*.opin Vinp
```

```
*.iopin VCC5
*.iopin VSS
x9 Vinp net1 VCC5 VSS inv 0 5 3v3
x1 net4 net2 VCC5 VSS inv 0 5 3v3
x5 net5 net3 VCC5 VSS inv_0_5_3v3
x7 net1 net4 VCC5 VSS inv 1 5 3v3
x2 net2 net5 VCC5 VSS inv 1 5 3v3
x6 net3 Vinp VCC5 VSS inv 0 5 3v3
.ends
* expanding symbol: PreEmphasisDriverNetlist 1v8 3v3.sym # of
pins=5
** sym path:
/home/saumeek/xschem test/PreEmphasisDriverNetlist 1v8 3v3.sym
** sch path:
/home/saumeek/xschem test/PreEmphasisDriverNetlist 1v8 3v3.sch
.subckt PreEmphasisDriverNetlist 1v8 3v3 dn VSS Vcc VCC5 DpH
*.ipin DpH
*.opin dn
*.iopin VSS
*.iopin Vcc
*.iopin VCC5
x1 VSS DpH xor_out Buf_out Vcc xor
x10 Vcc DpH xor out net2 VSS and
x2 VSS net1 Buf out Vcc buf2
```

.ends

x3 VSS DpH net1 Vcc buf1

x6 VSS net2 dn VCC5 buf2 3v3

```
* expanding
                                   symbol:
/home/saumeek/simulation library/inv 0 5 3v3.sym # of pins=4
** sym path: /home/saumeek/simulation library/inv 0 5 3v3.sym
** sch path: /home/saumeek/simulation library/inv 0 5 3v3.sch
.subckt inv 0 5 3v3 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM3 Vout Vin Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=10 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM1 Vout Vin Vcc Vcc sky130 fd pr pfet g5v0d10v5 L=0.5 W=20 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
.ends
* expanding
                                   symbol:
/home/saumeek/simulation library/inv 1 5 3v3.sym # of pins=4
** sym_path: /home/saumeek/simulation library/inv 1 5 3v3.sym
** sch path: /home/saumeek/simulation library/inv 1 5 3v3.sch
.subckt inv 1 5 3v3 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM3 Vout Vin Vcc Vcc sky130 fd pr pfet g5v0d10v5 L=0.5 W=80 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
```

```
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM4 Vout Vin Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=40 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
 .ends
* expanding symbol: /home/saumeek/simulation library/xor.sym # of
pins=5
** sym path: /home/saumeek/simulation library/xor.sym
** sch path: /home/saumeek/simulation library/xor.sch
.subckt xor Vss A Vo B Vcc
*.iopin Vcc
*.iopin Vss
*.ipin A
*.opin Vo
*.ipin B
XM1 net3 Ab Vcc Vcc sky130 fd pr pfet 01v8 L=0.15 W=35 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM2 net4 A Vcc Vcc sky130 fd pr pfet 01v8 L=0.15 W=35 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM3 Vo Ab net1 Vss sky130_fd_pr__nfet_01v8 L=0.15 W=17 nf=1 \times
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
```

```
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM4 net1 Bb Vss Vss sky130 fd pr \  \   nfet 01v8 L=0.15 W=17 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM5 Vo A net2 Vss sky130 fd pr nfet 01v8 L=0.15 W=17 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM6 net2 B Vss Vss sky130 fd pr _{\rm nfet} 01v8 L=0.15 W=17 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
x1 A Ab Vcc Vss inv111
x2 B Bb Vcc Vss inv111
XM7 Vo B net3 Vcc sky130 fd pr pfet 01v8 L=0.15 W=35 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM8 Vo Bb net4 Vcc sky130 fd pr pfet 01v8 L=0.15 W=35 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
  .ends
```

<sup>\*</sup> expanding symbol: /home/saumeek/simulation\_library/and.sym # of pins=5

```
** sym path: /home/saumeek/simulation library/and.sym
** sch path: /home/saumeek/simulation library/and.sch
 .subckt and Vcc B A C VSS
*.opin C
*.iopin Vcc
*.iopin VSS
*.ipin A
*.ipin B
XM1 net1 A Vcc Vcc sky130 fd pr pfet 01v8 L=0.15 W=45 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM2 net1 B Vcc Vcc sky130 fd pr pfet 01v8 L=0.15 W=45 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM3 net1 A net2 VSS sky130 fd pr nfet 01v8 L=0.15 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM4 net2 B VSS VSS sky130 fd pr nfet 01v8 L=0.15 W=60 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM5 C net1 Vcc Vcc sky130 fd pr pfet 01v8 L=0.15 W=65 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
```

```
XM6 C net1 VSS VSS sky130 fd pr nfet 01v8 L=0.15 W=25 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
 .ends
* expanding symbol: buf2.sym # of pins=4
** sym path: /home/saumeek/xschem test/buf2.sym
** sch path: /home/saumeek/xschem test/buf2.sch
.subckt buf2 Vss Vin Buf out Vcc
*.iopin Vcc
*.iopin Vss
*.ipin Vin
*.opin Buf out
x1 Vin net1 Vcc Vss inv2
x2 net1 Buf out Vcc Vss inv22
.ends
* expanding symbol: bufl.sym # of pins=4
** sym path: /home/saumeek/xschem test/bufl.sym
** sch path: /home/saumeek/xschem test/bufl.sch
.subckt buf1 Vss Vin Buf out Vcc
*.iopin Vcc
*.iopin Vss
*.ipin Vin
*.opin Buf out
x1 Vin net1 Vcc Vss inv1
x2 net1 Buf out Vcc Vss inv11
```

.ends

```
* expanding symbol: buf2 3v3.sym # of pins=4
** sym path: /home/saumeek/xschem test/buf2 3v3.sym
** sch path: /home/saumeek/xschem test/buf2 3v3.sch
 .subckt buf2 3v3 Vss Vin Buf out Vcc
*.iopin Vcc
*.iopin Vss
*.ipin Vin
*.opin Buf out
x1 Vin net1 Vcc Vss inv2 3v3
x3 net1 Buf out Vcc Vss inv22 3v3
 .ends
* expanding
                                               symbol: /home/saumeek/simulation library/inv111.sym #
of pins=4
** sym path: /home/saumeek/simulation library/inv111.sym
** sch path: /home/saumeek/simulation library/inv111.sch
.subckt inv111 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM2 Vout Vin Vcc Vcc sky130 fd pr pfet 01v8 L=0.15 W=6 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
```

```
XM1 Vout Vin Vss Vss sky130 fd pr nfet 01v8 L=0.15 W=3 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
  .ends
* expanding symbol: /home/saumeek/simulation library/inv2.sym # of
pins=4
** sym path: /home/saumeek/simulation library/inv2.sym
** sch path: /home/saumeek/simulation library/inv2.sch
.subckt inv2 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM1 Vout Vin Vss Vss sky130 fd pr nfet 01v8 L=0.17 W=2 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM2 Vout Vin Vcc Vcc sky130 fd pr pfet 01v8 L=0.17 W=16 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
 .ends
* expanding symbol: /home/saumeek/simulation library/inv22.sym # of
pins=4
```

\*\* sym path: /home/saumeek/simulation library/inv22.sym

```
** sch path: /home/saumeek/simulation library/inv22.sch
 .subckt inv22 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM1 Vout Vin Vss Vss sky130 fd pr nfet 01v8 L=0.17 W=20 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM2 Vout Vin Vcc Vcc sky130 fd pr pfet 01v8 L=0.17 W=5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
 .ends
* expanding
                                                                                    symbol: /home/saumeek/simulation library/inv1.sym # of
pins=4
** sym path: /home/saumeek/simulation library/inv1.sym
** sch path: /home/saumeek/simulation library/inv1.sch
 .subckt invl Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM1 Vout Vin Vss Vss sky130 fd pr nfet 01v8 L=0.17 W=1.7 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
```

```
XM2 Vout Vin Vcc Vcc sky130 fd pr pfet 01v8 L=0.17 W=3 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
  .ends
* expanding symbol: /home/saumeek/simulation library/inv11.sym # of
pins=4
** sym path: /home/saumeek/simulation library/inv11.sym
** sch path: /home/saumeek/simulation library/inv11.sch
.subckt inv11 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM1 Vout Vin Vss Vss sky130 fd pr nfet 01v8 L=0.17 W=3 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM2 Vout Vin Vcc Vcc sky130 fd pr pfet 01v8 L=0.17 W=6.5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
 .ends
                                                                                   symbol: /home/saumeek/simulation library/inv2 3v3.sym #
* expanding
of pins=4
** sym path: /home/saumeek/simulation library/inv2 3v3.sym
```

```
** sch path: /home/saumeek/simulation library/inv2 3v3.sch
 .subckt inv2 3v3 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM3 Vout Vin Vss Vss sky130 fd pr nfet g5v0d10v5 L=0.5 W=15 nf=4
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
XM1 Vout Vin Vcc Vcc sky130 fd pr pfet q5v0d10v5 L=0.5 W=3 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
 .ends
* expanding
                                                                                  symbol: /home/saumeek/simulation library/inv22 3v3.sym
# of pins=4
** sym path: /home/saumeek/simulation library/inv22 3v3.sym
** sch path: /home/saumeek/simulation library/inv22 3v3.sch
 .subckt inv22 3v3 Vin Vout Vcc Vss
*.ipin Vin
*.opin Vout
*.iopin Vcc
*.iopin Vss
XM3 Vout Vin Vcc Vcc sky130 fd pr pfet g5v0d10v5 L=0.5 W=20 nf=5
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' ps='2*i
0.29) ' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
```

```
XM4 Vout Vin Vss Vss sky130_fd_pr__nfet_g5v0d10v5 L=0.5 W=5 nf=1
ad='int((nf+1)/2) * W/nf * 0.29' as='int((nf+2)/2) * W/nf * 0.29'
+ pd='2*int((nf+1)/2) * (W/nf + 0.29)' ps='2*int((nf+2)/2) * (W/nf + 0.29)' nrd='0.29 / W' nrs='0.29 / W'
+ sa=0 sb=0 sd=0 mult=1 m=1
.ends
```

.end