```
// OutBinNibble.mal
//
// Note that this is nearly identical to the example
// given in Tanenbaum's book (Figure 4-17).
// Intrepretation of four additional opcodes (HALT, ERR, IN, OUT)
// have been added for completeness. Also, it interprets the opcode OUTBIN.
// Note:
//
// 1) SlashSlash-style ("//") comment characters have been added.
// 2) "nop" has been added as a pseudo-instruction to indicate that
//
     nothing should be done except goto the next instruction. It
//
     is a do-nothing sub-instruction that allows us to have MAL
//
     statements without a label.
//
// 3) instructions are "anchored" to locations in the control
//
     store as defined below with the ".label" pseudo-instruction
//
// 4) a default instruction may be specified using the ".default"
//
     pseudo-instruction. This instruction is placed in all
//
     unused locations of the control store by the mic1 MAL assembler.
//
// labeled statements are "anchored" at the specified control store address
.label
          nop1
                       0x00
.label
         bipush1
                       0x10
.label
          ldc w1
                       0x13
.label
          iload1
                       0x15
.label
          istore1
                       0x36
.label
          rot1
                       0x20
.label
         addd1
                       0x30
.label
         outBin1
                      0x40
.label
         pop1
                       0x57
.label
          dup1
                       0x59
.label
          swap1
                       0x5F
.label
          iadd1
                       0x60
          isub1
.label
                       0x64
          iand1
.label
                       0x7E
.label
          iinc1
                       0x84
          ifeg1
.label
                       0x99
.label
          iflt1
                       0x9B
.label
          if icmpeq1 0x9F
          goto1
                       0xA7
.label
          ireturn1
.label
                       0xAC
          ior1
.label
                       0xB0
.label
          invokevirtual1
                             0xB6
.label
         wide1 0xC4
.label
          in1
                       0xFC
          out1
.label
                       0xFD
.label
           err1
                       OxFE
.label
           halt1
                       OxFF
           wide_iload1 0x115
.label
.label
           wide istore1
                             0x136
// default instruction to place in any unused addresses of the control store
.default
          goto err1
```

```
Main1 PC = PC + 1; fetch; goto (MBR) // MBR holds opcode; get next byte; dispatch
                                   // Do nothing
nop1 goto Main1
iadd1 MAR = SP = SP - 1; rd
                                   // Read in next-to-top word on stack
iadd2 H = TOS
                                   // H = top of stack
iadd3 MDR = TOS = MDR + H; wr; goto Main1 // Add top two words; write to TOS
isub1 MAR = SP = SP - 1; rd
                                   // Read in next-to-top word on stack
isub2 H = TOS
                                   // H = top of stack
isub3 MDR = TOS = MDR - H; wr; goto Main1 // Do subtraction; write to TOS
iand1 MAR = SP = SP - 1; rd
                                   // Read in next-to-top word on stack
iand2 H = TOS
                                   // H = top of stack
iand3 MDR = TOS = MDR AND H; wr; goto Main1
                                              // Do AND; write to new TOS
ior1 MAR = SP = SP - 1; rd
                                   // Read in next-to-top word on stack
                                   // H = top of stack
ior2 H = Tos
ior3 MDR = TOS = MDR OR H; wr; goto Main1
                                              // Do OR; write to new TOS
dup1 MAR = SP = SP + 1
                                   // Increment SP and copy to MAR
dup2 MDR = TOS; wr; goto Main1
                                   // Write new stack word
                                   // Read in next-to-top word on stack
pop1 MAR = SP = SP - 1; rd
pop2
                                   // Wait for new TOS to be read from memory
pop3 TOS = MDR; goto Main1
                                   // Copy new word to TOS
swap1 MAR = SP - 1; rd // Set MAR to SP - 1; read 2nd word from stack
swap2 MAR = SP
                                   // Set MAR to top word
swap3 H = MDR; wr
                                   // Save TOS in H; write 2nd word to TOS
swap4 MDR = TOS
                                  // Copy old TOS to MDR
                           // Set MAR to SP - 1; write as 2nd word on stack
swap5 MAR = SP - 1; wr
swap6 TOS = H; goto Main1
                                   // Update TOS
           SP = MAR = SP + 1
                                   // MBR = the byte to push onto stack
bipush1
bipush2
           PC = PC + 1; fetch
                                   // Increment PC, fetch next opcode
bipush3
           MDR = TOS = MBR; wr; goto Main1
                                   // Sign-extend constant and push on stack
iload1
           H = LV
                                   // MBR contains index; copy LV to H
                                   // MAR = address of local variable to push
iload2
           MAR = MBRU + H; rd
           MAR = SP = SP + 1 // SP points to new top of stack; prepare write
iload3
iload4
           PC = PC + 1; fetch; wr // Inc PC; get next opcode; write top of stack
iload5
           TOS = MDR; goto Main1 // Update TOS
                                   // MBR contains index; Copy LV to H
istore1
           H = LV
                                   // MAR = address of local variable to store
istore2
           MAR = MBRU + H
into
           MDR = TOS; wr
                                  // Copy TOS to MDR; write word
istore3
istore4
          SP = MAR = SP - 1; rd
                                  // Read in next-to-top word on stack
istore5
          PC = PC + 1; fetch
                                  // Increment PC; fetch next opcode
istore6
          TOS = MDR; goto Main1
                                  // Update TOS
```

```
wide1 PC = PC + 1; fetch; goto (MBR OR 0x100)
                                    // Multiway branch with high bit set
wide iload1 PC = PC + 1; fetch
                                   // MBR contains 1st index byte; fetch 2nd
wide_iload2 H = MBRU << 8 // H = 1st index byte shifted left 8 bits wide iload3 H = MBRU OR H // H = 16-bit index of local variable
wide iload3 H = MBRU OR H
                                   // H = 16-bit index of local variable
wide iload4 MAR = LV + H; rd; goto iload3
                                    // MAR = address of local variable to push
                PC = PC + 1; fetch // MBR contains 1st index byte; fetch 2nd
wide istore1
ldc_w1 PC = PC + 1; fetch // MBR contains 1st index byte; fetch 2nd ldc_w2 H = MBRU << 8 // H = 1st index byte << 8 ldc_w3 H = MBRU OR H // H = 16-bit index byte
                              // MAR = address of local variable to store into
          MAR = H + CPP; rd; goto iload3 // MAR = address of constant in pool
iinc1 H = LV
                                    // MBR contains index; Copy LV to H
iinc2 MAR = MBRU + H; rd
                                    // Copy LV + index to MAR; Read variable
iinc3 PC = PC + 1; fetch
                                    // Fetch constant
                                   // Copy variable to H
// Fetch next opcode
iinc4 H = MDR
iinc5 PC = PC + 1; fetch
iinc6 MDR = MBR + H; wr; goto Main1 // Put sum in MDR; update variable
goto1 OPC = PC - 1
                                   // Save address of opcode.
                               // MBR = 1st byte of offset; fetch 2nd byte
// Shift and save signed first byte in H
// H = 16-bit branch offset
// Add offset to OPC
goto2 PC = PC + 1; fetch
goto3 H = MBR << 8
goto4 H = MBRU OR H
goto5 PC = OPC + H; fetch
                                   // Wait for fetch of next opcode
goto6 goto Main1
iflt1 MAR = SP = SP - 1; rd // Read in next-to-top word on stack
iflt2 OPC = TOS
                                    // Save TOS in OPC temporarily
iflt3 TOS = MDR
                                   // Put new top of stack in TOS
iflt4 N = OPC; if (N) goto T; else goto F // Branch on N bit
ifeq1 MAR = SP = SP - 1; rd
                                   // Read in next-to-top word of stack
ifeq2 OPC = TOS
                                    // Save TOS in OPC temporarily
ifeq3 TOS = MDR
                                    // Put new top of stack in TOS
ifeq4 Z = OPC; if (Z) goto T; else goto F // Branch on <math>Z bit
// Copy second stack word to H
if icmpeq3 H = MDR; rd
if_icmpeq4 OPC = TOS
if_icmpeq5 TOS = MDR
                                   // Save TOS in OPC temporarily
                                   // Put new top of stack in TOS
if_icmpeq6 Z = OPC - H; if (Z) goto T; else goto F
                              // If top 2 words are equal, goto T, else goto F
      OPC = PC - 1; fetch; goto goto2
                              // Same as goto1; needed for target address
F
     PC = PC + 1
                                   // Skip first offset byte
     PC = PC + 1; fetch
F2
                                   // PC now points to next opcode
     goto Main1
                                   // Wait for fetch of opcode
```

```
invokevirtual1 PC = PC + 1; fetch // MBR = index byte1; inc. PC, get 2nd byte
invokevirtual2  H = MBRU << 8  // Shift and save first byte in H
invokevirtual3 H = MBRU OR H // H = offset of method pointer from CI invokevirtual4 MAR = CPP + H; rd // Get pointer to method from CPP area
                                  // H = offset of method pointer from CPP
invokevirtual5 OPC = PC + 1 // Save Return PC in OPC temporarily
invokevirtual6 PC = MDR; fetch // PC points to new method; get param count
invokevirtual7 PC = PC + 1; fetch // Fetch 2nd byte of parameter count
invokevirtual8 H = MBRU << 8 // Shift and save first byte in H
invokevirtual9 H = MBRU OR H
                                   // H = number of parameters
invokevirtual10 PC = PC + 1; fetch // Fetch first byte of # locals invokevirtual11 TOS = SP - H // TOS = address of OBJREF - 1
invokevirtual12 TOS = MAR = TOS + 1 // TOS = address of OBJREF (new LV)
invokevirtual13 PC = PC + 1; fetch // Fetch second byte of # locals
invokevirtual14 H = MBRU << 8
                                  // Shift and save first byte in H
invokevirtual15 H = MBRU OR H
                                   // H = # locals
invokevirtual16 MDR = SP + H + 1; wr // Overwrite OBJREF with link pointer
invokevirtual17 MAR = SP = MDR; // Set SP, MAR to location to hold old PC
invokevirtual18 MDR = OPC; wr
                                  // Save old PC above the local variables
invokevirtual19 MAR = SP = SP + 1 // SP points to location to hold old LV
invokevirtual20 MDR = LV; wr
                                   // Save old LV above saved PC
invokevirtual21 PC = PC + 1; fetch // Fetch first opcode of new method.
invokevirtual22 LV = TOS; goto Main1 // Set LV to point to LV Frame
ireturn1
          MAR = SP = LV; rd
                                   // Reset SP, MAR to get link pointer
ireturn2
                                   // Wait for read
ireturn3 LV = MAR = MDR; rd
                                   // Set LV to link ptr; get old PC
ireturn4 MAR = LV + 1
                                   // Set MAR to read old LV
ireturn5   PC = MDR; rd; fetch
                                  // Restore PC; fetch next opcode
ireturn6 MAR = SP
                                   // Set MAR to write TOS
                                    // Restore LV
ireturn7 LV = MDR
ireturn8 MDR = TOS; wr; goto Main1 // Save return value on original TOS
halt1 goto halt1
err1 OPC = H = -1
      OPC = H + OPC
     MAR = H + OPC
                                   // compute IO address
      OPC = H = 1
                                   // 1
                                  // 10
      OPC = H = H + OPC
                                  // 100
      OPC = H = H + OPC
                                  // 1000
      OPC = H = H + OPC
                                 // 10001
      OPC = H = H + OPC + 1
                                   // 100010
      OPC = H = H + OPC
                                  // 1000101 'E'
     MDR = H + OPC + 1; wr
                                   // 1
      OPC = H = 1
      OPC = H = H + OPC
                                  // 10
                                  // 101
      OPC = H = H + OPC + 1
      OPC = H = H + OPC
                                  // 1010
                                  // 10100
      OPC = H = H + OPC
     OPC = H = H + OPC + 1
                                   // 101001
                                   // 1010010 'R'
     MDR = H + OPC; wr
      nop
                                  // 1010010 'R'
     MDR = H + OPC; wr
                                   // 1
      OPC = H = 1
                                  // 10
      OPC = H = H + OPC
                                   // 100
      OPC = H = H + OPC
                                   // 1001
      OPC = H = H + OPC + 1
```

```
// 1
     OPC = H = 1

OPC = H = H + OPC

OPC = H = H + OPC + 1

OPC = H = H + OPC

OPC = H = H + OPC
                              // 10
// 101
// 1010
// 10100
// 101001
// 1010010 'R'
     OPC = H = H + OPC + 1
MDR = H + OPC; wr
     goto halt1
out1 OPC = H = -1
     OPC = H + OPC
                               // compute OUT address
     MAR = H + OPC
                                   // write to output
     MDR = TOS; wr
     nop
     MAR = SP = SP - 1; rd // decrement stack pointer
     nop
     TOS = MDR; goto Main1
in1 OPC = H = -1
     OPC = H + OPC
     //
// OUTBIN - written by Prabu - 44 micro instructions
//
      Pop the top element of stack and print the value in binary format
//
        as 8 nibbles that are separated by a space
//
//
    Pseudo code
     - pop top of stack (value to be printed) to TOS and store CPP value
//
      - push the following constants to stack
//
//
           8 (number of nibbles to printed - outer loop iterations)
//
           4 (number of bits in a nibble - inner loop iterations)
           32 (ascii value for char blank)
//
           48 (ascii value for char zero)
//
     - use H, OPC, TOS, MDR, and CPP as temporary registers
//
//
           OPC: holds nibble size (inner loop counter variable)
//
           TOS: holds operand value to be printed out
//
           CPP: holds -3 (address for output operation)
//
      - outer loop (nibble iteration) - 8 times
//
            * inner loop (bit iteration) - 4 times
//
                 print the bit as '1' or '0'
//
            * print a blank
//
     - at the end, pop old CPP value to CPP
//
```

```
outBin1
         MAR = SP; rd
                                 // pop the top of stack element to TOS
     nop
                                 // Hold the operand to TOS
     TOS = MDR
     MDR = CPP; wr
                                 // Save CPP - write to stack
     MDR = H = 1
     MDR = H = H + MDR
     MDR = H = H + MDR
     MDR = H + MDR
                                // push nibble count (8) on stack
     MAR = SP = SP + 1; wr
                                 // OPC = 4
     OPC = MDR = H
     MAR = SP = SP + 1; wr
                                 // push bitcount (nibble size as 4) on stack
     MDR = H = H + MDR
     MDR = H = H + MDR
     MDR = H + MDR
                                 // MDR = 32
     MAR = SP = SP + 1; wr
                                 // push ascii char space on stack
     MDR = H + MDR
                                 // MDR = 48
     MAR = SP = SP + 1; wr
                                 // push ascii char zero on stack
     CPP = -1
     CPP = CPP - 1
     CPP = CPP - 1
                                 // CPP = -3 (address for output operation)
         MAR = SP; rd
                                 // read top of stack (ascii char zero)
bitLoop
     N = TOS; if (N) goto incOutCh; else goto printCh
incOutCh MDR = MDR + 1
         MAR = CPP; wr
                                 // print the bit value as ascii char
printCh
     H = TOS
                                 // Left shift the operand
     TOS = H + TOS
     OPC = OPC - 1; if (Z) goto decNibbles; else goto bitLoop
                                 // Decrement bitcount & test
decNibbles MAR = SP - 1; rd
                                 // read space char from the stack
     nop
     MAR = CPP; wr
                                 // write a space char to output device
     MDR = SP - 1
     MAR = MDR - 1; rd
                                 // MAR = SP-2
     H = CPP
     MAR = H + SP; rd
                                  // read previous nibble count i.e. MAR= SP-3
     OPC = MDR
     MDR = MDR - 1; wr; if (Z) goto endOutBin; else goto bitLoop1
                                  // write decremented nibble count
endOutBin H = CPP - 1
                                  // H = -4
     MAR = SP = H + SP; rd
     nop
                                 // Restore CPP value
     CPP = MDR
     MAR = SP = SP - 1; rd
     nop
     TOS = MDR; goto Main1
                            // Set TOS with the current TOS value
bitLoop1 goto bitLoop
```