

Board can be configured for Line or Tree/Star network. Tile 0 UART.TX LVDS7.out1 L7.in1 ← LVDS7.out0 OUT0 L7.in0 ← L7.out0 D L7.out1 D L7.in0 < LVDS7.in0 DINO POWER XTAG LVDS7.in1 LVDS_EN UART_RX ♦ DLVDS_EN LVDS.sch UART_TX ♦ XTAGout.in1 >XL.in1 RST L4.in1 < XTAGout.in0 XL.in0 TileO.sch XTAGout.out0 XL.out0 power.sch XTAGout.out1 DXL.out1 XTAG.in1 >XTAG.in1 XTAG.in0 Tile1 >XTAG.in0 XTAG.out0 XMOS USB/JTAG XTAG.out0 L7.in1< LVDS4.out1 L4.in1 ← XTAG.out1 OXTAG.out1 XMOS_TDO 2 LVDS4.out0 L4.in0 TDI 1 LVDS4.in0 >TDI XMOS_TDID L4.out0 TMS L4.out0D DINO TMS L4.out1D L4.out1 LVDS4.in1 DIN1 TCK >TCK DEBUG **DEBUG ♦** ♦ DEBUG XTAG.sch XMOS_USB.sch LVDS_EN LINE TREE LVDS2 L2.in1 →XTAGout.out1 TREE LINE L2.in1 L2.in1 V+□→ +3V3 LVDS3 XTAG.out1 → →XTAGout.out0 LVDS2.out0 DEN OUT1D / DL3.in1 L2.in0< L3.in0 L2.out0 LVDS3.out0 XTAG.out0 → ← XTAGout.in0 L2.out0 ✓ LVDS2.in0 >INO +3∨3 ← ∪∨+ >L3.in0 L3.out0 XTAG.in0 ← LVDS2.in1 >IN1 v-d→ \ \frac{2}{5} L3.out0 L2.out1 ₹ 4+v-LVDS.sch L3.out1 RN2 XTAG.in1 ← <mark>⊒ 3</mark> □L3.out0 1L3.out1 LVDS.sch Tile1.sch Open Source openPnP Sheet: / H2 MountingHole H4 MountingHole File: XMOS_XUF216_FB236.sch Title: XMOS top level Size: A4 Date: 2019-01-08 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 1/16






LWDS: 100 ohm Zdiff impedance in coupled microstrip line. Spacing 3.5 mil. Width 7 mil. H=180um. Side clearance 20mil. 1/2 FR-4: KB-6160/6160A/6100.

3/6 Lx0 IN +/-

Lx0_OUT +/-

4/5 Lx1 OUT +/-

7/8 Lx1_IN +/-



Optional pulldown if needed.

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown.
Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

Open Source
openPnP
Sheet: /LVDS7/
File: LVDS.sch


Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-08
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 2/16


Cards can be power by USB or by the barrel jack 8-48V. Alternative "+48V" can come from a connected daugther card. Both USB and +48V should not be connected on the same PCB. USB ground should be isolated from power ground for PC safety.


Power ports are Global in the schematics.




GND

⇟ GND









VDDIO/OTP_VCC and VDD can ramp up independently. In order to reduce stresses on the device, it is preferable to make them ramp up in a short time frame of each other, no more than 50 ms apart.


RST_N and TRST_N should be kept low until all power supplies are stable and within tolerances of their final voltage.

If your design is powered by VBUS, then RST_N should go high within 10 ms of attaching to VBUS in order to ensure that USB timings are met.

RST_N should be at least 1 ms after VDDIO good to enable the built—in flash to settle









Open Source openPnP Sheet: /POWER/ File: power.sch

Title: Power Size: A4

Date: 2019-01-08 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 3/16






LWDS: 100 ohm Zdiff impedance in coupled microstrip line. Spacing 3.5 mil. Width 7 mil. H=180um. Side clearance 20mil. FR-4: KB-6160/6160A/6160C 1/2

> 3/6 Lx0 IN +/-

Lx0_OUT +/-

Lx1 OUT +/-

 $Lx1_IN +/-$




Optional pulldown if needed.


Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.


This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


Open Source openPnP Sheet: /LVDS2/ File: LVDS.sch


Title: LVDS <-> Xlinks Size: A4 Date: 2019-01-08 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1 ld: 4/16















LWDS: 100 ohm Zdiff impedance in coupled microstrip line. Spacing 3.5 mil. Width 7 mil. H=180um. Side clearance 20mil. FR-4: KB-6160/6160A/6160C 1/2

> 3/6 Lx0 IN +/-

Lx0_OUT +/-

Lx1 OUT +/-

Lx1_IN +/-



Optional pulldown if needed.


Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

Open Source openPnP Sheet: /Tile1/LVDS1/ File: LVDS.sch

Title: LVDS <-> Xlinks

Size: A4 Date: 2019-01-08 Rev: BETA KiCad E.D.A. kicad (5.0.2)-1ld: 9/16




LWDS: 100 ohm Zdiff impedance in coupled microstrip line. Spacing 3,5 mil. Width 7 mil. H=180um. Side clearance 20mil. FR-4: KB-6160/6160A/6160C

1/2 Lx0_OUT +/-

3/6 Lx0_IN +/-

4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



INOD-DIN2 DOUT2+ DOUT2-ROUT1 OUTO & RIN1+ 0UT1 **(** ROUT2 RIN1-RIN2+ Not a Diff-pair. (EN & !EN) END END END L.in1-GND RIN2-!EN R37 DS90LV049TMT 100R

> Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

R38 100R


	_		
$Lx0_OUT +$	1 🔨 🔨	-1	Lx0_OUT +
Lx0_OUT -	2	2	Lx0_OUT -
Lx0 IN +	3	> 3	Lx0_IN +
Lx1 OUT +	4 🔪	$\sqrt{4}$	Lx1 OUT +
Lx1 OUT -	5 >	\sim 5	Lx1 OUT -
Lx0 IN -	6	6	Lx0 IN -
Lx1 IN +	7	7	Lx1 IN +
Lx1 IN -	8	8	Lx1 IN -
_			_
DC GND	SHIELD -	■ SHIELD	DC GND

Open Source
openPnP
Sheet: /LVDS4/
File: LVDS.sch

Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-08
 Rev: BETA


 KiCad E.D.A. kicad (5.0.2)-1
 Id: 10/16






LWDS: 100 ohm Zdiff impedance in coupled microstrip line. Spacing 3,5 mil. Width 7 mil. H=180um. Side clearance 20mil. FR-4: KB-6160/6160A/6160C

1/2 Lx0_OUT +/-





Optional pulldown if needed.

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


Lx0_OUT +	1	1	Lx0_OUT +
Lx0_OUT -	2	\sim 2	Lx0_OUT -
Lx0_IN +	3	> 3	Lx0_IN +
Lx1_OUT +	4 🔪	4	Lx1_OUT +
Lx1 OUT -	5 >	5	Lx1 OUT -
Lx0_IN -	6	6	Lx0_IN -
Lx1_IN +	7	7	Lx1_IN +
Lx1_IN -	8	→ 8	Lx1_IN -
	T	•	
DC GND	SHIELD -	■ SHIELD	DC GND


Open Source
openPnP
Sheet: /TileO/LVDS6/
File: LVDS.sch

 Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-08
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 12/16






LWDS: 100 ohm Zdiff impedance in coupled microstrip line. Spacing 3.5 mil. Width 7 mil. H=180um. Side clearance 20mil. 1/2 FR-4: KB-6160/6160A/6100.

3/6 Lx0 IN +/-

Lx0_OUT +/-

4/5 Lx1 OUT +/-

7/8 Lx1 IN +/-



Optional pulldown if needed.

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown.
Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


Open Source
openPnP
Sheet: /TileO/LVDS5/


File: LVDS.sch

Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-08
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 13/16






LWDS: 100 ohm Zdiff impedance in coupled microstrip line. Spacing 3.5 mil. Width 7 mil. H=180um. Side clearance 20mil. 1/2 FR-4: KB-6160/6160A/6100.

1/2 Lx0_OUT +/-

3/6 Lx0_IN +/-

4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



Optional pulldown if needed.

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown.
Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.


Open Source
openPnP
Sheet: /Tile0/LVDS0/
File: LVDS.sch

Title: LVDS <-> Ylinks

 Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-08
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 14/16






RJ45 PINOUT: LWDS: 100 ohm Zdiff impedance in coupled microstrip line. Spacing 3.5 mil. Width 7 mil. H=180um. Side clearance 20mil. 1/2 Lx0_OUT +/- FR-4: KB-6160/6160A/6160C

3/6 Lx0 IN +/-

4/5 Lx1_OUT +/-

7/8 Lx1_IN +/-



100nF C53

Unconnected LVDS input gives HI out on TTL side. Active XLinks input should be LO during reset. XMOS pins has internal pulldown. Transciever needs to be in HiZ during XMOS reset.

This should give hardware support for hotswap with unconnected active XLinks, with bootloader in Flash.

Lx0_OUT + Lx0_OUT - Lx0_IN + Lx1_OUT + Lx1_OUT - Lx0_IN -	1 2 3 4 5 6	$\begin{array}{c} 1\\2\\3\\4\\5\\6\\7\end{array}$	Lx0_OUT + Lx0_OUT - Lx0_IN + Lx1_OUT + Lx1_OUT - Lx0_IN -
Lx1_IN + Lx1_IN -	7 8	7 8	Lx1_IN + Lx1_IN -
DC GND	SHIELD -	■ SHIELD	DC GND

Open Source
openPnP
Sheet: /LVDS3/
File: LVDS.sch

Title: LVDS <-> Xlinks

 Size: A4
 Date: 2019-01-08
 Rev: BETA

 KiCad E.D.A. kicad (5.0.2)-1
 Id: 16/16