

PCB NOTES: * D for charge circuit are DB2|314 or similar SMD diode * +5V comes from USB micro type B * +5V switch voltage is the regulated 5V power for pi/peripherals * D2 - select diode of small inverse current (I R=1uA below/5V) * DNP should be in schematic and PCB, but not placed * 5mAh battery is ML621 or P044-ND from digikey * Reference AAA4000COL19.pdf for R3/R4 changes for different battery * To ensure <330mA of inrush current, 470pF Chosen based on SR=0.146*C t+14.78 for CT * SR requires >220us for to achieve <330mA inrush current * CT capacitor should be X5R/X7R dialectric rating with >25V rating * dV = I load*R on to give the voltage drop fron in/out * Reference TPS22958DGKR datasheet for layout example * NOTE: All the 5V traces from USB and to PI power need to support 3A at 5V OPERATION: DS3231 ALARM to turn on power: * When an ALARM(active low) is triggered, it forces interrupt on ATTiny ATTinv84 * Active low INT from DS3231 will assert EN/ON pin on load switch high * Active low INT from push button asserts EN/ON pin on load switch. will also assert pi_rx_dev_mode so pi knows it should halt running tracking so it can be operated on by user * Active high INT from pi: when pi wakes up, it needs to assert pi tx hold on while it is on. * If pi tx hold on goes low, uC holds power on for programmable time to allow safe shutdown of pi. Then EN is tied to GND to turn load switch off * SPI inputs used for programming a .hex via ICSP Shutting down pi: * Set ALARM time for next wake up. * Deassert pi tx hold on to signal power-down is commencing Limitations: * NO support yet for shutdown button. Might add this with SW for ATTiny84 TITLE: **REV: 1.0 New Schematic** 2018-10-14 Sheet: 1/1 Drawn By: glennicholls0 EasyEDA V5.7.26