Theory of Electromagnetic Fields

Andrzej Wolski

University of Liverpool, and the Cockcroft Institute, UK

Abstract

We discuss the theory of electromagnetic fields, with an emphasis on aspects relevant to radiofrequency systems in particle accelerators. We begin by reviewing Maxwell's equations and their physical significance. We show that in free space, there are solutions to Maxwell's equations representing the propagation of electromagnetic fields as waves. We introduce electromagnetic potentials, and show how they can be used to simplify the calculation of the fields in the presence of sources. We derive Poynting's theorem, which leads to expressions for the energy density and energy flux in an electromagnetic field. We discuss the properties of electromagnetic waves in cavities, waveguides and transmission lines.

Maxwell's equations

Maxwell's equations may be written in differential form as follows:

$$\nabla \cdot \vec{D} = \rho,$$

$$\nabla \cdot \vec{B} = 0,$$
(1)

$$\nabla \cdot \vec{B} = 0, \tag{2}$$

$$\nabla \times \vec{H} = \vec{J} + \frac{\partial \vec{D}}{\partial t}, \tag{3}$$

$$\nabla \times \vec{E} = -\frac{\partial \vec{B}}{\partial t}.$$
 (4)

The fields \vec{B} (magnetic flux density) and \vec{E} (electric field strength) determine the force on a particle of charge q travelling with velocity \vec{v} (the Lorentz force equation):

$$\vec{F} = q \left(\vec{E} + \vec{v} \times \vec{B} \right).$$

The electric displacement \vec{D} and magnetic intensity \vec{H} are related to the electric field and magnetic flux density by the constitutive relations:

$$\vec{D} = \varepsilon \vec{E},$$

$$\vec{B} = \mu \vec{H}.$$

The electric permittivity ε and magnetic permeability μ depend on the medium within which the fields exist. The values of these quantities in vacuum are fundamental physical constants. In SI units:

$$\mu_0 = 4\pi \times 10^{-7} \,\mathrm{Hm}^{-1},$$
 $\varepsilon_0 = \frac{1}{\mu_0 c^2},$

where c is the speed of light in vacuum. The permittivity and permeability of a material characterize the response of that material to electric and magnetic fields. In simplified models, they are often regarded as constants for a given material; however, in reality the permittivity and permeability can have a complicated dependence on the fields that are present. Note that the *relative permittivity* ε_r and the *relative* permeability μ_r are frequently used. These are dimensionless quantities, defined by:

$$\varepsilon_r = \frac{\varepsilon}{\varepsilon_0}, \quad \mu_r = \frac{\mu}{\mu_0}.$$
 (5)




Fig. 1: Snapshot of a numerical solution to Maxwell's equations for a bunch of electrons moving through a beam position monitor in an accelerator vacuum chamber. The colours show the strength of the electric field. The bunch is moving from right to left: the location of the bunch corresponds to the large region of high field intensity towards the left hand side. (Image courtesy of M. Korostelev.)

That is, the relative permittivity is the permittivity of a material relative to the permittivity of free space, and similarly for the relative permeability.

The quantities ρ and \vec{J} are respectively the electric charge density (charge per unit volume) and electric current density ($\vec{J} \cdot \vec{n}$ is the charge crossing unit area perpendicular to unit vector \vec{n} per unit time). Equations (2) and (4) are independent of ρ and \vec{J} , and are generally referred to as the "homogeneous" equations; the other two equations, (1) and (3) are dependent on ρ and \vec{J} , and are generally referred to as the "inhomogeneous" equations. The charge density and current density may be regarded as *sources* of electromagnetic fields. When the charge density and current density are specified (as functions of space, and, generally, time), one can integrate Maxwell's equations (1)–(3) to find possible electric and magnetic fields in the system. Usually, however, the solution one finds by integration is not unique: for example, as we shall see, there are many possible field patterns that may exist in a cavity (or waveguide) of given geometry.

Most realistic situations are sufficiently complicated that solutions to Maxwell's equations cannot be obtained analytically. A variety of computer codes exist to provide solutions numerically, once the charges, currents, and properties of the materials present are all specified, see for example References [1–3]. Solving for the fields in realistic systems (with three spatial dimensions, and a dependence on time) often requires a considerable amount of computing power; some sophisticated techniques have been developed for solving Maxwell's equations numerically with good efficiency [4]. An example of a numerical solution to Maxwell's equations in the context of a particle accelerator is shown in Fig. 1. We do not consider such techniques here, but focus instead on the analytical solutions that may be obtained in idealized situations. Although the solutions in such cases may not be sufficiently accurate to complete the design of real accelerator components, the analytical solutions do provide a useful basis for describing the fields in (for example) real RF cavities and waveguides.

An important feature of Maxwell's equations is that, for systems containing materials with constant permittivity and permeability (i.e. permittivity and permeability that are independent of the fields present), the equations are *linear* in the fields and sources. That is, each term in the equations involves a field or a source to (at most) the first power, and products of fields or sources do not appear. As a consequence, the *principle of superposition* applies: if \vec{E}_1, \vec{B}_1 and \vec{E}_2, \vec{B}_2 are solutions of Maxwell's equations with given boundary conditions, then $\vec{E}_T = \vec{E}_1 + \vec{E}_2$ and $\vec{B}_T = \vec{B}_1 + \vec{B}_2$ will also be so-

lutions of Maxwell's equations, with the same boundary conditions. This means that it is possible to represent complicated fields as superpositions of simpler fields. An important and widely used analysis technique for electromagnetic systems, including RF cavities and waveguides, is to find a set of solutions to Maxwell's equations from which more complete and complicated solutions may be constructed. The members of the set are known as *modes*; the modes can generally be labelled using *mode indices*. For example, plane electromagnetic waves in free space may be labelled using the three components of the wave vector that describes the direction and wavelength of the wave. Important properties of the electromagnetic fields, such as the frequency of oscillation, can often be expressed in terms of the mode indices.

Solutions to Maxwell's equations lead to a rich diversity of phenomena, including the fields around charges and currents in certain basic configurations, and the generation, transmission and absorption of electromagnetic radiation. Many existing texts cover these phenomena in detail; for example, Grant and Phillips [5], or the authoritative text by Jackson [6]. We consider these aspects rather briefly, with an emphasis on those features of the theory that are important for understanding the properties of RF components in accelerators.

2 Integral theorems and the physical interpretation of Maxwell's equations

2.1 Gauss' theorem and Coulomb's law

Guass' theorem states that for any smooth vector field \vec{a} :

$$\int_{V} \nabla \cdot \vec{a} \, dV = \oint_{\partial V} \vec{a} \cdot d\vec{S},$$

where V is a volume bounded by the closed surface ∂V . Note that the area element $d\vec{S}$ is oriented to point *out* of V.

Gauss' theorem is helpful for obtaining physical interpretations of two of Maxwell's equations, (1) and (2). First, applying Gauss' theorem to (1) gives:

$$\int_{V} \nabla \cdot \vec{D} \, dV = \oint_{\partial V} \vec{D} \cdot d\vec{S} = q,\tag{6}$$

where $q=\int_V \rho\,dV$ is the total charge enclosed by ∂V .

Suppose that we have a single isolated point charge in an homogeneous, isotropic medium with constant permittivity ε . In this case, it is interesting to take ∂V to be a sphere of radius r. By symmetry, the magnitude of the electric field must be the same at all points on ∂V , and must be normal to the surface at each point. Then, we can perform the surface integral in (6):

$$\oint_{\partial V} \vec{D} \cdot d\vec{S} = 4\pi r^2 D.$$

This is illustrated in Fig. 2: the outer circle represents a cross-section of a sphere (∂V) enclosing volume V, with the charge q at its centre. The red arrows in Fig. 2 represent the electric field lines, which are everywhere perpendicular to the surface ∂V . Since $\vec{D} = \varepsilon \vec{E}$, we find Coulomb's law for the magnitude of the electric field around a point charge:

$$E = \frac{q}{4\pi\varepsilon r^2}.$$

Applied to Maxwell's equation (2), Gauss' theorem leads to:

$$\int_{V} \nabla \cdot \vec{B} \, dV = \oint_{\partial V} \vec{B} \cdot d\vec{S} = 0.$$




Fig. 2: Electric field lines from a point charge q. The field lines are everywhere perpendicular to a spherical surface centered on the charge.

In other words, the magnetic flux integrated over any closed surface must equal zero – at least, until we discover magnetic monopoles. Lines of magnetic flux *always* occur in closed loops; lines of electric field may occur in closed loops, but in the presence of electric charges will have start (and end) points on the electric charges.

2.2 Stokes' theorem, Ampère's law, and Faraday's law

Stokes' theorem states that for any smooth vector field \vec{a} :

$$\int_{S} \nabla \times \vec{a} \cdot d\vec{S} = \oint_{\partial S} \vec{a} \cdot d\vec{l},\tag{7}$$

where the closed loop ∂S bounds the surface S. Applied to Maxwell's equation (3), Stokes' theorem leads to:

$$\oint_{\partial S} \vec{H} \cdot d\vec{l} = \int_{S} \vec{J} \cdot d\vec{S},\tag{8}$$

which is Ampère's law. From Ampère's law, we can derive an expression for the strength of the magnetic field around a long, straight wire carrying current I. The magnetic field must have rotational symmetry around the wire. There are two possibilities: a radial field, or a field consisting of closed concentric loops centred on the wire (or some superposition of these fields). A radial field would violate Maxwell's equation (2). Therefore, the field must consist of closed concentric loops; and by considering a circular loop of radius r, we can perform the integral in Eq. (8):

$$2\pi rH = I$$
,

where I is the total current carried by the wire. In this case, the line integral is performed around a loop ∂S centered on the wire, and in a plane perpendicular to the wire: essentially, this corresponds to one of the magnetic field lines, see Fig. 3. The total current passing through the surface S bounded by the loop ∂S is simply the total current I.

In an homogeneous, isotropic medium with constant permeability μ , $\vec{B} = \mu_0 \vec{H}$, and we obtain the expression for the magnetic flux density at distance r from the wire:

$$B = \frac{\mu I}{2\pi r}. (9)$$




Fig. 3: Magnetic field lines around a long straight wire carrying a current *I*.

Finally, applying Stokes' theorem to the homogeneous Maxwell's equation (4), we find:

$$\oint_{\partial S} \vec{E} \cdot d\vec{l} = -\frac{\partial}{\partial t} \int_{S} \vec{B} \cdot d\vec{S}. \tag{10}$$

Defining the electromotive force $\mathscr E$ as the integral of the electric field around a closed loop, and the magnetic flux Φ as the integral of the magnetic flux density over the surface bounded by the loop, Eq. (10) gives:

$$\mathscr{E} = -\frac{\partial \Phi}{\partial t},\tag{11}$$

which is Faraday's law of electromagnetic induction.

Maxwell's equations (3) and (4) are significant for RF systems: they tell us that a time dependent electric field will induce a magnetic field; and a time dependent magnetic field will induce an electric field. Consequently, the fields in RF cavities and waveguides always consist of both electric and magnetic fields.

Electromagnetic waves in free space

In free space (i.e. in the absence of any charges or currents) Maxwell's equations have a trivial solution in which all the fields vanish. However, there are also non-trivial solutions with considerable practical importance. In general, it is difficult to write down solutions to Maxwell's equations, because two of the equations involve both the electric and magnetic fields. However, by taking additional derivatives, it is possible to write equations for the fields that involve only either the electric or the magnetic field. This makes it easier to write down solutions: however, the drawback is that instead of first-order differential equations, the new equations are second-order in the derivatives. There is no guarantee that a solution to the second-order equations will also satisfy the first-order equations, and it is necessary to impose additional constraints to ensure that the first-order equations are satisfied. Fortunately, it turns out that this is not difficult to do, and taking additional derivatives is a useful technique for simplifying the analytical solution of Maxwell's equations in simple cases.

3.1 Wave equation for the electric field

In free space, Maxwell's equations (1) - (4) take the form:

$$\nabla \cdot \vec{E} = 0,$$

$$\nabla \cdot \vec{B} = 0.$$
(12)

$$\nabla \cdot \vec{B} = 0, \tag{13}$$

$$\nabla \times \vec{B} = \frac{1}{c^2} \frac{\partial \vec{E}}{\partial t}, \tag{14}$$

$$\nabla \times \vec{E} = -\frac{\partial \vec{B}}{\partial t},\tag{15}$$

where we have defined:

$$\frac{1}{c^2} = \mu_0 \varepsilon_0. \tag{16}$$

Our goal is to find a form of the equations in which the fields \vec{E} and \vec{B} appear separately, and not together in the same equation. As a first step, we take the curl of both sides of Eq. (15), and interchange the order of differentiation on the right hand side (which we are allowed to do, since the space and time coordinates are independent). We obtain:

$$\nabla \times \nabla \times \vec{E} = -\frac{\partial}{\partial t} \nabla \times \vec{B}. \tag{17}$$

Substituting for $\nabla \times \vec{B}$ from Eq. (14), this becomes:

$$\nabla \times \nabla \times \vec{E} = -\frac{1}{c^2} \frac{\partial^2 \vec{E}}{\partial t^2}.$$
 (18)

This second-order differential equation involves only the electric field, \vec{E} , so we have achieved our aim of decoupling the field equations. However, it is possible to make a further simplification, using a mathematical identity. For any differentiable vector field \vec{a} :

$$\nabla \times \nabla \times \vec{a} \equiv \nabla(\nabla \cdot \vec{a}) - \nabla^2 \vec{a}. \tag{19}$$

Using the identity (19), and also making use of Eq. (12), we obtain finally:

$$\nabla^2 \vec{E} - \frac{1}{c^2} \frac{\partial^2 \vec{E}}{\partial t^2} = 0. \tag{20}$$

Eq. (20) is the wave equation in three spatial dimensions. Note that each component of the electric field independently satisfies the wave equation. The solution, representing a plane wave propagating in the direction of the vector \vec{k} , may be written in the form:

$$\vec{E} = \vec{E}_0 \cos(\vec{k} \cdot \vec{r} - \omega t + \phi_0), \qquad (21)$$

where: \vec{E}_0 is a constant vector; ϕ_0 is a constant phase; ω and \vec{k} are constants related to the frequency f and wavelength λ of the wave by:

$$\omega = 2\pi f, \tag{22}$$

$$\lambda = \frac{2\pi}{|\vec{k}|}. (23)$$

If we substitute Eq. (21) into the wave equation (20), we find that it provides a valid solution as long as the angular frequency ω and wave vector \vec{k} satisfy the *dispersion relation*:

$$\frac{\omega}{|\vec{k}|} = c. \tag{24}$$

If we inspect Eq. (21), we see that a particle travelling in the direction of \vec{k} has to move at a speed $\omega/|\vec{k}|$ in order to remain at the same phase in the wave: thus, the quantity c is the *phase velocity* of the wave. This quantity c is, of course, the speed of light in a vacuum; and the identification of light with an electromagnetic wave (with the phase velocity related to the electric permittivity and magnetic permeability by Eq. (16)) was one of the great achievements of 19^{th} century physics.




Fig. 4: Electric and magnetic fields in a plane electromagnetic wave in free space. The wave vector \vec{k} is in the direction of the +z axis.

Wave equation for the magnetic field

So far, we have only considered the electric field. But Maxwell's equation (3) tells us that an electric field that varies with time must have a magnetic field associated with it. Therefore, we should look for a (non-trivial) solution for the magnetic field in free space. Starting with Eq. (14), and following the same procedure as above, we find that the magnetic field also satisfies the wave equation:

$$\nabla^2 \vec{B} - \frac{1}{c^2} \frac{\partial^2 \vec{B}}{\partial t^2} = 0, \tag{25}$$

with a similar solution:

$$\vec{B} = \vec{B}_0 \cos(\vec{k} \cdot \vec{r} - \omega t + \phi_0). \tag{26}$$

Here, we have written the same constants ω , \vec{k} and ϕ_0 as we used for the electric field, though we do not so far know they have to be the same. We shall show in the following section that these constants do indeed need to be the same for both the electric field and the magnetic field.

Relations between electric and magnetic fields in a plane wave in free space

As we commented above, although taking additional derivatives of Maxwell's equations allows us to decouple the equations for the electric and magnetic fields, we must impose additional constraints on the solutions, to ensure that the first-order equations are satisfied. In particular, substituting the expressions for the fields (21) and (26) into Eqs. (12) and (13) respectively, and noting that the latter equations must be satisfied at all points in space and at all times, we obtain:

$$\vec{k} \cdot \vec{E}_0 = 0,$$
 (27)
 $\vec{k} \cdot \vec{B}_0 = 0.$ (28)

$$\vec{k} \cdot \vec{B}_0 = 0. \tag{28}$$

Since k represents the direction of propagation of the wave, we see that the electric and magnetic fields must at all times and all places be perpendicular to the direction in which the wave is travelling. This is a feature that does not appear if we only consider the second-order equations.

Finally, substituting the expressions for the fields (21) and (26) into Eqs. (15) and (14) respectively, and again noting that the latter equations must be satisfied at all points in space and at all times, we see first that the quantities ω , \vec{k} and ϕ_0 appearing in (21) and (26) must be the same in each case. Also, we have the following relations between the magnitudes and directions of the fields:

$$\vec{k} \times \vec{E}_0 = \omega \vec{B}_0, \tag{29}$$

$$\vec{k} \times \vec{B}_0 = -\omega \vec{E}_0. \tag{30}$$

If we choose a coordinate system so that \vec{E}_0 is parallel to the x axis and \vec{B}_0 is parallel to the y axis, then \vec{k} must be parallel to the z axis: note that the vector product $\vec{E} \times \vec{B}$ is in the same direction as the direction of propagation of the wave – see Fig. 4. The magnitudes of the electric and magnetic fields are related by:

$$\frac{|\vec{E}|}{|\vec{B}|} = c. ag{31}$$

Note that the wave vector \vec{k} can be chosen arbitrarily: there are infinitely many "modes" in which an electromagnetic wave propagating in free space may appear; and the most general solution will be a sum over all modes. When the mode is specified (by giving the components of \vec{k}), the frequency is determined from the dispersion relation (24). However, the amplitude and phase are not determined (although the electric and magnetic fields must have the same phase, and their amplitudes must be related by Eq. (31)).

Finally, note that all the results derived in this section are strictly true only for electromagnetic fields in a vacuum. The generalisation to fields in uniform, homogenous, linear (i.e. constant permeability μ and permittivity ε) nonconducting media is straightforward. However, new features appear for waves in conductors, on boundaries, or in nonlinear media.

Complex notation for electromagnetic waves 3.4

We finish this section by introducing the complex notation for free waves. Note that the electric field given by equation (21) can also be written as:

$$\vec{E} = \operatorname{Re} \vec{E}_0 e^{i\phi_0} e^{i(\vec{k}\cdot\vec{r}-\omega t)}.$$
(32)

To avoid continually writing a constant phase factor when dealing with solutions to the wave equation, we replace the real (constant) vector \vec{E}_0 by the complex (constant) vector $\vec{E}_0' = \vec{E}_0 e^{i\phi_0}$. Also, we note that since all the equations describing the fields are linear, and that any two solutions can be linearly superposed to construct a third solution, the complex vectors:

$$\vec{E}' = \vec{E}'_0 e^{i(\vec{k} \cdot \vec{r} - \omega t)}, \qquad (33)$$

$$\vec{B}' = \vec{B}'_0 e^{i(\vec{k} \cdot \vec{r} - \omega t)} \qquad (34)$$

$$\vec{B}' = \vec{B}_0' e^{i(\vec{k} \cdot \vec{r} - \omega t)} \tag{34}$$

provide mathematically valid solutions to Maxwell's equations in free space, with the same relationships between the various quantities (frequency, wave vector, amplitudes, phase) as the solutions given in Eqs. (21) and (26). Therefore, as long as we deal with linear equations, we can carry out all the algebraic manipulation using *complex* field vectors, where it is implicit that the physical quantities are obtained by taking the real parts of the complex vectors. However, when using the complex notation, particular care is needed when taking the product of two complex vectors: to be safe, one should always take the real part before multiplying two complex quantities, the real parts of which represent physical quantities. Products of the electromagnetic field vectors occur in expressions for the energy density and energy flux in an electromagnetic field, as we shall see below.

Electromagnetic waves in conductors

Electromagnetic waves in free space are characterized by an amplitude that remains constant in space and time. This is also true for waves travelling through any isotropic, homogeneous, linear, non-conducting medium, which we may refer to as an "ideal" dielectric. The fact that real materials contain electric charges that can respond to electromagnetic fields means that the vacuum is really the only ideal dielectric. Some real materials (for example, many gases, and materials such as glass) have properties that approximate those of an ideal dielectric, at least over certain frequency ranges: such materials are transparent. However, we know that many materials are not transparent: even a thin sheet of a good conductor such as aluminium or copper, for example, can provide an effective barrier for electromagnetic radiation over a wide range of frequencies.

To understand the shielding effect of good conductors is relatively straightforward. Essentially, we follow the same procedure to derive the wave equations for the electromagnetic fields as we did for the case of a vacuum, but we include additional terms to represent the conductivity of the medium. These additional terms have the consequence that the amplitude of the wave decays as the wave propagates through the medium. The rate of decay of the wave is characterised by the skin depth, which depends (amongst other things) on the conductivity of the medium.

Let us consider an ohmic conductor. An ohmic conductor is defined by the relationship between the current density \vec{J} at a point in the conductor, and the electric field \vec{E} existing at the same point in the conductor:

$$\vec{J} = \sigma \vec{E},\tag{35}$$

where σ is a constant, the *conductivity* of the material.

In an uncharged ohmic conductor, Maxwell's equations (1) - (4) take the form:

$$\nabla \cdot \vec{E} = 0, \tag{36}$$

$$\nabla \cdot \vec{B} = 0, \tag{37}$$

$$\nabla \times \vec{B} = \mu \sigma \vec{E} + \mu \varepsilon \frac{\partial \vec{E}}{\partial t}, \tag{38}$$

$$\nabla \times \vec{E} = -\frac{\partial \vec{B}}{\partial t},\tag{39}$$

where μ is the (absolute) permeability of the medium, and ε is the (absolute) permittivity. Notice the appearance of the additional term on the right hand side of Eq. (38), compared to Eq. (14).

Following the same procedure as led to Eq. (20), we derive the following equation for the electric field in a conducting medium:

$$\nabla^2 \vec{E} - \mu \sigma \frac{\partial \vec{E}}{\partial t} - \mu \varepsilon \frac{\partial^2 \vec{E}}{\partial t^2} = 0. \tag{40}$$

This is again a wave equation, but with a term that includes a first-order time derivative. In the equation for a simple harmonic oscillator, such a term would represent a "frictional" force that leads to dissipation of the energy in the oscillator. There is a similar effect here; to see this, let us try a solution of the same form as for a wave in free space. The results we are seeking can be obtained more directly if we used the complex notation:

$$\vec{E} = \vec{E}_0 e^{i(\vec{k} \cdot \vec{r} - \omega t)}. \tag{41}$$

Substituting into the wave equation (40), we obtain the dispersion relation:

$$-\vec{k}^2 + i\mu\sigma\omega + \mu\varepsilon\omega^2 = 0. \tag{42}$$

Let us assume that the frequency ω is a real number. Then, to find a solution to Eq. (42), we have to allow the wave vector \vec{k} to be complex. Let us write the real and imaginary parts as $\vec{\alpha}$ and $\vec{\beta}$ respectively:

$$\vec{k} = \vec{\alpha} + i\vec{\beta}.\tag{43}$$

Substituting (43) into (42) and equating real and imaginary parts, we find (after some algebra) that:

$$|\vec{\alpha}| = \omega \sqrt{\mu \varepsilon} \left(\frac{1}{2} + \frac{1}{2} \sqrt{1 + \frac{\sigma^2}{\omega^2 \varepsilon^2}} \right)^{\frac{1}{2}},$$
 (44)




Fig. 5: Electric and magnetic fields in a plane electromagnetic wave in a conductor. The wave vector is in the direction of the +z axis.

$$|\vec{\beta}| = \frac{\omega\mu\sigma}{2|\vec{\alpha}|}. (45)$$

To understand the physical significance of $\vec{\alpha}$ and $\vec{\beta}$, we write the solution (41) to the wave equation as:

$$\vec{E} = \vec{E}_0 e^{-\vec{\beta} \cdot \vec{r}} e^{i(\vec{\alpha} \cdot \vec{r} - \omega t)}.$$
(46)

We see that there is still a wave-like oscillation of the electric field, but there is now also an exponential decay of the amplitude. The wavelength is determined by the *real part* of the wave vector:

$$\lambda = \frac{2\pi}{|\vec{\alpha}|}.\tag{47}$$

The imaginary part of the wave vector gives the distance δ over which the amplitude of the wave falls by a factor 1/e, known as the *skin depth*:

$$\delta = \frac{1}{|\vec{\beta}|}.\tag{48}$$

Accompanying the electric field, there must be a magnetic field:

$$\vec{B} = \vec{B}_0 \, e^{i(\vec{k} \cdot \vec{r} - \omega t)}.\tag{49}$$

From Maxwell's equation (4), the amplitudes of the electric and magnetic fields must be related by:

$$\vec{k} \times \vec{E}_0 = \omega \vec{B}_0. \tag{50}$$

The electric and magnetic fields are perpendicular to each other, and to the wave vector: this is the same situation as occurred for a plane wave in free space. However, since \vec{k} is complex for a wave in a conductor, there is a phase difference between the electric and magnetic fields, given by the complex phase of \vec{k} . The fields in a plane wave in a conductor are illustrated in Fig. 5.

The dispersion relation (42) gives a rather complicated algebraic relationship between the frequency and the wave vector, in which the electromagnetic properties of the medium (permittivity, permeability and conductivity) all appear. However, in many cases it is possible to write much simpler expressions that provide good approximations. First, there is the "poor conductor" regime:

if
$$\sigma \ll \omega \varepsilon$$
, then $|\vec{\alpha}| \approx \omega \sqrt{\mu \varepsilon}$, $|\vec{\beta}| \approx \frac{\sigma}{2} \sqrt{\frac{\mu}{\varepsilon}}$. (51)

The wavelength is related to the frequency in the way that we would expect for a dielectric.

Next there is the "good conductor" regime:

if
$$\sigma \gg \omega \varepsilon$$
, then $|\vec{\alpha}| \approx \sqrt{\frac{\omega \sigma \mu}{2}}$, $|\vec{\beta}| \approx |\vec{\alpha}|$. (52)

Here the situation is very different. The wavelength depends directly on the conductivity: for a good conductor, the wavelength is very much shorter than it would be for a wave at the same frequency in free space. The real and imaginary parts of the wave vector are approximately equal: this means that there is a significant reduction in the amplitude of the wave even over one wavelength. Also, the electric and magnetic fields are approximately $\pi/4$ out of phase.

The reduction in amplitude of a wave as it travels through a conductor is not difficult to understand. The electric charges in the conductor move in response to the electric field in the wave. The motion of the charges constitutes an electric current in the conductor, which results in ohmic losses: ultimately, the energy in the wave is dissipated as heat in the conductor. Note that whether or not a given material can be described as a "good conductor" depends on the frequency of the wave (and permittivity of the material): at a high enough frequency, any material will become a poor conductor.

5 Energy in electromagnetic fields

Waves are generally associated with the propagation of energy: the question then arises as to whether this is the case with electromagnetic waves, and, if so, how much energy is carried by a wave of a given amplitude. To address this question, we first need to find general expressions for the energy density and energy flux in an electromagnetic field. The appropriate expressions follow from Poynting's theorem, which may be derived from Maxwell's equations.

5.1 Poynting's theorem

First, we take the scalar product of Maxwell's equation (4) with the magnetic intensity \vec{H} on both sides, to give:

$$\vec{H} \cdot \nabla \times \vec{E} = -\vec{H} \cdot \frac{\partial \vec{B}}{\partial t}.$$
 (53)

Then, we take the scalar product of (3) with the electric field \vec{E} on both sides to give:

$$\vec{E} \cdot \nabla \times \vec{H} = \vec{E} \cdot \vec{J} + \vec{E} \cdot \frac{\partial \vec{D}}{\partial t}.$$
 (54)

Now we subtract Eq. (54) from Eq. (53) to give:

$$\vec{H} \cdot \nabla \times \vec{E} - \vec{E} \cdot \nabla \times \vec{H} = -\vec{E} \cdot \vec{J} - \vec{E} \cdot \frac{\partial \vec{D}}{\partial t} - \vec{H} \cdot \frac{\partial \vec{B}}{\partial t}.$$
 (55)

This may be rewritten as:

$$\frac{\partial}{\partial t} \left(\frac{1}{2} \varepsilon \vec{E}^2 + \frac{1}{2} \mu \vec{H}^2 \right) = -\nabla \cdot \left(\vec{E} \times \vec{H} \right) - \vec{E} \cdot \vec{J}. \tag{56}$$

Equation (56) is Poynting's theorem. It does not appear immediately to tell us much about the energy in an electromagnetic field; but the physical interpretation becomes a little clearer if we convert it from differential form into integral form. Integrating each term on either side over a volume V, and changing the first term on the right hand side into an integral over the closed surface A bounding V, we write:

$$\frac{\partial}{\partial t} \int_{V} (U_E + U_H) \ dV = -\oint_{A} \vec{S} \cdot d\vec{A} - \int_{V} \vec{E} \cdot \vec{J} \, dV, \tag{57}$$

where:

$$U_E = \frac{1}{2}\varepsilon \vec{E}^2 \tag{58}$$

$$U_H = \frac{1}{2}\mu \vec{H}^2 \tag{59}$$

$$\vec{S} = \vec{E} \times \vec{H}. \tag{60}$$

The physical interpretation follows from the volume integral on the right hand side of Eq. (57): this represents the rate at which the electric field does work on the charges contained within the volume V. If the field does work on the charges within the field, then there must be energy contained within the field that decreases as a result of the field doing work. Each of the terms within the integral on the left hand side of Eq. (57) has the dimensions of energy density (energy per unit volume). Therefore, the integral has the dimensions of energy; it is then natural to interpret the full expression on the left hand side of Eq. (57) as the rate of change of energy in the electromagnetic field within the volume V. The quantities U_E and U_H represent the energy per unit volume in the electric field and in the magnetic field respectively.

Finally, there remains the interpretation of the first term on the right hand side of Eq. (57). As well as the energy in the field decreasing as a result of the field doing work on charges, the energy may change as a result of a flow of energy purely within the field itself (i.e. even in the absence of any electric charge). Since the first term on the right hand side of Eq. (57) is a surface integral, it is natural to interpret the vector inside the integral as the energy flux within the field, i.e. the energy crossing unit area (perpendicular to the vector) per unit time. The vector \vec{S} defined by Eq. (60) is called the *Poynting vector*.

5.2 Energy in an electromagnetic wave

As an application of Poynting's theorem (or rather, of the expressions for energy density and energy flux that arise from it), let us consider the energy in a plane electromagnetic wave in free space. As we noted above, if we use complex notation for the fields, then we should take the real part to find the physical fields before using expressions involving the products of fields (such as the expressions for the energy density and energy flux).

The electric field in a plane wave in free space is given by:

$$\vec{E} = \vec{E}_0 \cos(\vec{k} \cdot \vec{r} - \omega t + \phi_0). \tag{61}$$

Thus, the energy density in the electric field is:

$$U_E = \frac{1}{2}\varepsilon_0 \vec{E}^2 = \frac{1}{2}\varepsilon_0 \vec{E}_0^2 \cos^2(\vec{k} \cdot \vec{r} - \omega t + \phi_0). \tag{62}$$

If we take the average over time at any point in space (or, the average over space at any point in time), we find that the average energy density is:

$$\langle U_E \rangle = \frac{1}{4} \varepsilon_0 \vec{E}_0^2. \tag{63}$$

The magnetic field in a plane wave in free space is given by:

$$\vec{B} = \vec{B}_0 \cos(\vec{k} \cdot \vec{r} - \omega t + \phi_0), \qquad (64)$$

where:

$$|\vec{B}_0| = \frac{|\vec{E}_0|}{c}. (65)$$

Since $\vec{B} = \mu_0 \vec{H}$, the energy density in the magnetic field is:

$$U_H = \frac{1}{2}\mu_0 \vec{H}^2 = \frac{1}{2\mu_0} \vec{B}_0^2 \cos^2(\vec{k} \cdot \vec{r} - \omega t + \phi_0).$$
 (66)

If we take the average over time at any point in space (or, the average over space at any point in time), we find that the average energy density is:

$$\langle U_H \rangle = \frac{1}{4\mu_0} \vec{B}_0^2. \tag{67}$$

Using the relationship (65) between the electric and magnetic fields in a plane wave, this can be written:

$$\langle U_H \rangle = \frac{1}{4\mu_0} \frac{E_0^2}{c^2}.$$
 (68)

Then, using Eq. (16):

$$\langle U_H \rangle = \frac{1}{4} \varepsilon_0 \vec{E}_0^2. \tag{69}$$

We see that in a plane electromagnetic wave in free space, the energy is shared equally between the electric field and the magnetic field, with the energy density averaged over time (or, over space) given by:

$$\langle U \rangle = \frac{1}{2} \varepsilon_0 \vec{E}_0^2. \tag{70}$$

Finally, let us calculate the energy flux in the wave. For this, we use the Poynting vector (60):

$$\vec{S} = \vec{E} \times \vec{H} = \hat{k} \frac{1}{\mu_0 c} \vec{E}_0^2 \cos^2(\vec{k} \cdot \vec{r} - \omega t + \phi_0),$$
 (71)

where \hat{k} is a unit vector in the direction of the wave vector. The average value (over time at a particular point in space, or over space at a particular time) is then given by:

$$\langle \vec{S} \rangle = \frac{1}{2} \frac{1}{\mu_0 c} \vec{E}_0^2 \hat{k} = \frac{1}{2} \varepsilon_0 c \vec{E}_0^2 \hat{k} = \frac{\vec{E}_0^2}{2Z_0} \hat{k}, \tag{72}$$

where Z_0 is the impedance of free space, defined by:

$$Z_0 = \sqrt{\frac{\mu_0}{\varepsilon_0}}. (73)$$

 Z_0 is a physical constant, with value $Z_0 \approx 376.73 \,\Omega$. Using Eq. (70) we find the relation between energy flux and energy density in a plane electromagnetic wave in free space:

$$\langle \vec{S} \rangle = \langle U \rangle c\hat{k}. \tag{74}$$

This is the relationship that we might expect in this case: the mean energy flux is given simply by the mean energy density moving at the speed of the wave in the direction of the wave. But note that this is not the general case. More generally, the energy in a wave propagates at the group velocity, which may be different from the phase velocity. For a plane electromagnetic wave in free space, the group velocity happens to be equal to the phase velocity, c. We shall discuss this further when we consider energy propagation in waveguides.

6 Electromagnetic potentials

We have seen that to find non-trivial solutions for Maxwell's electromagnetic field equations in free space, it is helpful to take additional derivatives of the equations, since this allows us to construct separate equations for the electric and magnetic fields. The same technique can be used to find solutions for the fields when sources (charge densities and currents) are present. Such situations are important, since they arise in the generation of electromagnetic waves. However, it turns out that in systems where charges and currents are present, it is often simpler to work with the *electromagnetic potentials*, from which the fields may be obtained by differentiation, than with the fields directly.

6.1 Relationships between the potentials and the fields

The scalar potential ϕ and vector potential \vec{A} are defined so that the electric and magnetic fields are obtained using the relations:

$$\vec{B} = \nabla \times \vec{A},\tag{75}$$

$$\vec{E} = -\nabla\phi - \frac{\partial\vec{A}}{\partial t}.$$
 (76)

We shall show below that as long as ϕ and \vec{A} satisfy appropriate equations, then the fields \vec{B} and \vec{E} derived from them using Eqs. (75) and (76) satisfy Maxwell's equations. But first, note that there is a many-to-one relationship between the potentials and the fields. That is, there are many different potentials that can give the same fields. For example, we could add any uniform (independent of position) value to the scalar potential ϕ , and leave the electric field \vec{E} unchanged, since the gradient of a constant is zero. Similarly, we could add any vector function with vanishing curl to the vector potential \vec{A} ; and if this function is independent of time, then again the electric and magnetic fields are unchanged. This property of the potentials is known as *gauge invariance*, and is of considerable practical value, as we shall see below.

6.2 Equations for the potentials

The fact that there is a relationship between the potentials and the fields implies that the potentials that are allowed in physics have to satisfy certain equations, corresponding to Maxwell's equations. This is, of course, the case. In this section, we shall derive the equations that must be satisfied by the potentials, if the fields that are derived from them are to satisfy Maxwell's equations.

However, to begin with, we show that two of Maxwell's equations (the ones independent of the sources) are in fact satisfied if the fields are derived from *any* potentials ϕ and \vec{A} using Eqs. (75) and (76). First, since the divergence of the curl of any differentiable vector field is always zero:

$$\nabla \cdot \nabla \times \vec{A} \equiv 0, \tag{77}$$

it follows that Maxwell's equation (2) is satisfied for any vector potential \vec{A} . Then, since the curl of the gradient of any differentiable scalar field is always zero:

$$\nabla \times \nabla \phi \equiv 0, \tag{78}$$

Maxwell's equation (4) is satisfied for any scalar potential ϕ and vector potential \vec{A} (as long as the magnetic field is obtained from the vector potential by Eq. (75)).

Now let us consider the equations involving the source terms (the charge density ρ and current density \vec{J}). Differential equations for the potentials can be obtained by substituting from Eqs. (75) and (76) into Maxwell's equations (1) and (3). We also need to use the constitutive relations between the magnetic field \vec{B} and the magnetic intensity \vec{H} , and between the electric field \vec{E} and the electric

displacement \vec{D} . For simplicity, let us assume a system of charges and currents in free space; then the constitutive relations are:

$$\vec{D} = \varepsilon_0 \vec{E}, \qquad \vec{B} = \mu_0 \vec{H}. \tag{79}$$

Substituting from Eq. (76) into Maxwell's equation (1) gives:

$$\nabla^2 \phi + \frac{\partial}{\partial t} \nabla \cdot \vec{A} = -\frac{\rho}{\varepsilon_0}.$$
 (80)

Similarly, substituting from Eq. (75) into Maxwell's equation (3) gives (after some algebra):

$$\nabla^2 \vec{A} - \frac{1}{c^2} \frac{\partial^2 \vec{A}}{\partial t^2} = -\mu_0 \vec{J} + \nabla \left(\nabla \cdot \vec{A} + \frac{1}{c^2} \frac{\partial \phi}{\partial t} \right). \tag{81}$$

Eqs. (80) and (81) relate the electromagnetic potentials to a charge density ρ and current density \vec{J} in free space. Unfortunately, they are coupled equations (the scalar potential ϕ and vector potential \vec{J} each appear in both equations), and are rather complicated. However, we noted above that the potentials for given electric and magnetic fields are not unique: the potentials have the property of gauge invariance. By imposing an additional constraint on the potentials, known as a *gauge condition*, it is possible to restrict the choice of potentials. With an appropriate choice of gauge, it is possible to decouple the potentials, and furthermore, arrive at equations that have standard solutions. In particular, with the gauge condition:

$$\nabla \cdot \vec{A} + \frac{1}{c^2} \frac{\partial \phi}{\partial t} = 0, \tag{82}$$

then Eq. (80) becomes:

$$\nabla^2 \phi - \frac{1}{c^2} \frac{\partial^2 \phi}{\partial t^2} = -\frac{\rho}{\varepsilon_0}.$$
 (83)

and Eq. (81) becomes:

$$\nabla^2 \vec{A} - \frac{1}{c^2} \frac{\partial^2 \vec{A}}{\partial t^2} = -\mu_0 \vec{J},\tag{84}$$

Eqs. (83) and (84) have the form of wave equations with source terms. It is possible to write solutions in terms of integrals over the sources: we shall do this shortly. However, before we do so, it is important to note that for any given potentials, it is possible to find new potentials that satisfy Eq. (82), but give the same fields as the original potentials. Eq. (82) is called the *Lorenz gauge*. The proof proceeds as follows.

First we show that any function ψ of position and time can be used to construct a gauge transformation; that is, we can use ψ to find new scalar and vector potentials (different from the original potentials) that given the same electric and magnetic fields as the original potentials. Given the original potentials ϕ and \vec{A} , and a function ψ , let us define new potentials ϕ' and \vec{A}' , as follows:

$$\phi' = \phi + \frac{\partial \psi}{\partial t}, \tag{85}$$

$$\vec{A}' = \vec{A} - \nabla \psi. \tag{86}$$

Eqs. (85) and (86) represent a gauge transformation. If the original potentials give fields \vec{E} and \vec{B} , then the magnetic field derived from the new vector potential is:

$$\vec{B}' = \nabla \times \vec{A}' = \nabla \times \vec{A} = \vec{B},\tag{87}$$

where we have used the fact that the curl of the gradient of any scalar function is zero. The electric field derived from the new potentials is:

$$\vec{E}' = -\nabla \phi' - \frac{\partial \vec{A}'}{\partial t}$$

$$= -\nabla \phi - \frac{\partial \vec{A}}{\partial t} - \nabla \frac{\partial \psi}{\partial t} + \frac{\partial}{\partial t} \nabla \psi$$

$$= -\nabla \phi - \frac{\partial \vec{A}}{\partial t}$$

$$= \vec{E}. \tag{88}$$

Here, we have made use of the fact that position and time are independent variables, so it is possible to interchange the order of differentiation. We see that for *any* function ψ , the fields derived from the new potentials are the same as the fields derived from the original potentials. We say that ψ generates a gauge transformation: it gives us new potentials, while leaving the fields unchanged.

Finally, we show how to choose a gauge transformation so that the new potentials satisfy the Lorenz gauge condition. In general, the new potentials satisfy the equation:

$$\nabla \cdot \vec{A}' + \frac{1}{c^2} \frac{\partial \phi'}{\partial t} = \nabla \cdot \vec{A} + \frac{1}{c^2} \frac{\partial \phi}{\partial t} - \nabla^2 \psi + \frac{1}{c^2} \frac{\partial^2 \psi}{\partial t^2}.$$
 (89)

Suppose we have potentials ϕ and \vec{A} that satisfy:

$$\nabla \cdot \vec{A} + \frac{1}{c^2} \frac{\partial \phi}{\partial t} = f, \tag{90}$$

where f is some function of position and time. (If f is non-zero, then the potentials ϕ and \vec{A} do not satisfy the Lorenz gauge condition.) Therefore, if ψ satisfies:

$$\nabla^2 \psi - \frac{1}{c^2} \frac{\partial^2 \psi}{\partial t^2} = f, \tag{91}$$

Then the new potentials ϕ' and \vec{A}' satisfy the Lorenz gauge condition:

$$\nabla \cdot \vec{A'} + \frac{1}{c^2} \frac{\partial \phi'}{\partial t} = 0. \tag{92}$$

Notice that Eq. (91) again has the form of a wave equation, with a source term. Assuming that we can solve such an equation, then it is always possible to find a gauge transformation such that, starting from some given original potentials, the new potentials satisfy the Lorenz gauge condition.

6.3 Solution of the wave equation with source term

In the Lorenz gauge (82):

$$\nabla \cdot \vec{A} + \frac{1}{c^2} \frac{\partial \phi}{\partial t} = 0,$$

the vector potential \vec{A} and the scalar potential ϕ satisfy the wave equations (84) and (83):

$$\nabla^2 \vec{A} - \frac{1}{c^2} \frac{\partial^2 \vec{A}}{\partial t^2} = -\mu_0 \vec{J},$$

$$\nabla^2 \phi - \frac{1}{c^2} \frac{\partial^2 \phi}{\partial t^2} \ = \ - \frac{\rho}{\varepsilon_0}.$$

Note that the wave equations have the form (for given charge density and current density) of two *uncoupled* second-order differential equations. In many situations, it is easier to solve these equations, than to solve Maxwell's equations for the fields (which take the form of four first-order *coupled* differential equations).




Fig. 6: Integration over a distributed source.

We state (without giving a full proof) the solution to the wave equation with a source term. The solution is:

$$\phi(\vec{r},t) = \frac{1}{4\pi\varepsilon_0} \int \frac{\rho(\vec{r}',t')}{|\vec{r}'-\vec{r}|} dV', \tag{93}$$

where:

$$t' = t - \frac{|\vec{r'} - \vec{r}|}{c}.\tag{94}$$

The integral extends over all space – see Fig. 6. Note that the source at each point in the integral has to be evaluated at a time t', which depends on the distance between the source point and the observation point (at which we are evaluating the potential). From the equation in the absence of any sources, we expect variations in the potential to propagate through space at a speed c (the speed of light). The difference between t' and t simply accounts for the time taken for the effect of any change in the charge density at the source point to propagate through space to the observation point.

We do not present a proof that Eq. (93) represents a solution to the wave equation (83). However, we can at least see that in the static case, Eq. (83) reduces to the familiar form of Poisson's equation:

$$\nabla^2 \phi = -\frac{\rho}{\varepsilon_0}.\tag{95}$$

For a point charge q at a point \vec{r}_0 , Eq. (95) has solution:

$$\phi(\vec{r}) = \frac{1}{4\pi\varepsilon_0} \frac{q}{|\vec{r_0} - \vec{r}|}.$$
(96)

This can be obtained directly from Eq. (93) if the source is given by a Dirac delta function:

$$\rho(\vec{r}') = q \,\delta(\vec{r}' - \vec{r}_0). \tag{97}$$

The wave equation for the vector potential (84) has a solution that can be expressed in a similar form to that for the scalar potential:

$$\vec{A}(\vec{r},t) = \frac{\mu_0}{4\pi} \int \frac{\vec{J}(\vec{r}',t')}{|\vec{r}' - \vec{r}|} dV'.$$
 (98)

Note that Eq. (98) can be expressed as three independent equations (integrals), for the three components of the vector potential.

Physical significance of the fields and potentials

An electromagnetic field is really a way of describing the interaction between particles that have electric charges. Given a system of charged particles, one could, in principle, write down equations for the evolution of the system purely in terms of the positions, velocities, and charges of the various particles. However, it is often convenient to carry out an intermediate step in which one computes the fields generated by the particles, and then computes the effects of the fields on the motion of the particles. Maxwell's equations provide a prescription for computing the fields arising from a given system of charges. The effects of the fields on a charged particle are expressed by the Lorentz force equation:

$$\vec{F} = q \left(\vec{E} + \vec{v} \times \vec{B} \right), \tag{99}$$

where \vec{F} is the force on the particle, q is the charge, and \vec{v} is the velocity of the particle. The motion of the particle under the influence of a force \vec{F} is then given by Newton's second law of motion:

$$\frac{d}{dt}\gamma m\vec{v} = \vec{F}.$$
 (100)

Eqs. (99) and (100) make clear the physical significance of the fields. But what is the significance of the potentials? At first, the feature of gauge invariance appears to make it difficult to assign any definite physical significance to the potentials: in any given system, we have a certain amount of freedom in changing the potentials without changing the fields that are present. However, let us consider first the case of a particle in a static electric field. In this case, the Lorentz force is given by:

$$\vec{F} = q\vec{E} = -q\,\nabla\phi.\tag{101}$$

If the particle moves from position $\vec{r_1}$ to position $\vec{r_2}$ under the influence of the Lorentz force, then the work done on the particle (by the field) is:

$$W = \int_{\vec{r}_1}^{\vec{r}_2} \vec{F} \cdot d\vec{\ell} = -q \int_{\vec{r}_1}^{\vec{r}_2} \nabla \phi \cdot d\vec{\ell} = -q \left[\phi(\vec{r}_2) - \phi(\vec{r}_1) \right]. \tag{102}$$

Note that the work done by the field when the particle moves between two points depends on the difference in the potential at the two points; and that the work done is independent of the path taken by the particle in moving between the two points. This suggests that the scalar potential ϕ is related to the energy of a particle in an *electrostatic* field. If a time-dependent magnetic field is present, the analysis becomes more complicated.

A more complete understanding of the physical significance of the scalar and vector potentials is probably best obtained in the context of Hamiltonian mechanics. In this formalism, the equations of motion of a particle are obtained from the Hamiltonian, $H(\vec{x}, \vec{p}; t)$; the Hamiltonian is a function of the particle coordinates \vec{x} , the (canonical) momentum \vec{p} , and an independent variable t (often corresponding to the time). Note that the canonical momentum can (and generally does) differ from the usual mechanical momentum. The Hamiltonian defines the dynamics of a system, in the same way that a force defines the dynamics in Newtonian mechanics. In Hamiltonian mechanics, the equations of motion of a particle are given by Hamilton's equations:

$$\frac{dx_i}{dt} = \frac{\partial H}{\partial p_i},\tag{103}$$

$$\frac{dx_i}{dt} = \frac{\partial H}{\partial p_i},$$

$$\frac{dp_i}{dt} = -\frac{\partial H}{\partial x_i}.$$
(103)

In the case of a charged particle in an electromagnetic field, the Hamiltonian is given by:

$$H = c\sqrt{(\vec{p} - q\vec{A})^2 + m^2c^2} + q\phi,$$
(105)

where the canonical momentum is:

$$\vec{p} = \vec{\beta}\gamma mc + q\vec{A},\tag{106}$$

where $\vec{\beta}$ is the normalised velocity of the particle, $\vec{\beta} = \vec{v}/c$.

Note that Eqs. (103) - (106) give the same dynamics as the Lorentz force equation (99) together with Newton's second law of motion, Eq. (100); they are just written in a different formalism. The significant point is that in the Hamiltonian formalism, the dynamics are expressed in terms of the potentials, rather than the fields. The Hamiltonian can be interpreted as the "total energy" of a particle, \mathcal{E} . Combining equations (105) and (106), we find:

$$\mathcal{E} = \gamma mc^2 + q\phi. \tag{107}$$

The first term gives the kinetic energy, and the second term gives the potential energy: this is consistent with our interpretation above, but now it is more general. Similarly, in Eq. (106) the "total momentum" consists of a mechanical term, and a potential term:

$$\vec{p} = \vec{\beta}\gamma mc + q\vec{A}.\tag{108}$$

The vector potential \vec{A} contributes to the total momentum of the particle, in the same way that the scalar potential ϕ contributes to the total energy of the particle. Gauge invariance allows us to find new potentials that leave the fields (and hence the dynamics) of the system unchanged. Since the fields are obtained by taking derivatives of the potentials, this suggests that only changes in potentials between different positions and times are significant for the dynamics of charged particles. This in turn implies that only changes in (total) energy and (total) momentum are significant for the dynamics.

7 Generation of electromagnetic waves

As an example of the practical application of the potentials in a physical system, let us consider the generation of electromagnetic waves from an oscillating, infinitesimal electric dipole. Although idealised, such a system provides a building block for constructing more realistic sources of radiation (such as the half-wave antenna), and is therefore of real interest. An infinitesimal electric dipole oscillating at a single frequency is known as an *Hertzian dipole*.

Consider two point-like particles located on the z axis, close to and on opposite sides of the origin. Suppose that electric charge flows between the particles, so that the charge on each particle oscillates, with the charge on one particle being:

$$q_1 = +q_0 e^{-i\omega t}, (109)$$

and the charge on the other particle being:

$$q_2 = -q_0 e^{-i\omega t}. ag{110}$$

The situation is illustrated in Fig. 7. The current at any point between the charges is:

$$\vec{I} = \frac{dq_1}{dt}\hat{z} = -i\omega q_0 e^{-i\omega t}\hat{z}.$$
(111)

In the limit that the distance between the charges approaches zero, the charge density vanishes; however, there remains a non-zero electric current at the origin, oscillating at frequency ω and with amplitude I_0 , where:

$$I_0 = -i\omega q_0. \tag{112}$$

Since the current is located only at a single point in space (the origin), it is straightforward to perform the integral in Eq. (98), to find the vector potential at any point away from the origin:

$$\vec{A}(\vec{r},t) = \frac{\mu_0}{4\pi} (I_0 \ell) \frac{e^{i(kr - \omega t)}}{r} \hat{z},\tag{113}$$




Fig. 7: Hertzian dipole: the charges oscillate around the origin along the z axis with infinitesimal amplitude. The vector potential at any point is parallel to the z axis, and oscillates at the same frequency as the dipole, with a phase difference and amplitude depending on the distance from the origin.

where:

$$k = -\frac{\omega}{c},\tag{114}$$

and ℓ is the length of the current: strictly speaking, we take the limit $\ell \to 0$, but we do so, we increase the current amplitude I_0 , so that the produce $I_0\ell$ remains non-zero and finite.

Notice that, with Eq. (113), we have quickly found a relatively simple expression for the vector potential around an Hertzian dipole. From the vector potential we can find the magnetic field; and from the magnetic field we can find the electric field. By working with the potentials rather than with the fields, we have greatly simplified the finding of the solution in what might otherwise have been quite a complex problem.

The magnetic field is given, as usual, by $\vec{B} = \nabla \times \vec{A}$. It is convenient to work in spherical polar coordinates, in which case the curl is written as:

$$\nabla \times \vec{A} \equiv \frac{1}{r^2 \sin \theta} \begin{vmatrix} \hat{r} & r\hat{\theta} & r\sin \theta \,\hat{\phi} \\ \frac{\partial}{\partial r} & \frac{\partial}{\partial \theta} & \frac{\partial}{\partial \phi} \\ A_r & rA_{\theta} & r\sin \theta A_{\phi} \end{vmatrix} . \tag{115}$$

Evaluating the curl for the vector potential given by Eq. (113) we find:

$$B_r = 0, (116)$$

$$B_{\theta} = 0, \tag{117}$$

$$B_{\phi} = \frac{\mu_0}{4\pi} (I_0 \ell) k \sin \theta \left(\frac{1}{kr} - i \right) \frac{e^{i(kr - \omega t)}}{r}. \tag{118}$$

The electric field can be obtained from $\nabla \times \vec{B} = \frac{1}{c^2} \frac{\partial \vec{E}}{\partial t}$ (which follows from Maxwells equation (3) in free space). The result is:

$$E_r = \frac{1}{4\pi\varepsilon_0} \frac{2}{c} (I_0 \ell) \left(1 + \frac{i}{kr} \right) \frac{e^{i(kr - \omega t)}}{r^2}, \tag{119}$$

$$E_{\theta} = \frac{1}{4\pi\varepsilon_0} (I_0 \ell) \frac{k}{c} \sin\theta \left(\frac{i}{k^2 r^2} + \frac{1}{kr} - i \right) \frac{e^{i(kr - \omega t)}}{r}, \tag{120}$$

$$E_{\phi} = 0. \tag{121}$$

Notice that the expressions for the fields are considerably more complicated than the expression for the vector potential, and would be difficult to obtain by directly solving Maxwell's equations.

The expressions for the fields all involve a phase factor $e^{i(kr-\omega t)}$, with additional factors giving the detailed dependence of the phase and amplitude on distance and angle from the dipole. The phase factor $e^{i(kr-\omega t)}$ means that the fields propagate as waves in the radial direction, with frequency ω (equal to the frequency of the dipole), and wavelength λ given by:

$$\lambda = \frac{2\pi}{k} = \frac{2\pi c}{\omega}.\tag{122}$$

If we make some approximations, we can simplify the expressions for the fields. In fact, we can identify two different regimes. The *near field* regime is defined by the condition $kr \ll 1$. In this case, the fields are observed at a distance from the dipole much less than the wavelength of the radiation emitted by the dipole. The dominant field components are then:

$$B_{\phi} \approx \frac{\mu_0}{4\pi} (I_0 \ell) \sin \theta \frac{e^{i(kr - \omega t)}}{r^2},$$
 (123)

$$E_r \approx \frac{1}{4\pi\varepsilon_0} \frac{2i}{c} (I_0 \ell) \frac{e^{i(kr - \omega t)}}{kr^3},$$
 (124)

$$E_{\theta} \approx \frac{1}{4\pi\varepsilon_0} (I_0 \ell) \frac{i}{c} \sin \theta \, \frac{e^{i(kr - \omega t)}}{kr^3}.$$
 (125)

The far field regime is defined by the condition $kr \gg 1$. In this regime, the fields are observed at distances from the dipole that are large compared to the wavelength of the radiation emitted by the dipole. The dominant field components are:

$$B_{\phi} \approx -i\frac{\mu_0}{4\pi} (I_0 \ell) k \sin \theta \frac{e^{i(kr-\omega t)}}{r},$$
 (126)

$$E_{\theta} \approx -i\frac{1}{4\pi\varepsilon_0}(I_0\ell)\frac{k}{c}\sin\theta\,\frac{e^{i(kr-\omega t)}}{r}.$$
 (127)

The following features of the fields in this regime are worth noting:

- The electric and magnetic field components are perpendicular to each other, and to the (radial) direction in which the wave is propagating.
- At any position and time, the electric and magnetic fields are in phase with each other.
- The ratio between the magnitudes of the fields at any given position is $|E_{\theta}|/|B_{\phi}| \approx c$.

These are all properties associated with plane waves in free space. Furthermore, the amplitudes of the fields falls off as 1/r: at sufficiently large distance from the oscillating dipole, the amplitudes decrease slowly with increasing distance. At a large distance from an oscillating dipole, the electromagnetic waves produced by the dipole make a good approximation to plane waves in free space.

It is also worth noting the dependence of the field amplitudes on the polar angle θ : the amplitudes vanish for $\theta=0$ and $\theta=\pi$, i.e. in the direction of oscillation of the charges in the dipole. However, the amplitudes reach a maximum for $\theta=\pi/2$, i.e. in a plane through the dipole, and perpendicular to the direction of oscillation of the dipole.

We have seen that electromagnetic waves carry energy. This suggests that the Hertzian dipole radiates energy, and that some energy "input" will be required to maintain the amplitude of oscillation of the dipole. This is indeed the case. Let us calculate the rate at which the dipole will radiate energy. As usual, we use the expression:

$$\vec{S} = \vec{E} \times \vec{H},\tag{128}$$




Fig. 8: Distribution of radiation power from an Hertzian dipole. The current in the dipole is oriented along the z axis. The distance of a point on the curve from the origin indicates the relative power density in the direction from the origin to the point on the curve.

where the Poynting vector \vec{S} gives the amount of energy in an electromagnetic field crossing unit area (perpendicular to \vec{S}) per unit time. Before taking the vector product, we need to take the real parts of the expressions for the fields:

$$B_{\phi} = \frac{\mu_0}{4\pi} (I_0 \ell) k \frac{\sin \theta}{r} \left(\frac{\cos(kr - \omega t)}{kr} + \sin(kr - \omega t) \right), \tag{129}$$

$$E_r = \frac{1}{4\pi\varepsilon_0} \frac{2}{c} (I_0 \ell) \frac{1}{r^2} \left(\cos(kr - \omega t) - \frac{\sin(kr - \omega t)}{kr} \right), \tag{130}$$

$$E_{\theta} = \frac{1}{4\pi\varepsilon_0} (I_0 \ell) \frac{k}{c} \frac{\sin \theta}{r} \left(-\frac{\sin(kr - \omega t)}{k^2 r^2} + \frac{\cos(kr - \omega t)}{kr} + \sin(kr - \omega t) \right). \tag{131}$$

The full expression for the Poynting vector will clearly be rather complicated; but if we take the average over time (or position), then we find that most terms vanish, and we are left with:

$$\langle \vec{S} \rangle = \frac{(I_0 \ell)^2 k^2}{32\pi^2 \varepsilon_0 c} \frac{\sin^2 \theta}{r^2} \hat{r}.$$
 (132)

As expected, the radiation is directional, with most of the power emitted in a plane through the dipole, and perpendicular to its direction of oscillation; no power is emitted in the direction in which the dipole oscillates. The power distribution is illustrated in Fig. 8. The power per unit area falls off with the square of the distance from the dipole. This is expected, from conservation of energy.

The total power emitted by the dipole is found by integrating the power per unit area given by Eq. (132) over a surface enclosing the dipole. For simplicity, let us take a sphere of radius r. Then, the total (time averaged) power emitted by the dipole is:

$$\langle P \rangle = \int_{\theta=0}^{\pi} \int_{\phi=0}^{2\pi} |\langle \vec{S} \rangle| \, r^2 \sin \theta \, d\theta \, d\phi. \tag{133}$$

Using the result:

$$\int_{\theta=0}^{\pi} \sin^3\theta \, d\theta = \frac{4}{3},\tag{134}$$

we find:

$$\langle P \rangle = \frac{(I_0 \ell)^2 k^2}{12\pi \varepsilon_0 c} = \frac{(I_0 \ell)^2 \omega^2}{12\pi \varepsilon_0 c^3}.$$
 (135)

Notice that, for a given amplitude of oscillation, the total power radiated varies as the square of the frequency of the oscillation. The consequences of this fact are familiar in an everyday observation. Gas molecules in the Earth's atmosphere behave as small oscillating dipoles when the electric charges within them respond to the electric field in the sunlight passing through the atmosphere. The dipoles re-radiate




Fig. 9: (a) Left: "Pill box" surface for derivation of the boundary conditions on the normal component of the magnetic flux density at the interface between two media. (b) Right: Geometry for derivation of the boundary conditions on the tangential component of the magnetic intensity at the interface between two media.

the energy they absorb, a phenomenon known as *Rayleigh scattering*. The energy from the oscillating dipoles is radiated over a range of directions; after many scattering "events", it appears to an observer that the light comes from all directions, not just the direction of the original source (the sun). Eq. (135) tells us that shorter wavelength (higher frequency) light is scattered much more strongly than longer wavelength (lower frequency) light. Thus, the sky appears blue.

8 Boundary conditions

Gauss' theorem and Stokes' theorem can be applied to Maxwell's equations to derive constraints on the behaviour of electromagnetic fields at boundaries between different materials. For RF systems in particle accelerators, the boundary conditions at the surfaces of highly-conductive materials are of particular significance.

8.1 General boundary conditions

Consider first a short cylinder or "pill box" that crosses the boundary between two media, with the flat ends of the cylinder parallel to the boundary, see Fig. 9 (a). Applying Gauss' theorem to Maxwell's equation (2) gives:

$$\int_{V} \nabla \cdot \vec{B} \, dV = \oint_{\partial V} \vec{B} \cdot d\vec{S} = 0,$$

where the boundary ∂V encloses the volume V within the cylinder. If we take the limit where the length of the cylinder (2h – see Fig. 9 (a)) approaches zero, then the only contributions to the surface integral come from the flat ends; if these have infinitesimal area dS, then since the orientations of these surfaces are in opposite directions on opposite sides of the boundary, and parallel to the normal component of the magnetic field, we find:

$$-B_{1\perp} dS + B_{2\perp} dS = 0,$$

where $B_{1\perp}$ and $B_{2\perp}$ are the normal components of the magnetic flux density on either side of the boundary. Hence:

$$B_{1\perp} = B_{2\perp}.\tag{136}$$

In other words, the normal component of the magnetic flux density is continuous across a boundary.

Applying the same argument, but starting from Maxwell's equation (1), we find:

$$D_{2\perp} - D_{1\perp} = \rho_s, \tag{137}$$

where D_{\perp} is the normal component of the electric displacement, and ρ_s is the *surface* charge density (i.e. the charge per unit area, existing purely on the boundary).

A third boundary condition, this time on the component of the magnetic field parallel to a boundary, can be obtained by applying Stokes' theorem to Maxwell's equation (3). In particular, we consider a surface S bounded by a loop ∂S that crosses the boundary of the material, see Fig. 9 (b). If we integrate both sides of Eq. (3) over that surface, and apply Stokes' theorem (7), we find:

$$\int_{S} \nabla \times \vec{H} \cdot d\vec{S} = \oint_{\partial S} \vec{H} \cdot d\vec{l} = \int_{S} \vec{J} \cdot d\vec{S} + \frac{\partial}{\partial t} \int_{S} \vec{D} \cdot d\vec{S}, \tag{138}$$

where I is the total current flowing through the surface S. Now, let the surface S take the form of a thin strip, with the short ends perpendicular to the boundary, and the long ends parallel to the boundary. In the limit that the length of the short ends goes to zero, the area of S goes to zero: the electric displacement integrated over S becomes zero. In principle, there may be some "surface current", with density (i.e. current per unit length) $\vec{J_s}$: this contribution to the right hand side of Eq. (138) remains non-zero in the limit that the lengths of the short sides of the loop go to zero. In particular, note that we are interested in the component of $\vec{J_s}$ that is perpendicular to the component of \vec{H} parallel to the surface. We denote this component of the surface current density $J_{s\perp}$. Then, we find from Eq. (138) (taking the limit of zero length for the short sides of the loop):

$$H_{2\parallel} - H_{1\parallel} = -J_{s\perp},\tag{139}$$

where $H_{1\parallel}$ is the component of the magnetic intensity parallel to the boundary at a point on one side of the boundary, and $H_{2\parallel}$ is the component of the magnetic intensity parallel to the boundary at a nearby point on the other side of the boundary.

A final boundary condition can be obtained using the same argument that led to Eq. (139), but starting from Maxwell's equation (3). The result is:

$$E_{2||} = E_{1||}, \tag{140}$$

that is, the tangential component of the electric field \vec{E} is continuous across any boundary.

8.2 Electromagnetic waves on boundaries

The boundary conditions (136), (137), (139), and (140) must be satisfied for the fields in an electromagnetic wave incident on the boundary between two media. This requirement leads to the familiar phenomena of reflection and refraction: the laws of reflection and refraction, and the amplitudes of the reflected and refracted waves can be derived from the boundary conditions, as we shall now show.

Consider a plane boundary between two media (see Fig. 10). We choose the coordinate system so that the boundary lies in the x-y plane, with the z axis pointing from medium 1 into medium 2. We write a general expression for the electric field in a plane wave incident on the boundary from medium 1:

$$\vec{E}_I = \vec{E}_{0I} e^{i(\vec{k}_I \cdot \vec{r} - \omega_I t)}. \tag{141}$$

In order to satisfy the boundary conditions, there must be a wave present on the far side of the boundary, i.e. a transmitted wave in medium 2:

$$\vec{E}_T = \vec{E}_{0T} e^{i(\vec{k}_T \cdot \vec{r} - \omega_T t)}. \tag{142}$$




Fig. 10: Incident, reflected, and transmitted waves on a boundary between two media.

Let us assume that there is also an additional (reflected) wave in medium 1, i.e. on the incident side of the boundary. It will turn out that such a wave will be required by the boundary conditions. The electric field in this wave can be written:

$$\vec{E}_R = \vec{E}_{0R} e^{i(\vec{k}_R \cdot \vec{r} - \omega_R t)}.$$
(143)

First of all, the boundary conditions must be satisfied at all times. This is only possible if all waves are oscillating with the same frequency:

$$\omega_I = \omega_T = \omega_R = \omega. \tag{144}$$

Also, the boundary conditions must be satisfied for all points on the boundary. This is only possible if the phases of all the waves vary in the same way across the boundary. Therefore, if \vec{p} is *any* point on the boundary:

$$\vec{k}_I \cdot \vec{p} = \vec{k}_T \cdot \vec{p} = \vec{k}_R \cdot \vec{p}. \tag{145}$$

Let us further specify our coordinate system so that \vec{k}_I lies in the x-z plane, i.e. the y component of \vec{k}_I is zero. Then, if we choose \vec{p} to lie on the y axis, we see from Eq. (145) that:

$$k_{Ty} = k_{Ry} = k_{Iy} = 0. (146)$$

Therefore, the transmitted and reflected waves also lie in the x-z plane.

Now let us choose \vec{p} to lie on the x axis. Then, again using Eq. (145), we find that:

$$k_{Tx} = k_{Rx} = k_{Ix}. (147)$$

If we define the angle θ_I as the angle between \vec{k}_I and the z axis (the normal to the boundary), and similarly for θ_T and θ_R , then Eq. (147) can be expressed:

$$k_T \sin \theta_T = k_R \sin \theta_R = k_I \sin \theta_I. \tag{148}$$

Since the incident and reflected waves are travelling in the same medium, and have the same frequency, the magnitudes of their wave vectors must be the same, i.e. $k_R = k_I$. Therefore, we have the law of reflection:

$$\sin \theta_R = \sin \theta_I. \tag{149}$$




Fig. 11: Electric and magnetic fields in the incident, reflected, and transmitted waves on a boundary between two media. Left: The incident wave is N polarised, i.e. with the electric field normal to the plane of incidence. Right: The incident wave is P polarised, i.e. with the electric field parallel to the plane of incidence.

The angles of the transmitted and incident waves must be related by:

$$\frac{\sin \theta_I}{\sin \theta_T} = \frac{k_T}{k_I} = \frac{v_1}{v_2},\tag{150}$$

where v_1 and v_2 are the phase velocities in the media 1 and 2 respectively, and we have used the dispersion relation $v = \omega/k$. If we define the refractive index n of a medium as the ratio between the speed of light in vacuum to the speed of light in the medium:

$$n = \frac{c}{v},\tag{151}$$

then Eq. (150) can be expressed:

$$\frac{\sin \theta_I}{\sin \theta_T} = \frac{n_2}{n_1}.\tag{152}$$

This is the familiar form of the law of refraction, Snell's law.

So far, we have derived expressions for the relative directions of the incident, reflected, and transmitted waves. To do this, we have only used the fact that boundary conditions on the fields in the wave exits. Now, we shall derive expressions for the relative amplitudes of the waves: for this, we shall need to apply the boundary conditions themselves.

It turns out that there are different relationships between the amplitudes of the waves, depending on the orientation of the electric field with respect to the plane of incidence (that is, the plane defined by the normal to the boundary and the wave vector of the incident wave). Let us first consider the case that the electric field is normal to the plane of incidence, i.e. "N polarisation", see Fig. 11, left. Then, the electric field must be tangential to the boundary. Using the boundary condition (140), the tangential component of the electric field is continuous across the boundary, and so:

$$\vec{E}_{0I} + \vec{E}_{0R} = \vec{E}_{0T}.\tag{153}$$

Using the boundary condition (139), the tangential component of the magnetic intensity \vec{H} is also continuous across the boundary. However, because the magnetic field in a plane wave is perpendicular to the electric field, the magnetic intensity in each wave must lie in the plane of incidence, and at an angle to the boundary. Taking the directions of the wave vectors into account:

$$\vec{H}_{0I}\cos\theta_I - \vec{H}_{0R}\cos\theta_I = \vec{H}_{0T}\cos\theta_T. \tag{154}$$

Using the definition of the impedance Z of a medium as the ratio between the amplitude of the electric field and the amplitude of the magnetic intensity:

$$Z = \frac{E_0}{H_0},\tag{155}$$

we can solve Eqs. (153) and (154) to give:

$$\left(\frac{E_{0R}}{E_{0I}}\right)_{N} = \frac{Z_{2}\cos\theta_{I} - Z_{1}\cos\theta_{T}}{Z_{2}\cos\theta_{I} + Z_{1}\cos\theta_{T}},$$
(156)

$$\left(\frac{E_{0R}}{E_{0I}}\right)_{N} = \frac{Z_{2}\cos\theta_{I} - Z_{1}\cos\theta_{T}}{Z_{2}\cos\theta_{I} + Z_{1}\cos\theta_{T}},$$

$$\left(\frac{E_{0T}}{E_{0I}}\right)_{N} = \frac{2Z_{2}\cos\theta_{I}}{Z_{2}\cos\theta_{I} + Z_{1}\cos\theta_{T}}.$$
(156)

Following a similar procedure for the case that the electric field is oriented so that it is parallel to the plane of incidence ("P polarisation", see Fig. 11, right), we find:

$$\left(\frac{E_{0R}}{E_{0I}}\right)_{P} = \frac{Z_2 \cos \theta_T - Z_1 \cos \theta_I}{Z_2 \cos \theta_T + Z_1 \cos \theta_I},$$
(158)

$$\left(\frac{E_{0R}}{E_{0I}}\right)_{P} = \frac{Z_{2}\cos\theta_{T} - Z_{1}\cos\theta_{I}}{Z_{2}\cos\theta_{T} + Z_{1}\cos\theta_{I}},$$

$$\left(\frac{E_{0T}}{E_{0I}}\right)_{P} = \frac{2Z_{2}\cos\theta_{I}}{Z_{2}\cos\theta_{T} + Z_{1}\cos\theta_{I}}.$$
(158)

Equations (156), (157), (158) and (159) are known as Fresnel's equations: they give the amplitudes of the reflected and transmitted waves relative to the amplitude of the incident wave, in terms of the properties of the media (specifically, the impedance) on either side of the boundary, and the angle of the incident wave. Many important phenomena, including total internal reflection, and polarisation by reflection, follow from Fresnel's equations. However, we shall focus on the consequences for a wave incident on a good conductor.

First, note that for a dielectric with permittivity ε and permeability μ , the impedance is given by:

$$Z = \sqrt{\frac{\mu}{\varepsilon}}. (160)$$

This follows from Eq. (155), using the constitutive relation $\vec{B}=\mu\vec{H}$, and the relation between the field amplitudes in an electromagnetic wave $E_0/B_0=v$, where the phase velocity $v=1/\sqrt{\mu\varepsilon}$.

Now let us consider what happens when a wave is incident on the surface of a conductor. Using Maxwell's equation (4), the impedance can be written (in general) for a plane wave:

$$Z = \frac{E_0}{H_0} = \frac{\mu\omega}{k},\tag{161}$$

In a good conductor (for which the conductivity $\sigma \gg \omega \varepsilon$), the wave vector is complex; and this means that the impedance will also be complex. This implies a phase difference between the electric and magnetic fields, which does indeed occur in a conductor. In the context of Fresnel's equations, complex impedances will describe the phase relationships between the incident, reflected, and transmitted waves. From Eq. (52), the wave vector in a good conductor is given (approximately) by:

$$k \approx (1+i)\sqrt{\frac{\omega\sigma\mu}{2}}.$$
 (162)

Therefore, we can write:

$$Z \approx (1 - i)\sqrt{\frac{\omega\mu}{2\sigma}} = (1 - i)\sqrt{\frac{\omega\varepsilon}{2\sigma}}\sqrt{\frac{\mu}{\varepsilon}}.$$
 (163)

Consider a wave incident on a good conductor from a dielectric. If the permittivity and permeability of the conductor are similar to those in the dielectric, then, since $\sigma \gg \omega \varepsilon$ (by definition, for a good conductor), the impedance of the conductor will be much less than the impedance of the dielectric. Fresnel's equations become (for both N and P polarisation):

$$\frac{E_{0R}}{E_{0I}} \approx -1, \qquad \frac{E_{0T}}{E_{0I}} \approx 0.$$
 (164)

There is (almost) perfect reflection of the wave (with a change of phase); and very little of the wave penetrates into the conductor.

At optical frequencies and below, most metals are good conductors. In practice, as we expect from the above discussion, most metals have highly reflective surfaces. This is of considerable importance for RF systems in particle accelerators, as we shall see when we consider cavities and waveguides, in the following sections.

8.3 Fields on the boundary of an ideal conductor

We have seen that a good conductor will reflect most of the energy in a wave incident on its surface. We shall define an *ideal conductor* as a material that reflects all the energy in an electromagnetic wave incident on its surface¹. In that case, the fields at any point inside the ideal conductor will be zero at all times. From the boundary conditions (136) and (140), this implies that, at the surface of the conductor:

$$B_{\perp} = 0, \qquad E_{\parallel} = 0.$$
 (165)

That is, the normal component of the magnetic field, and the tangential component of the electric field must vanish at the boundary. These conditions impose strict constraints on the patterns of electromagnetic field that can persist in RF cavities, or that can propagate along waveguides.

The remaining boundary conditions, (137) and (139), allow for discontinuities in the normal component of the electric field, and the tangential component of the magnetic field, depending on the presence of surface charge and surface current. In an ideal conductor, both surface charge and surface current can be present: this allows the field to take non-zero values at the boundary of (and within a cavity enclosed by) an ideal conductor.

9 Fields in cavities

In the previous section, we saw that most of the energy in an electromagnetic wave is reflected from the surface of a good conductor. This provides the possibility of storing electromagnetic energy in the form of standing waves in a cavity; the situation will be analogous to a standing mechanical wave on, say, a violin string. We also saw in the previous section that there are constraints on the fields on the surface of a good conductor: in particular, at the surface of an ideal conductor, the normal component of the magnetic field and the tangential component of the electric field must both vanish. As a result, the possible field patterns (and frequencies) of the standing waves that can persist within the cavity are determined by the shape of the cavity. This is one of the most important practical aspects for RF cavities in particle accelerators. Usually, the energy stored in a cavity is needed to manipulate a charged particle beam in a particular way (for example, to accelerate or deflect the beam). The effect on the beam is determined by the field pattern. Therefore, it is important to design the shape of the cavity, so that the fields in the cavity interact with the beam in the desired way; and that undesirable interactions (which always occur to some extent) are minimised. The relationship between the shape of the cavity and the different field patterns (or *modes*) that can persist within the cavity will be the main topic of the present section. Other practical issues (for example, how the electromagnetic waves enter the cavity) are beyond our scope.

¹It is tempting to identify superconductors with ideal conductors; however, superconductors are rather complicated materials, that show sometimes surprising behaviour not always consistent with our definition of an ideal conductor.




Fig. 12: Rectangular cavity.

Modes in a rectangular cavity 9.1

We consider first a rectangular cavity with perfectly conducting walls, containing a perfect vacuum (see Fig. 12). The wave equation for the electric field inside the cavity is:

$$\nabla^2 \vec{E} - \frac{1}{c^2} \frac{\partial^2 \vec{E}}{\partial t^2} = 0, \tag{166}$$

where c is the speed of light in a vacuum. There is a similar equation for the magnetic field \vec{B} . We look for solutions to the wave equations for \vec{E} and \vec{B} that also satisfy Maxwell's equations, and also satisfy the boundary conditions for the fields at the walls of the cavity. If the walls of the cavity are ideal conductors, then the boundary conditions are:

$$E_{\parallel} = 0, \tag{167}$$

$$E_{\parallel} = 0,$$
 (167)
 $B_{\perp} = 0,$ (168)

where E_{\parallel} is the component of the electric field tangential to the wall, and B_{\perp} is the component of the magnetic field normal to the wall.

Free-space plane wave solutions will not satisfy the boundary conditions. However, we can look for solutions of the form:

$$\vec{E}(x,y,z,t) = \vec{E}_{\vec{r}}e^{-i\omega t},\tag{169}$$

where $\vec{E}_{\vec{r}} = \vec{E}_{\vec{r}}(x,y,z)$ is a vector function of position (independent of time). Substituting into the wave equation, we find that the spatial dependence satisfies:

$$\nabla^2 \vec{E}_{\vec{r}} + \frac{\omega^2}{c^2} \vec{E}_{\vec{r}} = 0. \tag{170}$$

The full solution can be derived using the method of separation of variables (in fact, we have begun the process by separating the time from the spatial variables). However, it is sufficient to quote the result, and verify the solution simply by substitution into the wave equation. The components of the electric field in the rectangular cavity are given by:

$$E_x = E_{x0} \cos k_x x \sin k_y y \sin k_z z e^{-i\omega t}, \qquad (171)$$

$$E_y = E_{y0} \sin k_x x \cos k_y y \sin k_z z e^{-i\omega t}, \qquad (172)$$

$$E_z = E_{z0} \sin k_x x \sin k_y y \cos k_z z e^{-i\omega t}. \tag{173}$$




Fig. 13: Boundary conditions in a rectangular cavity. The field component E_y is parallel to the walls of the cavity (and must therefore vanish) at x = 0 and $x = a_x$.

To satisfy the wave equation, we require:

$$k_x^2 + k_y^2 + k_z^2 = \frac{\omega^2}{c^2}. ag{174}$$

Maxwell's equation $\nabla \cdot \vec{E} = 0$, imposes a constraint on the components of the wave vector and the amplitudes of the field components:

$$k_x E_{x0} + k_y E_{y0} + k_z E_{z0} = 0. (175)$$

We also need to satisfy the boundary conditions, in particular that the tangential component of the electric field vanishes at the walls of the cavity. This imposes additional constraints on k_x , k_y and k_z . Consider:

$$E_y = E_{y0} \sin k_x x \cos k_y y \sin k_z z e^{-i\omega t}. \tag{176}$$

The boundary conditions require that $E_y=0$ at x=0 and $x=a_x$, for all y,z, and t (see Fig. 13). These conditions are satisfied if $k_xa_x=m_x\pi$, where m_x is an integer. To satisfy *all* the boundary conditions, we require:

$$k_x = \frac{m_x \pi}{a_x}, \qquad k_y = \frac{m_y \pi}{a_y}, \qquad k_z = \frac{m_z \pi}{a_z}, \tag{177}$$

where m_x , m_y and m_z are integers. Note that these integers play a large part in determining the shape of the electric field (though even when these numbers are specified, there is still some freedom in choosing the relative amplitudes of the field components). The quantities m_x , m_y , and m_z , are called the *mode numbers*. The frequency of oscillation is determined completely by the mode numbers, for a given size and shape of cavity.

The magnetic field can be obtained from the electric field, using Maxwell's equation:

$$\nabla \times \vec{E} = -\frac{\partial \vec{B}}{\partial t}.$$
 (178)

This gives:

$$B_x = \frac{i}{\omega} (E_{y0}k_z - E_{z0}k_y) \sin k_x x \cos k_y y \cos k_z z e^{-i\omega t},$$
 (179)

$$B_y = \frac{i}{\omega} (E_{z0}k_x - E_{x0}k_z) \cos k_x x \sin k_y y \cos k_z z e^{-i\omega t}, \qquad (180)$$

$$B_z = \frac{i}{\omega} (E_{x0}k_y - E_{y0}k_x) \cos k_x x \cos k_y y \sin k_z z e^{-i\omega t}.$$
 (181)

It is left as an exercise for the reader to show that these fields satisfy the boundary condition on the magnetic field at the walls of the cavity, and also satisfy the remaining Maxwell's equations:

$$\nabla \cdot \vec{B} = 0$$
, and $\nabla \times \vec{B} = \frac{1}{c^2} \frac{\partial \vec{E}}{\partial t}$. (182)




Fig. 14: Mode spectra in rectangular cavities. Top: all side lengths equal. Middle: two side lengths equal. Bottom: all side lengths different. Note that we show all modes, including those with two (or three) mode numbers equal to zero, even though such modes will have zero amplitude.

Note that the frequency of oscillation of the wave in the cavity is determined by the mode numbers m_x , m_y and m_z :

$$\omega = \pi c \sqrt{\left(\frac{m_x}{a_x}\right)^2 + \left(\frac{m_y}{a_y}\right)^2 + \left(\frac{m_z}{a_z}\right)^2}.$$
 (183)

For a cubic cavity $(a_x = a_y = a_z)$, there will be a degree of degeneracy, i.e. there will generally be several different sets of mode numbers leading to different field patterns, but all with the same frequency of oscillation. The degeneracy can be broken by making the side lengths different: see Fig. 14.

Some examples of field patterns in different modes of a rectangular cavity are shown in Fig. 15.

9.2 Quality factor

Note that the standing wave solution represents an oscillation that will continue indefinitely: there is no mechanism for dissipating the energy. This is because we have assumed that the walls of the cavity are made from an ideal conductor, and the energy incident upon a wall is completely reflected. These assumptions are implicit in the boundary conditions we have imposed, that the tangential component of the electric field and the normal component of the magnetic field vanish at the boundary.

In practice, the walls of the cavity will not be perfectly conducting, and the boundary conditions will vary slightly from those we have assumed. The electric and (oscillating) magnetic fields on the walls will induce currents, which will dissipate the energy. The rate of energy dissipation is usually quantified by the "quality factor", Q. The equation of motion for a damped harmonic oscillator:

$$\frac{d^2u}{dt^2} + \frac{\omega}{Q}\frac{du}{dt} + \omega^2 u = 0 \tag{184}$$

has the solution:

$$u = u_0 e^{-\frac{\omega t}{2Q}} \cos(\omega' t - \phi), \tag{185}$$

where:

$$\omega' = \omega \sqrt{\frac{4Q^2 - 1}{4Q^2}}. (186)$$

The quality factor Q is (for $Q \gg 1$) the number of oscillations over which the energy in the oscillator (proportional to the square of the amplitude of u) falls by a factor 1/e. More precisely, the rate of energy




Fig. 15: Examples of modes in rectangular cavity. From top to bottom: (110), (111), (210), and (211).

dissipation (the dissipated power, P_d) is given by:

$$P_d = -\frac{d\mathcal{E}}{dt} = \frac{\omega}{Q}\mathcal{E}.$$
 (187)

If a field is generated in a rectangular cavity corresponding to one of the modes we have calculated, the fields generating currents in the walls will be small, and the dissipation will be slow: such modes (with integer values of m_x , m_y and m_z) will have a high quality factor, compared to other field patterns inside the cavity. A mode with a high quality factor is called a resonant mode. In a rectangular cavity, the modes corresponding to integer values of the mode numbers are resonant modes.

9.3 Energy stored in a rectangular cavity

It is often useful to know the energy stored in a cavity. For a rectangular cavity, it is relatively straightforward to calculate the energy stored in a particular mode, given the amplitude of the fields. The energy density in an electric field is:

$$U_E = \frac{1}{2}\vec{D} \cdot \vec{E}.\tag{188}$$

Therefore, the total energy stored in the electric field in a cavity is:

$$\mathcal{E}_E = \frac{1}{2}\varepsilon_0 \int \vec{E}^2 dV, \tag{189}$$

where the volume integral extends over the entire volume of the cavity. In a resonant mode, we have:

$$\int_0^{a_x} \cos^2 k_x x \, dx = \int_0^{a_x} \sin^2 k_x x \, dx = \frac{1}{2},\tag{190}$$

where $k_x = m_x \pi/a_x$, and m_x is a non-zero integer. We have similar results for the y and z directions, so we find (for m_x , m_y and m_z all non-zero integers):

$$\mathcal{E}_E = \frac{1}{16} \varepsilon_0 (E_{x0}^2 + E_{y0}^2 + E_{z0}^2) \cos^2 \omega t.$$
 (191)

The energy varies as the square of the field amplitude, and oscillates sinusoidally in time.

Now let us calculate the energy in the magnetic field. The energy density is:

$$U_B = \frac{1}{2}\vec{B} \cdot \vec{H}. \tag{192}$$

Using:

$$k_x^2 + k_y^2 + k_z^2 = \frac{\omega^2}{c^2}$$
, and $E_{x0}k_x + E_{y0}k_y + E_{z0}k_z = 0$, (193)

we find, after some algebraic manipulation (and noting that the magnetic field is 90° out of phase with the electric field):

$$\mathcal{E}_B = \frac{1}{16} \frac{1}{\mu_0 c^2} (E_{x0}^2 + E_{y0}^2 + E_{z0}^2) \sin^2 \omega t.$$
 (194)

As in the case of the electric field, the numerical factor is correct if the mode numbers m_x , m_y and m_z are non-zero integers.

Finally, using $1/c^2 = \mu_0 \varepsilon_0$, we have (for m_x , m_y and m_z non-zero integers):

$$\mathcal{E}_E + \mathcal{E}_B = \frac{1}{16} \varepsilon_0 (E_{x0}^2 + E_{y0}^2 + E_{z0}^2). \tag{195}$$

The total energy in the cavity is constant over time, although the energy "oscillates" between the electric field and the magnetic field.

The power flux in the electromagnetic field is given by the Poynting vector:

$$\vec{S} = \vec{E} \times \vec{H}.\tag{196}$$

Since the electric and magnetic fields in the cavity are 90° out of phase (if the electric field varies as $\cos \omega t$, then the magnetic field varies as $\sin \omega t$), averaging the Poynting vector over time at any point in the cavity gives zero: this is again consistent with conservation of energy.

9.4 Shunt impedance

We have seen that in practice, some of the energy stored in a cavity will be dissipated in the walls, and that the rate of energy dissipation for a given mode is measured by the quality factor, Q (Eq. (187)):

$$P_d = -\frac{d\mathcal{E}}{dt} = \frac{\omega}{Q}\mathcal{E}.$$

For a mode with a longitudinal electric field component $E_{z0} = V_0/L$ (where L is the length of the cavity), we define the *shunt impedance*, R_s :

$$R_s = \frac{V_0^2}{2P_d}. (197)$$

(Note that different definitions of the shunt impedance are used, depending on the context: some definitions omit the factor 1/2).

Combining Eqs. (187) and (197), we see that:

$$\frac{R_s}{Q} = \frac{V_0^2}{2P_d} \cdot \frac{P_d}{\omega \mathcal{E}} = \frac{V_0^2}{2\omega \mathcal{E}}.$$
 (198)

Consider a mode with $B_z = 0$. Such modes have only transverse components of the magnetic field, and are called TM modes. Using equation (181), we see that the electric field in TM modes obeys:

$$k_y E_{x0} = k_x E_{y0}. (199)$$

We also have, from (175):

$$k_x E_{x0} + k_y E_{y0} + k_z E_{z0} = 0. (200)$$

These relations allow us to write the energy stored in the cavity purely in terms of the mode numbers and the peak longitudinal electric field:

$$\mathcal{E} = \frac{\varepsilon_0}{8} \left(\frac{k_x^2 + k_y^2 + k_z^2}{k_x^2 + k_y^2} \right) E_{z0}^2.$$
 (201)

Combining equations (198) and (201), we see that:

$$\frac{R_s}{Q} = \frac{16}{\varepsilon_0} \left(\frac{k_x^2 + k_y^2}{k_x^2 + k_y^2 + k_z^2} \right) \frac{L^2}{\omega}.$$
 (202)

For a TM mode in a rectangular cavity, the quantity R_s/Q depends only on the length of the cavity and the mode numbers. It is independent of such factors as the material of the walls. In fact, this result generalises: for TM modes, R_s/Q depends only on the geometry of the cavity, and the mode numbers. This is of practical significance since, to optimise the design of a cavity for accelerating a beam, the goal is to maximise R_s/Q for the accelerating mode, and minimise this quantity for all other modes. Since R_s/Q is independent of such quantities as the material from which the cavity is made, it is possible while designing the cavity to focus on optimising the geometry to achieve the highest R_s/Q for the desired mode (and minimise R_s/Q) for the other modes. Properties of the material from which the cavity will be made can safely be neglected at this stage of the design process.

9.5 Cylindrical cavities

Most cavities in accelerators are closer to a cylindrical than a rectangular geometry. It is worth considering the solutions to Maxwell's equations, subject to the usual boundary conditions, for a cylinder with perfectly conducting walls. We can find the modes in just the same way as we did for a rectangular cavity: that is, we find solutions to the wave equations for the electric and magnetic fields using separation of variables; then we find the "allowed" solutions by imposing the boundary conditions. The algebra is more complicated this time, because we have to work in cylindrical polar coordinates. We will not go through the derivation in detail: the solutions for the fields can be checked by taking the appropriate derivatives.

One set of modes (not the most general solution) we can write down is as follows:

$$E_r = -iB_0 \frac{n\omega}{k_r^2 r} J_n(k_r r) \sin n\theta \sin k_z z e^{-i\omega t}, \qquad (203)$$

$$E_{\theta} = -iB_0 \frac{\omega}{k_r} J'_n(k_r r) \cos n\theta \sin k_z z e^{-i\omega t}, \qquad (204)$$

$$E_z = 0, (205)$$

$$B_r = B_0 \frac{k_z}{k_r} J_n'(k_r r) \cos n\theta \cos k_z z e^{-i\omega t}, \qquad (206)$$

$$B_{\theta} = -B_0 \frac{nk_z}{k_r^2 r} J_n(k_r r) \sin n\theta \cos k_z z e^{-i\omega t}, \qquad (207)$$

$$B_z = B_0 J_n(k_r r) \cos n\theta \sin k_z z e^{-i\omega t}. \tag{208}$$

Note that $J_n(x)$ is a Bessel function of order n, and $J'_n(x)$ is the derivative of $J_n(x)$. The Bessel functions (Fig. 16) are solutions of the differential equation:

$$y'' + \frac{y'}{x} + \left(1 - \frac{n^2}{x^2}\right)y = 0. {(209)}$$

This equation appears when we separate variables in finding a solution to the wave equation in cylindrical polar coordinates.

Because of the dependence of the fields on the azimuthal angle θ , we require that n is an integer: n provides an azimuthal index in specifying a mode.

From the boundary conditions, E_{θ} and B_r must both vanish on the curved wall of the cavity, i.e. when r = a, where a is the radius of the cylinder. Therefore, we have a constraint on k_r :

$$J_n'(k_r a) = 0, (210)$$

or:

$$k_r = \frac{p'_{nm}}{a},\tag{211}$$

where p'_{nm} is the mth zero of the derivative of the nth order Bessel function. This equation is analogous to the conditions we had for the rectangular cavity, e.g. $k_x = m_x \pi/a_x$. We can use the integer m as a radial index in specifying a mode.

We also need to have $B_z = E_r = E_\theta = 0$ on the flat ends of the cavity. Assuming the flat ends of the cavity are at z = 0 and z = L, these boundary conditions are satisfied if:

$$\sin k_z L = 0,$$
 therefore $k_z = \frac{\ell \pi}{L},$ (212)




Fig. 16: Bessel functions. The red, green, blue and purple lines show (respectively) the first, second, third and fourth order Bessel functions $J_n(x)$.

where ℓ is an integer. ℓ provides a longitudinal index in specifying a mode.

Also, we find that:

$$\nabla^2 \vec{E} = -(k_r^2 + k_z^2) \vec{E},\tag{213}$$

so from the wave equation:

$$\nabla^2 \vec{E} - \frac{1}{c^2} \frac{\partial^2 \vec{E}}{\partial t^2} = 0, \tag{214}$$

we must have:

$$k_r^2 + k_z^2 = \frac{\omega^2}{c^2}. (215)$$

Similar equations hold for the magnetic field, \vec{B} .

In the modes that we are considering, the longitudinal component of the electric field $E_z=0$, i.e. the electric field is purely transverse. These modes are known as "TE" modes. A specific mode of this type, with indices n (azimuthal), m (radial), and ℓ (longitudinal) is commonly written as $\text{TE}_{nm\ell}$. The frequency of mode $\text{TE}_{nm\ell}$ depends on the dimensions of the cavity, and is given by:

$$\omega_{nm\ell} = c\sqrt{k_r^2 + k_z^2} = c\sqrt{\left(\frac{p'_{nm}}{a}\right)^2 + \left(\frac{\ell\pi}{L}\right)^2}.$$
 (216)

The fields in the TE_{110} mode in a cylindrical cavity are shown in Fig. 17.

TE modes are useful for giving a transverse deflection to a beam in an accelerator, but are not much use for providing acceleration. Fortunately, cylindrical cavities allow another set of modes that have non-zero longitudinal electric field:

$$E_r = -E_0 \frac{k_z}{k_r} J_n'(k_r r) \cos n\theta \sin k_z z e^{-i\omega t}, \qquad (217)$$

$$E_{\theta} = E_0 \frac{nk_z}{k_r^2 r} J_n(k_r r) \sin n\theta \sin k_z z e^{-i\omega t}, \qquad (218)$$

$$E_z = E_0 J_n(k_r r) \cos n\theta \cos k_z z e^{-i\omega t}, \qquad (219)$$




Fig. 17: TE_{110} mode in a cylindrical cavity. Left: Electric field. Right: Magnetic field. Top: 3-dimensional view. Bottom: Cross-sectional view.

$$B_r = iE_0 \frac{n\omega}{c^2 k_r^2 r} J_n(k_r r) \sin n\theta \cos k_z z e^{-i\omega t}, \qquad (220)$$

$$B_{\theta} = iE_0 \frac{\omega}{c^2 k_r} J'_n(k_r r) \cos n\theta \cos k_z z e^{-i\omega t}, \qquad (221)$$

$$B_z = 0. (222)$$

In these modes, the magnetic field is purely transverse (zero longitudinal component); therefore, they are referred to as "TM" modes. As before, for physical fields, n must be an integer. The boundary conditions on the fields give:

$$k_r = \frac{p_{nm}}{a}, \quad \text{and} \quad k_z = \frac{\ell \pi}{L},$$
 (223)

where p_{nm} is the mth zero of the nth order Bessel function $J_n(x)$. The frequency of a mode $TM_{nm\ell}$ is given by:

$$\omega_{nm\ell} = c\sqrt{k_r^2 + k_z^2} = c\sqrt{\left(\frac{p_{nm}}{a}\right)^2 + \left(\frac{\ell\pi}{L}\right)^2}.$$
 (224)

The lowest frequency accelerating mode in a cylindrical cavity is the TM_{010} mode ($n=0, m=1, \ell=0$). The fields in the TM_{010} (see Fig. 18) mode are given by:

$$E_r = 0, (225)$$

$$E_{\theta} = 0, \tag{226}$$

$$E_z = E_0 J_0 \left(p_{01} \frac{r}{a} \right) e^{-i\omega t}, \tag{227}$$

$$B_r = 0, (228)$$




Fig. 18: Fields in the TM₀₁₀ mode in a cylindrical cavity. Left: Electric field. Right: Magnetic field.

$$B_{\theta} = -i\frac{E_0}{c}J_1\left(p_{01}\frac{r}{a}\right)e^{-i\omega t}, \tag{229}$$

$$B_z = 0. (230)$$

The frequency of the TM_{010} mode is determined by the radius of the cavity, and is independent of its length:

$$\omega_{010} = p_{01} - \frac{c}{a}. (231)$$

(Note that $p_{01}\approx 2.40483$.) However, to get the maximum acceleration from the cavity, the time taken for a particle to pass through the cavity should be one half of the RF period, i.e. π/ω . Therefore, for best efficiency, the length of the cavity should be $L=\pi v/\omega$, where v is the velocity of the particle. For ultra-relativistic particles, the length of the cavity should be $L=\lambda/2$, where λ is the wavelength of an electromagnetic wave with angular frequency ω in free space.

10 Waveguides

Cavities are useful for storing energy in electromagnetic fields, but it is also necessary to transfer electromagnetic energy between different locations, e.g. from an RF power source such as a klystron, to an RF cavity. Waveguides are generally used for carrying large amounts of energy (high power RF). For low power RF signals (e.g. for timing or control systems), transmission lines are generally used. Although the basic physics in waveguides and transmission lines is the same – both involve electromagnetic waves propagating through bounded regions – different formalisms are used for their analysis, depending on the geometry of the boundaries. In this section, we consider waveguides; we consider transmission lines in the following section.

As was the case for cavities, the patterns of the fields in the resonant modes are determined by the geometry of the boundary. The resonant modes in a waveguide with circular cross-section will look somewhat different from the modes in a waveguide with rectangular cross-section. The physical principles and general methods are the same in both cases; however, the algebra is somewhat easier for a rectangular waveguide. Therefore, we shall consider here only waveguides with rectangular cross-section.

10.1 Modes in a rectangular waveguide

Consider an ideal conducting tube with rectangular cross-section, of width a_x and height a_y (Fig. 19). This is essentially a cavity resonator with length $a_z \to \infty$. The electric field must solve the wave




Fig. 19: Rectangular waveguide.

equation:

$$\nabla^2 \vec{E} - \frac{1}{c^2} \frac{\partial^2 \vec{E}}{\partial t^2} = 0, \tag{232}$$

together (as usual) with Maxwell's equations. By comparison with the rectangular cavity case, we expect to find standing waves in x and y, with plane wave solution in z. Therefore, we try a solution of the form:

$$E_x = E_{x0}\cos k_x x \sin k_y y e^{i(k_z z - \omega t)}, \qquad (233)$$

$$E_y = E_{y0} \sin k_x x \cos k_y y e^{i(k_z z - \omega t)}, \qquad (234)$$

$$E_z = iE_{z0}\sin k_x x \sin k_y y e^{i(k_z z - \omega t)}. \tag{235}$$

To satisfy the wave equation, we must have:

$$k_x^2 + k_y^2 + k_z^2 = \frac{\omega^2}{c^2}. (236)$$

We must of course also satisfy Maxwell's equation:

$$\nabla \cdot \vec{E} = 0, \tag{237}$$

at all x, y and z. This leads to the condition:

$$k_x E_{x0} + k_y E_{y0} + k_z E_{z0} = 0, (238)$$

which is the same as we found for a rectangular cavity.

Now we apply the boundary conditions. In particular, the tangential component of the electric field must vanish at all boundaries. For example, we must have $E_z=0$ for all t and all z, at x=0 and $x=a_x$, and at y=0 and $y=a_y$ (see Fig. 19). Therefore, $\sin k_x a_x=0$, and $\sin k_y a_y=0$, and hence:

$$k_x = \frac{m_x \pi}{a_x}, \qquad m_x = 0, 1, 2 \dots$$
 (239)

$$k_y = \frac{m_y \pi}{a_y}, \qquad m_y = 0, 1, 2 \dots$$
 (240)

These conditions also ensure that $E_x = 0$ at y = 0 and at $y = a_y$, and that $E_y = 0$ at x = 0 and at $x = a_x$.

We can find the magnetic field in the waveguide from:

$$\nabla \times \vec{E} = -\frac{\partial \vec{B}}{\partial t}.$$
 (241)

The result is:

$$B_x = \frac{1}{\omega} (k_y E_{z0} - k_z E_{y0}) \sin k_x x \cos k_y y e^{i(k_z z - \omega t)}, \qquad (242)$$

$$B_y = \frac{1}{\omega} (k_z E_{x0} - k_x E_{z0}) \cos k_x x \sin k_y y e^{i(k_z z - \omega t)}, \qquad (243)$$

$$B_z = \frac{1}{i\omega} (k_x E_{y0} - k_y E_{x0}) \cos k_x x \cos k_y y e^{i(k_z z - \omega t)}. \tag{244}$$

The conditions (239) and (240):

$$k_x = \frac{m_x \pi}{a_x}, \qquad m_x = 0, 1, 2 \dots$$

$$k_y = \frac{m_y \pi}{a_y}, \qquad m_y = 0, 1, 2 \dots$$

ensure that the boundary conditions on the magnetic field are satisfied. Also, the conditions (236):

$$k_x^2 + k_y^2 + k_z^2 = \frac{\omega^2}{c^2},$$

and (238):

$$k_x E_{x0} + k_y E_{y0} + k_z E_{z0} = 0,$$

ensure that Maxwell's equation:

$$\nabla \times \vec{B} = \frac{1}{c^2} \frac{\partial \vec{E}}{\partial t} \tag{245}$$

is satisfied.

In a rectangular cavity, the mode could be specified by a set of three numbers, m_x , m_y , and m_z , that determined the wave numbers and the frequency of oscillation of the field. Because m_x , m_y and m_z had to be integers, there was a discrete spectrum of allowed frequencies of oscillation in a cavity. In a waveguide, we only need two integer mode numbers, m_x and m_y , corresponding to the wave numbers in the transverse dimensions. The third wave number, in the longitudinal direction, is allowed to take values over a continuous range: this is because of the absence of boundaries in the longitudinal direction. Therefore, there is a continuous range of frequencies also allowed.

When we discussed cylindrical cavities, we wrote down two sets of modes for the fields: TE modes $(E_z=0)$, and TM modes $(B_z=0)$. We can also define TE and TM modes in rectangular cavities, and rectangular waveguides. For a TE mode in a waveguide, the longitudinal component of the electric field is zero at all positions and times, which implies that:

$$E_{z0} = 0. (246)$$

From (238), it follows that in a TE mode, the wave numbers and amplitudes must be related by:

$$k_x E_{x0} + k_y E_{y0} = 0. (247)$$

Similarly, for a TM mode, we have (using 244):

$$B_{z0} = 0, \quad k_x E_{u0} - k_u E_{x0} = 0. \tag{248}$$

10.2 Cut-off frequency in a waveguide

We have seen that in a waveguide, specifying the mode does not uniquely specify the frequency. This is a consequence of the fact that there are no boundaries in the longitudinal direction: there are only two mode numbers required to specify the transverse dependence of the field; the longitudinal dependence is not constrained by boundaries. The frequency of oscillation of fields in the waveguide depends on the longitudinal variation of the field, as well as on the transverse variation. However, if we want a wave to propagate along the waveguide, there is a minimum frequency of oscillation that is needed to achieve this, as we shall now show.

Let us write equation (236) in the form:

$$k_z^2 = \frac{\omega^2}{c^2} - k_x^2 - k_y^2. \tag{249}$$

If the wave is to propagate with no attentuation (i.e. propagate without any loss in amplitude), then k_z must be real. We therefore require that:

$$\frac{\omega^2}{c^2} > k_x^2 + k_y^2. \tag{250}$$

This can be written:

$$\frac{\omega}{c} > \pi \sqrt{\left(\frac{m_x}{a_x}\right)^2 + \left(\frac{m_y}{a_y}\right)^2}.$$
 (251)

We define the *cut-off* frequency ω_{co} :

$$\omega_{\rm co} = \pi c \sqrt{\left(\frac{m_x}{a_x}\right)^2 + \left(\frac{m_y}{a_y}\right)^2}.$$
 (252)

Above the cut-off frequency, the wave will propagate without loss of amplitude (in a waveguide with ideal conducting walls). At the cut-off frequency, the group velocity of the wave is zero: the wave is effectively a standing wave. Below the cut-off frequency, oscillating fields can still exist within the waveguide, but they take the form of attenuated (evanescent) waves, rather than propagating waves: the longitudinal wave number is purely imaginary.

Note that at least one of the mode numbers m_x and m_y must be non-zero, for a field to be present at all. Therefore, the minimum cut-off frequency of all the possible modes is given by:

$$\omega_{\rm co} = -\frac{\pi}{a}c,\tag{253}$$

where c is the speed of light, and a is the side length of the *longest* side of the waveguide cross-section.

10.3 Phase velocity, dispersion, and group velocity

Consider an electromagnetic wave that propagates down a waveguide, with longitudinal wave number k_z and frequency ω . The phase velocity v_p is given by:

$$v_p = \frac{\omega}{k_z} = \frac{\sqrt{k_x^2 + k_y^2 + k_z^2}}{k_z} c.$$
 (254)

This is the speed at which one would have to travel along the waveguide to stay at a constant phase of the electromagnetic wave (i.e. $k_z z - \omega t = \text{constant}$). However, since k_x , k_y and k_z are all real, it follows that the phase velocity is greater than the speed of light:

$$v_p > c. (255)$$




Fig. 20: Dispersion curve (in red) for waves in a waveguide. The broken black line shows phase velocity $\omega/k_z=c$.

The dispersion curve (Fig. 20) shows how the frequency ω varies with the longitudinal wave number k_z .

Although the phase velocity of a wave in a waveguide is greater than the speed of light, this does not violate special relativity, since energy and information signals travel down the waveguide at the group velocity, rather than the phase velocity. The group velocity v_q is given by:

$$v_g = \frac{d\omega}{dk_z} = \frac{k_z}{\sqrt{k_x^2 + k_y^2 + k_z^2}} c = \frac{k_z}{\omega} c^2,$$
 (256)

so we have:

$$v_q < c. (257)$$

Note that for a rectangular waveguide, the phase and group velocities are related by:

$$v_p v_g = c^2. (258)$$

Using equation (236):

$$k_x^2 + k_y^2 + k_z^2 = \frac{\omega^2}{c^2},$$

and the boundary conditions (239) and (240):

$$k_x = \frac{m_x \pi}{a_x}$$
 and $k_y = \frac{m_y \pi}{a_y}$,

we can write the group velocity (256) for a given mode (m_x, m_y) in terms of the frequency ω :

$$v_g = c\sqrt{1 - \frac{\pi^2 c^2}{\omega^2} \left(\frac{m_x^2}{a_x^2} + \frac{m_y^2}{a_y^2}\right)}.$$
 (259)

Energy in the wave propagates along the waveguide only for $\omega > \omega_{co}$ (where ω_{co} is the cut-off frequency). Note the limiting behaviour of the group velocity, for $\omega > \omega_{co}$:

$$\lim_{\omega \to \infty} v_g = c, \tag{260}$$




Fig. 21: Group velocity in a waveguide.

$$\lim_{\omega \to \omega_{\text{CO}}} v_g = 0. \tag{261}$$

The variation of group velocity with frequency is illustrated in Fig. 21.

10.4 Energy density and energy flow in a waveguide

The main purpose of a waveguide is to carry electromagnetic energy from one place to another: therefore, it is of interest to know the energy density and the energy flow in a waveguide, for a given mode and field amplitude.

The energy density in the waveguide can be calculated from:

$$U = \frac{1}{2}\varepsilon_0 \vec{E}^2 + \frac{1}{2}\frac{\vec{B}^2}{\mu_0}.$$
 (262)

Using the expressions for the fields (233) – (235), and assuming that both k_x and k_y are non-zero, we see that the *time-average energy per unit length* in the electric field is:

$$\iint \langle U_E \rangle \, dx \, dy = \frac{1}{16} \varepsilon_0 A \left(E_{x0}^2 + E_{y0}^2 + E_{z0}^2 \right), \tag{263}$$

where A is the cross-sectional area of the waveguide.

The fields in a waveguide are just a superposition of plane waves in free space. We know that in such waves, the energy is shared equally between the electric and magnetic fields. Using the expressions for the magnetic field (242) - (244), we can indeed show that the magnetic energy is equal (on average) to the electric energy - though the algebra is rather complicated. The total time-average energy per unit length in the waveguide is then given by:

$$\iint \langle U \rangle \, dx \, dy = \frac{1}{8} \varepsilon_0 A \left(E_{x0}^2 + E_{y0}^2 + E_{z0}^2 \right). \tag{264}$$

The energy flow along the waveguide is given by the Poynting vector, $\vec{S} = \vec{E} \times \vec{H}$. Taking the real parts of the field components, we find for the time-average transverse components:

$$\langle S_x \rangle = \langle S_y \rangle = 0. \tag{265}$$

The longitudinal component is non-zero; taking the time average and integrating over the cross section gives the time average energy flow along the waveguide

$$\iint \langle S_z \rangle \, dx \, dy = \frac{1}{8\mu_0} A (E_{x0}^2 + E_{y0}^2 + E_{z0}^2) \frac{k_z}{\omega}. \tag{266}$$




Fig. 22: Inductance in a transmission line.

Using equation (256) for the group velocity v_g , the time-average energy flow along the waveguide can be written in the form:

$$\iint \langle S_z \rangle \, dx \, dy = \frac{1}{8} \varepsilon_0 A (E_{x0}^2 + E_{y0}^2 + E_{z0}^2) v_g. \tag{267}$$

Thus, the energy density per unit length and the rate of energy flow are related by:

$$\iint \langle S_z \rangle \, dx \, dy = v_g \iint \langle U \rangle \, dx \, dy. \tag{268}$$

This is consistent with our interpretation of the group velocity as the speed at which energy is carried by a wave.

The boundary conditions that we have applied implicitly assume ideal conducting walls. In that case, there will be no energy losses to the walls, and electromagnetic waves can propagate indefinitely along the waveguide without any reduction in amplitude. In practice, there will be some attenuation, because of the finite conductivity of the walls of the wavguide. However, using a metal with high conductivity (such as copper or aluminium), attenuation lengths can be quite long, of order many metres. This makes waveguides very suitable for high-power RF applications.

11 Transmission lines

Transmission lines are used (as are waveguides) to guide electromagnetic waves from one place to another. A coaxial cable (used, for example, to connect a radio or television to an aerial) is an example of a transmission line. Transmission lines may be less bulky and less expensive than waveguides; but they generally have higher losses, so are more appropriate for carrying low-power signals over short distances.

11.1 LC model of a transmission line

Consider an infinitely long, parallel wire with zero resistance. In general, the wire will have some inductance per unit length, L, which means that when an alternating current I flows in the wire, there will be a potential difference between different points along the wire (Fig. 22). If V is the potential at some point along the wire with respect to earth, then the potential difference between two points along the wire is given by:

$$\Delta V = \frac{\partial V}{\partial x} \delta x = -L \delta x \frac{\partial I}{\partial t}.$$
 (269)

In general, as well as the inductance, there will also be some capacitance per unit length, C, between the wire and earth (Fig. 23). This means that the current in the wire can vary with position:

$$\frac{\partial I}{\partial x}\delta x = -C\delta x \frac{\partial V}{\partial t}.$$
 (270)




Fig. 23: Capacitance in a transmission line.

The "complete" model, including both inductance and capacitance, is referred to as the LC model for a transmission line.

We wish to solve the equations for the current and voltage in the transmission line, as functions of position and time. Let us take Equations (269) and (270) above:

$$\frac{\partial V}{\partial x} = -L \frac{\partial I}{\partial t},\tag{271}$$

$$\frac{\partial I}{\partial x} = -C \frac{\partial V}{\partial t}.$$
 (272)

These equations are analogous to Maxwell's equations: they show how changes (with respect to time and position) in current and voltage are related to each other. They take the form of two, coupled first-order differential equations. The fact that they are coupled means that the solution is not obvious; however, we can take the same approach that we did with Maxwell's equations in free space. By taking additional derivatives, we can arrive at two *uncoupled* second-order differential equations. The solution to the uncoupled equations is more apparent than the solution to the coupled equations. Differentiate (271) with respect to t:

$$\frac{\partial^2 V}{\partial x \partial t} = -L \frac{\partial^2 I}{\partial t^2},\tag{273}$$

and (272) with respect to x:

$$\frac{\partial^2 I}{\partial x^2} = -C \frac{\partial^2 V}{\partial t \partial x}.$$
 (274)

Hence:

$$\frac{\partial^2 I}{\partial x^2} = LC \frac{\partial^2 I}{\partial t^2}.$$
 (275)

Similarly (by differentiating (271) with respect to x and (272) with respect to t), we find:

$$\frac{\partial^2 V}{\partial x^2} = LC \frac{\partial^2 V}{\partial t^2}.$$
 (276)

Equations (275) and (276) are wave equations for the current in the wire, and the voltage between the wire and earth. The waves travel with speed v, given by:

$$v = \frac{1}{\sqrt{LC}}. (277)$$

The solutions to the wave equations may be written:

$$V = V_0 e^{i(kx - \omega t)}, (278)$$




Fig. 24: Termination of a transmission line with an impedance R.

$$I = I_0 e^{i(kx - \omega t)}, (279)$$

where the phase velocity is:

$$v = \frac{\omega}{k} = \frac{1}{\sqrt{LC}}. (280)$$

Note that the inductance per unit length L and the capacitance per unit length C are real and positive. Therefore, if the frequency ω is real, the wave number k will also be real: this implies that waves propagate along the transmission line with constant amplitude. This result is expected, given our assumption about the line having zero resistance.

The solutions must also satisfy the first-order equations (269) and (270). Substituting the above solutions into these equations, we find:

$$kV_0 = \omega LI_0, \tag{281}$$

$$kI_0 = \omega CV_0. \tag{282}$$

Hence:

$$\frac{V_0}{I_0} = \sqrt{\frac{L}{C}} = Z. \tag{283}$$

The ratio of the voltage to the current is called the *characteristic impedance*, Z, of the transmission line. Z is measured in ohms, Ω . Note that, since L and C are real and positive, the impedance is a real number: this means that the voltage and current are in phase. The characteristic impedance of a transmission line is analogous to the impedance of a medium for electromagnetic waves: the impedance of a transmission line gives the ratio of the voltage amplitude to the current amplitude; the impedance of a medium for electromagnetic waves gives the ratio of the electric field amplitude to the magnetic field amplitude.

11.2 Impedance matching

So far, we have assumed that the transmission line has infinite length. Obviously, this cannot be achieved in practice. We can terminate the transmission line using a "load" with impedance Z_L that dissipates the energy in the wave while maintaining the same ratio of voltage to current as exists all along the transmission line – see Fig. 24. In that case, our above analysis for the infinite line will remain valid for the finite line, and we say that the impedances of the line and the load are properly *matched*.

What happens if the impedance of the load, Z_L , is not properly matched to the characteristic impedance of the transmission line, Z? In that case, we need to consider a solution consisting of a superposition of waves travelling in opposite directions:

$$V = V_0 e^{i(kx - \omega t)} + K V_0 e^{i(-kx - \omega t)}.$$
 (284)




Fig. 25: A "lossy" transmission line.

The corresponding current is given by:

$$I = \frac{V_0}{Z}e^{i(kx-\omega t)} - K\frac{V_0}{Z}e^{i(-kx-\omega t)}. \tag{285}$$

Note the minus sign in the second term in the expression for the current: this comes from equations (271) and (272). Let us take the end of the transmission line, where the load is located, to be at x = 0. At this position, we have:

$$V = V_0 e^{-i\omega t} (1+K), (286)$$

$$I = \frac{V_0}{Z}e^{-i\omega t}(1-K). \tag{287}$$

If the impedance of the load is Z_L , then:

$$Z_L = \frac{V}{I} = Z \frac{1+K}{1-K}. (288)$$

Solving this equation for K (which gives the relative amplitude and phase of the "reflected" wave), we find:

$$K = \frac{Z_L/Z - 1}{Z_L/Z + 1} = \frac{Z_L - Z}{Z_L + Z}.$$
 (289)

Note that if $Z_L = Z$, there is no reflected wave: the termination is correctly matched to the characteristic impedance of the transmission line.

11.3 "Lossy" transmission lines

So far, we have assumed that the conductors in the transmission line have zero resistance, and are separated by a perfect insulator. Usually, though, the conductors will have finite conductivity; and the insulator will have some finite resistance. To understand the impact that this has, we need to modify our transmission line model to include:

- a resistance per unit length R in series with the inductance;
- a conductance per unit length G in parallel with the capacitance.

The modified transmission line is illustrated in Fig. 25.

The equations for the current and voltage are then:

$$\frac{\partial V}{\partial x} = -L\frac{\partial I}{\partial t} - RI, \tag{290}$$

$$\frac{\partial I}{\partial x} = -C\frac{\partial V}{\partial t} - GV. \tag{291}$$

We can find solutions to the equations (290) and (291) for the voltage and current in the lossy transmission line by considering the case that we propagate a wave with a single, well-defined frequency ω . In that case, we can replace each time derivative by a factor $-i\omega$. The equations become:

$$\frac{\partial V}{\partial x} = i\omega LI - RI = -\tilde{L}\frac{\partial I}{\partial t}, \tag{292}$$

$$\frac{\partial I}{\partial x} = i\omega CV - GV = -\tilde{C}\frac{\partial V}{\partial t},\tag{293}$$

where

$$\tilde{L} = L - \frac{R}{i\omega}$$
 and $\tilde{C} = C - \frac{G}{i\omega}$. (294)

The new equations (292) and (293) for the lossy transmission line look exactly like the original equations (271) and (272) for a lossless transmission line, but with the capacitance C and inductance L replaced by (complex) quantities \tilde{C} and \tilde{L} . The imaginary parts of \tilde{C} and \tilde{L} characterise the losses in the lossy transmission line.

Mathematically, we can solve the equations for a lossy transmission line in exactly the same way as we did for the lossless line. In particular, we find for the phase velocity:

$$v = \frac{1}{\sqrt{\tilde{L}\tilde{C}}} = \frac{1}{\sqrt{\left(L + i\frac{R}{\omega}\right)\left(C + i\frac{G}{\omega}\right)}},\tag{295}$$

and for the impedance:

$$Z = \sqrt{\frac{\tilde{L}}{\tilde{C}}} = \sqrt{\frac{L + i\frac{R}{\omega}}{C + i\frac{G}{\omega}}}.$$
 (296)

Since the impedance (296) is now a complex number, there will be a phase difference (given by the complex phase of the impedance) between the current and voltage in the transmission line. Note that the phase velocity (295) depends explicitly on the frequency. That means that a lossy transmission line will exhibit dispersion: waves of different frequencies will travel at different speeds, and a the shape of a wave "pulse" composed of different frequencies will change as it travels along the transmission line. Dispersion is one reason why it is important to keep losses in a transmission line as small as possible (for example, by using high-quality materials). The other reason is that in a lossy transmission line, the wave amplitude will attenuate, much like an electromagnetic wave propagating in a conductor.

Recall that we can write the phase velocity:

$$v = \frac{\omega}{k},\tag{297}$$

where k is the wave number appearing in the solution to the wave equation:

$$V = V_0 e^{i(kx - \omega t)},\tag{298}$$

and similarly for the current I. Using Eq. (295) for the phase velocity, we have:

$$k = \omega \sqrt{LC} \sqrt{\left(1 + i\frac{R}{\omega L}\right) \left(1 + i\frac{G}{\omega C}\right)}.$$
 (299)

Let us assume $R \ll \omega L$ (i.e. good conductivity along the transmission line) and $G \ll \omega C$ (i.e. poor conductivity between the lines); then we can make a Taylor series expansion, to find:

$$k \approx \omega \sqrt{LC} \left[1 + \frac{i}{2\omega} \left(\frac{R}{L} + \frac{G}{C} \right) \right].$$
 (300)




Fig. 26: Coaxial cable transmission line.

Finally, we write:

$$k = \alpha + i\beta, \tag{301}$$

and equate real and imaginary parts in equation (300) to give:

$$\alpha \approx \omega \sqrt{LC},$$
 (302)

and:

$$\beta \approx \frac{1}{2} \left(\frac{R}{Z_0} + GZ_0 \right), \tag{303}$$

where $Z_0 = \sqrt{L/C}$ is the impedance with R = G = 0 (not to be confused with the impedance of free space). Note that since:

$$V = V_0 e^{i(kx - \omega t)} = V_0 e^{-\beta x} e^{i(\alpha x - \omega t)}, \tag{304}$$

the value of α gives the wavelength $\lambda = 1/\alpha$, and the value of β gives the attenuation length $\delta = 1/\beta$.

11.4 Example: a coaxial cable

A lossless transmission line has two key properties: the phase velocity v, and the characteristic impedance Z. These are given in terms of the inductance per unit length L, and the capacitance per unit length C:

$$v = \frac{1}{\sqrt{LC}}, \qquad Z = \sqrt{\frac{L}{C}}.$$

The problem, when designing or analysing a transmission line, is to calculate the values of L and C. These are determined by the geometry of the transmission line, and are calculated by solving Maxwell's equations.

As an example, we consider a coaxial cable transmission line, consisting of a central wire of radius a, surrounded by a conducting "sheath" of internal radius d – see Fig. 26. The central wire and surrounding sheath are separated by a dielectric of permittivity ε and permeability μ . Suppose that the central wire carries charge per unit length $+\lambda$, and the surrounding sheath carries charge per unit length $-\lambda$ (so that the sheath is at zero potential). We can apply Maxwell's equation (1) with Gauss' theorem, to find that the electric field in the dielectric is given by:

$$|\vec{E}| = \frac{\lambda}{2\pi\varepsilon r},\tag{305}$$




Fig. 27: Inductance in a coaxial cable. A change in the current I flowing in the cable will lead to a change in the magnetic flux through the shaded area; by Faraday's law, the change in flux will induce an electromotive force, which results in a difference between the voltages V_2 and V_1 .

where r is the radial distance from the axis. The potential between the conductors is given by:

$$V = \int_{a}^{d} \vec{E} \cdot d\vec{r} = \frac{\lambda}{2\pi\varepsilon} \ln\left(\frac{d}{a}\right). \tag{306}$$

Hence the capacitance per unit length of the coaxial cable is:

$$C = \frac{\lambda}{V} = \frac{2\pi\varepsilon}{\ln\left(d/a\right)}. (307)$$

To find the inductance per unit length, we consider a length l of the cable. If the central wire carries a current I, then the magnetic field at a radius r from the axis is given by:

$$|\vec{B}| = \frac{\mu I}{2\pi r}.\tag{308}$$

The flux through the shaded area shown in Fig. 27 is given by:

$$\Phi = l \int_{a}^{d} |\vec{B}| dr = \frac{\mu l I}{2\pi} \ln\left(\frac{d}{a}\right). \tag{309}$$

A change in the flux through the shaded area will (by Faraday's law) induce an electromotive force around the boundary of this area; assuming that the outer sheath of the coaxial cable is earthed, the change in voltage between two points in the cable separated by distance l will be:

$$\Delta V = V_2 - V_1 = -\frac{d\Phi}{dt}.\tag{310}$$

The change in the voltage can also be expressed in terms of the inductance per unit length of the cable:

$$\Delta V = -lL \frac{dI}{dt},\tag{311}$$

where I is the current flowing in the cable. Hence the inductance per unit length is given by:

$$L = \frac{\Phi}{lI} = \frac{\mu}{2\pi} \ln\left(\frac{d}{a}\right). \tag{312}$$

With the expression in Eq. (307) for the capacitance per unit length:

$$C = \frac{2\pi\varepsilon}{\ln\left(d/a\right)},$$

the phase velocity of waves along the coaxial cable is given by:

$$v = \frac{1}{\sqrt{LC}} = \frac{1}{\sqrt{\mu\varepsilon}},\tag{313}$$

and the characteristic impedance of the cable is given by:

$$Z = \sqrt{\frac{L}{C}} = \frac{1}{2\pi} \ln\left(\frac{d}{a}\right) \sqrt{\frac{\mu}{\varepsilon}}.$$
 (314)

References

- [1] Vector Fields Software, http://www.cobham.com.
- [2] Computer Simulation Technology, http://www.cst.com.
- [3] ESRF Insertion Devices Group, http://www.esrf.eu/Accelerators/Groups/InsertionDevices/Software/Radia.
- [4] S. Russenschuck, "Foundation of numerical field computation," Proceedings of the CERN Accelerator School Course on Magnets, Bruges, Belgium (2009).
- [5] I. S. Grant and W. R. Phillips, "Electromagnetism," John Wiley and Sons, 2nd Edition (1990).
- [6] J. D. Jackson, "Classical electrodynamics," John Wiley and Sons, 3rd Edition (1998).