# Thermodynamics: An Engineering Approach 8th Edition Yunus A. Çengel, Michael A. Boles McGraw-Hill, 2015

## Topic 5 First Law of Thermodynamics

### **Objectives**

- Explain the basic concepts of thermodynamics such as system, process, and cycle.
- Define the concept of heat and the terminology associated with energy transfer by heat.
- Discuss the three mechanisms of heat transfer: conduction, convection, and radiation.
- Define the concept of work, including electrical work and several forms of mechanical work.
- Introduce the first law of thermodynamics, energy balances, and mechanisms of energy transfer to or from a system.
- Determine that a fluid flowing across a control surface of a control volume carries energy across the control surface in addition to any energy transfer across the control surface that may be in the form of heat and/or work.

### SYSTEMS AND CONTROL VOLUMES

- System: A quantity of matter or a region in space chosen for study.
- Surroundings: The mass or region outside the system
- Boundary: The real or imaginary surface that separates the system from its surroundings.
- The boundary of a system can be fixed or movable.
- Systems may be considered to be closed or open.
- Closed system (Control mass): A fixed amount of mass, and no mass can cross its boundary




FIGURE 1–18
System, surroundings, and boundary.




FIGURE 1–19

Mass cannot cross the boundaries of a closed system, but energy can.





FIGURE 1–20
A closed system with a moving boundary.




FIGURE 1–22
An open system (a control volume) with one inlet and one exit.

- Open system (control volume): A properly selected region in space.
- It usually encloses a device that involves mass flow such as a compressor, turbine, or nozzle.
- Both mass and energy can cross the boundary of a control volume.
- Control surface: The boundaries of a control volume. It can be real or imaginary.

A control volume can involve fixed, moving, real, and imaginary boundaries.



(a) A control volume (CV) with real and imaginary boundaries




(b) A control volume (CV) with fixed and moving boundaries as well as real and imaginary boundaries

### THE FIRST LAW OF THERMODYNAMICS

- The first law of thermodynamics (the conservation of energy principle) provides a sound basis for studying the relationships among the various forms of energy and energy interactions.
- The first law states that energy can be neither created nor destroyed during a process; it can only change forms.

The First Law: For all adiabatic processes between two specified states of a closed system, the net work done is the same regardless of the nature of the closed system and the details of the process.



#### FIGURE 2-39

Energy cannot be created or destroyed; it can only change forms.






FIGURE 2-40

The increase in the energy of a potato in an oven is equal to the amount of heat transferred to it.




### FIGURE 2-41

In the absence of any work interactions, the energy change of a system is equal to the net heat transfer.




### FIGURE 2-42

The work (electrical) done on an adiabatic system is equal to the increase in the energy of the system.



#### FIGURE 2-43

The work (shaft) done on an adiabatic system is equal to the increase in the energy of the system.



#### FIGURE 2-44


The work (boundary) done on an adiabatic system is equal to the increase in the energy of the system.

### **Energy Balance**

$$\begin{pmatrix} \text{Total energy} \\ \text{entering the system} \end{pmatrix} - \begin{pmatrix} \text{Total energy} \\ \text{leaving the system} \end{pmatrix} = \begin{pmatrix} \text{Change in the total} \\ \text{energy of the system} \end{pmatrix}$$

$$E_{\rm in} - E_{\rm out} = \Delta E_{\rm system}$$

The net change (increase or decrease) in the total energy of the system during a process is equal to the difference between the total energy entering and the total energy leaving the system during that process.




#### FIGURE 2-45

The energy change of a system during a process is equal to the *net* work and heat transfer between the system and its surroundings.

### **Example**

A heater running off 120 V and 5 A with an efficiency of 70% is used to heat a pool. The pool loses heat at a constant rate of 120 W. Over the course of the day, the sun provides 500 kJ of heat over a 6 hour period. Determine the rate of heating (or cooling) in the pool. What is the net energy gain (or lost) by the pool after the 6 hour sunny period?



### Energy Change of a System, $\Delta E_{\text{system}}$

Energy change = Energy at final state - Energy at initial state


$$\Delta E_{
m system} = E_{
m final} - E_{
m initial} = E_2 - E_1$$
  
 $\Delta E = \Delta U + \Delta KE + \Delta PE$ 

Internal, kinetic, and potential energy changes

$$\Delta U = m(u_2 - u_1)$$

$$\Delta KE = \frac{1}{2}m(V_2^2 - V_1^2)$$

$$\Delta PE = mg(z_2 - z_1)$$



### FIGURE 2-46

For stationary systems,  $\Delta KE = \Delta PE = 0$ ; thus  $\Delta E = \Delta U$ .

### Mechanisms of Energy Transfer, $E_{in}$ and $E_{out}$

Energy balance for any system undergoing any kind of process can be expressed more compactly as

$$\underbrace{E_{\text{in}} - E_{\text{out}}}_{\text{Net energy transfer}} = \underbrace{\Delta E_{\text{system}}}_{\text{Change in internal, kinetic,}} \text{(kJ)}$$
Change in internal, kinetic, potential, etc., energies

or, in the rate form, as

$$\underline{\dot{E}_{\text{in}} - \dot{E}_{\text{out}}} = \underline{dE_{\text{system}}/dt} \quad \text{(kW)}$$
Rate of net energy transfer by heat, work, and mass kinetic, potential, etc., energies

For constant rates, the total quantities during a time interval  $\Delta t$  are related to the quantities per unit time as

$$Q = \dot{Q} \Delta t$$
,  $W = \dot{W} \Delta t$ , and  $\Delta E = (dE/dt) \Delta t$  (kJ) (2-37)

The energy balance can be expressed on a **per unit mass** basis as

$$e_{\rm in} - e_{\rm out} = \Delta e_{\rm system}$$
 (kJ/kg) (2–38)

which is obtained by dividing all the quantities in Eq. 2–35 by the mass m of the system. Energy balance can also be expressed in the differential form as


$$\delta E_{\rm in} - \delta E_{\rm out} = dE_{\rm system}$$
 or  $\delta e_{\rm in} - \delta e_{\rm out} = de_{\rm system}$  (2-39)

Mechanisms of energy transfer:

- Heat transfer
- Work transfer
- Mass flow


A closed mass involves only *heat transfer* and *work*.

$$\begin{split} E_{\rm in} - E_{\rm out} &= (Q_{\rm in} - Q_{\rm out}) + (W_{\rm in} - W_{\rm out}) + (E_{\rm mass,in} - E_{\rm mass,out}) = \Delta E_{\rm system} \\ W_{\rm net,out} &= Q_{\rm net,in} \quad {\rm or} \quad \dot{W}_{\rm net,out} = \dot{Q}_{\rm net,in} \quad {\rm (for~a~cycle)} \end{split}$$



#### FIGURE 2-47

The energy content of a control volume can be changed by mass flow as well as heat and work interactions.



#### FIGURE 2-48

For a cycle  $\Delta E = 0$ , thus Q = W.

### PROCESSES AND CYCLES

Process: Any change that a system undergoes from one equilibrium state to another.

Path: The series of states through which a system passes during a process.

To describe a process completely, one should specify the initial and final states, as well as the path it follows, and the interactions with the surroundings.

Quasistatic or quasi-equilibrium process: When a process proceeds in such a manner that the system remains infinitesimally close to an equilibrium state at all times.






FIGURE 1–29
A process between states 1 and 2 and the process path.



#### FIGURE 1-30

Quasi-equilibrium and nonquasiequilibrium compression processes.

- Process diagrams plotted by employing thermodynamic properties as coordinates are very useful in visualizing the processes.
- Some common properties that are used as coordinates are temperature T, pressure P, and volume V (or specific volume v).
- The prefix *iso* is often used to designate a process for which a particular property remains constant.
- Isothermal process: A process during which the temperature T remains constant.
- Isobaric process: A process during which the pressure P remains constant.
- Isochoric (or isometric) process: A process during which the specific volume v remains constant.
- Cycle: A process during which the initial and final states are identical.




#### FIGURE 1-31

The *P-V* diagram of a compression process.

### The Steady-Flow Process


- The term steady implies no change with time. The opposite of steady is unsteady, or transient.
- A large number of engineering devices operate for long periods of time under the same conditions, and they are classified as steady-flow devices.
- Steady-flow process: A process during which a fluid flows through a control volume steadily.
- Steady-flow conditions can be closely approximated by devices that are intended for continuous operation such as turbines, pumps, boilers, condensers, and heat exchangers or power plants or refrigeration systems.



#### Time: 3 PM

#### FIGURE 1–32

During a steady-flow process, fluid properties within the control volume may change with position but not with time.




### FIGURE 1-33

Under steady-flow conditions, the mass and energy contents of a control volume remain constant.

### **ENERGY TRANSFER BY HEAT**


Heat: The form of energy that is transferred between two systems (or a system and its surroundings) by virtue of a temperature difference.



### FIGURE 2-14

Energy can cross the boundaries of a closed system in the form of heat and work.

Room air 25°C



#### FIGURE 2-15

Temperature difference is the driving force for heat transfer. The larger the temperature difference, the higher is the rate of heat transfer.


$$q = \frac{Q}{m}$$
 (kJ/kg) Heat transfer per unit mass

$$Q = \dot{Q} \Delta t$$

Amount of heat transfer  $\left(kJ\right)$  when heat transfer rate is constant


$$Q = \int_{t_1}^{t_2} \dot{Q} \, dt$$

Amount of heat transfer  $Q = \int_{-\infty}^{\infty} \dot{Q} dt$  Amount of heat transfer rate changes with time changes with time




#### FIGURE 2-16

Energy is recognized as heat transfer only as it crosses the system boundary.



#### FIGURE 2-18

The relationships among q, Q, and Q.



#### FIGURE 2-17


During an adiabatic process, a system exchanges no heat with its surroundings.

### Historical Background on Heat

- Kinetic theory: Treats molecules as tiny balls that are in motion and thus possess kinetic energy.
- Heat: The energy associated with the random motion of atoms and molecules.

#### **Heat transfer mechanisms:**

- Conduction: The transfer of energy from the more energetic particles of a substance to the adjacent less energetic ones as a result of interaction between particles.
- Convection: The transfer of energy between a solid surface and the adjacent fluid that is in motion, and it involves the combined effects of conduction and fluid motion.
- Radiation: The transfer of energy due to the emission of electromagnetic waves (or photons).



#### FIGURE 2-19

In the early nineteenth century, heat was thought to be an invisible fluid called the *caloric* that flowed from warmer bodies to the cooler ones.

### Mechanisms of Heat Transfer

- There are 3 modes of heat transfer:
  - Conduction
  - Convection
  - Radiation
- All modes require temperature difference between source and sink
- Heat transfers from high temperature to low temperature

### Conduction

- Transfer of more energetic particles to less energetic particles
- Occurs in solids, liquids, and gasses
  - Liquids and gasses: collision of molecules during random motion (Brownian motion)
  - Solids: combination of crystal lattice vibrations and energy transport by free electrons


### Conduction

$$\dot{Q}_{cond} = -k_t A \frac{\Delta T}{\Delta x}$$

- Heat of conduction is proportional to temperature difference  $(\Delta T)$  and area normal to heat transfer
- Thermal conductivity, *k<sub>t</sub>*: proportionality constant measures material's ability to conduct heat
- Conductors (e.g. most metals) have high k<sub>t</sub>
- Insulators (e.g. wood, styrofoam) have low  $k_t$  Fourier's law of heat conduction  $\dot{Q}_{cond} = -k_t A \frac{dT}{dx}$ 
  - Negative sign is used due to negative temperature gradient

### Conduction

$$\dot{Q}_{cond} = -k_t A \frac{\Delta T}{\Delta x}$$



### **Example**

The temperature distribution across a wall 1 m thick at a certain instant of time is given as

$$T(x) = a + bx + cx^2$$

where T is in degrees Celsius and x is in meters, while a, b, and c are listed below. The wall has an area of  $10 \ m^2$  and a thermal conductivity of  $40 \ \frac{W}{mK}$ . Determine the rate of heat transfer entering the wall and leaving the wall. Is the wall gaining or losing energy?

$$a = 900^{\circ}\text{C}$$
  $b = -300\frac{^{\circ}\text{C}}{m}$   $c = -50\frac{^{\circ}\text{C}}{m^2}$ 

**Solution 2** 

### Convection


- Transfer of energy to/from a solid surface from/to an adjacent moving fluid (liquid or gas)
- Combination of conduction and fluid motion
- Faster fluid motion results in more heat transfer
- If fluid is motionless then pure conduction occurs
- Forced convection: fluid is forced over surface by external means (fan, pump, wind, etc.)
- Free (or natural) convection: fluid motion is caused by buoyancy force due to changes in density (e.g. warmer air rises because it is less dense)

### Convection

- Heat transfer in processes that involve phase changes in fluids are consider to be convection
  - Movement of vapor bubbles through a liquid (evaporation)
  - Falling of liquid droplets (condensation)
- Newton's Law of Cooling  $\dot{Q}_{conv} = hA(T_S T_f)$
- Convective heat transfer coefficient, h
  - not a property of the fluid
  - Determined experimentally; affected by surface geometry, fluid properties, fluid velocity
- $T_s$  surface temperature;  $T_f$  bulk fluid temperature
  - Note: the temperature of fluid at the surface is  $T_s$  not  $T_f$  (continuum)

### Convection

$$\dot{Q}_{conv} = hA(T_S - T_f)$$



### Radiation

- Energy is emitted by matter in the form of electromagnetic waves (or photons)
- Results from the change of electronic configurations of atoms or molecules
- Does not require presence of medium between source and sink; can work in a vacuum
- All bodies at a temperature above absolute zero emit thermal radiation

### Radiation

$$\sigma = 5.67 \times 10^{-8} \frac{W}{m^2 K^4}$$

- Maximum radiation from a surface: Stefan-Boltzman's Law  $\dot{Q}_{emit.max} = \sigma A T_s^4$
- Surface that emits maximum radiation is called a blackbody
- Real surfaces emit less than the maximum


$$\dot{Q}_{emit,max} = \varepsilon \sigma A T_s^4$$

- Emissivity,  $\varepsilon$ : material property between 0 and 1 (for blackbodies  $\varepsilon = 1$ )
- For a large surface surrounding a radiation source:

$$\dot{Q}_{rad} = \varepsilon \sigma A (T_s^4 - T_{surr}^4)$$

### **Radiation**

$$\dot{Q}_{rad} = \varepsilon \sigma A (T_s^4 - T_{surr}^4)$$




### **ENERGY TRANSFER BY WORK**

- Work: The energy transfer associated with a force acting through a distance.
  - A rising piston, a rotating shaft, and an electric wire crossing the system boundaries are all associated with work interactions
- Formal sign convention: Heat transfer to a system and work done by a system are positive; heat transfer from a system and work done on a system are negative.
- Alternative to sign convention is to use the subscripts in and out to indicate direction. This is the primary approach in this text.

W = 30 kJ m = 2 kg  $\Delta t = 5 \text{ s}$   $\dot{W} = 6 \text{ kW}$  w = 15 kJ/kg

Work done per unit mass

$$w = \frac{W}{m} \qquad (kJ/kg)$$



#### FIGURE 2-20

The relationships among w, W, and  $\dot{W}$ .

### FIGURE 2–21


Specifying the directions of heat and work.

### Heat vs. Work

- Both are recognized at the boundaries of a system as they cross the boundaries. That is, both heat and work are boundary phenomena.
- Systems possess energy, but not heat or work.
- Both are associated with a *process*, not a state.
- Unlike properties, heat or work has no meaning at a state.
- Both are *path functions* (i.e., their magnitudes depend on the path followed during a process as well as the end states).

Properties are point functions have exact differentials (d).

$$\int_{1}^{2} dV = V_2 - V_1 = \Delta V$$



#### FIGURE 2–22

Properties are point functions; but heat and work are path functions (their magnitudes depend on the path followed).

$$\int_{1}^{2} dV = V_{2} - V_{1} = \Delta V \quad \begin{array}{c} \text{Path functions} \\ \text{have inexact} \\ \text{differentials } (\delta) \end{array} \int_{1}^{2} \delta W = W_{12} \qquad (not \ \Delta W)$$

### **Electrical Work**

Electrical work

$$W_e = \mathbf{V}N$$

Electrical power


$$\dot{W}_e = \mathbf{V}I \qquad (\mathbf{W})$$

When potential difference and current change with time

$$W_e = \int_1^2 \mathbf{V} I \, dt \qquad \text{(kJ)}$$

When potential difference and current remain constant

$$W_e = \mathbf{V}I \ \Delta t$$
 (kJ)




### FIGURE 2-27


Electrical power in terms of resistance R, current I, and potential difference V.

### MECHANICAL FORMS OF WORK

- There are two requirements for a work interaction between a system and its surroundings to exist:
  - there must be a force acting on the boundary.
  - the boundary must move.

Work = Force 
$$\times$$
 Distance  $W = Fs$  (kJ)





### FIGURE 2-28

The work done is proportional to the force applied (F) and the distance traveled (s).

### Shaft Work


A force 
$$F$$
 acting through a moment arm  $r$   $T = Fr \rightarrow F = \frac{T}{r}$  generates a torque  $T$ 

This force acts through a distance s  $s = (2\pi r)n$ 

Shaft work 
$$W_{\rm sh} = F_S = \left(\frac{\mathrm{T}}{r}\right)(2\pi rn) = 2\pi n\mathrm{T}$$
 (kJ)


The power transmitted through the shaft is the shaft work done per unit time

$$\dot{W}_{\rm sh} = 2\pi \dot{n} T \qquad (kW)$$





Energy transmission through rotating shafts is commonly encountered in practice.




#### FIGURE 2-30

Shaft work is proportional to the torque applied and the number of revolutions of the shaft. When the length of the spring changes by a differential amount dx under the influence of a force F, the work done is

$$\delta W_{\rm spring} = F \, dx$$

For linear elastic springs, the displacement *x* is proportional to the force applied

$$F = kx$$
 (kN) k: spring constant (kN/m)



#### FIGURE 2-32


Elongation of a spring under the influence of a force.

### Spring Work

Substituting and integrating yield

$$W_{\text{spring}} = \frac{1}{2}k(x_2^2 - x_1^2)$$
 (kJ)

 $x_1$  and  $x_2$ : the initial and the final displacements



#### FIGURE 2–33

The displacement of a linear spring doubles when the force is doubled.

### **Example**

Determine the energy necessary to stretch a spring (with a spring constant of 200 lbf/in) 4 inches. Express your answer in Btu.

**Useful Information:** 1 Btu = 778.169 lbf · ft


**Solution 3** 

## Work Associated with the Stretching of a Liquid Film

$$W_{\text{surface}} = \int_{1}^{2} \sigma_{s} dA \qquad \text{(kJ)}$$


#### Work Done on Elastic Solid Bars

$$W_{\text{elastic}} = \int_{1}^{2} F \, dx = \int_{1}^{2} \sigma_n A \, dx \qquad \text{(kJ)}$$



#### FIGURE 2-34

Solid bars behave as springs under the influence of a force.



#### FIGURE 2-35

Stretching a liquid film with a U-shaped wire, and the forces acting on the movable wire of length *b*.

### Work Done to Raise or to Accelerate a Body


- 1. The work transfer needed to raise a body is equal to the change in the potential energy of the body.
- 2. The work transfer needed to accelerate a body is equal to the change in the kinetic energy of the body.

### **Nonmechanical Forms of Work**

**Electrical work**: The generalized force is the *voltage* (the electrical potential) and the generalized displacement is the *electrical charge*.

Magnetic work: The generalized force is the *magnetic field strength* and the generalized displacement is the total *magnetic dipole moment*.

Electrical polarization work: The generalized force is the *electric field* strength and the generalized displacement is the *polarization of the medium*.



#### FIGURE 2-36

The energy transferred to a body while being raised is equal to the change in its potential energy.

### Summary

- Systems and control volumes
- Processes and cycles
  - The steady-flow process
- Energy transfer by heat
- Energy transfer by work
- Mechanical forms of work
- The first law of thermodynamics
  - Energy balance
  - Energy change of a system
  - Mechanisms of energy transfer (heat, work, mass flow)