Alarm Help - MV SERIES -



ALARM ADDRESS	A5.5	ALARM NO.	1129
ALARM TEXT	ARM SEN. DETECT ERR. PLS CHK. CIRCUIT.		
Related Signal	Input: X0.4 , X0.5 , X0.6 , X0.7 (MV154/154APC/MV204) X6.4 , X6.5 , X6.6 , X6.7 (184C) Output: Y1.0, Y1.1 (MV154/154APC/MV204) , Y4.6, Y4.7 (184C)		
CAUSE	ARM Action time over 3 seconds •		
ACTION	1.Check ARM position detector signal • 2.Check ARM Motor • ARM Break • ARM 60 D Position • ARM 0 D Position • ARM Bottom Position •		