OPERATING INSTRUCTIONS

The video input is auto video sensing, when your additional source is switched on the picture will override the navigation map picture. It will revert back to the navigation picture when your source is switched off.

The second input (Camera Input) is activated when the Blue cable is made live (adding a 12v+ supply) This input will override the additional source or the navigation map when activated.





NAV-INHON

VIDEO INPUT
HONDA ACCORD / LEGEND
Without TV Tuner

NAV TV (Europe) LTD



NAV TV (Europe) LTD

Distribution Centre Unit 21B Vale Business Park Llandow, Vale of Glamorgan CF71 7PF

Telephone: + 44 (0)8445 783 783 Fax: + 44 (0)1446 77 22 47

technical@nav.tv

LOCATION & REMOVAL

Ensure the vehicle is equipped with Navigation

All the plugs for can be accessed at the Navigation screen which is located in dash, or at navigation computer







INSTALLATION

All the wires can be accessed at the rear of the Screen unit. The wires are in the 20 way plug

NAV- INHON	Vehicle Navigation			
DVD ROM 06				
RED	White (pin 20)			
GREEN	Red (pin 19)			
BLUE	Yellow (pin 10)			
YELLOW	Black (pin 9)			
CD ROM <06				
RED	pin 13			
GREEN	pin 12			
BLUE	pin 3			
YELLOW	pin 2			

Rear of supplied plug

NAV (Input)	16	15	14	13	12	11	10	9
SCREEN (Out)	8	7	6	5	4	3	2	1

20 WAY PLUG AT REAR OF SCREEN



INSTALLATION

Other connections

YELLOW to 12v+ ignition / acc

BLACK to 12v- ground

RED to 12v+ to activate video input (also auto switching)

BLUE to 12v+ to activate camera input

(002)

