

NAV-INROV



NAV TV (Europe) LTD

Distribution Centre Unit 21B Vale Business Park Llandow, Vale of Glamorgan CF71 7PF

Telephone: + 44 (0)8445 783 783 + 44 (0)1446 77 22 47 Fax:

technical@nav.tv

VIDEO INPUT ROVER / RANGE ROVER <2005 Without TV Tuner NAV TV (Europe) LTD

LOCATION & REMOVAL

Ensure the vehicle is equipped with Navigation Connections are made at the blue plug located on the navigation unit. The unit is removed with removal keys.



INSTALLATION

The following plugs are to be used

Locate the blue plug at the Navigation unit, remove it from the unit and insert it into the supplied harness.

Insert the supplied harness into the navigation unit, plug in and mount the interface and carry out other connections:

Other connections

RED to 12v+ ignition / acc

BLACK to 12v- ground

BLUE to 12v+ to activate camera input

OPERATING INSTRUCTIONS

The video input is auto video sensing, when your additional source is switched on the picture will override the navigation map picture. It will revert back to the navigation picture when your source is switched off.

The second input (Camera Input) is activated when the Blue cable is made live (adding a 12v+ supply) This input will override the additional source or the navigation map when activated.



