LVV-T2190

November 9, 2021

1 MTAOS add aberrations to M1M3+M2+hexapod

This notebook is used for the level 3 integration tests from test plan LVV-P81 (https://jira.lsstcorp.org/secure/Tests.jspa#/testPlan/LVV-P81) as part of test cylce LVV-C176 (https://jira.lsstcorp.org/secure/Tests.jspa#/testCycle/LVV-C176). The following tests are currently run as part of this notebook:

• LVV-T2190 (https://jira.lsstcorp.org/secure/Tests.jspa#/testCase/LVV-T2190)

Execution steps are separated by horizontal lines. Upon completion, save the notebook and its output as a pdf file to be attached to the test execution in JIRA.

Last updated by E. Dennihy 20211020

Load all the needed libraries. Get the remotes ready Code in the notebook including section: "Check the summary state of each CSC".

```
[1]: %load_ext autoreload %autoreload 2
```

```
[2]: import rubin_jupyter_utils.lab.notebook as nb
nb.utils.get_node()
```

/tmp/ipykernel_55787/1665379685.py:2: DeprecationWarning: Call to deprecated
function (or staticmethod) get_node. (Please use lsst.rsp.get_node())
 nb.utils.get_node()

[2]: 'andes05.cp.lsst.org'

```
[3]: import os
import sys
import asyncio
import logging

import pandas as pd
import numpy as np

from matplotlib import pyplot as plt
```

```
from lsst.ts import salobj
     from lsst.ts.observatory.control.maintel import MTCS, ComCam
     from lsst.ts.observatory.control import RotType
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
[4]: logging.basicConfig(format="%(name)s:%(message)s", level=logging.DEBUG)
[5]: log = logging.getLogger("setup")
     log.level = logging.DEBUG
[6]: domain = salobj.Domain()
[7]: mtcs = MTCS(domain=domain, log=log)
     mtcs.set_rem_loglevel(40)
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
[8]: await mtcs.start_task
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
[8]: [None, None, None, None, None, None, None, None, None]
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
    <IPython.core.display.HTML object>
```

<IPython.core.display.HTML object> <IPython.core.display.HTML object>

```
<IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
     Ready M1M3: Raise mirror, turn on FB, clear forces
     Need to have M1M3 LUT use its inclinometer.
     Ready M2: Turn on FB, clear forces
     Need to have M2 LUT use its inclinometer
     Get camera hexapod ready: check config; make sure LUT is on, and has valid inputs; make sure
     hex is at LUT position
     Get M2 hexapod ready: check config; make sure LUT is on, and has valid inputs; make sure hex is
     at LUT position
     Slew to the next target. Choose a target such that the rotator stays within a couple of degrees of
     its initial position. This is because the CCW is not running (MTmount in simulation mode).
 [9]: target = await mtcs.find_target(el=60, az=120, mag_limit=8)
      print(target)
     HD 172858
[10]: await mtcs.slew_object(target, rot_type=RotType.PhysicalSky, rot=1.9)
     <IPython.core.display.HTML object>
     <IPython.core.display.HTML object>
```

```
<IPython.core.display.HTML object>
```

add 1um of z7 to the system via OFC

Compare the corrections sent vs forces and position changes applied. This is currently done in a separate notebook.

```
[11]: wavefront_errors = np.zeros(19)
      wavefront_errors[3] += 1.0 # add1 um to z7
[12]: l
[13]: print(await mtcs.rem.mtaos.cmd addAberration.set start(wf=wavefront errors,
       →timeout=10))
     private_revCode: 8e276e56, private_sndStamp: 1636480426.529292,
     private rcvStamp: 1636480426.5300248, private seqNum: 232802593,
     private_identity: MTAOS, private_origin: 247075, private_host: 0, ack: 303,
     error: 0, result: Done, host: 0, identity: edennihy@nb-edennihy, origin: 55787,
     cmdtype: 2, timeout: 0.0
     This command primes the corrections, the issue Correction command is needed to actually command
     them to be sent
[14]: salobj.current_tai()
[14]: 1636480505.3890316
      await mtcs.rem.mtaos.cmd_issueCorrection.start(timeout=60.)
[15]:
[15]: <ddsutil.MTAOS_ackcmd_8e276e56 at 0x7f4e3c8f96d0>
     Make plots using telemetry from each component to verify the changes in the DOFs. This step does
```

not currently involve running any commands in this notebook. This step must be verified using a separate noteboook.

reset the corrections using the resetCorrection command

Compare the corrections sent vs forces and position changes applied (these are all expected to be zero). This is currently done in a separate notebook or on Chronograf.

```
[16]: await mtcs.rem.mtaos.cmd_resetCorrection.start()
[16]: <ddsutil.MTAOS_ackcmd_8e276e56 at 0x7f4e3c3b0610>
[17]: await mtcs.rem.mtaos.cmd_issueCorrection.start(timeout=60.)
[17]: <ddsutil.MTAOS_ackcmd_8e276e56 at 0x7f4e3c2e8430>
```

add 2um of z7 to the system via OFC

Compare the corrections sent vs forces and position changes applied. This is currently done in a separate notebook or on Chronograf.

```
[18]: wavefront_errors[3] = 2.0 # add 2.0 um of z7
[19]: print(await mtcs.rem.mtaos.cmd_addAberration.set_start(wf=wavefront_errors,__
       →timeout=10))
     private_revCode: 8e276e56, private_sndStamp: 1636480559.4982584,
     private_rcvStamp: 1636480559.4985392, private_seqNum: 232802594,
     private_identity: MTAOS, private_origin: 247075, private_host: 0, ack: 303,
     error: 0, result: Done, host: 0, identity: edennihy@nb-edennihy, origin: 55787,
     cmdtype: 2, timeout: 0.0
[20]: await mtcs.rem.mtaos.cmd_issueCorrection.start(timeout=60.)
[20]: <ddsutil.MTAOS ackcmd 8e276e56 at 0x7f4dea1e91f0>
     Stop Tracking
[21]: await mtcs.stop_tracking()
     <IPython.core.display.HTML object>
[22]: salobj.current_tai()
[22]: 1636480581.6822271
     Check that the corrections in step 10 are twice of those in step 7. This step does not currently
     involve running any commands in this notebook. This step must be verified using a separate
     noteboook.
     Wrap up. Put each component to the following states: mtaos -> standby m1m3 -> lower mirror
     -> standby m2 -> standby camera hex -> standby m2 hex -> standby
 []: await mtcs.set_state(salobj.State.STANDBY, components=["mtaos"])
      await mtcs.lower_m1m3()
      await mtcs.set_state(salobj.State.STANDBY, components=["mtm1m3"])
 []:
```

await mtcs.set_state(salobj.State.STANDBY, components=["mtm2"])

await mtcs.set_state(salobj.State.STANDBY, components=["mthexapod_1"])

await mtcs.set_state(salobj.State.STANDBY, components=["mthexapod 2"])

[]:

[]:

[]: await mtcs.standby()