

COMPUTER ORGANIZATION AND DESIGN

The Hardware/Software Interface

Topic 2


Assembly Programming

- Operations and Operands

Levels of Program Code

- High-level language (translator: compiler)
 - Level of abstraction closer to problem domain
 - Provides productivity and portability
- Assembly language (translator: assembler)
 - Low-level language
 - Symbolic representation of binary machine code
 - Direct correspondence to machine code
 - More readable than machine code
- Machine language
 - Binary digits (bits) language of digital circuits
 - Composed of instructions (commands for computer) and data
 - Instructions and data encoded in binary digitals

Processing Different Languages





Assembly Language

- When to use?
 - Compilers introduce uncertainty about execution time and size
 - Use when speed and size of program are critical
 - Can mix high-level language with assembly
- Drawbacks of Assembly language
 - Can be very time consuming
 - No assembler optimization
 - Almost impossible to be portable
 - Different computers support different assembly languages that requires different assembler
 - Assembly languages are similar
 - Hard to debug



Instruction Set

- or ISA, all commands that computer understands including data types, registers, addressing modes, etc.
- Different computers have different instruction sets
 - But with many common aspects
- Types of
 - Reduced Instruction Set Computer RISC
 - Complex Instruction Set Computer CISC



The MIPS Instruction Set

- Used as the example throughout the book
 - Originated from Stanford MIPS commercialized by MIPS Technologies (<u>www.mips.com</u>)
- Large share of embedded core market
- Typical features of many modern ISAs
 - See MIPS Reference Card, and Appendixes B and E



Arithmetic Operations

- Add and subtract, three operands
 - Two sources and one destination add a, b, c # a = b + c
- All MIPS arithmetic operations have this regular form
- Design Principle 1: Simplicity favors regularity
 - Regularity makes implementation simpler
 - Simplicity enables higher performance at lower cost



Arithmetic Example

C/C++ code:

$$f = (g + h) - (i + j);$$

Compiled pseudo-MIPS assembly code:

```
add t0, g, h # temp t0 = g + h add t1, i, j # temp t1 = i + j sub f, t0, t1 # f = t0 - t1
```



Operands in MIPS Assembly

- Register operands
- Memory operands
- Immediate operands (constant)



Register Operands

- Arithmetic instructions use register operands
- MIPS architecture has a 32 imes 32-bit register file
 - Used for frequently accessed data
 - Numbered 0 to 31
 - Each register is a 32-bit word
- Names recognized by MIPS assembler
 - \$t0~\$t9, \$s0~\$s7, etc.
 - Or \$0-\$31, accepted by certain assemblers
- Design Principle 2: Smaller is faster



Register Operands

- \$zero: constant 0 (reg 0, also written as \$0)
- \$at: Assembler Temporary (reg 1, or \$1)
- \$v0, \$v1: result values (reg's 2 and 3, or \$2 and \$3)
- \$a0 \$a3: arguments (reg's 4 7, or \$4 \$7)
- \$t0 \$t7: temporaries (reg's 8 15, or \$8 \$15)
- \$s0 \$s7: saved (reg's 16 23, or \$16 \$23)
- \$t8, \$t9: temporaries (reg's 24 and 25, or \$24 and \$25)
- \$k0, \$k1: reserved for OS kernel (reg's 26 and 27, \$26/27)
- \$gp: global pointer for static data (reg 28, or \$28)
- \$sp: stack pointer (reg 29, or \$29)
- \$fp: frame pointer (reg 30, or \$30)
- \$ra: return address (reg 31, or \$31)



Register Operand Example

C/C++ code:

$$f = (g + h) - (i + j);$$

- Put f, g, h, i, and j in \$s0, \$s1, \$s2, \$s3, and \$s4, respectively
- Compiled MIPS code:

```
add $t0, $s1, $s2
add $t1, $s3, $s4
sub $s0, $t0, $t1
```



Memory Operands

- Memory used mainly for composite data
 - Arrays, structures, dynamic data
- In arithmetic operations
 - Load values from memory into registers
 - Store result from register to memory
- MIPS memory is byte addressable
 - Each address identifies an 8-bit byte
- Memory is organized in words
 - Word address must be a multiple of 4 alignment restriction
- MIPS is Big Endian (except some MIPS extension)
 - Most-significant byte at least address of a word
 - Little Endian: least-significant byte at least address



Memory Operand Example 1

C/C++ code:

```
g = h + A[8]; //g, h, A are words
```

- g in \$s1, h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32 (4 bytes/word)

```
lw $t0, 32($s3) # load word
add $s1, $s2, $t0

offset base address register
```



Memory Operand Example 2

C code:

```
A[12] = h + A[8];
```

- h in \$s2, base address of A in \$s3
- Compiled MIPS code:
 - Index 8 requires offset of 32

```
lw $t0, 32($s3)  # load word
add $t0, $s2, $t0
sw $t0, 48($s3)  # store word
```



Registers vs. Memory

- Registers are faster to access than memory
- Operating on memory data requires loads and stores
 - More instructions to be executed
- Compiler must use registers for variables as much as possible
 - Only spill to memory for less frequently used variables
 - Register optimization is important!



Immediate Operands

- Immediate operands constant data specified in an instruction addi \$s3, \$s3, 4
- No subtract immediate instruction
 - Just use a negative constant addi \$s2, \$s1, -1
- Design Principle 3: Make the common case fast
 - Small constants are common
 - Immediate operand avoids loading data from memery



The Constant Zero

- MIPS register 0 (\$zero) is the constant 0
 - Cannot be overwritten
- Useful for common operations
 - E.g., move between registers add \$t2, \$s1, \$zero



Logical Operations

Instructions for bitwise manipulation

Operation	С	Java	MIPS
Shift left	<<	<<	s11
Shift right	>>	>>>	srl
Bitwise AND	&	&	and, andi
Bitwise OR			or, ori
Bitwise NOT	~	~	nor

 Useful for extracting and inserting groups of bits in a word



Shift Operations

sll/srl rd, rt, shamt

- rt: source register
- rd: destination register
- shamt: how many bits to shift
- Shift left logical
 - Shift left and fill vacated bits with 0 bits
 - s11 by *i* bits = multiplies by 2^i
- Shift right logical
 - Shift right and fill vacated bits with 0 bits
 - $srl by i bits = divides by 2^i (unsigned only)$



AND Operations

- Useful to mask bits in a word
 - Select some bits, clear others to 0

```
and $t0, $t1, $t2
```

```
$t2 | 0000 0000 0000 0000 00 11 01 1100 0000
```



OR Operations

- Useful to include bits in a word
 - Set some bits to 1, leave others unchanged

```
or $t0, $t1, $t2
```

\$t2 0000 0000	0000 0000 00	00 11 0°	1 1100 0000
------------------	--------------	----------	-------------

\$t0 | 0000 0000 0000 0000 00 11 11 01 1100 0000



NOT Operations

- Useful to invert bits in a word
 - Change 0 to 1, and 1 to 0
- MIPS doesn't have NOT instruction, implemented with NOR instruction

```
nor $t0, $t1, $zero ← Register $0: always read as zero
```

```
$t1 0000 0000 0000 0000 0011 11 00 0000 0000
```



Load 32-bit Constants

- Most constants are small
 - 16-bit immediate is sufficient
- For the occasional 32-bit constant lui rt, constant
 - Copies 16-bit constant to left 16 bits of rt
 - Clears right 16 bits of rt to 0




Branch/Jump Operations

- Branch to a labeled instruction if a condition is true
 - Otherwise, continue sequentially
- beq rs, rt, L1
 - if (rs == rt) branch to instruction labeled L1;
- bne rs, rt, L1
 - if (rs != rt) branch to instruction labeled L1;
- j L1
 - unconditional jump to instruction labeled L1



Compiling If Statements

C code:



- f,g,h,i,j in \$s0, \$s1, \$s2, \$s3, \$s4 respectively
- Compiled MIPS code:

```
bne $s3, $s4, Else
add $s0, $s1, $s2
j Exit
Else: sub $s0, $s1, $s2
Exit: ... Assembler calculates addresses
```

Compiling Loop Statements

C code:

```
while (save[i] == k) i += 1;
```


- i in \$s3, k in \$s5, address of save in \$s6
- Compiled MIPS code:

```
Loop: sll $t1, $s3, 2
add $t1, $t1, $s6
lw $t0, 0($t1)
bne $t0, $s5, Exit
addi $s3, $s3, 1
j Loop
Exit: ...
```



Basic Blocks

- A basic block is a sequence of instructions with
 - No embedded branches (except at end)
 - No branch targets (except at beginning)



- A compiler identifies basic blocks for optimization
- An advanced processor can accelerate execution of basic blocks



Conditional Operations

- Set result to 1 if a condition is true, otherwise, set to 0
 - slt rd, rs, rt
 - if (rs < rt) rd = 1; else rd = 0;
 - slti rt, rs, constant
 - if (rs < constant) rt = 1; else rt = 0;</pre>
- Use in combination with beq, bne

```
slt $t0, $s1, $s2 # if ($s1 < $s2)
bne $t0, $zero, L # branch to L</pre>
```



Branch Instruction Design

- Why not blt, bge, etc?
- Hardware for <, ≥, ... slower than =, ≠</p>
 - Combining branch involves more work per instruction, requiring a slower clock
 - All instructions penalized!
- beq and bne are the common cases
- This is a good design compromise



Assembler Pseudoinstructions

- Most assembly instructions and machine instructions have one-to-one correspondence
- Pseudoinstructions: not a real implementation, assembler's imagination

```
move $t0, $t1 \rightarrow add $t0, $t1, $zero blt $t0, $t1, L \rightarrow slt $at, $t0, $t1 bne $at, $zero, L
```

\$at (register 1): assembler temporary



Benchmark Programs

- Measure MIPS instruction executions in benchmark programs
 - Consider making the common case fast
 - Consider compromises

Instruction class	MIPS examples	SPEC CPU2006 INT	SPEC CPU2006 FP
Arithmetic	add, sub, addi	16%	48%
Data transfer	lw, sw, lb, lbu, lh, lhu, sb, lui	35%	36%
Logical	and, or, nor, andi, ori, sll, srl	12%	4%
Cond. Branch	beq, bne, slt, slti, sltiu	34%	8%
Jump	j, jr, jal	2%	0%