

A

A

B


B

C

C

D

D



Sheet: /LS/
File: LS4.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 8.0.9

Rev:
Id: 3/6

A

A

B

B


C

C

D

D

Remove R20–R22, R26–R28, and install Q7–Q12 for use with dumb coils



Sheet: /Ignition/
File: IGN6.kicad_sch





Title:

Size: A4 | Date:
KiCad E.D.A. 8.0.9

Rev:
Id: 5/6

A

A



Sheet: /Injector/
File: INJ6.kicad_sch

Title:

Size: A4 | Date:

KiCad E.D.A. 8.0.9

Rev:
Id: 6/6

A

B

C


D

A

B

C

D



Sheet: /LS HOT/
File: LS_HOT.kicad_sch

Title:

Size: A4 Date:
KiCad E.D.A. 8.0.9

Rev:
Id: 8/6

1 2 3 4 5 6

A

A

B


B

C

C

D

D



Sheet: /EGT/
File: egt.kicad_sch

Title:

Size: A4 | Date:
KiCad E.D.A. 8.0.9

Rev:
Id: 9/6

1 2 3 4 5 6