

LeScratch User Manual

V0.1.0 2015-03-24

Revision History

Revision	Data	Author	Description	
0.1.0	2015-03-24	Alessia	Initial version	



Table of Contents


目录

1.	Installation	
	1.1 Pre-requisites	3
	1.2 Run	4
2.	Scratch Commands	4
	2.1 GPIOs	
	2.1.1 Introduction	
	2.1.2 Example 1 – GPIO Board	5
	2.2 I2C	
	2.2.1 Introduction	6
	2.2.2 Example 1 – USB Hub	
	2.3 SPI	
	2.3.1 Introduction	8
	2.3.2 Example 1 – LNdigital	8
	2.4 LN Digital	9
	2.4 LN Digital	9
	2.4.2 Example 1 – LNIO	

1. Installation

1.1 Pre-requisites

The Scratch Handler Program: LeScratch is implemented in Python for hardware IO and extensions. It provides the functions to communicate with other boards. Links@GitHub.https://github.com/LeMaker/LeScratch/



Enable the SPI module

The extension boards communicate with the Banana Pi/Pro through the interfaces. The I2C module is included in the latest Banana Pi/Pro distributions and is enabled by default. But the SPI driver should be enabled manually::

\$ sudo modprobe spi-sun7i

And you can permanently enable it by commenting out the ``blacklist spi-sun7i`` line in ``/etc/modprobe.d/bpi-blacklist.conf``.

\$ sudo nano /etc/modprobe.d/bpi-blacklist.conf

Then enable spi modules by adding ``spi-sun7i`` and ``spidev`` to ``/etc/modules``

\$ sudo nano /etc/modules

Enable the MESH mode for Scratch

Please refer to http://wiki.scratch.mit.edu/wiki/Mesh => 1.3 Mesh by Modification of Scratch for details. Reboot after setting up the above steps.

1.2 Run

The file LeScratch.py can be run independently by either of the following: and it is suggested to start the Mesh mode Scratch first, and then run the python script, such that the connections will be built once the script runs.

\$ sudo python LeScratch.py

or

\$ sudo python3 LeScratch.py

2. Scratch Commands

2.1 GPIOs

2.1.1 Introduction

In the first place, remember to declare which GPIOs are going to be used by broadcast g[num]in and g[num]out, "in" means this GPIO will be the input and "out" means this GPIO will be an output. Then the declared GPIOs can be set to 1 or 0 easily:

Set the GPIO to High/1: g[num]on Set the GPIO to Low /0: g[num]off

Usages of the General Purpose INPUT OUTPUT Controls:

Command Format:	g[num]in	g[num]out	g[num]on	g[num]off
	Input	Output	on/high	off/low


Number out of the List [4, 5, 6, 12, 13, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27]

2.1.2 Example 1 – GPIO Board



Purchase link: http://www.lenovator.com/

The GPIO board can be used to indicate the status of all the 40 pins on Banana Pi/Pro. The switches are related to some GPIO that can be used as input detection.



```
When keyboard Space is pressed
when space key pressed
                                          Declare GPIO 17 as input
broadcast g17in▼
                                          Declare GPIO 4 as output
broadcast g4out▼
                                          While true
forever
                                          Update step
 broadcast update▼
                                          Check
        GPIO-17▼ sensor value = 0
                                          if GPIO 17 = 0
  broadcast g4on▼
                                          Set GPIO 4 to on/high
   wait 1 secs
                                          Wait for 1 second
                                          Set GPIO 4 off/low
   broadcast g4off▼
                                          Wait for 1 second
   wait 1 secs
                                          {Forever loop}
```

2.2 I2C

2.2.1 Introduction

I2C has various address, once you attach an extension board to banana pro/pi, open the terminal and use i2c-tools to detect its address:

```
$ sudo i2cdetect -y 2
```

To specify the address, use the following formats:

```
Command "i2"+ "address 0x(20-27)" + "a" + "bit (0 to 7)" for Port A Command "i2"+ "address 0x(20-27)" + "b" + "bit (0 to 7)" for Port B Command "bit"+ "address 0x(20-27)" + "a" + "bit (7 to 0)" for Port A Command "bit"+ "address 0x(20-27)" + "b" + "bit (7 to 0)" for Port B
```

Examples:

```
i221a1 => i2c address 0x21 Port A bit 1 ON
i222b4 => i2c address 0x22 Port B bit 4 ON
bit22b01010101 => address 0x22 port B from bit 7 to 0, output => 0b01010101
bit21a01010101 => address 0x21 port A from bit 7 to 0, output => 0b01010101
bit21aon => address 0x21 Port A all ON, 0b111111111
bit21boff => address 0x21 Port B all OFF/clear, 0b00000000
bit22aoff => address 0x22 Port A all OFF/clear
```

2.2.2 Example 1 – USB Hub

The USB Hub extension board has (4 Port USB Hub & 23017 x2 32GPIO) use I2C communication with banana pro/pi such that Scratch can control the extended functions.



Purchase link: http://www.lenovator.com/




When keyboard a is pressed (address 0x24, 0x26) Clear port A, B

While true Set address 0x24 port A to 0b10010111 Set address 0x24 port B to 0b01101000 {Forever loop}

When keyboard b is pressed (address 0x24, 0x26) Clear port A, B

While true
Set address 0x24 port A bit4 and bit7 to 1,
wait for 1 second
Set address 0x24 port B to bit and bit6 to 1
{Forever loop}

When up arrow is pressed (address 0x24, 0x26) Clear port A, B



2.3 SPI

2.3.1 Introduction


LN Digital has one 16 bits mcp23s17 that communicates with banana pro using SPI. Mcp23s17 has 8 various addresses that allow extending 8 boards at the same time.


```
Command "sp"+ "address (0-7)" + "a" + "bit (0 to 7)" for Port A
Command "sp"+ "address (0-7)" + "b" + "bit (0 to 7)" for Port B
Command "bits"+ "address (0-7)" + "a" + "bit (7 to 0)" for Port A
Command "bits"+ "address (0-7)" + "b" + "bit (7 to 0)" for Port B

Examples: (address 0-7 = 0x40-4E)
sp0a1 => spi address 0x40 Port A bit 1 ON
sp1b4 => spi address 0x42 Port B bit 4 ON
bits2b01010101 => address 0x44 port B from bit 7 to 0, output => 01010101
bits3a01010101 => address 0x46 port A from bit 7 to 0, output => 01010101
bits4aon => address 0x48 Port A all ON, 0b11111111
bits5boff => address 0x4B Port A all OFF/clear, 0b000000000
bits6aoff => address 0x4B Port A all OFF/clear
```

2.3.2 Example 1 – LNdigital

LNdigital can use general SPI format commands to control or use LNIO commands as it will be explained in the next part.





2.4 LN Digital

2.4.1 Introduction

LN Digital has one 16 bits mcp23s17 that can be configured as 8 bits port A and port B or 16 bits. Each port (A/B) can be configured as either input or output. By default it is configured as port A – output (1 to 8), port B – input (1 to 8).

LNDI[num]in LNDI[num]out LNDI[num]on LNDI[num]off Number (1 to 8)

Set the output to High/1: LNDI [num]on Set the output to Low /0: LNDI [num]off

2.4.2 Example 1 – LNIO

The extension board LN Digital use SPI communication with banana pro / pi such that Scratch can access the following:

- 8 Open-Collector Outputs
- **8 LED Indicators**
- 8 Digital Inputs
- 4 Tactile Switches (The interrupt event is set to listen on the 4 inputs switch.)
- 2 Changeover Relays (Port A output bit1 relay 1, Port A output bit2 relay 2.)



Purchase link: http://www.lenovator.com/LN-Digital%28PCBA%29

