M5Stack Unit AC Measure I2C Protocol													V1 (FW Version) 2023/3/24						
REG MAP (Addr:0x42)			0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F	note
	Voltage(V)	0x00 R	thousand's	hundred's	ten's digit	unit's digit		tenths	hundredth										
String	Current(A)	0x10	digit thousand's	digit hundred's	ten's digit	unit's digit		tenths	hundredth										
	Active Power(W)	R 0x20	digit thousand's	digit hundred's	ten's digit			tenths	s hundredth										
	Apparent	R 0x30	digit thousand's	digit hundred's					s hundredth										
	Power(VA)	R	digit	digit	ten's digit	unit's digit		tenths	S										
	Power Factor	0x40 R	unit's digit		tenths	hundredth s													
	kW.h	0x50 R	ten millions	millions	hundred thousand's digit	ten thousand's digit	thousand's digit	hundred's digit	ten's digit	unit's digit		tenths	hundredth s						
	Voltage(V)	0x60 R	voltage-L	voltage-H															Voltage: Voltage = (voltage-L + voltage- H * 256) / 100 [1]
	Current(A)	0x70 R	current-L	current-H															Current: Current = (Current-L + Current- H * 256) / 100
	Active Power(W)	0x80 R	active power- byte0	active power- byte1	active power byte2	active power byte3													Active Power: ActivePower = (ActivePower-L + ActivePower-H * 256) / 100
Value	Apparent Power(VA)	0x90 R	apparent power- byte0	apparent power- byte1	apparent power- byte2	apparent power- byte3													Apparent Power: ApparentPower = (Apparent Power-L + ApparentPower-H * 256) / 100
	Power Factor	0xA0 R	power factor																Power Factor: power factor / 100
	kW.h	0xB0 R/W	kW.h- byte0	kW.h- byte1	kW.h- byte2	kW.h- byte3													kW.h: kW.h = (kW.h-byte0 + kW.h- byte1 * 256 + kW.h-byte2 * 65536 + kW.h-byte3 * 16777216) / 100
	Voltage Coefficient	0xC0 R/W	voltage coefficient																Voltage Coefficient: voltage coefficient / 100
-	Current Coefficient	0xD0 R/W	current coefficient																Current Coefficient: current coefficient / 100
	Save Coefficient	0xE0 W	save																Save: set a value > 1, will save voltage and current coefficient
	Data Ready	0xF0 R													Data Ready				Data Ready: Data Ready=1, data ready; Data Ready = 0, data not ready
	Firmware Version	0xF0 R															Version		Version: firmware version number
Ī	I2C Address	0xF0 R/W																Address	Address: I2C Address
[1] For exa	mple, the actual v		100.55V, aı	nd the obtai	ned data is	100.55*100=	10055, Ten	nperature-L	= 0x47, Ter	mperature-H	= 0x27								