	M5Stack Unit QRCode I2C Protocol															V1 (FW Version) 2023/3/24		
REG MAP (Addr:0x21)		0	1	2	3	4	5	6	7	8	9	Α	В	С	D	E	F	note
QRCode Trigger	0x0000 W/R	Trigger																Trigger: 0: Stop continuously decode 1: Start continuously decode
QRCode Data Status	0x0010 R	Status																Status(reset after read qrcode data): 0: not ready 1: data good 2: need to read again
QRCode Length	0x0020 R	Length-L	Length-H															QRCode Length: Length = (Length-L + Length-H * 256)
Jump Bootloader	0x00F0 W														Jump			Jump Bootloader: Write 1 jump to bootloader
Firmware Version	0x00F0 R															Version		Version: firmware version number
I2C Address	0x00F0 W/R																Address	Address: I2C Address
QRCode Data	0x1000 R								0x1000	-0x11FF								