2 ARM Cortex-M4 Instructions and Addressing Modes

Learning Objectives

After completing this experiment, you will be able to:

- Classify ARM Cortex-M4 instructions into data-processing, load/store, and branch categories.
- Perform arithmetic, logical, and shift/rotate operations using data-processing instructions (including Operand2 with the barrel shifter).
- Move data between registers and memory using load/store instructions with immediate, register-offset, and pre-/post-indexed addressing modes.
- Declare and initialize data objects (arrays, strings, buffers) with assembler directives, and use pointers to access and modify them.
- Trace how instructions affect registers and xPSR flags using the **Keil uVision5** debugger (breakpoints, single-step, register/memory views).

Experiment Overview

This experiment develops fluency with the ARM Cortex-M4 instruction set for data manipulation and memory access. You will practice using arithmetic, logical, and shift/rotate instructions, and learn how data moves between registers and memory through load/store instructions and their addressing modes. You will also define data with assembler directives and use pointers to read and update memory.

In this experiment, you will:

- Write and run short assembly routines that use data-processing instructions to transform register values.
- Apply immediate, register-offset, and pre-/post-indexed addressing modes to load from and store to memory.
- Define arrays, strings, and buffers with directives, and use pointers to traverse and modify them.
- Observe instruction effects on registers and flags with the Keil uVision5 debugger to verify correctness.

By the end of this lab, you will be able to implement, assemble, and debug Cortex-M4 programs that perform register-level computation and structured memory access—providing the foundation for flow control and procedure calls in later experiments.

Contents

2 A	RM Cor	rtex-M4 Instructions and Addressing Modes
1	Theo	pretical Background
	1.1	Data Processing Instructions
		1.1.1 Arithmetic Instructions
		1.1.2 Logical and Move Instructions
		1.1.3 Shift and Rotate Instructions
		1.1.4 Barrel Shifter
	1.2	Load and Store Instructions
		1.2.1 Loading Addresses and Values: LDR, LDR =, and ADR
		1.2.2 Understanding Pointer Declarations
		1.2.3 Declaring Arrays and Strings
	1.3	Addressing Modes
2	Proc	edure
	2.1	Examples
		2.1.1 Example 1 — Data Processing Instructions
		2.1.2 Example 2 — Load/Store with Different Addressing Modes 1
	2.2	Tasks
		2.2.1 Task 1 — Bitwise Register Manipulation
		2.2.2 Task 2 — Addressing Modes with an Array

1 Theoretical Background

As mentioned in Experiment 1, assembly instructions are split into three main categories: data processing, load/store, and branch instructions. This experiment focuses on data processing instructions, load/store instructions and their addressing modes. branch instructions and flow control will be covered in the next experiment.

1.1 Data Processing Instructions

Data processing instructions perform arithmetic and logical operations on data stored in registers. They can also manipulate the condition flags in the xPSR based on the results of the operations. Common data processing instructions take the following form:

{LABEL} OPCODE{<cond>}{S} Rd, Rn, Operand2

where:

- LABEL: optional label for branching.
- OPCODE: the operation to be performed (e.g., ADD, SUB, AND, ORR).
- **<cond>**: optional condition code that predicates execution.
- S: optional suffix indicating whether to update the condition flags.
- Rd: destination register where the result is stored.
- Rn: first operand register.
- Operand2: second operand, which can be an immediate value limited to 8 bits, a register, or a barrel shifter operation (see Section 1.1.4).

1.1.1 Arithmetic Instructions

Arithmetic instructions perform basic mathematical operations. Some common arithmetic instructions include addition, subtraction, multiplication, and their variants. The following table summarizes some of the most commonly used arithmetic instructions in the ARM Cortex-M4 architecture.

Table 2.1: Common ARM Cortex-M4 Arithmetic Instructions

Instr.	Syntax	Operation	Description
ADD	ADD{S} Rd, Rn, Operand2	$Rd \leftarrow Rn + Operand2$	Operand2 may be a register, an immediate, or a shifted register.
ADC	ADC{S} Rd, Rn, Operand2	$Rd \leftarrow Rn + Operand2 + C$	Adds carry-in C .
SUB	SUB{S} Rd, Rn, Operand2	$Rd \leftarrow Rn - Operand2$	Standard subtraction.
SBC	SBC{S} Rd, Rn, Operand2	$Rd \leftarrow Rn - Operand2 - \overline{C}$	Subtract with carry. If carry flag is clear, result is reduced by one. Used for multiword arithmetic.
RSB	RSB{S} Rd, Rn, Operand2	$Rd \leftarrow Operand2 - Rn$	Reverse subtract.
MUL	MUL{S} Rd, Rn, Rm	$Rd \leftarrow (Rn \times Rm)_{[31:0]}$	$32 \times 32 \rightarrow \text{low } 32 \text{ bits.}$
MLA	MLA Rd, Rn, Rm, Ra	$Rd \leftarrow (Rn \times Rm) + Ra$	Multiply-accumulate.
MLS	MLS Rd, Rn, Rm, Ra	$Rd \leftarrow Ra - (Rn \times Rm)$	Multiply-subtract.
UMULL	UMULL RdLo, RdHi, Rn, Rm	$\{RdHi, RdLo\} \leftarrow Rn \times Rm$	Unsigned $32 \times 32 \rightarrow 64$ -bit product.
SMULL	SMULL RdLo, RdHi, Rn, Rm	$\{RdHi, RdLo\} \leftarrow Rn \times Rm$	Signed $32 \times 32 \rightarrow 64$ -bit product.

Note: C denotes the carry flag in xPSR. Operand2 may be an immediate or a shifted register depending on the encoding.

1.1.2 Logical and Move Instructions

Logical instructions perform bitwise operations on data, while move instructions transfer data between registers or load immediate values. The following table summarizes some of the most commonly used logical and move instructions in the ARM Cortex-M4 architecture.

Table 2.2: Logical and Move Instructions

Instr.	Syntax	Operation	Description
AND	AND Rd, Rn, Operand2	$Rd \leftarrow Rn \& Operand2$	Bitwise AND.
ORR	ORR Rd, Rn, Operand2	$Rd \leftarrow Rn Operand 2$	Bitwise OR.
EOR	EOR Rd, Rn, Operand2	$Rd \leftarrow Rn \oplus Operand2$	Bitwise XOR.
BIC	BIC Rd, Rn, Operand2	$Rd \leftarrow Rn \& \neg Operand 2$	Bit clear.
MVN	MVN Rd, Operand2	$Rd \leftarrow \neg Operand2$	Bitwise NOT of operand.
MOV	MOV Rd, Operand2	$Rd \leftarrow Operand2$	Register or immediate move.
MOVW	MOVW Rd, #imm16	$Rd[15:0] \leftarrow imm16$	Write low halfword.
MOVT	MOVT Rd, #imm16	$Rd[31{:}16] \leftarrow imm16$	Write high halfword (low preserved).

Note: C denotes the carry flag in xPSR. Operand2 may be an immediate or a shifted register depending on the encoding.

In this experiment, you will work with bitwise logical instructions to manipulate individual bits within registers. Such operations are fundamental in microcontroller programming, where control and status registers often contain multiple configuration fields packed into a single 32-bit word. Understanding how to set, clear, toggle, or test specific bits without altering the rest of the register is essential for safely modifying hardware configurations and controlling peripherals.

Set and Clear Bits To set, clear, or toggle specific bits in a register, you can use the following logical instructions:

- ORR Rd, Rn, #mask: Sets bits in Rd where the corresponding bits in mask are 1.
- BIC Rd, Rn, #mask: Clears bits in Rd where the corresponding bits in mask are 1.
- EOR Rd, Rn, #mask: Toggles bits in Rd where the corresponding bits in mask are 1.

BIC is essentially an AND operation with the negated mask, i.e., BIC Rd, Rn, #mask is equivalent to AND Rd, Rn, #~mask.

Check Bits To check whether certain bits are set or cleared, you can use the AND instruction followed by a comparison:

- AND Rd, Rn, #mask: Isolates bits in Rn where the corresponding bits in mask are 1. The result is stored in Rd.
- You can then use CMP Rd, #0 to determine if the result is zero (all masked bits cleared) or non-zero (at least one bit set).
- Alternatively, you can use TST Rn, #mask, which performs the AND operation and updates the condition flags without storing the result.

The TST instruction and its interaction with the condition flags will be explored in more detail in the next experiment, where you will learn how conditional execution and branching depend on flag states.

1.1.3 Shift and Rotate Instructions

Table 2.3: Shift and Rotate Instructions

Instr.	Syntax	Operation	Description
LSL	LSL Rd, Rm, #sh Rs	$Rd \leftarrow Rm \ll sh$	Logical left shift by immediate or by register.
LSR	LSR Rd, Rm, #sh Rs	$Rd \leftarrow Rm \gg sh$	Logical right shift (zero fill).
ASR	ASR Rd, Rm, #sh Rs	$Rd \leftarrow Rm \gg sh$	Arithmetic right shift (sign fill).
ROR	ROR Rd, Rm, #sh Rs	$Rd \leftarrow \text{ROR}(Rm, sh)$	Rotate right by immediate or by register.
RRX	RRX Rd, Rm	$Rd \leftarrow \mathrm{ROR}_C(Rm, 1)$	Rotate right 1 bit through carry (uses C as incoming bit 31, outgoing bit $0 \to C$).

Note: Shift amount can be an immediate #sh (0-31) or a register Rs (low 8 bits used). For immediates: LSL #0 = no shift; LSR #0 is treated as shift by 32; ASR #0 is treated as shift by 32; ROR #0 means RRX.

Not all shift/rotate instructions are explicitly present in the ARMv7-M ISA. For example, there is no ROL (rotate left) or ASL (arithmetic shift left) instruction, as these operations can be achieved using existing shift instructions: ROL can be implemented using ROR with a complementary shift amount, and ASL is equivalent to LSL.

1.1.4 Barrel Shifter

The barrel shifter is a hardware feature that allows for efficient shifting and rotating of register values as part of data processing instructions. It can perform operations such as logical shifts (left or right), arithmetic shifts, and rotations on the second operand (Operand2) before it is used in the instruction without wasting extra instructions or cycles.

Examples of barrel shifter usage:

```
ADD RO, R2, R1, LSL #2 ; RO = R2 + (R1 << 2) using barrel shifter SUB R3, R4, R5, LSR #1 ; R3 = R4 - (R5 >> 1) using barrel shifter ORR R6, R7, R8, ROR #3 ; R6 = R7 / (R8 \text{ rotated right by } 3)
```

Listing 2.1: Barrel shifter examples

1.2 Load and Store Instructions

Since the ARM Cortex-M4 follows the RISC design philosophy, it uses a load/store architecture. This means that arithmetic and logical instructions operate only on registers. Any data in memory must first be loaded into a register before processing, and results must be stored back to memory if they need to be preserved.

Table 2.4: Load and Store Instructions (Summary)

Instr.	Syntax Example	Description
LDR / STR	LDR/STR Rt, [Rn, #off]	Load/store a 32-bit word.
LDRB / STRB	LDRB/STRB Rt, [Rn, #off]	Load/store an 8-bit byte.
LDRH / STRH	LDRH/STRH Rt, [Rn, #off]	Load/store a 16-bit halfword.
LDRSB / LDRSH	LDRSB/LDRSH Rt, [Rn, #off]	Load signed byte/halfword and sign-extend to 32 bits.
LDRD / STRD	LDRD/STRD Rt, Rt2, [Rn, #off]	${\it Load/store}$ a 64-bit doubleword (two registers).

```
Reset_Handler
                RO, =XVAL
                                   ; RO = &XVAL (address of XVAL)
        LDR
                R1, [R0]
        LDR
                                   ; R1 = 0x12345678 (load word from memory)
                R5, XVAL
                                   ; R5 = PC-relative address of XVAL (if in range)
        ADR
                R2, [R0]
                                   ; R2 = 0x78 (lowest byte of XVAL)
        LDRB
                R3, [R0]
        LDRH
                                   ; R3 = 0x5678 (lowest halfword of XVAL)
        MOV
                R4, #0xFF
                RO, YPTR
                                   ; RO = contents of YPTR = &YVAL
        LDR
                R4, [R0]
        STRB
                                   ; store OxFF into YVAL (low byte only)
STOP
                STOP
        B
        AREA
                MYDATA, DATA, READONLY
XVAL
        DCD
                0x12345678
                                   ; word in memory
YPTR
        DCD
                YVAL
                                   ; contains the address of YVAL
        AREA
                MYDATA2, DATA, READWRITE
YVAL
        DCD
        END
```

Listing 2.2: Examples of Load and Store Instructions

1.2.1 Loading Addresses and Values: LDR, LDR =, and ADR

In ARM assembly, it is important to distinguish between loading a *value* from memory and loading the *address* of a label. Although these instructions look similar, their behavior and purpose differ depending on how the assembler interprets them.

• LDR Rn, label Loads the 32-bit *value* stored at the memory address identified by label into register Rn. The CPU performs a direct memory read:

$$\mathtt{Rn} \leftarrow [\mathtt{label}]$$

Example: LDR RO, XVAL loads the contents of XVAL (e.g., 0x12345678) into RO.

• LDR Rn, =label Loads the *address* of label into Rn, rather than the data stored at that address. The assembler generates this by either constructing the address using MOVW/MOVT instructions or placing it in a nearby *literal pool* for PC-relative loading.¹

$$\mathtt{Rn} \leftarrow \mathtt{\&label}$$

Example: LDR RO, =XVAL places the address of XVAL in RO.

• ADR Rn, label Loads the *address* of label into Rn by computing it relative to the current program counter. This method requires no literal pool or memory access but only works for nearby addresses (about ±4 KB in Thumb mode):

$$\mathtt{Rn} \leftarrow \mathtt{PC} + \mathtt{offset(label)}$$

¹For more details, see ARM Developer Documentation, "Literal pools and LDR =const". https://developer.arm.com/documentation/dui0473/m/dom1359731147760

1.2.2 Understanding Pointer Declarations

The directive YPTR DCD YVAL reserves a 32-bit word at the label YPTR and initializes it with the address of YVAL. In other words, YPTR acts as a *pointer variable* that holds the address of another variable (YVAL). Executing LDR Rn, YPTR loads the 32-bit contents stored at YPTR—that is, the address of YVAL—into Rn, making Rn a pointer to YVAL.

Address	Label	Contents
0x2000	XVAL	0x12345678
0x2004	YPTR	0x2008 (address of YVAL)
0x2008	YVAL	0x00000000

1.2.3 Declaring Arrays and Strings

Data in assembly is defined using assembler directives that reserve and optionally initialize memory. Common directives include DCD, DCW, and DCB, which define words, halfwords, and bytes, respectively. These are typically placed within a DATA area to create arrays, lookup tables, buffers, or strings.

- DCD Define Constant Word (32 bits per element)
- DCW Define Constant Halfword (16 bits per element)
- DCB Define Constant Byte (8 bits per element)
- SPACE Reserve uninitialized memory (in bytes)
- FILL Fill memory with a specified value for a given length

	AREA	MYDATA, DATA, READON	NLY
NUMBERS	DCD	10, 20, 30, 40	; array of 32-bit integers
BYTES	DCB	1, 2, 3, 4	; array of bytes
TEXT	DCB	"HELLO",O	; null-terminated ASCII string
BUFFER	SPACE	64	; reserve 64 bytes (uninitialized)
PATTERN	FILL	0xFF, 64	; fill 64 bytes with OxFF

Listing 2.3: Declaring arrays and strings in memory

Each label (e.g., NUMBERS, TEXT) marks the starting address of a data object in memory. You can load these addresses into registers using LDR RO, =NUMBERS or ADR RO, TEXT, then access individual elements through the appropriate addressing modes.

Note: Strings are stored as consecutive ASCII characters in memory. A terminating zero (0x00) is typically appended to indicate the end of the string, similar to C-style strings.

1.3 Addressing Modes

Addressing modes define how the effective address or operand value is obtained by an instruction. The ARM Cortex-M4 supports several common addressing modes, summarized below:

Table 2.5: General Addressing Modes in ARM Cortex-M4

Mode	Syntax Example	Description
Immediate	MOV RO, #10	Operand is a constant value encoded in the instruction.
Register Direct	MOV RO, R1	Operand is taken directly from a register.
Register Indirect	LDR RO, [R1]	Register holds the address of the operand in memory.
Register Offset	LDR RO, [R1, R2]	Effective address $=$ base register $+$ offset register.
Immediate Offset	LDR RO, [R1, #4]	Effective address $=$ base register $+$ constant offset.
Pre-indexed	LDR RO, [R1, #4]!	Base updated first, then memory access.
Post-indexed	LDR RO, [R1], #4	Memory access first, then base register updated.

Listing 2.4: Examples of Offset, Pre-indexed, and Post-indexed Addressing Modes

2 Procedure

2.1 Examples

2.1.1 Example 1 — Data Processing Instructions

This example demonstrates various arithmetic and bitwise operations on registers.

```
AREA RESET, CODE, READONLY
       EXPORT __Vectors
__Vectors
       DCD 0x20001000
       DCD Reset_Handler
        ALIGN
       AREA MYCODE, CODE, READONLY
       ENTRY
       EXPORT Reset_Handler
Reset Handler
        ; Load values from memory into registers
               R1, NUM1 ; R1 = 50
       LDR
               R2, NUM2
       LDR
                                   ; R2 = 12
        ; Arithmetic operations
               R3, R1, R2
                                  ; R3 = 50 + 12 = 62
        ADD
       SUB
               R3, R3, #4
                                  ; R3 = 62 - 4 = 58
       MUL
               R4. R3. R2
                                   ; R4 = 58 * 12 = 696
        ; Logical operations
               R5, R4, #0xFF
                                  ; R5 = 696 \& 0xFF = 0xB8 (184)
               R5, R4, #0xFF
R5, R5, #0x01
R5, R5, #0x08
       ORR
                                  ; R5 = 0xB8 / 0x01 = 0xB9 (185)
       BIC
                                 ; R5 = 0xB9 \& -0x08 = 0xB1 (177)
                                  ; R5 = 0xB1 ^0 0x02 = 0xB3 (179)
       EOR
               R5, R5, #0x02
        ; Shift and Barrel Shifter
               R8, R4, #4
       LSL
                                  ; logical left shift by 4 bits
               R9, R4, #8 ; logical right shift by 8 bits
R5, R5, R5, LSL #1 ; R5 = R5 + (R5 << 1) = 3 * R5
       LSR
       ADD
        ; Store result in memory using a pointer
             R6, RP ; R6 = address \ of \ RESULT
       LDR
       STR
               R5, [R6]
                                   ; RESULT = R5
        ; Read back for verification
               R7, [R6]
                           ; R7 = RESULT
       LDR
STOP
               STOP
       AREA CONSTANTS, DATA, READONLY
       DCD 50 ; First integer
NUM1
       DCD
NUM2
               12
                               ; Second integer
               RESULT
                               ; Pointer to RESULT variable
    AREA MYDATA, DATA, READWRITE
RESULT DCD
               0
                       ; Will hold the final computed value
    END
```

Listing 2.5: Arithmetic and bitwise operations example

2.1.2 Example 2 — Load/Store with Different Addressing Modes

This example demonstrates load and store instructions using various addressing modes.

```
RESET, CODE, READONLY
       AREA
      EXPORT __Vectors
__Vectors
                           ; Initial SP (example)
             0x20001000
      DCD
      DCD
             Reset_Handler
                               ; Reset vector
             MYCODE, CODE, READONLY
       AREA
      ENTRY
      EXPORT Reset_Handler
Reset_Handler
       ; Base address of the array
           RO, =ARRAY ; RO = \&ARRAY
      LDR
       ; 1) Immediate Offset: EA = RO + #8 (third element)
             R1, [R0, #8] ; R1 = ARRAY[2] = ? (expect 30)
      LDR
      LDR
             R7, =OUT
                          ; OUT[O] = R1
            R1, [R7, #0]
      STR.
       ; -----
       ; 2) Pre-indexed: R2 = [R2 + #4], then R2 = R2 + #4
       ; Use a scratch pointer so RO remains the base.
       : -----
             R2, R0
                                ; R2 = &ARRAY
      MOV
             R3, [R2, #4]!
                                ; R2 -> &ARRAY[1], R3 = ARRAY[1] = ? (expect
      LDR
   20)
            R3, [R7, #4]
      STR.
                                ; OUT[1] = R3
       ; After this, R2 now points at ARRAY[1].
       ; 3) Post-indexed: R4 = [R4], then R4 = R4 + #12
          Load first element, then advance pointer to the 4th.
       ; -----
            R4, R0
                                 ; R4 = &ARRAY
      MOV
                                ; R5 = ARRAY[0] = ? (expect 10), R4 ->
      LDR
             R5, [R4], #12
   &ARRAY[3]
      STR
            R5, [R7, #8]
                                ; OUT[2] = R5
       ; 4) Register Offset: EA = RO + R6
       ; Offset register holds byte offset (multiple of 4 for words).
                            ; byte offset to ARRAY[3]
      VOM
             R6, #12
      LDR.
             R8, [R0, R6]
                                ; R8 = ARRAY[3] = ? (expect 40)
             R8, [R0, R6] ; KS = AKKAYL
R8, [R7, #12] ; OUT[3] = R8
      STR
       ; read second element via register offset
            R6, #4
                               ; byte offset to ARRAY[1]
      VOM
            R9, [R0, R6]
                                 ; R9 = ARRAY[1] = ? (expect 20)
      LDR
STOP
             STOP
             CONSTS, DATA, READONLY
      AREA
      DCD 10, 20, 30, 40 ; four words at consecutive addresses
ARRAY
      AREA MYDATA, DATA, READWRITE
OUT
      DCD 0, 0, 0, 0
                         ; capture buffer for observed loads. Could by
   replaced by space 16
      END
```

Listing 2.6: Load/store with different addressing modes example

2.2 Tasks

2.2.1 Task 1 — Bitwise Register Manipulation

Start with R0 = 0x12345678. Perform the following operations and observe the results in the debugger (verify in hex and binary):

- Clear bits 4–7 (second hex nibble).
- Set bits 8–11 (force that nibble to F).
- Toggle bits 28–31 (highest nibble).

Hint: Use BIC, ORR, and EOR with appropriate masks.

2.2.2 Task 2 — Addressing Modes with an Array

Given:

```
ARRAY DCD 0x11, 0x22, 0x33, 0x44
OUT SPACE 16
```

Load each element using a different addressing mode, then store to OUT:

- \bullet 0x11 via immediate offset
- 0x22 via pre-indexed
- 0x33 via post-indexed
- 0x44 via register offset

Hint: Put ARRAY's base in R1 (e.g., LDR R1, =ARRAY). Verify OUT in memory after execution.