



BIRZEIT UNIVERSITY

Department of Electrical & Computer Engineering
ENCS4110 – Computer Design Laboratory

Experiment 02

Data Processing and Memory Operations

Date: November 2025

2 Data Processing and Memory Operations

Learning Objectives

After completing this experiment, you will be able to:

- Perform arithmetic, logical, and shift/rotate operations using data-processing instructions (including `Operand2` with the barrel shifter).
- Move data between registers and memory using load/store instructions with immediate, register-offset, and pre-/post-indexed addressing modes.
- Declare and initialize data objects (arrays, strings, buffers) with assembler directives, and use pointers to access and modify them.
- Trace how instructions affect registers and xPSR flags using the **Keil uVision5** debugger (breakpoints, single-step, register/memory views).

Experiment Overview

This experiment develops fluency with the ARM Cortex-M4 instruction set for data manipulation and memory access. You will practice arithmetic, logical, and shift/rotate instructions, apply various addressing modes for load/store operations, and define data structures with assembler directives. By the end of this lab, you will be able to write assembly routines that perform register-level computation and structured memory access, providing the foundation for flow control and procedure calls in later experiments.

Contents

1	Theoretical Background	4
1.1	Data Processing Instructions	4
1.1.1	Arithmetic Instructions	4
1.1.2	Logical and Move Instructions	5
1.1.3	Shift and Rotate Instructions	6
1.1.4	Barrel Shifter	6
1.2	Load and Store Instructions	6
1.2.1	Declaring Data in Memory	7
1.2.2	Understanding Pointer Declarations	8
1.2.3	Loading Addresses and Values: LDR, LDR =, and ADR	8
1.3	Addressing Modes	8
2	Procedure	10
2.1	Examples	10
2.1.1	Example 1 — Data Processing Instructions	10
2.1.2	Example 2 — Load/Store with Different Addressing Modes	11
2.2	Tasks	12
2.2.1	Task 1 — Bitwise Register Manipulation	12
2.2.2	Task 2 — Addressing Modes with an Array	12

1 Theoretical Background

As mentioned in Experiment 1, assembly instructions are split into three main categories: data processing, load/store, and branch instructions. This experiment focuses on data processing instructions, load/store instructions and their addressing modes. Branch instructions and flow control will be covered in the next experiment.

1.1 Data Processing Instructions

Data processing instructions perform arithmetic and logical operations on data stored in registers. They can also manipulate the condition flags in the xPSR based on the results of the operations. Common data processing instructions take the following form:

`{LABEL} OPCODE{<cond>}{S} Rd, Rn, Operand2`

where:

- **LABEL**: optional label for branching.
- **OPCODE**: the operation to be performed (e.g., ADD, SUB, AND, ORR).
- **<cond>**: optional condition code that predicates execution.
- **S**: optional suffix indicating whether to update the condition flags.
- **Rd**: destination register where the result is stored.
- **Rn**: first operand register.
- **Operand2**: second operand, which can be an immediate value limited to 8 bits, a register, or a barrel shifter operation (see Section 1.1.4).

1.1.1 Arithmetic Instructions

Arithmetic instructions perform basic mathematical operations. Some common arithmetic instructions include addition, subtraction, multiplication, and their variants. The following table summarizes some of the most commonly used arithmetic instructions in the ARM Cortex-M4 architecture.

Table 2.1: Common ARM Cortex-M4 Arithmetic Instructions

Instr.	Syntax	Operation	Description
ADD	ADD{S} Rd, Rn, Operand2	$Rd \leftarrow Rn + Operand2$	<i>Operand2</i> may be a register, an immediate, or a shifted register.
ADC	ADC{S} Rd, Rn, Operand2	$Rd \leftarrow Rn + Operand2 + C$	Adds carry-in <i>C</i> .
SUB	SUB{S} Rd, Rn, Operand2	$Rd \leftarrow Rn - Operand2$	Standard subtraction.
SBC	SBC{S} Rd, Rn, Operand2	$Rd \leftarrow Rn - Operand2 - \bar{C}$	Subtract with carry. If carry flag is clear, result is reduced by one. Used for multiword arithmetic.
RSB	RSB{S} Rd, Rn, Operand2	$Rd \leftarrow Operand2 - Rn$	Reverse subtract.
MUL	MUL{S} Rd, Rn, Rm	$Rd \leftarrow (Rn \times Rm)_{[31:0]}$	$32 \times 32 \rightarrow$ low 32 bits.
MLA	MLA Rd, Rn, Rm, Ra	$Rd \leftarrow (Rn \times Rm) + Ra$	Multiply-accumulate.
MLS	MLS Rd, Rn, Rm, Ra	$Rd \leftarrow Ra - (Rn \times Rm)$	Multiply-subtract.
UMULL	UMULL RdLo, RdHi, Rn, Rm	$\{RdHi, RdLo\} \leftarrow Rn \times Rm$	Unsigned $32 \times 32 \rightarrow$ 64-bit product.
SMULL	SMULL RdLo, RdHi, Rn, Rm	$\{RdHi, RdLo\} \leftarrow Rn \times Rm$	Signed $32 \times 32 \rightarrow$ 64-bit product.
UDIV	UDIV Rd, Rn, Rm	$Rd \leftarrow Rn \div Rm$	Unsigned division.
SDIV	SDIV Rd, Rn, Rm	$Rd \leftarrow Rn \div Rm$	Signed division.

Note: *C* denotes the carry flag in xPSR. *Operand2* may be an immediate or a shifted register depending on the encoding.

1.1.2 Logical and Move Instructions

Logical instructions perform bitwise operations on data, while move instructions transfer data between registers or load immediate values. The following table summarizes some of the most commonly used logical and move instructions in the ARM Cortex-M4 architecture.

Table 2.2: Logical and Move Instructions

Instr.	Syntax	Operation	Description
AND	AND Rd, Rn, Operand2	$Rd \leftarrow Rn \& Operand2$	Bitwise AND.
ORR	ORR Rd, Rn, Operand2	$Rd \leftarrow Rn Operand2$	Bitwise OR.
EOR	EOR Rd, Rn, Operand2	$Rd \leftarrow Rn \oplus Operand2$	Bitwise XOR.
BIC	BIC Rd, Rn, Operand2	$Rd \leftarrow Rn \& \neg Operand2$	Bit clear.
MVN	MVN Rd, Operand2	$Rd \leftarrow \neg Operand2$	Bitwise NOT of operand.
MOV	MOV Rd, Operand2	$Rd \leftarrow Operand2$	Register or immediate move.
MOVW	MOVW Rd, #imm16	$Rd[15:0] \leftarrow imm16$	Write low halfword.
MOVT	MOVT Rd, #imm16	$Rd[31:16] \leftarrow imm16$	Write high halfword (low preserved).

Note: C denotes the carry flag in xPSR. $Operand2$ may be an immediate or a shifted register depending on the encoding.

In this experiment, you will work with bitwise logical instructions to manipulate individual bits within registers. Such operations are fundamental in microcontroller programming, where control and status registers often contain multiple configuration fields packed into a single 32-bit word. Understanding how to set, clear, toggle, or test specific bits without altering the rest of the register is essential for safely modifying hardware configurations and controlling peripherals.

Set and Clear Bits To set, clear, or toggle specific bits in a register, you can use the following logical instructions:

- ORR Rd, Rn, #mask: Sets bits in Rd where the corresponding bits in mask are 1.
- BIC Rd, Rn, #mask: Clears bits in Rd where the corresponding bits in mask are 1.
- EOR Rd, Rn, #mask: Toggles bits in Rd where the corresponding bits in mask are 1.

BIC is essentially an AND operation with the negated mask, i.e., BIC Rd, Rn, #mask is equivalent to AND Rd, Rn, #~mask.

Check Bits To check whether certain bits are set or cleared, you can use the AND instruction followed by a comparison:

- AND Rd, Rn, #mask: Isolates bits in Rn where the corresponding bits in mask are 1. The result is stored in Rd.
- You can then use CMP Rd, #0 to determine if the result is zero (all masked bits cleared) or non-zero (at least one bit set).
- Alternatively, you can use TST Rn, #mask, which performs the AND operation and updates the condition flags without storing the result.

The TST instruction and its interaction with the condition flags will be explored in more detail in the next experiment, where you will learn how conditional execution and branching depend on flag states.

1.1.3 Shift and Rotate Instructions

Table 2.3: Shift and Rotate Instructions

Instr.	Syntax	Operation	Description
LSL	LSL Rd, Rm, #sh Rs	$Rd \leftarrow Rm \ll sh$	Logical left shift by immediate or by register.
LSR	LSR Rd, Rm, #sh Rs	$Rd \leftarrow Rm \gg sh$	Logical right shift (zero fill).
ASR	ASR Rd, Rm, #sh Rs	$Rd \leftarrow Rm \gg sh$	Arithmetic right shift (sign fill).
ROR	ROR Rd, Rm, #sh Rs	$Rd \leftarrow ROR(Rm, sh)$	Rotate right by immediate or by register.
RRX	RRX Rd, Rm	$Rd \leftarrow ROR_C(Rm, 1)$	Rotate right 1 bit through carry (uses C as incoming bit 31, outgoing bit 0 $\rightarrow C$).

Note: Shift amount can be an immediate #sh (0–31) or a register Rs (low 8 bits used). For immediates: LSL #0 = no shift; LSR #0 is treated as shift by 32; ASR #0 is treated as shift by 32; ROR #0 means RRX.

Not all shift/rotate instructions are explicitly present in the ARMv7-M ISA. For example, there is no ROL (rotate left) or ASL (arithmetic shift left) instruction, as these operations can be achieved using existing shift instructions: ROL can be implemented using ROR with a complementary shift amount, and ASL is equivalent to LSL.

1.1.4 Barrel Shifter

The barrel shifter is a hardware feature that allows for efficient shifting and rotating of register values as part of data processing instructions. It can perform operations such as logical shifts (left or right), arithmetic shifts, and rotations on the second operand (Operand2) before it is used in the instruction without wasting extra instructions or cycles.

Examples of barrel shifter usage:

```

ADD  R0, R2, R1, LSL #2      ; R0 = R2 + (R1 << 2) using barrel shifter
SUB  R3, R4, R5, LSR #1      ; R3 = R4 - (R5 >> 1) using barrel shifter
ORR   R6, R7, R8, ROR #3      ; R6 = R7 / (R8 rotated right by 3)

```

Listing 2.1: Barrel shifter examples

1.2 Load and Store Instructions

Since the ARM Cortex-M4 follows the RISC design philosophy, it uses a load/store architecture. This means that arithmetic and logical instructions operate only on registers. Any data in memory must first be loaded into a register before processing, and results must be stored back to memory if they need to be preserved.

Table 2.4: Load and Store Instructions (Summary)

Instr.	Syntax Example	Description
LDR / STR	LDR/STR Rt, [Rn, #off]	Load/store a 32-bit word.
LDRB / STRB	LDRB/STRB Rt, [Rn, #off]	Load/store an 8-bit byte.
LDRH / STRH	LDRH/STRH Rt, [Rn, #off]	Load/store a 16-bit halfword.
LDRSB / LDRSH	LDRSB/LDRSH Rt, [Rn, #off]	Load signed byte/halfword and sign-extend to 32 bits.
LDRD / STRD	LDRD/STRD Rt, Rt2, [Rn, #off]	Load/store a 64-bit doubleword (two registers).

```

Reset_Handler
    LDR    R0, =XVAL           ; R0 = &XVAL (address of XVAL)
    LDR    R1, [R0]            ; R1 = 0x12345678 (load word from memory)
    ADR    R5, XVAL           ; R5 = PC-relative address of XVAL (if in range)

    LDRB   R2, [R0]            ; R2 = 0x78 (lowest byte of XVAL)
    LDRH   R3, [R0]            ; R3 = 0x5678 (lowest halfword of XVAL)

    MOV    R4, #0xFF
    LDR    R0, YPTR            ; R0 = contents of YPTR = &YVAL
    STRB   R4, [R0]            ; store 0xFF into YVAL (low byte only)

STOP    B      STOP

    AREA   CONSTANTS, DATA, READONLY
XVAL    DCD    0x12345678      ; word in memory
YPTR    DCD    YVAL           ; contains the address of YVAL

    AREA   MYDATA, DATA, READWRITE
YVAL    DCD    0

END

```

Listing 2.2: Examples of Load and Store Instructions

1.2.1 Declaring Data in Memory

Data in assembly is defined using *assembler directives* that reserve and optionally initialize memory. Common directives include DCD, DCW, and DCB, which define words, halfwords, and bytes, respectively. These are typically placed within a DATA area to create arrays, lookup tables, buffers, or strings.

- DCD — Define Constant Word (32 bits per element)
- DCW — Define Constant Halfword (16 bits per element)
- DCB — Define Constant Byte (8 bits per element)
- SPACE — Reserve uninitialized memory (in bytes)
- FILL — Fill memory with a specified value for a given length

	AREA	CONSTANTS, DATA, READONLY	
NUMBERS	DCD	10, 20, 30, 40	; array of 32-bit integers
BYTES	DCB	1, 2, 3, 4	; array of bytes
TEXT	DCB	"HELLO",0	; null-terminated ASCII string
	AREA	MYDATA, DATA, READWRITE	
BUFFER	SPACE	64	; reserve 64 bytes (uninitialized)
PATTERN	FILL	0xFF, 64	; fill 64 bytes with 0xFF

Listing 2.3: Declaring arrays and strings in memory

Each label (e.g., NUMBERS, TEXT) marks the starting address of a data object in memory. You can load these addresses into registers using LDR R0, =NUMBERS or ADR R0, TEXT, then access individual elements through the appropriate addressing modes.

Note: Strings are stored as consecutive ASCII characters in memory. A terminating zero (0x00) is typically appended to indicate the end of the string, similar to C-style strings.

1.2.2 Understanding Pointer Declarations

The directive YPTR DCD YVAL reserves a 32-bit word at the label YPTR and initializes it with the address of YVAL. In other words, YPTR acts as a *pointer variable* that holds the address of another variable (YVAL). Executing LDR Rn, YPTR loads the 32-bit contents stored at YPTR—that is, the address of YVAL—into Rn, making Rn a pointer to YVAL.

Address	Label	Contents
0x2000	XVAL	0x12345678
0x2004	YPTR	0x2008 (address of YVAL)
0x2008	YVAL	0x00000000

1.2.3 Loading Addresses and Values: LDR, LDR =, and ADR

In ARM assembly, it is important to distinguish between loading a *value* from memory and loading the *address* of a label. Although these instructions look similar, their behavior and purpose differ depending on how the assembler interprets them.

- **LDR Rn, label** Loads the 32-bit *value* stored at the memory address identified by **label** into register Rn. The CPU performs a direct memory read:

$$Rn \leftarrow [label]$$

Example: LDR R0, XVAL loads the contents of XVAL (e.g., 0x12345678) into R0.

- **LDR Rn, =label** Loads the *address* of **label** into Rn, rather than the data stored at that address. The assembler generates this by either constructing the address using MOVW/MOVVT instructions or placing it in a nearby *literal pool* for PC-relative loading.¹

$$Rn \leftarrow &label$$

Example: LDR R0, =XVAL places the address of XVAL in R0.

- **ADR Rn, label** Loads the *address* of **label** into Rn by computing it relative to the current program counter. This method requires no literal pool or memory access but only works for nearby addresses (about ± 4 KB in Thumb mode):

$$Rn \leftarrow PC + offset(label)$$

1.3 Addressing Modes

Addressing modes define how the effective address or operand value is obtained by an instruction. The ARM Cortex-M4 supports several common addressing modes, summarized below:

Table 2.5: General Addressing Modes in ARM Cortex-M4

Mode	Syntax Example	Description
Immediate	MOV R0, #10	Operand is a constant value encoded in the instruction.
Register Direct	MOV R0, R1	Operand is taken directly from a register.
Register Indirect	LDR R0, [R1]	Register holds the address of the operand in memory.
Register Offset	LDR R0, [R1, R2]	Effective address = base register + offset register.
Immediate Offset	LDR R0, [R1, #4]	Effective address = base register + constant offset.
Pre-indexed	LDR R0, [R1, #4]!	Base updated first, then memory access.
Post-indexed	LDR R0, [R1], #4	Memory access first, then base register updated.

¹For more details, see ARM Developer Documentation, “Literal pools and LDR =const”. <https://developer.arm.com/documentation/dui0473/m/dom1359731147760>

```
; Immediate Offset
    LDR    R0, [R1, #4]      ; R0 = word at memory[R1 + 4]
; Register Offset
    LDR    R0, [R1, R2]      ; R0 = word at memory[R1 + R2]
; Pre-indexed
    LDR    R0, [R1, #4]!    ; R1 = R1 + 4, then load R0 = [R1]
; Post-indexed
    LDR    R0, [R1], #4      ; load R0 = [R1], then R1 = R1 + 4
```

Listing 2.4: Examples of Offset, Pre-indexed, and Post-indexed Addressing Modes

2 Procedure

2.1 Examples

2.1.1 Example 1 — Data Processing Instructions

This example demonstrates various arithmetic and bitwise operations on registers.

```
AREA RESET, CODE, READONLY
EXPORT __Vectors
__Vectors
    DCD 0x20001000
    DCD Reset_Handler
    ALIGN

    AREA MYCODE, CODE, READONLY
    ENTRY
    EXPORT Reset_Handler
Reset_Handler
    ; Load values from memory into registers
    LDR R1, NUM1          ; R1 = 50
    LDR R2, NUM2          ; R2 = 12
    ; Arithmetic operations
    ADD R3, R1, R2        ; R3 = 50 + 12 = 62
    SUB R3, R3, #4        ; R3 = 62 - 4 = 58
    MUL R4, R3, R2        ; R4 = 58 * 12 = 696
    ; Logical operations
    AND R5, R4, #0xFF     ; R5 = 696 & 0xFF = 0xB8 (184)
    ORR R5, R5, #0x01     ; R5 = 0xB8 | 0x01 = 0xB9 (185)
    BIC R5, R5, #0x08     ; R5 = 0xB9 & ~0x08 = 0xB1 (177)
    EOR R5, R5, #0x02     ; R5 = 0xB1 ^ 0x02 = 0xB3 (179)
    ; Shift and Barrel Shifter
    LSL R8, R4, #4        ; logical left shift by 4 bits
    LSR R9, R4, #8        ; logical right shift by 8 bits
    ADD R5, R5, R5, LSL #1 ; R5 = R5 + (R5 << 1) = 3 * R5
    ; Store result in memory using a pointer
    LDR R6, RP             ; R6 = address of RESULT
    STR R5, [R6]            ; RESULT = R5
    ; Read back for verification
    LDR R7, [R6]            ; R7 = RESULT
STOP
    B STOP

    AREA CONSTANTS, DATA, READONLY
NUM1  DCD 50              ; First integer
NUM2  DCD 12              ; Second integer
RP    DCD RESULT           ; Pointer to RESULT variable

    AREA MYDATA, DATA, READWRITE
RESULT DCD 0                ; Will hold the final computed value
END
```

Listing 2.5: Arithmetic and bitwise operations example

2.1.2 Example 2 — Load/Store with Different Addressing Modes

This example demonstrates load and store instructions using various addressing modes.

```

AREA    RESET, CODE, READONLY
EXPORT  __Vectors
__Vectors
    DCD    0x20001000      ; Initial SP (example)
    DCD    Reset_Handler   ; Reset vector
    AREA   MYCODE, CODE, READONLY
    ENTRY
    EXPORT  Reset_Handler

Reset_Handler
    LDR    R0, =ARRAY          ; R0 = &ARRAY (base address)
    ; 1) Immediate Offset: EA = R0 + #8 (third element)
    ;
    LDR    R1, [R0, #8]        ; R1 = ARRAY[2] = ? (expect 30)
    LDR    R7, =OUT
    STR    R1, [R7, #0]        ; OUT[0] = R1
    ; 2) Pre-indexed: R2 = [R2 + #4], then R2 = R2 + #4
    ;     Use a scratch pointer so R0 remains the base.
    ;
    MOV    R2, R0              ; R2 = &ARRAY
    LDR    R3, [R2, #4]!       ; R2 -> &ARRAY[1], R3 = ARRAY[1] = ? (expect
    20)
    STR    R3, [R7, #4]        ; OUT[1] = R3
    ; After this, R2 now points at ARRAY[1].
    ; 3) Post-indexed: R4 = [R4], then R4 = R4 + #12
    ;     Load first element, then advance pointer to the 4th.
    ;
    MOV    R4, R0              ; R4 = &ARRAY
    LDR    R5, [R4], #12        ; R5 = ARRAY[0] = ? (expect 10), R4 ->
    &ARRAY[3]
    STR    R5, [R7, #8]        ; OUT[2] = R5
    ; 4) Register Offset: EA = R0 + R6
    ;     Offset register holds byte offset (multiple of 4 for words).
    ;
    MOV    R6, #12              ; byte offset to ARRAY[3]
    LDR    R8, [R0, R6]         ; R8 = ARRAY[3] = ? (expect 40)
    STR    R8, [R7, #12]        ; OUT[3] = R8
    ; read second element via register offset
    MOV    R6, #4                ; byte offset to ARRAY[1]
    LDR    R9, [R0, R6]         ; R9 = ARRAY[1] = ? (expect 20)
STOP
    B     STOP
    AREA   CONSTS, DATA, READONLY
ARRAY  DCD    10, 20, 30, 40    ; four words at consecutive addresses
    AREA   MYDATA, DATA, READWRITE
OUT    DCD    0, 0, 0, 0        ; capture buffer for observed loads.
    END

```

Listing 2.6: Load/store with different addressing modes example

2.2 Tasks

2.2.1 Task 1 — Bitwise Register Manipulation

Start with R0 = 0x12345678. Perform the following operations and observe the results in the debugger (verify in hex and binary):

- Clear bits 4–7 (second hex nibble).
- Set bits 8–11 (force that nibble to F).
- Toggle bits 28–31 (highest nibble).

Hint: Use BIC, ORR, and EOR with appropriate masks.

2.2.2 Task 2 — Addressing Modes with an Array

Given:

ARRAY	DCD	0x11, 0x22, 0x33, 0x44
OUT	SPACE	16

Load each element using a different addressing mode, then store to OUT:

- 0x11 via *immediate offset*
- 0x22 via *pre-indexed*
- 0x33 via *post-indexed*
- 0x44 via *register offset*

Hint: Put ARRAY's base in R1 (e.g., LDR R1, =ARRAY). Verify OUT in memory after execution.